X20(c)SL81xx

Information:

B&R makes every effort to keep data sheets as current as possible. From a safety point of view, however, the current version of the data sheet must always be used.

The certified, currently valid data sheet is available for download on the B&R website (<u>www.br-automation.com</u>).

Information:

This data sheet must be used with mapp Safety.

B&R safety technology can still be used in Safety Releases ≤1.10, however. The documentation is available for download on the B&R website (<u>www.br-automation.com</u>).

For additional information about mapp Safety, additional technical descriptions (e.g. connection examples and error detection) as well as generally valid contents (intended use, etc.), see section Safety technology in Automation Help.

Organization of notices

Safety notices

Contain **only** information that warns of dangerous functions or situations.

Signal word	Description
Danger!	Failure to observe these safety guidelines and notices will result in death, severe injury or substantial damage to property.
Warning!	Failure to observe these safety guidelines and notices can result in death, severe injury or substantial damage to property.
Caution!	Failure to observe these safety guidelines and notices can result in minor injury or damage to property.
Notice!	Failure to observe these safety guidelines and notices can result in damage to property.

Table 1: Organization of safety notices

General notices

Contain useful information for users and instructions for avoiding malfunctions.

Signal word	Description
Information:	Useful information, application tips and instructions for avoiding malfunctions.

Table 2: Organization of general notices

1 General information

The modules are equipped with SafeLOGIC functionality that allows them to safely execute applications designed in SafeDESIGNER. The modules can be used in safety applications up to PL e or SIL 3.

The SafeLOGIC controller coordinates the safety-related communication of all modules involved in the application. In this context, the SafeLOGIC controller also monitors the configuration of these modules and autonomously carries out parameter downloads to the modules if necessary. This guarantees a consistent and correct module configuration in the network from a safety point of view in all scenarios involving module replacement and service. For X20 SafeLOGIC products, these services are executed by the X20 SafeLOGIC controller. For X20 SafeLOGIC products, these services are executed on the standard CPU in interaction with Automation Runtime. The safety-related characteristics for applications up to PL e or SIL 3 are provided in both variants, however.

X20 SafeLOGIC-X and X90 SafeLOGIC products also have the I/O properties described in section "SafeIO" in Automation Help.

- openSAFETY manager for up to 10 / 20 / 100 / 280 SafeNODES
- · Flexibly programmable using Automation Studio / SafeDESIGNER
- Innovative management of safe machine options (SafeOPTION)
- Parameter and configuration management

Information:

This module is not suitable for POWERLINK ring redundancy applications.

2 Coated modules

Coated modules are X20 modules with a protective coating for the electronics component. This coating protects X20c modules from condensation.

The modules' electronics are fully compatible with the corresponding X20 modules.

Information:

For simplification purposes, only images and module IDs of uncoated modules are used in this data sheet.

The coating has been certified according to the following standards:

- Condensation: BMW GS 95011-4, 2x 1 cycle
- Corrosive gas: EN 60068-2-60, Method 4, exposure 21 days

Contrary to the specifications for X20 system modules without safety certification and despite the tests performed, X20 safety modules are **NOT suited for applications with corrosive gases (EN 60068-2-60)!**



3 Order data

X20SL8100	X20SL8101 X20SL8110			
Order number	Short description			
	CPUs			
X20SL8100	X20 SafeLOGIC, safety controller, openSAFETY gateway, removable application memory: SafeKEY, 1 POWERLINK interface, controlled node, integrated 2-port hub, including power sup- ply module, 1x terminal block X20TB52 and X20 end cover plate X20AC0SR1 (right) included, order SafeKEY and SafeLOGIC range of functions using the X20MK configurator!			
X20cSL8100	X20 SafeLOGIC, coated, safety controller, openSAFETY gateway, removable application mem- ory: SafeKEY, 1 POWERLINK interface, controlled node, integrated 2-port hub, including power supply module, 1x terminal block X20TB52 and X20 end cover plate X20AC0SR1 (right) includ- ed, order SafeKEY and SafeLOGIC range of functions using the X20MK configurator!			
X20SL8101	X20 SafeLOGIC with X20 bus controller, safety controller, openSAFETY gateway, removable application memory: SafeKEY, 1 POWERLINK interface, controlled node, integrated 2-port hub, including power supply module for internal I/O power supply and X2X Link power supply, 1x terminal block X20TB52 and X20 end cover plate X20AC0SR1 (right) included, order SafeKEY and SafeLOGIC range of functions using the X20MK configurator!			
X20cSL8101	X20 SafeLOGIC with X20 bus controller, coated, safety controller, openSAFETY gateway, re- movable application memory: SafeKEY, 1 POWERLINK interface, controlled node, integrated 2-port hub, including power supply module for internal I/O power supply and X2X Link power supply, 1x terminal block X20TB52 and X20 end cover plate X20AC0SR1 (right) included, order SafeKEY and SafeLOGIC range of functions using the X20MK configurator!			
X20SL8110	X20 SafeLOGIC, safety controller, openSAFETY gateway, removable application memory: SafeKEY, 1 POWERLINK interface, 1 slot for X20 interface module, controlled node, integrat- ed 2-port hub, including power supply module, 1x terminal block X20TB52 and X20 end cover plate X20AC0SR1 (right) included, order SafeKEY and SafeLOGIC range of functions using the X20MK configurator!			
	Required accessories			
X2UMKU223	X20 SateKEY, 8 MB, for the X20SL81xx series, exclusively for mapp Safety, range of license functions determined via a package-based licensing model or via Technology Guarding in Automation Runtime			
X20MKXXXX.XXX	X20 SafeKEY, for X20SL81xx series, for legacy safety and mapp Safety. The available range of functions is defined by "Safety Technology Guarding". Licenses are stored on a SafeKEY dongle. The range of functions required for the application must be compiled by selecting the available technology functions in the X20MK configurator. Each solution is delivered exclusively as a set consisting of the SafeKEY and the activated licenses for the selected technology functions.			
X20cMK0223	X20 SafeKEY, coated, 8 MB, for the X20SL81xx series, exclusively for mapp Safety, range of license functions determined via a package-based licensing model or via Technology Guarding in Automation Runtime			

Table 3: X20SL8100, X20cSL8100, X20SL8101, X20cSL8101, X20SL8110 - Order data

4 Technical data

Order number	X20SL8100	X20cSL8100	X20SL8101	X20cSL8101	X20SL8110
Short description		1		1	J
Interfaces			POWERLINK		
System module			CPU		
General information					-
B&R ID code	0xDD61	0xE287	0xE649	0xE926	0xE64A
System requirements			ŀ		1
Automation Studio	4.0.16	or later	4.1.6	or later	V4.2.5 or later
Automation Runtime	V3.08 or late	r (for AsSafe-	F4.09 or later, F4.10	or later, A4.23 or later	B4.25 or later
SafeDESIGNER	ty library F4	1.06 or later) or later	4.1.0	or later	V4.2 or later
Safety Release		1.7 0	r later		1.10 or later
mapp Technology Package 1)			mapp Safety 5.7.0 or late	er	
Cooling		·	Fanless		
Status indicators		CPU fu	Inction, POWERLINK, S	afeKEY	
Diagnostics					
CPU function		Yes	s. using LED status indic	ator	
POWERLINK		Yes	s. using LED status indic	ator	
SafeKEY		Yes	s, using LED status indic	ator	
Blackout mode			-,g		
Scope			Network	segment	-
Function		-	Progra	mmable	-
Standalone mode		-	Y	les .	-
Power consumption	4 (3 W	5:	3 W	3.9 W ²⁾
Power consumption for X2X Link pow- er supply		-	1.42	2 W ³⁾	-
Power consumption					1
Internal I/O		-	0.6	W ³⁾	-
Additional power dissipation caused			-		
by actuators (resistive) [W]					
Electrical isolation					
Fieldbus - X2X Link		-	Y	es	-
Fieldbus - I/O		-	Y	es	-
Certifications					
CE			Yes		
Functional safety	cULus FSPC E361559 Energy and industrial systems Certified for functional safety ANSI UL 1998:2013				
Functional safety	IEC 61508:2010, SIL 3 EN 62061:2013, SIL 3 EN ISO 13849-1:2015, Cat. 4 / PL e IEC 61511:2004, SIL 3				
Functional safety			EN 50156-1:2004		
ATEX	Zone 2, II 3G Ex nA nC IIA T5 Gc IP20, Ta (see X20 user's manual) ETZI' 09 ATEX 0083X				
UL		Ir	cULus E115267	ant	
HazLoc		cCSAus	244665		_
	Process control equipment for hazardous locations Class I, Division 2, Groups ABCD, T5				
DNV	Temperature: A (0 - 45°C) In prep. Humidity: B (up to 100%) Vibration: A (0.7 g)			In preparation	
		EMC: B (bridge	and open deck)		
LR		EN	JV1		-
KR		Υ	es		-
ABS	Yes -				
EAC	Yes				
Safety characteristics					
EN ISO 13849-1:2015					
Category			Cat. 4		
PL DO	PL e				
	>94%				
MITED			2500 years		
Mission time			Max. 20 years		

Table 4: X20SL8100, X20cSL8100, X20SL8101, X20cSL8101, X20SL8110 - Technical data

X20(c)SL81xx

Order number	¥2051 8100	¥20cSI 8100	¥20SI 8101	¥20cSI 8101	¥20SI 8110
	ALCOLOTOU	ALOCOLUTION	ALCOLUTOT	ALCOLOIUT	ALGOLOTIC
IEC 61511:2004					
EN 62061:2013					
			CII 2		
SIL CL			SIL 3		
SFF			>90%		
PFH / PFH _d					
Module			<1*10 ⁻¹⁰		
openSAFETY wired			Negligible		
openSAFETY wireless		<1*10 ⁻¹⁴ * Nur	nber of openSAFETY pa	ckets per hour	
PFD			<2*10-5		
Proof test interval (PT)			20 years		
Functionality		-	20)00.0		
Communication with each other			Voc		
Comment for Opfo Commissioning Op			165		
Support for Safe Commissioning Op-					
			E40		
BOOL	512				
			64		
UINT			64		
DINT			64		
UDINT			64		
SafeMOTION support	Y	es, depends on the num	ber of available operating	licenses on the SafeKE	Y
Max, number of SafeMOTION axes		70. depends	on the data width of the r	nodules used	
Timing precision		Time * 0.05	+ Cycle time of the safet	vapplication	
Shortest task class cycle time			1 me		
Max number of SofeNODEs	100 depende en t	ho number of ovail	1 1113 290, dopond	a on the number of avail	able enerat
Max. number of SaleNODES	able operating licen	ses on the SafeKEV	200, depend	the SafeKEV and avail	able operat-
May pumber of DOW/EDUNK and					
Max. number of POWERLINK con-	5	0		100	
Data exchange between CPU and					
			= 10 1 1		
Max. total data width for each direc- tion ⁵⁾			512 bytes		
Max. number of data points for each direction					
BOOL			1024		
INT			128		
			120		
UINT			120		
DINI	64				
UDINT			64		
Data exchange between SafeDOMAIN					
and SafeDOMAIN 6)					
Use as Managing SafeDOMAIN		Yes, starting with map	op Safety 5.10.0 and hard	ware upgrade 2.2.1.0	
Use as Connected SafeDOMAIN		Yes, starting with map	op Safety 5.10.0 and hard	ware upgrade 2.2.1.0	
Max. total data width for each direc- tion ⁵⁾	64 bytes				
Max. total number of data points for each direction 7)	16				
Max. number of data points for each					
			400		
BOOL			128		
INT			16		
UINT			16		
DINT			16		
UDINT			16		
Max. number of linked Managing	Starting with ma	pp Safety 5.10.0	Starting with mapp Sa	afety 5.10.0 and hardwar	e upgrade 2.2.1.0: 20
SafeDOMAINs	and hardware up	ograde 2.2.1.0: 10			
Limit values for SafeDESIGNER appli	cation				
Max. resources available for					
SafeDESIGNER info window entries 8)					
FB instances			4096		
Marker memory	262 144 bytes				
Stack memory	32 768 bytes				
Memory for safe input data	6111 hitos				
Memory for safe sutput data	0144 Dytes				
Memory for standard in this to	2048 bytes				
ivientory for standard input data			1024 bytes		
Memory for standard output data			1024 bytes		
Marker count			16,382		
Additional SafeDESIGNER limit values					
Max. number of function block types			512		
Max. number of force variables			64		
Max. number of variable with vari-	1023				
able status					
Input SL / BC / X2X Link power suppl	ply				
Input voltage			24 VDC -15% / +20%	,	
Input current	Max.	0.25 A	Max.	0.9 A	Max. 0.25 A

Table 4: X20SL8100, X20cSL8100, X20SL8101, X20cSL8101, X20SL8110 - Technical data

X20(c)SL81xx

Order number	X20SL8100	X20cSL8100	X20SL8101	X20cSL8101	X20SL8110	
Fuse	· · · · · · · · · · · · · · · · · · ·	-	Integrated, can	not be replaced	-	
Reverse polarity protection			Yes			
Output SL / BC / X2X Link power sup	ply		-			
Nominal output power	·	-	1	W	-	
Parallel connection		-	Ye	S ⁽⁹⁾	-	
Redundant operation	·	-	Y	es	-	
Overload characteristics		-	Short-circuit proof,	temporary overload	-	
Input I/O power supply			041/00.4	50/ / + 000/		
	·	-	24 VDC -1	5% / +20%	-	
Fuse		-	Required line fuse: I	viax. 10 A, slow-blow	-	
Reverse polarity protection	· · · · · · · · · · · · · · · · · · ·	-	Y	es	-	
Output I/O power supply			041	(DO		
Nominal output voltage	·	-	24		-	
Benavior on short circuit		-	Required		-	
Permissible contact load		-	10) A	-	
Interfaces				de		
Fieldbus	L	P	JWERLINK controlled no	de		
Type	l		Type 3 ¹⁰	b)		
	<u> </u>		x snielded RJ45 port (nu			
Line length	<u> </u>	Max. 100 n	n between 2 nodes (segr	nent length)	,	
I ransfer rate			100 Mbit/s			
l ranster	ļ					
Physical layer			100BASE-TX			
Half-duplex	<u> </u>		Yes		<u>.</u>	
Full-duplex	ļ		No			
Autonegotiation	Yes					
Auto-MDI/MDIX	<u> </u>	Yes				
Fieldbus	200 µs					
X2X Link	- 200 µs -			-		
synchronization between bus systems	- Yes -					
Operating conditions			1			
Mounting orientation		-				
Horizontal			Yes			
Vertical			Yes			
Installation elevation above sea level		0 to 2000 m, no limitation				
Degree of protection per EN 60529	IP20					
Ambient conditions						
Temperature						
Operation						
Horizontal mounting orientation	0 to 60°C	-25 to 60°C	0 to 60°C	-25 to 60°C	0 to 60°C	
Vertical mounting orientation	0 to 45°C	-25 to 45°C	0 to 45°C	-25 to 45°C	0 to 45°C	
Derating		-	See section	"Derating".	-	
Storage			-40 to 85°C			
Transport			-40 to 85°C			
Relative humidity						
Operation	5 to 95%, non- condensing	Up to 100%, condensing	5 to 95%, non- condensing	Up to 100%, condensing	5 to 95%, non- condensing	
Storage	5 to 95%, non-condensing					
Transport	5 to 95%. non-condensing					
Mechanical properties				-		
Note	Order SafeKEY and SafeLOGIC range of functions using the X20MK configurator. X20 end cover plate (right) included in delivery 12-pin X20 terminal block, safety-keyed, included in delivery					
	[Safe	KEY cover included in de	elivery	-	
Dimensions					07.5	
Width	62.5 ^{+0.2} mm 87.5 ^{+0.2} mm				87.5 ^{+0.2} mm	
Height	99 mm					
Depth			75 mm			
vveignt	190 g					

Table 4: X20SL8100, X20cSL8100, X20SL8101, X20cSL8101, X20SL8110 - Technical data

1) The system requirements of the mapp Technology Package must be observed (see Automation Help).

2) Power consumption without interface module

3) The specified values are maximum values. For examples of the exact calculation, see section "Mechanical and electrical configuration" in the X20 system user's manual.

4) If hardware upgrades <2.2.0.0 or Automation Runtime versions <AR 4.72 are used, legacy bandwidths apply.

5) Each 8 BOOL are combined to 1 byte. Possible stuffing bytes due to alignment must be taken into account. For additional information, see section "Real-time operating system \rightarrow Target systems \rightarrow Target systems - SG4 \rightarrow Runtime behavior - SG4 \rightarrow Alignment" in Automation Help.

6) For additional information about SafeDOMAIN-to-SafeDOMAIN communication, see section "SafeDOMAIN-to-SafeDOMAIN communication" in Automation Help.

7) It is important to note that 8 BOOL count as 1 data point.

8) For a parameter description, see section "Message window" in the SafeDESIGNER documentation.

9) In parallel operation, it is only permitted to expect 75% of the nominal power. It is important to make sure that all power supply units operated in parallel are switched on and off at the same time.

10) For additional information, see section "Communication → POWERLINK → General information → Hardware - CN" in Automation Help. It is important to note, however, that the SafeLOGIC controller does not support "early writing of output data". The use of "poll-response chaining" is not recommended for controlled nodes in the same POWERLINK line.

11) The minimum cycle time specifies how far the bus cycle can be reduced without communication errors occurring.

X20SL8101: Derating for SafeLOGIC / Bus controller / X2X Link power supply

The nominal output power of the X2X Link power supply is 7 W and depends on the operating temperature and mounting orientation.

The derating curve must be shifted to the left with a horizontal mounting orientation depending on the I/O output current.

Module	X20SL8101
Derating penalty	
Load at 24 VDC I/O, max. 10 A	-5°C
Load at 24 VDC I/O, max. 3 A	+0°C

Table 5: Derating penalty

The resulting nominal output power is listed in the following table.



Table 6: Derating for SafeLOGIC / Bus controller / X2X Link power supply

Information:

Regardless of the values specified in the derating curve, the module cannot be operated above the values specified in the technical data.

Danger!

Operation outside the technical data is not permitted and can result in dangerous states.

Information:

For additional information about installation, see section "Installation notes for X20 modules" in Automation Help.

5 Operating and connection elements

LEDs and buttons/switches are provided for operating the SafeLOGIC. These elements can be used to perform the following actions:

- Module replacement, including a test of the complete module configuration (section "Module replacement" in Automation Help)
- Firmware replacement (section "Acknowledging a firmware modification" in Automation Help)
- SafeKEY replacement, possibly including transfer of the module configuration from the old SafeKEY (section "Changing the application on the SafeLOGIC controller by replacing the SafeKEY (X20 SafeLOGIC only)" in Automation Help)
- SafeLOGIC controller replacement (section "Module replacement" in Automation Help)

Operation of the SafeLOGIC controller can be displayed via the standard CPU.

A SafeLOGIC controller has the following operating and connection elements:

X20SL810x



Figure 1: X20SL810x - Operating elements

X20SL8110



Figure 2: X20SL8110 - Operating elements

Slot for interface modules

The X20SL8110 SafeLOGIC controller is equipped with a slot for interface modules.

Different bus or network systems can be flexibly integrated into the X20 system by selecting the appropriate interface module.

The following interface modules can be used in the X20SL8110 SafeLOGIC controller:

Module	Description
X20IF10E3-1	X20 interface module for DTM configuration, 1 PROFINET RT device (slave) interface, electrically isolated

5.1 Safety processor

5.1.1 LED status indicators of the safety processor

		FW-ACKN SK-XCHG SCAN - 12 EN	R/E ENTER MXCHG FW-ACKN FAILSAFE SKEY - TEST TER
LED	Color	Status	Description
R/E		Off	Boot phase
	Green	On	Application exists and is being executed
		Blinking	Application exists but is not being executed (in the download dialog box for the SafeDESIGNER, "Automatic start" was not selected OR boot phase, i.e. not all necessary safe modules on the network were configured correctly.) In addition, boot states 0x1840 to 0x3440 under index:subindex 0x2410:0x01 must be checked in section "SafeLOGIC - Channel list".
	Orange	On	SafeDESIGNER in "Debug" mode
		Blinks at 0.5 Hz	SafeDESIGNER in "Debug" mode, application in "Stop"
		Blinks at 1 Hz	No application on SafeKEY
ENTER	Green	On	Authorization missing
		Blinks 1x for 0.8 s	Confirmation of correct entry
		Blinks (1 Hz) for 5 s	Faulty operation
MXCHG	Orange	Off	Module configuration OK
			Replacement of 1 module detected
			Replacement of 2 modules detected
			Replacement of 3 modules detected
			Replacement of 4 modules detected
			Replacement of more than 4 modules detected
			Missing module detected
FW-ACKN	Orange	Off	Firmware configuration OK
		Blinking	Firmware update completed
		On	SafeKEY exchanged
ENTER MXCHG FW-ACKN	Green Orange Orange	Running sequence	Performing module scan or startup phase (Note: Check STATUS LED, see sec- tion "LED status indicators for the POWERLINK interface"!)
-	5-		

Table 7: Safety processor status indicators

FAILSAFE	Red		LED "FAILSAFE" indicates the startup behavior or the "FailSafe" state related to
		Off	
		01	
			Boot phase
			Safety firmware PRE_OPERATIONAL state or "SafeOSstate!=RUN"
			Safe communication channel not OK, openSAFETY connection valid problem or "SafeOSstate!=RUN" If the SafeLOGIC controller remains in this state for a longer time, parameter "Default safe data duration" of the "Group: Safety response time default values" must be checked.
		Boot phase, faulty firmware, setup mode active For details about setup mode, see section "Setup mode" in Automation Help.	
			Test/Pilot firmware or safety application created with test/pilot version of SafeDESIGNER
			SafeDESIGNER in "Debug" mode
		On	Safety state active for the entire module (= state "FailSafe")
SKEY	Orange	Off	No access to the SafeKEY
		Blinking	Access to the SafeKEY

Table 7: Safety processor status indicators

Danger!

A constantly lit FAILSAFE LED indicates a possible safety-related system error. It is your responsibility to ensure that all necessary repair measures are initiated after an error occurs since subsequent errors can result in a hazard!

5.1.2 LED test

The functionality of the LEDs can be tested using the following sequence:

- Move the selector switch to TEST.
- Press the ENTER confirmation button.
- All of the safety processor LEDs will turn on (left module of the SafeLOGIC controller) for the exact duration that the confirmation button is pressed.

5.1.3 Selector switch and confirmation button

If configuration confirmations by the user are necessary, they are performed by preselecting the desired function using the selector switch and then pressing the ENTER confirmation button.



Switch position	Functionality	Description
FW-ACKN	Firmware acknowledgment	Acknowledges a firmware change on one or more modules
Unlabeled position between	Setup mode	Enables/Disables setup mode
FW-ACKN and SK-COPY		For details about setup mode, see section "Setup mode" in Automation Help.
(=0xD)		
SK-COPY	SafeKEY copy	Copy of the configuration data from the SafeKEY ¹⁾
TEST	Test	Performs an LED test
Unlabeled position between	CLEAR DATA	Deletes the following "user data":
TEST and n		Remanent data
		Configuration file from the standard application
		SafeOPTION
1,2,3,4,n	Module replacement	Confirms exchange of 1, 2, 3, 4 or more than 4 modules.
SCAN	Scan	Triggers a module scan
SK-XCHG	SafeKEY exchange	Confirmation of SafeKEY exchange
Unlabeled position between	SafeKEY format	Formats the SafeKEY ¹⁾
FW-ACKN and SK-XCHG		

Figure 3: Selector switch and confirmation button

Table 8: Confirmation modes

1) Triggers an automatic restart.

Confirmation

The confirmation button must be pressed for 0.5 to 5 s to receive confirmation. After 0.5 s, the ENTER LED (see section "LED status indicators of the safety processor") is illuminated. After releasing the confirmation button, the ENTER LED remains illuminated for an extra 0.8 s. This sequence indicates a correct entry.

- If the confirmation button is released before 0.5 s, it has no effect.
- If the confirmation button is pressed for longer than 5 s, then the ENTER LED blinks for 5 s to display an error.

Another possible reason for an error is an improper placement of the selector switch. If the user wants to confirm a module replacement for one specific module, for example, then the selector switch must be at position "1" (see section "Replacing an individual module" in Automation Help). In this case, if a placement other than "1" is confirmed with the confirmation button, it is considered an error and the ENTER LED blinks for 5 s.

Confirmation of "Setup mode", "CLEAR DATA" and "SafeKEY format"

The confirmation button must be pressed for 20 to 30 s to receive confirmation. After 20 s, the ENTER LED is illuminated. After releasing the confirmation button, the ENTER LED remains illuminated for an extra 0.8 s. This sequence indicates a correct entry.

- If the confirmation button is released before 20 s, it has no effect.
- If the confirmation button is pressed for longer than 30 s, then the ENTER LED blinks for 5 s to display an error.

5.2 Slot for application memory (SafeKEY)

In order to operate the SafeLOGIC controller, application memory (SafeKEY) is required to save the program, the parameters and the system configuration.

The SafeKEY is equipped with a mechanical locking mechanism to make it more difficult to inadvertently remove during operation.



Figure 4: SafeKEY unlocked



Information:

Removing a SafeKEY during operation causes the X20 SafeLOGIC controller to be restarted and all safety-related actuators to be cut off.

Removing a SafeKEY during operation can destroy the data on the SafeKEY.

Removing a SafeKEY during operation must therefore always be avoided.

The "Backing up the SafeKEY" sequence is not affected by this general rule.

Information:

It must be taken into account that modules operated on the local X2X Link network of the X20SL8101 are only correctly configured if a valid SafeDESIGNER project exists on the SafeKEY. Otherwise, channel "ModuleOk" of the modules as well as the SafeLOGIC controllers in Automation Studio remains FALSE.

5.3 POWERLINK interface

5.3.1 LED status indicators for the POWERLINK interface

Figure	LED	Color	Status	Description
	STATUS ¹⁾	Green/Red		LED "Status/Error".
				LED states are described in section 5.3.2 "LED STATUS".
STATUS	L/A IFx	Green	On	The link to the remote station is established.
L/A IF1			Blinking	The link to the remote station is established. The LED blinks if Ethernet activity is taking place on the bus.

Table 9: POWERLINK interface status indicators

1) LED "Status/Error" is a green/red dual LED.

5.3.2 LED STATUS

LED "Status/Error" is a green and red dual LED. The color green (status) is superimposed on the color red (error).

Red - Error	Description
On	The controlled node (CN) is in an error state (failed Ethernet frames, increased number of collisions on the network, etc.). If an error occurs in the following states, then the green LED blinks over the red LED:
	 PRE_OPERATIONAL_1 PRE_OPERATIONAL_2 READY_TO_OPERATE
	Status Green
	Error Red
	LED "STATUS"
	Note:
	Several red blinking signals are displayed immediately after the device is switched on. This is not an error, how- ever.
	 The LED is lit red for CNs with set physical node number 0 to which no node number has yet been assigned by dynamic node allocation (DNA).

Green - Status	Description
Off	No power supply or mode NOT_ACTIVE.
	The controlled node (CN) is either not supplied with power, or it is in state NOT_ACTIVE. The CN waits in this state for about 5 seconds after a restart. Communication is not possible with the CN. If no POWERLINK communication is detected during these 5 seconds, the CN enters state BASIC_ETHERNET (flickering).
	If POWERLINK communication is detected before this time expires, however, the CN immediately enters state PRE_OP- ERATIONAL_1.
Flickering green (approx. 10 Hz)	Mode BASIC_ETHERNET.
	The CN has not detected any POWERLINK communication. It is possible to communicate directly with the CN in this state (e.g. With UDP, IP, etc.).
	If POWERLINK communication is detected while in this state, the CN enters state PRE_OPERATIONAL_1.
Single flash (approx. 1 Hz)	Mode PRE_OPERATIONAL_1.
	The CN waits until it receives an SoC frame and then switches to state PRE_OPERATIONAL_2.
Double flash (approx. 1 Hz)	Mode PRE_OPERATIONAL_2.
	The CN is normally configured by the manager in this state. A command then switches the CN to the READY_TO_OP-
	ERATE state.
Triple flash (approx. 1 Hz)	Mode READY_TO_OPERATE.
	The manager switches the CN via command to the OPERATIONAL state.
On	Mode OPERATIONAL.
	The PDO mapping is active and cyclic data is evaluated.
Blinking (approx. 2.5 Hz)	Mode STOPPED.
	Output data is not being output, and no input data is being provided. It is only possible to switch to or leave this state
	after the manager has given the appropriate command.

Table 11: Status/Error LED lit green: LED indicating operating state



Figure 6: LED status indicators - Blink times

5.3.3 POWERLINK node number



Figure 7: POWERLINK node number switches

The node number of the POWERLINK station is set using the two number switches. Node numbers between 0x01 and 0xEF are permitted.

Switch position	Description
0x00	Reserved, switch position not permitted.
0x01 to 0xEF	Node number of the POWERLINK station, operation as controlled node (CN)
0xF0 to 0xFF	Reserved, switch position not permitted.

Table 12: POWERLINK node number

5.3.4 RJ45 ports

For information about wiring X20 modules with an Ethernet interface, see section "Mechanical and electrical configuration - Wiring guidelines for X20 modules with Ethernet cables" of the X20 user's manual.





Interface	Pinout		
	Pin	Ethernet	
	1	RXD	Receive data
	2	RXD\	Receive data\
	3	TXD	Transmit data
	4	Termination	
	5	Termination	
	6	TXD\	Transmit data\
Shielded RJ45 port	7	Termination	
	8	Termination	

Table 13: Pinout for RJ45 port

5.4 Integrated power supply

A power supply is integrated in the SafeLOGIC controller.

5.4.1 LED status indicators for the integrated power supply

X20SL81x0

Figure	LED	Color	Status	Description
	DCOK	Green	On	Voltage applied to module
X20 SL 8100 жоод			Off	Voltage not applied to module

Table 14: X20SL81x0 - LED status indicators for the integrated power supply

X20SL8101

Figure	LED	Color	Status	Description			
	r	Green	Off	No power to module			
			Single flash	Mode RESET			
			Blinking	Mode PREOPERATIONAL			
			On	Mode RUN			
	е	Red	Off	Module not supplied with power or everything OK			
			Double flash	The LED indicates one of the following states:			
20 SL 8101							The SafeLOGIC controller / bus controller / X2X Link power supply for the power supply is over- loaded
				 I/O power supply too low 			
					Input voltage for the SafeLOGIC controller / bus controller / X2X Link power supply is too low		
×	e+r	Solid red / Sing	le green flash	Invalid firmware			
	I F	Red	Off	The SafeLOGIC controller / bus controller / X2X Link power supply is in the valid range.			
			On	The SafeLOGIC controller / bus controller / X2X Link power supply for the power supply is overloaded.			

Table 15: X20SL8101 - LED status indicators for the integrated power supply

5.4.2 Pinout for the integrated power supply



Figure 9: X20SL81x0 - Pinout of the integrated power supply Figure 10: X20SL8101 - Pinout of the integrated power supply

5.4.3 Connection examples

X20SL81x0



Figure 11: X20SL81x0 - Connection example

X20SL8101 - With 2 isolated power supplies



Figure 12: X20SL8101 - Connection example with 2 isolated power supplies

X20SL8101 - With one power supply and jumper





6 Register description

6.1 Parameters in the I/O configuration

Group: POWERLINK parameters

Parameter	Description	Default value	Unit
Mode	SafeLOGIC can only be operated as a "controlled node" (CN). A "managing	Controlled	-
	node" (MN) is not supported.	node	

Table 16: I/O configuration parameters: POWERLINK parameters

Information:

There are additional configuration parameters available. For details, see Automation Help under "Communication \rightarrow POWERLINK \rightarrow AR configuration \rightarrow POW-ERLINK controlled node configuration (SG4)".

Group: Function model

Parameter	Description	Default value	Unit
Function model	This parameter is reserved for future functional expansions.	Default	-
		Boldan	

Table 17: I/O configuration parameters: Function model

Group: General						
Parameter		Description	Default value	Unit		
Module supervised	System behavior when a module is missing On -			-		
	Parameter value	Ilue Description				
	On	Missing module triggers service mode				
	Off	Missing module is ignored				
Interface slot enable	This parameter enables	data transfer for the interface card.	On	-		
(X20SL8110 only)						
	Parameter value	Description				
	On	Data transfer for the interface card is enabled.				
	Off	Data transfer for the interface card is disabled.				
Node used as IP gateway	This parameter is reser	ved for future functional expansions.	240	_		
Standalone mode	This parameter enables	s standalone mode (see section Blackout mode in Au-	Off	_		
(X20SL8101 only)	tomation Help under: I	Hardware \rightarrow X20 system \rightarrow Additional information \rightarrow	_			
	Blackout mode) and all	lows the SafeLOGIC controller to be started up without				
	an active master.					
	Deveryoten vielen	Description				
		Standalana mada ia anablad				
	Off	Standalone mode is disabled.				
SafeDOMAIN ID	In applications with mu	Itiple SafeLOGIC controllers, this parameter defines the	Assigned	-		
	unique SateLOGIC address. automatically					
	Permissible valu	ues: 1 to 1000				
SafeNODE ID	Unique safety address of the module		1	-		
	Permissible valu	Permissible values: 1				
Manual cycle time configuration	Specification for the cycle time mode Yes -					
	Parameter value Description					
	res	Operation with a fixed cycle time (in accordance wi	in parameter "Cy	rcie time").		
Cycle time	This parameter determi	nes the cycle time of the safety application.	4000	μs		
	 Permissible values: 800 to 20,000 µs (corresponds to 0.8 to 20 ms) 					
	The set value must be an integer multiple of the POWERLINK cycle time!					

Table 18: I/O configuration parameters: General

Information:

Parameter "Cycle time" must be greater than the processing time for the safety application and must correspond to an integer multiple of the POWERLINK cycle time. The processing time can be determined in the online dialog window using function "Info". If the parameter "Cycle time" is less than or too close to the necessary processing time, a cycle time violation can occur.

For additional information, see section "Dialog box 'SafePLC info' in SafeDESIGNER" in Automation Help.

Group: SafeDESIGNER-to-SafeLOGIC communication

When SPROXY is enabled, the SafeLOGIC controller can be accessed via a TCP/IP port on the standard CPU. This uses SafeDESIGNER setting "SL - Communication through BR-CPU".

Parameter	Description	Default value	Unit
Server communication port	TCP/IP port number used to access the SafeLOGIC controller	Assigned	-
	Recommended values: 50,000 to 50,100	automatically	
	Note: If multiple SafeLOGIC controllers are being used in the project, then a different port number must be configured for each one!		

Table 19: I/O configuration parameters: SafeDESIGNER-to-SafeLOGIC communication

Group: CPU-to-SafeLOGIC communication

Parameter	Description	Default value	Unit
Number of BOOL channels	Number of BOOL channels from the CPU to the SafeLOGIC controller	8	-
	 Permissible values: 0, 8, 16, 24, 32, 40, 48, 56, 64, 72, 80, 88, 96, 128, 256, 384, 512, 640, 768, 896, 1024. 		
Number of INT channels	Number of INT channels from the CPU to the SafeLOGIC controller	0	-
	Permissible values: 0 to 128.		
Number of UINT channels	Number of UINT channels from the CPU to the SafeLOGIC controller	0	-
	Permissible values: 0 to 128.		
Number of DINT channels	Number of DINT channels from the CPU to the SafeLOGIC controller	0	-
	Permissible values: 0 to 64.		
Number of UDINT channels	Number of UDINT channels from the CPU to the SafeLOGIC controller	0	-
	Permissible values: 0 to 64.		

Table 20: I/O configuration parameters: CPU-to-SafeLOGIC communication

Group: SafeLOGIC-to-CPU communication

Parameter	Description	Default value	Unit
Number of BOOL channels	Number of BOOL channels from the SafeLOGIC controller to the CPU	8	-
	 Permissible values: 0, 8, 16, 24, 32, 40, 48, 56, 64, 72, 80, 88, 96, 128, 256, 384, 512, 640, 768, 896, 1024. 		
Number of INT channels	Number of INT channels from the SafeLOGIC controller to the CPU	0	-
	Permissible values: 0 to 128.		
Number of UINT channels	Number of UINT channels from the SafeLOGIC controller to the CPU	0	-
	Permissible values: 0 to 128.		
Number of DINT channels	Number of DINT channels from the SafeLOGIC controller to the CPU	0	-
	Permissible values: 0 to 64.		
Number of UDINT channels	Number of UDINT channels from the SafeLOGIC controller to the CPU	0	-
	Permissible values: 0 to 64.		

Table 21: I/O configuration parameters: SafeLOGIC-to-CPU communication

Group: SafeDOMAIN-to-SafeDOMAIN communication

Starting with mapp Safety 5.10.0 and hardware upgrade 2.2.1.0

For additional information about SafeDOMAIN-to-SafeDOMAIN communication, see section "SafeDOMAIN-to-SafeDOMAIN communication" in Automation Help.

Parameter	Description	Default value	Unit
Group: Managing SafeDOMAIN connection Configuration of the SafeDOMAINs to which t	xx nis SafeDOMAIN establishes a connection.		
SafeDOMAIN ID of connection xx	SafeDOMAIN ID of the Managing SafeDOMAIN to which a connection should be established	0	-
Group: Output channels This data is generated by the connected Man	aging SafeDOMAIN.		
Number of BOOL channels	Number of BOOL channels from the SafeDOMAIN to the SafeDOMAIN	8	-
	 Permissible values: 0, 8, 16, 24, 32, 40, 48, 56, 64, 72, 80, 88, 96, 104, 112, 120, 128. 		I
Number of INT channels	Number of INT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		
Number of UINT channels	Number of UINT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		
Number of DINT channels	Number of DINT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		
Number of UDINT channels	Number of UDINT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		1
Group: Input channels This data is received by the connected Manag	ing SafeDOMAIN.		
Number of BOOL channels	Number of BOOL channels from the SafeDOMAIN to the SafeDOMAIN	8	-
	 Permissible values: 0, 8, 16, 24, 32, 40, 48, 56, 64, 72, 80, 88, 96, 104, 112, 120, 128. 		l
Number of INT channels	Number of INT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		
Number of UINT channels	Number of UINT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		
Number of DINT channels	Number of DINT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		1
Number of UDINT channels	Number of UDINT channels from the SafeDOMAIN to the SafeDOMAIN	0	-
	Permissible values: 0 to 16.		1

Table 22: I/O configuration parameters: SafeDOMAIN-to-SafeDOMAIN communication

Group: Power supply parameters (X20SL8101 only)

Parameter	Description	Default value	Unit
Module status information	This parameter enables/disables additional status information in the I/O mapping.	On	-
Current/voltage information	This parameter enables/disables additional current and voltage information in the I/O mapping.	Off	-

Table 23: I/O configuration parameters: Power supply parameters

6.2 Parameters in SafeDESIGNER

6.2.1 SafeLOGIC basic settings

Group: Basic

Parameter	Description Default value Unit							
Min. required firmware revision	This parameter is reserved	for future functional expansions.	Basic release	-				
Asynchronous communication load	This parameter can be used in the SafeLOGIC cycle. The asynchronous bandwidth is Increasing the value usuall provides sufficient asynchro- lacroceing the value glas per	In the SafeLOGIC cycle. This parameter can be used to determine how much asynchronous bandwidth is used for SafeNODE configuration. Increasing the value usually shortens the startup time as long as the network provides sufficient asynchronous bandwidth.						
	however.							
	Parameter value Description							
	Low	Processing of a SSDO/SNMT service is divided ad	cross 5 SafeLOC	GIC cycles, i.e.				
	the load in the cycle is low, but startup takes longer because a SSDO/SNMT service is processed only every 5 SafeLOGIC cycles. Time required per SafeLOGIC cycle: 145 μs							
	Medium	One SSDO/SNMT service is processed in each Sa the cycle is low, and optimized startup has the same Time required per SafeLOGIC cycle: 260 µs	ifeLOGIC cycle, e importance.	i.e. the load in				
	High	5 SSDO/SNMT services are processed in each Sa the cycle is relatively high to favor optimized startup Time required per SafeLOGIC cycle: 860 µs	feLOGIC cycle, behavior.	i.e. the load in				
	Auto	For SafeLOGIC cycles <3 ms, this setting results i communication load = Low"; for SafeLOGIC cycles "Asynchronous communication load = High".	n the behavior " >3 ms, it results	Asynchronous in the behavior				
Node quarding timeout	Timeout for changing the s	afety modules to the PRE_OPERATIONAL state af-	60	s				
	ter the SafeLOGIC controll	er drops out or if there is a communication problem	00					
	between the safety module This parameter also define	and the SafeLOGIC controller.						
	detect a missing module.							
	Permissible values:	30 to 300 s						
	Notes							
	The shorter the time, the greater the amount of asynchronous data traffic. This activities is not activities by a statuting the status for a first fir							
	Ins setting is not critical to safety functionality. The time for safely cutting off actuators is determined independently of this.							
Auto-acknowledge SafeKEY exchange	This parameter enables auto knowledgment request "Sat	omatic acknowledgment of a SafeKEY exchange (ac- feKEY exchange").	No	-				
	Parameter value	Description						
	Yes - Warning Automatic acknowledgment of SafeKEY exchange is enabled.							
	No	Automatic acknowledgment of SafeKEY exchange	is not enabled.					
Process data transfer rate	This parameter defines the	base transfer rate for process data.	High	-				
	Parameter value	Description						
	High	Normal transfer rate.						
	Low	Reduced transfer rate to support networks with low to	ransfer rates (dat	a transmission				
		time >1 s). In rare cases, the connection to SafeNODEs present in the network may be aborted Connection aborts to Connected SafeDOMAINs are not affected. Connection aborts to SafeNODEs can be avoided by setting up a new SafeDOMAII in a separate network with a normal transfer rate and connecting this network t the original network with a reduced transfer rate via SafeDOMAIN-to-SafeDOMAII communication.						
Availability source	This parameter sets the s	source for the availability settings of the individual	SafeDESIGN-					
	SafeNODEs.							
	Parameter value Description							
	SafeDESIGNER	The availability of the SafeNODEs is defined in Safe	eDESIGNER.					
	SafeCOMMISSIONING	The availability of SafeNODEs is defined via "Safe in SafeCOMMISSIONING.	NODE availabili	ty" parameters				
Maximum number of simultaneous module	This parameter creating	nu manu modulos are addressed simultaneously by	200					
startups (hardware upgrade 2.4.0.0 or later)	the SafeLOGIC controller d startup time but reduces the	uring startup. Reducing the parameter increases the e number of transfer errors.	200	-				
	Permissible values: 1 to 280							

Table 24: SafeDESIGNER parameters: Basic

Information:

Startup time is also affected by the asynchronous bandwidth on the POWERLINK network. For ways to optimize, see section Communication \rightarrow POWERLINK \rightarrow General information \rightarrow Multiple asynchronous send in Automation Help.

Information:

The information in section "Automatic acknowledgment" in Automation Help must be observed when using parameter "Auto-acknowledge SafeKEY exchange".

Group: Safety response time default values

The parameters for the safety response time are generally set in the same way for all stations involved in the application. This is why these parameters are configured for the SafeLOGIC controller in the "Safety response time default values" group in SafeDESIGNER.

If "Manual configuration = No" is set for the individual modules, then these default values are used.

Parameter	Description	Default value	Unit
Default safe data duration	This parameter specifies the maximum permissible data transmission time between the SafeLOGIC controller and SafeIO module. For additional information about the actual data transmission time, see section Diagnostics and service \rightarrow Diagnostics tools \rightarrow Network analyzer \rightarrow Editor \rightarrow Calculation of safety runtime in Automation Help. The following formula can be used as the lower limit: "Value of the Network Analyzer" * 2 + SafeLOGIC cycle time * 2 The stability of the system cannot be ensured for smaller values.	20000	μs
	 Permissible values: 2000 to 10,000,000 µs (corresponds to 2 ms to 10 s) 		
Default additional tolerated packet loss	This parameter specifies the number of additional tolerated lost packets during data transfer.	1	Packets
	Permissible values: 0 to 10		
Default node guarding packets	This parameter specifies the maximum number of packets used for node guard- ing.	5	Packets
	Permissible values: 1 to 255		
	Note		
	The larger the configured value, the greater the amount of asynchro- nous data traffic.		
	 This setting is not critical to safety functionality. The time for safely cut- ting off actuators is determined independently of this. 		

Table 25: SafeDESIGNER parameters: Safety response time default values

Group: Module configuration

Parameter		Description	Default value	Unit			
Keep remanent	Automatically resets the remanent data (see Automation Help No						
	for SafeDESIGNER func	tion block "SF_RemanentData_SAFEDINT" or					
	"SF_RemanentData_SAFE	DWORD")					
	Parameter value	Description					
	Yes - Warning Remanent data is not automatically reset.						
	No Remanent data is automatically reset if a modified SafeDESIGNER fied CRC and/or timestamp) is loaded to the SafeLOGIC controller.						
Max. cycle time	Parameter for checking whether a maximum time between 2 SafeLOGIC cycles 20000 µs is exceeded.						
	Permissible values: 2000 to 21,000 µs (corresponds to 2 to 21 ms)						
	Important:						
	This value should not be the same as the actual cycle time; jitter must also be taken into account.						

Table 26: SafeDESIGNER parameters: Module configuration

Danger!

If parameter "Keep remanent" is set to Yes - Warning, it is important when saving data after a project download to note that the data still has the same meaning in the application program.

6.2.2 Settings for the SafeDOMAIN-to-SafeDOMAIN connection

Starting with mapp Safety 5.10.0 and hardware upgrade 2.2.1.0

A connection between 2 SafeDOMAINs must be set up in order to exchange data. Setting up the connection and defining the safe data to be transferred takes place in the Connected SafeDOMAIN.

For additional information about SafeDOMAIN-to-SafeDOMAIN communication, see section "SafeDOMAIN-to-SafeDOMAIN communication" in Automation Help.

Information:

Since SafeDOMAIN-to-SafeDOMAIN communication is represented as an additional safety module on the Managing SafeDOMAIN, the parameters for the connection are only available and set in the Managing SafeDOMAIN project.

6.2.2.1 Connected SafeDOMAIN parameters

Starting with mapp Safety 5.10.0 and hardware upgrade 2.2.1.0

Group: Basic

Parameter		Default value	Unit					
Min. required firmware revision	This parameter is reserved	for future functional expansions.	Basic release	-				
Availability	This parameter can be used to configure the module as "optional". Optional Permanent - modules do not have to be present, i.e. the SafeLOGIC controller will not in- dicate that these modules are not present. However, this parameter does not influence the module's signal or status data.							
	Parameter value Description							
	Permanent	This module is mandatory for the application						
		The module must be in OPERATIONAL mode munication with the SafeLOGIC controller mus (SafeModuleOK = SAFETRUE). Processing of the OGIC controller is delayed after startup until this with "Availability = Permanent". After startup, module problems are indicated by a	e after startup, t be established safety application state is achieved a quickly blinking	and safe com- d without errors on on the SafeL- d for all modules				
		on the SafeLOGIC controller. An entry is also made	de in the logbook					
	Optional	The module is not required for the application.						
		The module is not taken into account during startu cation is started regardless of whether the modules in OPERATIONAL mode or if safe communication these modules and the SafeLOGIC controller.	ip, which means s with "Availability is properly esta	the safety appli- y = Optional" are blished between				
		After startup, module problems are NOT indicated LED on the SafeLOGIC controller. An entry is NO	d by a quickly bli T made in the log	nking "MXCHG" gbook.				
	Startup	This module is optional. The system determines ho startup.	w the module wil	I proceed during				
		If it is determined that the module is physically pr of whether it is in OPERATIONAL mode or not), "Availability = Permanent" is set.	resent during sta then the modul	rtup (regardless e behaves as if				
		If it is determined that the module is not physically module behaves as if "Availability = Optional" is so	v present during : et.	startup, then the				
	Never	The module is not required for the application.						
		The module is not taken into account during startu cation is started regardless of whether the module physically present.	ip, which means es with "Availabi	the safety appli- lity = Never" are				
		Unlike when "Availability = Optional" is configured "Availability = Never", which optimizes system sta	d, the module is rtup behavior.	not started with				
		After startup, module problems are NOT indicated LED on the SafeLOGIC controller. An entry is NO	d by a quickly bli T made in the lo	nking "MXCHG" gbook.				

Table 27: SafeDESIGNER parameters: Basic

Parameter		Description	Default value	Unit			
Safe data duration	This parameter specifies tween the SafeLOGIC co For additional information tion Diagnostics and servi → Calculation of safety ru The following formula car "Value of the Network An The stability of the system	This parameter specifies the maximum permissible data transmission time be- tween the SafeLOGIC controller and SafeIO module. For additional information about the actual data transmission time, see sec- tion Diagnostics and service → Diagnostics tools → Network analyzer → Editor → Calculation of safety runtime in Automation Help. The following formula can be used as the lower limit: "Value of the Network Analyzer" * 2 + SafeLOGIC cycle time * 2 The stability of the system cannot be ensured for smaller values.					
	 Permissible value s) 	s: 2000 to 10,000,000 μs (corresponds to 2 ms to 10					
Additional tolerated packet loss	This parameter specifies data transfer.	This parameter specifies the number of additional tolerated lost packets during data transfer.					
Slow connection	This parameter specifies	whether this connection is a slow connection	No	-			
	Parameter value	Description					
	Yes	Yes This is a connection with a large ratio between the telegram runtime (affects the parameter calculatio Rule of thumb: "Yes" from ratio 50:1 (telegram run					
	No	No Default connection, parameter calculation unchanged					
Node guarding packets	This parameter specifies t ing. Permissible value Note The larger the co nous data traffic.	 This parameter specifies the maximum number of packets used for node guarding. Permissible values: 1 to 255 Note The larger the configured value, the greater the amount of asynchronous data traffic. 		Packets			
	This setting is not ting off actuators	critical to safety functionality. The time for safely cut- is determined independently of this.					

Table 28: SafeDESIGNER parameters: Safety response time

Information:

Parameter "Slow connection" can also be used to specify that the connection between the Connected SafeDOMAIN and Managing SafeDOMAIN is slow. If a value of a few seconds is needed for the connection timeout, then this parameter must be enabled ("Slow connection = Yes").

6.3 SafeLOGIC - Channel list

Channel name	Access via Au- tomation Studio	Access via SafeDESIGNER	Data type	Description
ModuleOk	Read	-	BOOL	Indicates whether the module is physically present and con- figured and whether a SafeDESIGNER project is present
SerialNumber	Read	-	UDINT	Module serial number
ModuleID	Read	-	UDINT	Module ID
HardwareVariant	Read	-	UDINT	Hardware variant
FirmwareVersion	Read	-	UDINT	Firmware version of the module
SafeFirmwareVersion	Read	-	UINT	Channel for reading the version of the safe firmware
UDID_low	Read	-	UDINT	UDID, lower 4 bytes
UDID_high	Read	-	UINT	UDID, upper 2 bytes
BOOL1xxxx	Write	Read	BOOL	CPU to SafeLOGIC communication channel
INT1xxx	Write	Read	INT	CPU to SafeLOGIC communication channel
UINT1xxx	Write	Read	UINT	CPU to SafeLOGIC communication channel
DINT1xxx	Write	Read	DINT	CPU to SafeLOGIC communication channel
UDINT1xxx	Write	Read	UDINT	CPU to SafeLOGIC communication channel
BOOL0xxxx	Read	Write	BOOL	SafeLOGIC to CPU communication channel
INT0xxx	Read	Write	INT	SafeLOGIC to CPU communication channel
UINT0xxx	Read	Write	UINT	SafeLOGIC to CPU communication channel
DINT0xxx	Read	Write	DINT	SafeLOGIC to CPU communication channel
UDINT0xxx	Read	Write	UDINT	SafeLOGIC to CPU communication channel
SafeModuleOK ¹⁾	-	Read	SAFEBOOL	Indicates whether the safe communication chan- nel between SafeDOMAIN and SafeDOMAIN is OK
SafeBOOLxxx ¹⁾	Read	Read/Write	SAFEBOOL	SafeDOMAIN-to-SafeDOMAIN communication channel
SafeINTxx ¹⁾	Read	Read/Write	SAFEINT	SafeDOMAIN-to-SafeDOMAIN communication channel
SafeUINTxx 1)	Read	Read/Write	SAFEWORD	SafeDOMAIN-to-SafeDOMAIN communication channel
SafeDINTxx 1)	Read	Read/Write	SAFEDINT	SafeDOMAIN-to-SafeDOMAIN communication channel
SafeUDINTxx 1)	Read	Read/Write	SAFEDWORD	SafeDOMAIN-to-SafeDOMAIN communication channel
SafeCommissioningOptionBITxxx	-	Read	SAFEBOOL	Internal channels for Safe Commissioning Options
SafeCommissioningOptionINTxx	-	Read	SAFEINT	Internal channels for Safe Commissioning Options
SafeCommissioningOptionUINTxx	-	Read	SAFEWORD	Internal channels for Safe Commissioning Options
SafeCommissioningOptionDINTxx	-	Read	SAFEDINT	Internal channels for Safe Commissioning Options
SafeCommissioningOptionUDINTxx	-	Read	SAFEDWORD	Internal channels for Safe Commissioning Options

Table 29: SafeLOGIC - Channel list

1) Starting with mapp Safety 5.10.0 and hardware upgrade 2.2.1.0. For additional information about SafeDOMAIN-to-SafeDOMAIN communication, see section "SafeDOMAIN-to-SafeDOMAIN communication" in Automation Help.

Information:

Additional diagnostic data points are available on the X20SL8101 and the X20SL8110.

For details, see section Communication \rightarrow POWERLINK \rightarrow Diagnostics \rightarrow Diagnostic data points \rightarrow Bus controller in Automation Help.

X20(c)SL81xx

In addition, the following data can be read via POWERLINK registers:

Index:Subindex	Object name	Data type	Access	Values	Description
0x2000:0x04	SafetyFWversion1	UDINT	Read	-	Higher-order 2 bytes: Hardware variant of the module
					Lower-order 2 bytes: Firmware version - Safety processor 1
0x2000:0x05	SafetyFWversion2	UDINT	Read	-	Higher-order 2 bytes: Hardware variant of the module
					Lower-order 2 bytes: Firmware version - Safety processor 2
0x2000:0x08	Project_CRC	UDINT	Read	-	CRC of the SafeDESIGNER project
0x2000:0x09	Project_Time	DATE_AND_TIME	Read	-	Timestamp of the SafeDESIGNER project
0x2000:0x0C	Project_Name	STRING	Read	-	Project name of the SafeDESIGNER project
		(without zero termination)			
0x2000:0x0D	Project_Author	STRING	Read	-	Name of the author of the SafeDESIGNER project
		(without zero termination)			
0x2000:0x0E	SafeOS_RUN_STATE	BOOL	Read	0	SafeOS is not in RUN (identical to SafeOSstate!=0x66)
				1	SafeOS is in RUN (identical to SafeOSstate==0x66)
0x2000:0x0F	BOOT_STATE	UDINT	Read	General fi	rmware startup status;
				Using the	updated "Bootstate" object (0x2410:0x01) is recommended.
				0x00	Startup not yet begun
				0x01	Initialization started
				0x10	Cyclic hardware tests running
				0x11	openSAFETY stack running
				0x12	SafeOS running
0x2000:0x10	openSAFETYstate	UDINT	Read	0	PREOPERATIONAL state (all cyclic safe data zeroed out)
				1	OPERATIONAL state
0x2000:0x11	SafeOsState	UDINT	Read	Status of	the safety application (corresponds to LED "R/E"on the
				SafeLOGI	C controller). For details, see section "State of the safety con-
				troller" in /	Automation Help.
				0x00	Invalid (e.g. SafeKEY blank) or startup still active (BOOT_STATE!=0x12)
				0x0F	ON (startup / internal initialization) or error (check logbook)
				0x33	Loading (startup / internal initialization)
				0x55	Stop [Safe]
				0x66	Run [Safe]
				0x99	Halt [Debug]
				0xAA	Stop [Debug]
				0xCC	Run [Debug]
				0xF0	No execution
0x2000:0x12	Temperature	INT	Read	-	Measured temperature in 0.1°C
0x2000:0x14	SafeKEY TotalMemory	UDINT	Read	-	Total memory on the SafeKEY.
					Specified in sectors (1 sector = 0x10000 bytes)
0x2000:0x15	SafeKEY_AvailableMem-	UDINT	Read	-	Available memory on the SafeKEY.
	ory				Specified in sectors (1 sector = 0x10000 bytes)

The following objects are also available:

Index:Subindex	Data type	Access	Values	Description
0x2410:0x01	UDINT	Read	Bootstate; Startup state of	the SafeLOGIC controller.
			Some of the second	of the boot states do not occur during normal startup or are cycled through so
			• The bo	that they are not visible externally. ot states usually cycle through in ascending order. There are cases, however, in
			0x0003	previous value is captured. Startup communication processor OK, no communication with the safety proces-
			0x0008	Sofs SafaKEX check (valid SafaKEX not connected)
			0x0008	FAIL SAFE. At least one of the safety processors is in the safe state
			0x0020	Internal communication with safety processors started
			0x0024	Firmware update of safety processors
			0x0030	Startup of safety processors
			0x0040	Firmware of safety processors started
			0x0440	Firmware of safety processors running
			0x0840	Loads the SafeDESIGNER application of valid SafeDESIGNER application not found
			0x1840	Waiting for acknowledgments (e.g. module replacement)
			0x2A40	configured. Multiple SCAN cycles are carried out until all modules are found: 0x2040: First cycle 0x2140: Second cycle 0x2240: Third cycle
			0x3040	 Missing modules. Startup cannot be resumed since modules are missing that are configured with "Availability = Permanant"
			0x3440	Configuration of existing safety modules completed. Stabilizing cyclic openSAFETY data exchange. Note: If the best state remains here, sheek SafeDESIGNER parameters "(Default) Safe
			0x4040	data duration" and "(Default) Additional tolerated packet loss".
0x2410:0x02	UDINT	Read	-	SCAN progress (how many modules have already been processed in the current scan)
0x2410:0x03	UDINT	Read	-	Supply voltage (in mV)
0x2410:0x04	UDINT	Read	-	CRC of the firmware header on safety processor 1
0x2410:0x05	UDINT	Read	-	CRC of the firmware header on safety processor 2
0x2410:0x06		Read	-	Maximum cycle time (time from cycle start to cycle end)
0x2410:0x08	UDINT	Read	-	SafeLOGIC status word
0x2410:0x09	UDINT	Read	-	Number of missing modules
0x2410:0x0A	UDINT	Read	-	Number of UDID mismatches
0x2410:0x0B	UDINT	Read	-	Number of firmware mismatches
0x2410:0x0C	UDINT	Read	-	Number of configured modules
0x2410:0x0D		Read	-	Flag for missing subsequently loadable files: Bit 0: Safe Commissioning Options missing in AUTOCNF.BIN Bit 1: SafeNODE Availability missing in AUTOCNF.BIN Bit 2: EMODATA1.BIN missing Bit 3: TABDATA1.BIN
0x2410:0x0E	UDINT	Read	-	openSAFETY common event counter SERR_k_SFS_LENGTH
0x2410:0x0F	UDINT	Read	-	openSAFETY common event counter SERR_k_SFS_TOO_LONG
0x2410:0x10	UDINT	Read	-	openSAFETY common event counter SERR_k_SFS_FRM_ID
0x2410:0x11	UDINT	Read	-	openSAFETY common event counter SERR_k_SFS_SADR_INV
0x2410:0x12		Read	-	openSAFETY common event counter SERR_K_SFS_SDN_INV
0x2410:0x13	UDINT	Read	-	openSAFETY common event counter SERR k SFS_CRC1
0x2410:0x15	UDINT	Read	-	openSAFETY common event counter SERR_k_SFS_CRC2
0x2410:0x16	UDINT	Read	-	openSAFETY common event counter SERR_k_SFS_DATA
0x2410:0x17	UDINT	Read	-	openSAFETY common event counter SERR_k_CYC_REJECT
0x2410:0x18	UDINT	Read	-	openSAFETY common event counter SERR_k_CYC_ERROR
0x2410:0x19		Read	-	openSAFETY common event counter SERR_k_ACYC_REJECT
0x2410:0x1A 0x2410:0x1B to 0x2410:0x1E	UDINT	Read	-	Reserved for future openSAFETY common event counters
0x2410:0x20	UDINT	Read	-	Number of SCFM errors
0x2410:0x21	UDINT	Read	-	Number of SCM errors
0x2410:0x22	UDINT	Read	-	Number of SDN errors
0x2410:0x23	UDINT	Read	-	Number of SFS errors
0x2410:0x24		Read	-	Number of SHNF errors
0x2410.0x25	UDINT	Read	-	Number of SNMTS errors
0x2410:0x27	UDINT	Read	-	Number of SOD errors
0x2410:0x28	UDINT	Read	-	Number of SPDO errors

X20(c)SL81xx

Indox:Subindox	Data tupo	Access	Values	Description
		Access	values	Number of SSC error
0x2410:0x29		Read	-	Number of SSC errors
0x2410:0x2A		Read	-	Number of SSDOC errors
0x2410:0x2B	UDINI	Read	-	Number of SSDOS errors
0x2410:0x2C	UDINI	Read	-	I otal memory for parameter files
0x2410:0x2D	UDINT	Read	-	Available memory for parameter files
0x2410:0x2E	UDINT	Read	-	Total memory for project files
0x2410:0x2F	UDINT	Read	-	Available memory for project files
0x2410:0x30	UDINT	Read	-	Total memory for subsequently loadable C libraries and tables
0x2410:0x31	UDINT	Read	-	Available memory for subsequently loadable C libraries and tables
0x2410:0x32	UDINT	Read	-	Total memory for dynamic memory management in subsequently loadable C libraries
0x2410:0x33	UDINT	Read	-	Available memory for dynamic memory management in subsequently loadable C libraries
0x2410:0x34 to 0x2410:0xFE	UDINT	Read	-	Reserved for future expansions
0x2424:0x01	UDINT	Read	-	AutoCnf.bin - Timestamp
0x2424:0x02	UDINT	Read	-	AutoCnf.bin - Number of CRCs
0x2424:0x03	UDINT	Read	-	AutoCnf.bin - Size of file in bytes
0x2424:0x04 to 0x2424:0x0A	UDINT	Read	-	AutoCnf.bin - Reserved for future expansions
0x2424:0x0B to 0x2424:0xn	UDINT	Read	-	AutoCnf.bin - CRC 1 to N
0x2424:0xn+1 to 0x2424:0xFE	UDINT	Read	-	AutoCnf.bin - Reserved for future expansions
0x2425:0x01	UDINT	Read	-	EmoData1.bin - Timestamp
0x2425:0x02	UDINT	Read	-	EmoData1.bin - Number of CRCs
0x2425:0x03	UDINT	Read	-	EmoData1.bin - Size of file in bytes
0x2425:0x04 to 0x2425:0x0A	UDINT	Read	-	EmoData1.bin - Reserved for future expansions
0x2425:0x0B to 0x2425:0xn	UDINT	Read	-	EmoData1.bin - CRC 1 to N
0x2425:0xn+1 to 0x2425:0xFE	UDINT	Read	-	EmoData1.bin - Reserved for future expansions
0x2426:0x01	UDINT	Read	-	TabData1.bin - Timestamp
0x2426:0x02	UDINT	Read	-	TabData1.bin - Number of CRCs
0x2426:0x03	UDINT	Read	-	TabData1.bin - Size of file in bytes
0x2426:0x04 to 0x2426:0x0A	UDINT	Read	-	TabData1.bin - Reserved for future expansions
0x2426:0x0B to 0x2426:0xn	UDINT	Read	-	TabData1.bin - CRC 1 to N
0x2426:0xn+1 to 0x2426:0xFE	UDINT	Read	-	TabData1.bin - Reserved for future expansions
0x2427:0x01	UDINT	Read	-	ParData1.bin - Timestamp
0x2427:0x02	UDINT	Read	-	ParData1.bin - Number of CRCs
0x2427:0x03	UDINT	Read	-	ParData1.bin - Size of file in bytes
0x2427:0x04 to 0x2427:0x0A	UDINT	Read	-	ParData1.bin - Reserved for future expansions
0x2427:0x0B to 0x2427:0xn	UDINT	Read	-	ParData1.bin - CRC 1 to N
0x2427:0xn+1 to 0x2427:0xFE	UDINT	Read	-	ParData1.bin - Reserved for future expansions

The following information about each openSAFETY node can be retrieved in object range 0x2416 to 0x2423 (data type: UDINT, Access: Read):

Parameter ID	Value
0	SafeModule ID
1	Status word Bit 0: Missing module Bit 1: Firmware mismatch on module Bit 2: UDID mismatch on module Bit 3: Reserved Bit 4: Reserved Bit 5: "Connection valid" bit of module Bit 6 to 31: Reserved
2	Connection valid statistics (number of negative edges of the connection valid bit)
3	Propagation delay statistics (average value of the data transmission time). The unit depends on parameter "Process data transfer rate".
	 If the value of the parameter is "High", the unit is 100 μs.
	If the value of the parameter is "Low", the unit is 1 ms.
	This value corresponds to the measurement of the forward and return channels and thus twice the theoretical runtime that is determined by the Network Analyzer.

The following formulas must be used to calculate the index/subindex:

$$Index = \frac{Module_number}{23} + 0x2416$$

Subindex = Parameter...ID...+...{[.(Module...number...-..1)...%...23...]..×...11...}...%....254....+...1

 Module number:
 Sequential number of the desired module

 Parameter ID:
 See previous table

6.4 Power supply module (X20SL8101 only) - Channel list

A power supply module is already integrated on station 1 on the X2X Link.

Channel name	Access via Au- tomation Studio	Access via SafeDESIGNER	Data type	Description
ModuleOk	Read	-	BOOL	Indicates whether the module is physi- cally present in the slot and configured
ModuleID	Read	-	UINT	Module ID
HardwareVariant	Read	-	UINT	Hardware variant
FirmwareVersion	Read	-	UINT	Firmware version of the module
StatusInput01	Read	-	BOOL	Warning if overcurrent (>2.3 A) or undervoltage (<4.7 V)
StatusInput02	Read	-	BOOL	I/O power supply below the warning limit of 20.4 V
SupplyCurrent	Read	-	USINT	Bus supply current with a resolution of 0.1 A
SupplyVoltage	Read	-	USINT	Bus supply voltage with a resolution of 0.1 V

Table 30: Power supply module - Channel list

7 Version history

Version	Date	Comment				
2.15	August 2022	Chapter 6.2.1 "SafeLOGIC basic settings": Group "Basic": Parameter "Process data transfer rate": Updated description of value "Low".				
2.14	May 2022	Chapter 4 "Technical data": Updated DNV certification.				
		Updated chapter 8 "Declaration of conformity".				
2.12	November 2021	Chapter 4 "Technical data": Updated derating.				
		Chapter 5.2 "Slot for application memory (SafeKEY)": Updated information.				
2.11	August 2021	Chapter 4 "Technical data":				
		Updated marker memory.				
		Updated marker count.				
2.10	May 2021	Chapter 1 "General information": Added information.				
		Chapter 4 "Technical data":				
		 Updated display of system requirements. 				
		 Added max. number of SafeMOTION axes 				
		 Updated memory for safe input data. 				
2.09	Eebruary 2021	Chanter 4 "Technical data"				
2.00	robradiy 2021					
		 Data exchange between CPU and SafeLOGIC controller: Added footnote for max. total data width for each direction. 				
		 Data exchange between SafeDOMAIN and SafeDOMAIN: Added footnote for max. total data width for each direction. 				
		 X20SL8110: Corrected width. 				
		Chanter 6.2.1 "Safel OGIC basic settings": Group "Basic": Added parameter "Maximum number of simultaneous				
		module startups".				
2.08	November 2020	Chapter 4 "Technical data"				
		 Added use as connected saleboinand. Undated may number of linked Managing SafeDOMAINs 				
		Editorial changes.				
2.07	August 2020	Chapter 4 "Lechnical data":				
		- General information: Added additional power dissipation caused by actuators (resistive) [W].				
		 Updated certifications. 				
		Editorial changes				
2.06	May 2020	Chapter 4 "Technical data":				
		 Added rootnote for system requirements. 				
		 Updated certifications. Eventine ality Date such as a between OpfoDOMAIN and OpfoDOMAIN, Added even swerker of links 				
		 Functionality: Data exchange between SateDOWAIN and SateDOWAIN: Added max. humber of linked Managing SafeDOMAINs 				
		 Added footnote for data exchange between CPU and Safel OGIC controller 				
		 Coated modules: Updated operating temperature. 				
0.05	Eshman 2000	Editorial changes. Observe 4 Tracking data to add data supported between OxforDOMAIN and OxforDOMAIN				
2.05	February 2020	Chapter 4 Technical data : Added data exchange between SaleDOMAIN and SaleDOMAIN. Chapter 6 4 "December in the I/O configuration". Added group "SafeDOMAIN to SafeDOMAIN.				
		Chapter 6.1 Parameters in the I/O conlightation . Added group SalebomAin-to-SalebomAin continunication .				
		Added chapter 6.2. Settings for the salebolikativ-to-salebolikativ connection .				
		Chapter 0.5 SaleLOGIC - Chamerist : Added new chamers.				
2 04	November 2010	Chanter 4 "Technical data": Undated certifications				
2.07		Undated chapter 5.1.3 "Selector switch and confirmation button"				
		Chapter 6.2 "Parameters in SafeDESIGNER": Undated description of parameter "Asynchronous communication				
		load".				
		Editorial changes.				
2.03	August 2019	Chapter 3 "Order data": Added X20(c)MK0223 accessories.				
2.02	May 2019	First edition for mapp Safety				

Table 31: Version history

8 Declaration of conformity

This document was originally written in the German language. The German edition therefore represents the original documentation in accordance with Machinery Directive 2006/42/EC. Documents in other languages should be interpreted as translations of the original documentation.

Product manufacturer:

B&R Industrial Automation GmbH B&R Strasse 1 5142 Eggelsberg Austria Telephone: +43 7748 6586-0 Fax: +43 7748 6586-26 office@br-automation.com

Commercial register number: FN 111651 v Commercial registry: Regional court Ried im Innkreis UID number: ATU62367156 Legal structure: Limited liability company Corporate headquarters: Municipality of Eggelsberg (Upper Austria)

Declarations of conformity for B&R products are available for download on the B&R website (<u>www.br-automation.com</u>).