

# **ACOPOSmulti with SafeMC**

## **User's Manual**

Version: **2.4 (February 2014)**  
Model no.: **MAACPMSAFEMC-ENG**

All information contained in this manual is current as of its creation/publication. B&R reserves the right to change the contents of this manual without notice. The information contained herein is believed to be accurate as of the date of publication; however, Bernecker + Rainer Industrie-Elektronik Ges.m.b.H. makes no warranty, expressed or implied, with regard to the products or documentation contained within this manual. In addition, Bernecker + Rainer Industrie-Elektronik Ges.m.b.H. shall not be liable for any incidental or consequential damages in connection with or arising from the furnishing, performance or use of the product(s) in this documentation. Software names, hardware names and trademarks are registered by their respective companies.



## **Chapter 1: General information**

## **Chapter 2: ACOPOSmulti SafeMC**

## **Chapter 3: System features**

## **Chapter 4: Safety technology**

## **Chapter 5: PLCopen Safety**

## **Chapter 6: SafeDESIGNER**

## **Chapter 7: Standards and certifications**

## **Appendix A: EC declaration of conformity**

<b>Chapter 1 General information.....</b>	<b>11</b>
1 Manual history.....	11
1.1 Publications.....	12
1.2 Release information.....	13
2 Safety guidelines.....	13
2.1 Organization of safety notices.....	13
2.2 General information.....	13
2.3 Qualified personnel.....	13
2.4 Intended use.....	14
2.5 Disclaimer.....	14
2.6 Protection against electrostatic discharge.....	14
2.6.1 Packaging.....	14
2.6.2 Guidelines for proper ESD handling.....	14
2.7 Transport and storage.....	15
2.8 Handling and installation.....	15
2.9 Operation.....	15
2.9.1 Protection against touching electrical parts.....	15
2.9.2 Protection against hazardous movements.....	16
2.10 Functional safety data and specifications.....	17
3 Environmentally friendly disposal.....	17
3.1 Separation of materials.....	17
<b>Chapter 2 ACOPOSmulti SafeMC.....</b>	<b>18</b>
1 Configuration of an ACOPOSmulti drive system.....	18
2 Status indicators.....	19
2.1 8BVI inverter modules with SafeMC.....	19
2.1.1 Single-axis modules.....	19
2.1.2 Dual-axis modules.....	20
2.1.3 RDY, RUN, ERR (8BVI, 8BVP, 8B0P) - LED status indicators.....	21
2.1.4 POWERLINK - LED status indicators.....	21
2.1.5 LED Status indicators - Backup battery.....	21
2.1.6 SafeMC module - LED status indicators.....	22
2.1.7 Status changes when booting the operating system loader.....	23
2.1.8 Setting the POWERLINK station number.....	23
3 Data sheets.....	24
3.1 Module overview.....	24
3.2 Safe single-width inverter modules (single-axis modules).....	25
3.2.1 8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1.....	25
3.2.2 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1.....	29
3.2.3 8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1.....	33
3.2.4 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1.....	38
3.2.5 Wiring: Safe single-width inverter modules (single-axis modules).....	43
3.3 Safe double-width inverter modules (single-axis modules).....	46
3.3.1 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1.....	46
3.3.2 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1.....	50
3.3.3 8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1.....	54
3.3.4 Wiring: Safe double-width inverter modules (single-axis modules).....	59
3.4 Safe single-width inverter modules (dual-axis modules).....	63
3.4.1 8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1.....	63
3.4.2 8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1.....	67
3.4.3 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1.....	71
3.4.4 Wiring: Safe single-width inverter modules (dual-axis modules).....	76
3.5 Safe double-width inverter modules (dual-axis modules).....	81
3.5.1 8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1.....	81
3.5.2 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1.....	85
3.5.3 Wiring: Safe double-width inverter modules (dual-axis modules).....	90
3.6 Safe 4x width inverter modules (single-axis modules).....	95



3.6.1 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1.....	95
3.6.2 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1.....	99
3.6.3 Wiring: Safe 4x width inverter modules (single-axis modules).....	104
3.7 Safe 8x width inverter modules (single-axis modules).....	109
3.7.1 8BVI1650HCSS.000-1.....	109
3.7.2 Wiring: Safe 8x-width inverter modules (single-axis modules).....	113
4 Installation.....	118
5 Dimensioning.....	119
6 Wiring.....	120
6.1 General information.....	120
6.1.1 EMC-compatible installation.....	120
6.1.2 Overview.....	121
6.1.3 Connection diagrams for ground and shield connections.....	124
6.1.4 Insulation and high voltage testing.....	126
<b>Chapter 3 System features.....</b>	<b>128</b>
1 SafeMC Module.....	128
1.1 General Information.....	128
1.2 Safety functions.....	128
2 Integrated safety technology.....	128
3 System requirements.....	130
4 System limits.....	131
5 Safe response time.....	131
5.1 Signal processing on the safe B&R input module.....	132
5.2 Data runtime on the bus.....	132
5.3 Signal processing on the safe B&R output module.....	132
5.4 Signal processing on the safe B&R SafeMC module.....	132
5.5 Calculating the safe response time.....	133
5.6 Parameters for the safe response time in SafeDESIGNER.....	135
5.7 Minimum signal lengths.....	137
6 Detection of errors within the module.....	137
<b>Chapter 4 Safety technology.....</b>	<b>138</b>
1 Integrated safety technology in the ACOPOSMulti with SafeMC.....	138
1.1 General Information.....	138
1.2 Safe power transmission.....	138
1.3 The closed-circuit principle.....	140
2 Principle - Implementing the safety functions.....	141
2.1 Safe pulse disabling.....	142
2.2 Safe motor holding brake output.....	143
2.3 EnDat 2.2 functional safety encoder.....	144
2.3.1 Encoder mounting with proof of fatigue strength.....	144
2.3.2 Encoder mounting without proof of fatigue strength - Safe lag error monitoring.....	145
2.3.3 Safe encoder counting range.....	148
3 Safety-related characteristic values of integrated safety functions.....	149
4 Integrated safety functions.....	151
4.1 Fail-safe state.....	151
4.1.1 Parameters.....	151
4.1.2 Behavior.....	151
4.2 Functional fail-safe state.....	152
4.2.1 Parameters.....	152
4.2.2 Behavior.....	152
4.3 Safe Position, Safe Speed.....	154
4.3.1 Parameters.....	154
4.3.2 Behavior.....	155
4.4 STO - Safe Torque Off.....	157
4.4.1 Parameters.....	157

4.4.2 Behavior.....	157
4.5 Single-channel Safe Torque Off, STO1.....	158
4.5.1 Parameters.....	158
4.5.2 Behavior.....	158
4.6 Safe Brake Control, SBC.....	159
4.6.1 Parameters.....	159
4.6.2 Behavior.....	159
4.7 Safe Operating Stop, SOS.....	160
4.7.1 Parameters.....	160
4.7.2 Behavior.....	160
4.8 Safe Stop 1, SS1.....	161
4.8.1 Parameters.....	161
4.8.2 Behavior.....	161
4.8.3 SS1 - Stopping procedure with ramp-based monitoring.....	162
4.8.4 SS1 - Stopping procedure with time-monitoring.....	163
4.9 Safe Stop 2, SS2.....	164
4.9.1 Parameters.....	164
4.9.2 Behavior.....	164
4.9.3 SS2 - Stopping procedure with ramp-based monitoring.....	166
4.9.4 SS2 - Stopping procedure with time-monitoring.....	166
4.10 Safely Limited Speed, SLS.....	167
4.10.1 Parameters.....	167
4.10.2 Behavior.....	167
4.10.3 SLS - Stopping procedure with ramp-based monitoring.....	169
4.10.4 SLS - Stopping procedure with time-monitoring.....	169
4.11 Safe Maximum Speed, SMS.....	170
4.11.1 Parameters.....	170
4.11.2 Behavior.....	170
4.12 Safely Limited Increment, SLI.....	171
4.12.1 Parameters.....	171
4.12.2 Behavior.....	171
4.13 Safe Direction, SDI.....	172
4.13.1 Parameters.....	172
4.13.2 Behavior.....	172
4.14 Safe Homing.....	174
4.14.1 Parameters.....	174
4.14.2 Behavior.....	175
4.14.3 Direct mode.....	176
4.14.4 Reference Switch mode.....	177
4.14.5 Home Offset / Home Offset with Correction mode (only for ACOPOSmulti with SafeMC EnDat 2.2). ..	180
4.15 Safely Limited Position, SLP.....	182
4.15.1 Parameters.....	182
4.15.2 Behavior.....	182
4.16 Safe Maximum Position, SMP.....	184
4.16.1 Parameters.....	184
4.16.2 Behavior.....	184
5 Status LEDs.....	185
6 SafeMC - Register description.....	185
6.1 Parameters in the I/O configuration of the SafeMC module.....	185
6.2 SafeDESIGNER parameters.....	186
6.2.1 Safety Release 1.3.....	186
6.2.2 Safety Release 1.4.....	192
6.3 Channel list.....	198
7 Programming the safety application.....	199
7.1 SafeMC Help Tool.....	200
7.1.1 Status and Control Bits tab.....	200
7.1.2 Velocity tab.....	202

7.1.3 Delay Time tab.....	204
7.1.4 SMP/SLP Speed Limits tab.....	205
7.1.5 Safe Brake Test SBT tab.....	207
7.1.6 Options tab.....	209
7.2 Application in SafeDESIGNER.....	209
7.3 Access the data on the SafeMC module in Automation Studio.....	210
7.3.1 I/O mapping.....	210
7.3.2 ACOPOSmulti parameter IDs.....	211
7.3.3 Library SafeMC.....	212
7.4 Validate the safety functions.....	217
7.5 Maintenance scenarios.....	218
7.5.1 Commissioning.....	218
7.5.2 Replacing ACOPOSmulti with SafeMC safe inverter modules.....	218
7.5.3 Replacing a safe encoder / motor.....	218
7.5.4 Firmware update / Acknowledging a firmware exchange.....	218
7.5.5 Decommissioning a system.....	219
<b>Chapter 5 PLCopen Safety.....</b>	<b>220</b>
1 Definition of terms.....	220
2 SF_SafeMC_BR.....	221
2.1 Formal parameters of the function block.....	222
2.2 SafeMC module parameters.....	224
2.3 Integrated safety functions.....	226
2.3.1 Fail-safe state.....	226
2.3.2 Functional fail-safe state.....	227
2.3.3 Safe Position, Safe Speed.....	229
2.3.4 STO - Safe Torque Off.....	232
2.3.5 Single-channel Safe Torque Off, STO1.....	233
2.3.6 Safe Brake Control, SBC.....	234
2.3.7 Safe Operating Stop, SOS.....	235
2.3.8 Safe Stop 1, SS1.....	236
2.3.9 Safe Stop 2, SS2.....	239
2.3.10 Safely Limited Speed, SLS.....	242
2.3.11 Safe Maximum Speed, SMS.....	245
2.3.12 Safely Limited Increment, SLI.....	246
2.3.13 Safe Direction, SDI.....	247
2.3.14 Safe Homing.....	249
2.3.15 Safely Limited Position, SLP.....	257
2.3.16 Safe Maximum Position, SMP.....	259
2.4 Error prevention.....	261
2.4.1 Exceeding monitored limits.....	261
2.4.2 Plausibility errors.....	261
2.4.3 Sporadically changing/toggling signal levels or impermissible signals.....	261
2.4.4 Simultaneous edge change.....	262
2.4.5 Machine/system startup without performing functional testing of safety equipment.....	262
2.5 Input parameters.....	263
2.5.1 General information about the "S_Request" inputs.....	263
2.5.2 Activate.....	264
2.5.3 S_RequestSTO.....	265
2.5.4 S_RequestSTO1.....	266
2.5.5 S_RequestSBC.....	267
2.5.6 S_RequestSOS.....	268
2.5.7 S_RequestSS1.....	269
2.5.8 S_RequestSS2.....	271
2.5.9 S_RequestSLS1.....	272
2.5.10 S_RequestSLS2.....	273
2.5.11 S_RequestSLS3.....	274

2.5.12 S_RequestSLS4.....	275
2.5.13 S_RequestSLI.....	276
2.5.14 S_RequestSDIpos.....	277
2.5.15 S_RequestSDIneg.....	278
2.5.16 Reset.....	279
2.5.17 S_AxisID.....	280
2.6 Output parameters.....	281
2.6.1 Ready.....	281
2.6.2 S_SafetyActiveSTO.....	282
2.6.3 S_SafetyActiveSTO1.....	283
2.6.4 S_SafetyActiveSBC.....	284
2.6.5 S_SafetyActiveSOS.....	285
2.6.6 S_SafetyActiveSS1.....	286
2.6.7 S_SafetyActiveSS2.....	287
2.6.8 S_SafetyActiveSLS1.....	288
2.6.9 S_SafetyActiveSLS2.....	289
2.6.10 S_SafetyActiveSLS3.....	290
2.6.11 S_SafetyActiveSLS4.....	291
2.6.12 S_SafetyActiveSLI.....	292
2.6.13 S_SafetyActiveSDIpos.....	293
2.6.14 S_SafetyActiveSDIneg.....	294
2.6.15 S_SafetyActiveSDC.....	295
2.6.16 S_AllReqFuncActive.....	296
2.6.17 S_NotErrFUNC.....	297
2.6.18 Error.....	298
2.6.19 DiagCode.....	299
2.6.20 Diagnostic codes.....	300
2.6.21 AxisStatus.....	301
2.7 State machine.....	302
2.8 Signal sequence diagram of the function block.....	302
3 SF_SafeMC_BR_V2.....	303
3.1 Formal parameters of the function block.....	304
3.2 SafeMC module parameters.....	306
3.3 Integrated safety functions.....	309
3.3.1 Fail-safe state.....	309
3.3.2 Functional fail-safe state.....	310
3.3.3 Safe Position, Safe Speed.....	312
3.3.4 STO - Safe Torque Off.....	315
3.3.5 Single-channel Safe Torque Off, STO1.....	316
3.3.6 Safe Brake Control, SBC.....	317
3.3.7 Safe Operating Stop, SOS.....	318
3.3.8 Safe Stop 1, SS1.....	319
3.3.9 Safe Stop 2, SS2.....	322
3.3.10 Safely Limited Speed, SLS.....	325
3.3.11 Safe Maximum Speed, SMS.....	328
3.3.12 Safely Limited Increment, SLI.....	329
3.3.13 Safe Direction, SDI.....	330
3.3.14 Safe Homing.....	332
3.3.15 Safely Limited Position, SLP.....	340
3.3.16 Safe Maximum Position, SMP.....	342
3.4 Safe encoder connection monitoring.....	344
3.4.1 Encoder mounting with proof of fatigue strength.....	344
3.4.2 Encoder mounting without proof of fatigue strength - Safe lag error monitoring.....	344
3.5 Error prevention.....	347
3.5.1 Exceeding monitored limits.....	347
3.5.2 Plausibility errors.....	348
3.5.3 Sporadically changing/toggling signal levels or impermissible signals.....	348

3.5.4 Simultaneous edge change.....	349
3.5.5 Machine/system startup without performing functional testing of safety equipment.....	349
3.6 Input parameters.....	350
3.6.1 General information about the "S_Request" inputs.....	350
3.6.2 Activate.....	351
3.6.3 S_RequestSTO.....	352
3.6.4 S_RequestSTO1.....	353
3.6.5 S_RequestSBC.....	354
3.6.6 S_RequestSOS.....	355
3.6.7 S_RequestSS1.....	356
3.6.8 S_RequestSS2.....	358
3.6.9 S_RequestSLS1.....	359
3.6.10 S_RequestSLS2.....	360
3.6.11 S_RequestSLS3.....	361
3.6.12 S_RequestSLS4.....	362
3.6.13 S_RequestSLI.....	363
3.6.14 S_RequestSDIpos.....	364
3.6.15 S_RequestSDIneg.....	365
3.6.16 S_RequestSLP.....	366
3.6.17 S_RequestHoming.....	368
3.6.18 S_ReferenceSwitch.....	370
3.6.19 Reset.....	371
3.6.20 S_AxisID.....	372
3.7 Output parameters.....	373
3.7.1 Ready.....	373
3.7.2 S_SafetyActiveSTO.....	374
3.7.3 S_SafetyActiveSTO1.....	375
3.7.4 S_SafetyActiveSBC.....	376
3.7.5 S_SafetyActiveSOS.....	377
3.7.6 S_SafetyActiveSS1.....	378
3.7.7 S_SafetyActiveSS2.....	379
3.7.8 S_SafetyActiveSLS1.....	380
3.7.9 S_SafetyActiveSLS2.....	381
3.7.10 S_SafetyActiveSLS3.....	382
3.7.11 S_SafetyActiveSLS4.....	383
3.7.12 S_SafetyActiveSLI.....	384
3.7.13 S_SafetyActiveSDIpos.....	385
3.7.14 S_SafetyActiveSDIneg.....	386
3.7.15 S_SafetyActiveSLP.....	387
3.7.16 S_SafetyActiveSMP.....	388
3.7.17 S_SafePositionValid.....	389
3.7.18 S_SafetyActiveSDC.....	390
3.7.19 S_AllReqFuncActive.....	391
3.7.20 S_NotErrFUNC.....	392
3.7.21 Error.....	393
3.7.22 DiagCode.....	394
3.7.23 Diagnostic codes.....	394
3.7.24 AxisStatus.....	395
3.8 State machine.....	396
3.9 Signal sequence diagram of the function block.....	396
4 SF_SafeMC_Speed_BR.....	397
4.1 Formal parameters of the function block.....	397
4.2 Function.....	397
4.3 Error prevention.....	397
4.3.1 Plausibility errors.....	398
4.3.2 Validate the speed signal.....	398
4.3.3 Machine/system startup without performing functional testing of safety equipment.....	398

4.4 Input parameters.....	399
4.4.1 S_AxisID.....	399
4.5 Output parameters.....	400
4.5.1 S_ScaledSpeed.....	400
4.5.2 S_NotErrENC.....	401
4.6 Signal sequence diagram of the function block.....	402
4.7 Application example.....	402
5 SF_SafeMC_Position_BR.....	403
5.1 Formal parameters of the function block.....	403
5.2 Function.....	403
5.3 Error prevention.....	404
5.3.1 Plausibility errors.....	404
5.3.2 Validate the position signal.....	404
5.3.3 Machine/system startup without performing functional testing of safety equipment.....	404
5.4 Input parameters.....	405
5.4.1 S_AxisID.....	405
5.5 Output parameters.....	406
5.5.1 S_SafePosition.....	406
5.5.2 S_SafePositionValid.....	407
5.6 Signal sequence diagram of the function block.....	408
5.7 Application example.....	408
<b>Chapter 6 SafeDESIGNER.....</b>	<b>409</b>
<b>Chapter 7 Standards and certifications.....</b>	<b>410</b>
1 Applicable European directives.....	410
2 Applicable standards.....	410
2.1 Limit values.....	410
3 Environmental limits.....	410
3.1 Mechanical conditions in accordance with IEC 61800-2.....	410
3.2 Climate conditions in accordance with IEC 61800-2.....	411
4 Requirements for immunity to disturbances (EMC).....	412
4.1 Evaluation criteria (performance criteria).....	412
4.2 Low-frequency disturbances in accordance with IEC 61800-3.....	412
4.3 High-frequency disturbances in accordance with IEC 61800-3.....	413
5 Requirements for emissions (EMC).....	413
5.1 High-frequency emissions in accordance with IEC 61800-3.....	413
6 Additional environmental limit values in accordance with IEC 61800-2.....	414
7 International certifications.....	415
8 Standards and definitions for safety technology.....	416
<b>Appendix A EC declaration of conformity.....</b>	<b>419</b>

# Chapter 1 • General information

## Information:

This user's manual is only valid together with the ACOPOSmulti User's Manual MAACPM-ENG and the Integrated Safety User'S Manual MASAFETY1-ENG!

## 1 Manual history

## Information:

B&R keeps the printed version of user's manuals as current as possible.

From a safety standpoint, however, the current version from the B&R website must be used ([www.br-automation.com](http://www.br-automation.com)) .

Version	Date	Comment
1.00	26-Mar-10	Start of revision history publication
2.2	19-Mar-12	Update manual for Safety Release 1.4
2.3	24-Sep-12	Chapter "General information": Disclaimer added Chapter "System characteristics": Added "Detection of errors within the module" Chapter "Safety technology / Integrated safety technology in the ACOPOSmulti with SafeMC / The safe power transmission": Added "Encoder options and danger notice" Chapter "Safety technology / Safety characteristics": Added "Danger notice regarding measurement devices"

Table 1: Manual history

Version	Date	Comment
2.4	17-Feb-14	<p>Chapter "General information / Safety notices / Operation / Protection against touching electrical parts": Danger warning updated</p> <p>Chapter "ACOPOSMulti with SafeMC": Information about motor and encoder cable after order data added and danger warning about safe motor holding brake (X4A/X4B connect) added</p> <p>Chapter "ACOPOSMulti with SafeMC / Wiring / General information / Overview: Additional PE-connection for 8BVE expansion modules added</p> <p>Chapter "Safety technology / Integrated safety technology in the ACOPOSMulti with SafeMC / The safe power transmission": Information about motor cable added</p> <p>Chapter "Safety technology / Principle - Implementing the safety functions": Danger warning changed</p> <p>Chapter "Safety technology / Principle - Implementing the safety functions / Safe motor holding brake output": Danger warning about safe motor holding brake added</p> <p>Chapter "Safety technology / Principle - Implementing the safety functions / EnDat 2.2 Functional Safety encoder / Encoder mounting with proof of fatigue strength": Title changed (previously: Fault exclusion)</p> <p>Chapter "Safety technology / Principle - Implementing the safety functions / EnDat 2.2 Functional Safety encoder / Encoder mounting without proof of fatigue strength - Safe lag error monitoring": Shared content with user's manual ACOPOSMulti with SafeMC SinCos (previously: Safe monitoring without elimination of errors)</p> <p>Chapter "Safety technology / Safety characteristics of the integrated safety functions": Description of Safe Operating Stop (SOS) revised</p> <p>Chapter "Safety technology / Integrated safety functions": SafePosition, SafeSpeed added</p> <p>Chapter "Safety technology / SafeMC - Register description / Parameters in the I/O configuration of the SafeMC module": Parameter removed from "General" group</p> <p>Chapter "Safety technology / Programming the safety application": SBT added with reference to ACOPOSMulti SafeMC SinCos, shared content</p> <p>Chapter "Safety technology / Programming the safety application / SafeMC Help Tool": Safe Brake Test SBT information added</p> <p>Chapter "Safety technology / Programming the safety application / Software development in SafeDESIGNER": Reference to ACOPOSMulti SafeMC SinCos, shared content</p> <p>Chapter "Safety technology / Programming the safety application / Access the data on the SafeMC module in Automation Studio / ACOPOSMulti Parameter IDs": Shared content with ACOPOSMulti SafeMC SinCos, extended</p> <p>Chapter "Safety technology / Programming the safety application / Access the data on the SafeMC module in Automation Studio / Library SafeMC": Description optimized, re-structured, SBT added (shared content with ACOPOSMulti SafeMC SinCos)</p> <p>Chapter "Safety technology / Programming the safety application / Maintenance scenarios / Replacing a safe encoder / motor": Shared content with user's manual ACOPOSMulti with SafeMC SinCos</p> <p>Chapter "PLCopen Safety / SF_SafeMC_BR and ../SF_SafeMC_BR_V2": Section "Integrated safety functions" same as section in the Chapter "Safety technology / Integrated safety functions"</p> <p>Chapter "PLCopen Safety / SF_SafeMC_BR_V2 / Safe encoder connection monitoring / Encoder mounting with proof of fatigue strength": Shared content with user's manual ACOPOSMulti with SafeMC SinCos (previously: Fault exclusion)</p> <p>Chapter "PLCopen Safety / SF_SafeMC_BR_V2 / Safe encoder connection monitoring / Encoder mounting without proof of fatigue strength - Safe lag error monitoring": Shared content with user's manual ACOPOSMulti with SafeMC SinCos (previously: Safe monitoring without elimination of errors)</p> <p>Chapter "Standards and Certifications": EN 954-1 removed, Changed ...according to IFA (previously BGIA)... 2/2012, Additional Environmental Limit Values in accordance with IEC 61800-2: Footnote removed</p>

Table 1: Manual history

## 1.1 Publications

Model number	Medium	Contents
MAACPMsAFEMc2-ENG	Electronic	Complete
MAACPMsAFEMc-ENG	Electronic	Complete
MAACPM-ENG	Electronic	Complete
MASAFETY-ENG	Electronic	Complete
MASAFETY1-ENG	Print version	Without chapter 4: PLCopen
MASAFETY2-ENG	Print version	Only chapter 4: PLCopen

Table 2: Publications



## 1.2 Release information

Manual version	Valid for
V1.00	Safety Release 1.3
V2.2 V2.3 V2.4	Safety Release 1.3 and Safety Release 1.4

Table 3: Release information

## 2 Safety guidelines

### 2.1 Organization of safety notices

Safety notices in this manual are organized as follows:

Safety notice	Description
<b>Danger!</b>	Disregarding these safety guidelines and notices can be life-threatening.
<b>Warning!</b>	Disregarding these safety guidelines and notices can result in severe injury or substantial damage to equipment.
<b>Caution!</b>	Disregarding these safety guidelines and notices can result in injury or damage to equipment.
<b>Information:</b>	This information is important for preventing errors.

Table 4: Description of the safety notices used in this documentation

### 2.2 General information

B&R drive systems and servo motors have been designed, developed and manufactured for conventional use in industrial environments.

They were not designed, developed and manufactured for any use involving serious risks or hazards that could lead to death, injury, serious physical damage or loss of any kind without the implementation of exceptionally stringent safety precautions.

In particular, such risks and hazards include the use of these devices to monitor nuclear reactions in nuclear power plants, their use in flight control or flight safety systems as well as in the control of mass transportation systems, medical life support systems or weapons systems.

#### **Danger!**

**Drive systems and servo motors can have exposed parts with voltages applied (e.g. terminals) or hot surfaces. Additional hazards include moving machine parts. Improperly removing required covers, inappropriate use of the devices or their improper installation or operation can result in severe personal injury or damage to property.**

All tasks such as the transport, installation, commissioning and servicing of devices are only permitted to be carried out by qualified personnel. Qualified personnel are those familiar with the transport, mounting, installation, commissioning and operation of devices who also have the appropriate qualifications (e.g. IEC 60364). National accident prevention regulations must be observed.

The safety notices, connection descriptions (type plate and documentation) and limit values listed in the technical data are to be read carefully before installation and commissioning and must be observed.

#### **Danger!**

**The improper handling of drive systems and servo motors can cause severe personal injury or damage to property!**

### 2.3 Qualified personnel

Use of safety-related products is restricted to the following persons:

- Qualified personnel who are familiar with relevant safety concepts for automation technology as well as applicable standards and regulations
- Qualified personnel who plan, develop, install and commission safety equipment in machines and systems

Qualified personnel in the context of this manual's safety guidelines are those who, because of their training, experience and instruction combined with their knowledge of relevant standards, regulations, accident prevention guidelines and operating conditions, are qualified to carry out essential tasks and recognize and avoid potentially dangerous situations.

In this regard, sufficient language skills are also required in order to be able to properly understand this manual.

## 2.4 Intended use

Servo drives are components designed to be installed in electrical systems or machines. They are not permitted to be used unless the machine meets directive 2006/42/EC (machine directive) as well as directive 2004/108/EC (EMC directive).

Drive systems are only permitted to be operated directly on grounded, three-phase industrial mains (TN, TT power mains). When used in residential areas, shops or small businesses, additional measures must be implemented by the user.

### **Danger!**

**Drive systems are not permitted to be operated directly on IT and TN-S mains with a grounded phase conductor and protective ground conductor!**

Technical data as well as connection and environmental specifications can be found on the type plate and in this user's manual. These specifications regarding connection and environmental conditions must be observed!

### **Danger!**

**Electronic devices are never completely failsafe. If the drive systems fails, the user is responsible for making sure that the motor is placed in a secure state.**

## 2.5 Disclaimer

It is the user's responsibility to clear the use of B&R safety-related components with the respective authorities.

B&R will not assume warranty or liability for damages that occur due to:

- Improper use
- Non-observance of standards and guidelines
- Unauthorized modifications to devices, connections and settings
- Operation of unauthorized or unsuitable devices or device groups
- Failure to follow the safety notices covered in this manual

## 2.6 Protection against electrostatic discharge

Electrical components that can be damaged by electrostatic discharge (ESD) must be handled accordingly.

### 2.6.1 Packaging

Electrical components with a housing do not require any special ESD packaging, but they must still be handled properly (see section 2.6.2 "Guidelines for proper ESD handling" on page 14).

Electrical components without a housing are protected by ESD protective packaging.

### 2.6.2 Guidelines for proper ESD handling

#### Electrical components with a housing

- Do not touch the connector contacts on connected cables.
- Do not touch the contact tips on circuit boards.

#### Electrical components without a housing

The following applies in addition to the points listed under "Electrical components with a housing":

- Any persons handling electrical components or devices with installed electrical components must be grounded.
- Components may only be touched on their narrow sides or front plate.
- Components should always be stored in a suitable medium (ESD packaging, conductive foam, etc.).  
Metallic surfaces are not suitable storage surfaces!
- Components should not be subjected to electrostatic discharge (e.g. through the use of charged plastics).
- Ensure a minimum distance of 10 cm from monitors and TV sets.

- Measurement devices and equipment must be grounded.
- Measurement probes on potential-free measurement devices must be discharged on sufficiently grounded surfaces before taking measurements.

### Individual components

- ESD protective measures for individual components are thoroughly integrated at B&R (conductive floors, footwear, arm bands, etc.).
- These increased ESD protective measures for individual components are not necessary for customers handling B&R products.

## 2.7 Transport and storage

During transport and storage, devices must be protected against undue stress (mechanical loads, temperature, humidity, aggressive atmospheres, etc.).

Drive systems contain components sensitive to electrostatic charges that can be damaged by inappropriate handling. It is therefore necessary to provide the required protective measures against electrostatic discharge when installing or removing these drive systems.

## 2.8 Handling and installation

### Warning!

**B&R drive systems and servo motors can be heavy.**

**During handling and installation of heavy B&R drive systems or servo motors, there is therefore the danger of personal injury or damage to equipment (through shearing, impacts, cutting or crushing). Suitable protective equipment (e.g. safety glasses, protective gloves, safety shoes, etc.) should be used when necessary!**

Installation must be performed according to this documentation using suitable equipment and tools.

Devices may only be installed by qualified personnel without voltage applied. Before installation, voltage to the control cabinet must be switched off and prevented from being switched on again.

General safety guidelines and national accident prevention regulations (e.g. VBG 4) for working with high voltage systems must be observed.

Electrical installation must be carried out according to applicable guidelines (e.g. line cross-section, fuses, protective ground connections, see also 5 "Dimensioning" on page 119).

## 2.9 Operation

### 2.9.1 Protection against touching electrical parts

### Danger!

**To operate drive systems, it is necessary for certain parts to carry dangerous voltage levels over 42 VDC. Touching one of these parts can result in a life-threatening electric shock. This could lead to death, severe injury or damage to equipment.**

Before turning on a drive system, it is important to ensure that the housing is properly connected to ground (PE rail). Ground connections must be established even when testing or operating the drive system for a short time!

Before turning the device on, all parts that carry voltage must be securely covered. During operation, all covers and control cabinet doors must remain closed.

### Danger!

**If an application uses the safety functions integrated in the drive system, then the safety functions must be fully validated before being turned on for the first time. This could lead to death, severe injury or damage to equipment.**

Control and power connections can still carry voltage even if the motor is not turning. Touching these connections when the device is switched on is prohibited.

Before performing any work on drive systems, they must first be disconnected from the power mains and prevented from being switched on again.

## **Danger!**

### **Dangerously high voltage**

**Before performing service work, disconnect the power supply and wait 5 minutes to ensure that the capacitors have discharged. Observe regulations!**

**This delay time of 5 minutes begins as soon as all of the synchronous motors connected to the drive system that has been disconnected from the supply have come to a standstill. If the synchronous motors are not stationary when the drive system is disconnected from the supply, then the delay time must be extended accordingly.**

The ACOPOSmulti modules are labeled with the following warning:




Figure 1: Warning sticker on the ACOPOSmulti module

The connections for drive system signal voltages ranging from 5 to 30 V are safely isolated circuits. The signal voltage connections and interfaces are therefore only permitted to be connected to devices or electrical components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1 and that correspond to SELV / PELV or a class DVC A safety extra low voltage in accordance with EN 61800-5-1.

Never remove the electrical connections from the drive system with voltage applied. In some cases, electric arcs may occur that can cause personal injury and/or damage to contacts.

## **2.9.2 Protection against hazardous movements**

## **Danger!**

**Improper control of motors can result in unintended hazardous movements! Such incorrect behavior can have various causes:**

- **Incorrect installation or a mistake when handling components**
- **Improper or incomplete wiring**
- **Defective devices (drive system, motor, position encoder, cables, brake)**
- **Incorrect control (e.g. caused by software error)**

Some of the errors listed above can be detected and prevented by the drive system's internal monitoring. Nevertheless, it is still possible for the motor shaft to move any time the device is switched on! For this reason, higher-level safety precautions need to be put in place to ensure that personnel and machines are protected.

The moving parts on machines must be shielded in such a way as to prevent unintentional access by personnel. This type of protection can be achieved by using stable mechanical protective equipment such as protective covers, protective fences, protective gates or light barriers.

Removing, bypassing or circumventing these protective measures and entering the area where movement takes place is prohibited.

A sufficient number of emergency stop switches must be installed in direct proximity to the machine and be easily accessible at all times. This emergency stop equipment must be checked before the machine is commissioned.

On free running motors, the shaft key (if present) must be removed or measures taken to prevent its ejection. The holding brake built into motors cannot prevent hoisting equipment from dropping hanging loads.

## 2.10 Functional safety data and specifications

Data and specifications for individual safety functions are listed in the section "3 "Safety-related characteristic values of integrated safety functions" on page 149".

The specifications are calculated based on a proof test interval of maximum 20 years. A proof test cannot be carried out for B&R drive systems, so the proof test interval is the mission time of the system.

According to the standards EN ISO 13849, EN 62061 and IEC 61508, the safety functions described in section 4 "Safety technology" on page 138 cannot be used beyond the specified mission time.

### **Danger!**

**Operating ACOPOSmulti SafeMC modules beyond the specified mission time is not permitted!**

**The user must ensure that all ACOPOSmulti SafeMC modules are removed from operation i.e. replaced by new ACOPOSmulti SafeMC modules, before their mission time expires.**

## 3 Environmentally friendly disposal

All B&R drive systems and servo motors are designed to inflict as little harm as possible on the environment.

### 3.1 Separation of materials

It is necessary to separate different materials so the device can undergo an environmentally friendly recycling process.

Component	Disposal
Drive systems, servo motors, cables	Electronic recycling
Cardboard box / paper packaging	Paper/cardboard recycling

Table 5: Environmentally friendly separation of materials

Disposal must comply with applicable legal regulations.

## Chapter 2 • ACOPOSmulti SafeMC

### 1 Configuration of an ACOPOSmulti drive system

The ACOPOSmulti drive system consists of a mounting plate, different modules (power supply, auxiliary supply and inverter, expansion and capacitor modules), plug-in modules as well as a line filter and - only in combination with 8BVP active power supply modules - a regeneration choke.

The ACOPOSmulti drive system is configured in 10 steps:

1. Determine the cooling method.
2. Define or verify the supply voltage range and mains type.
3. Select the ACOPOSmulti inverter modules according to the application requirements.
4. Select the ACOPOSmulti plug-in modules for the motor encoder and external axis encoder according to the application requirements.
5. If the ACOPOSmulti drive system should be expandable:  
Determine the number of optional slots on the mounting plate for other ACOPOSmulti modules
6. Select ACOPOSmulti power supply modules according to the application requirements (active/passive power supply module) based on the total power of the ACOPOSmulti inverter modules needed (derating information must be taken into consideration if the supply voltage < 3x 400 VAC)
7. Check the maximum chargeable DC bus capacitance.
8. Select the ACOPOSmulti auxiliary supply module based on the total power required for the 24 VDC supply of the selected ACOPOSmulti module, ACOPOSmulti plug-in modules as well as the peripheral supply (e.g. PLC, actuators, motor holding brakes, sensors)

#### **Danger!**

**ACOPOSmulti auxiliary supply modules 8B0C0320Hx00.00A-1 may not be used in combination with ACOPOSmulti inverter modules with SafeMC!**

9. Determine the total number of slots by adding the width units of all selected ACOPOSmulti modules (including optional slots).
10. Select the ACOPOSmulti mounting plate according to the total number of slots required and specified cooling method.

## 2 Status indicators

Status indicators are located on the black cover of each module.

### 2.1 8BVI inverter modules with SafeMC

#### 2.1.1 Single-axis modules




Figure 2: Indicator groups for 8BVI inverter modules with SafeMC (single-axis modules)

##### 2.1.1.1 LED Status indicators

Indicator group	Labeling	Color	Function	Description
POWERLINK	R/E	Green/red	Ready/Error	see "POWERLINK - LED status indicators" on page 21
	L/D1	Green	Link/Data activity on Port 1	
	L/D2		Link/Data activity on Port 2	
Inverter axis 1	RDY	Green	Ready	see "RDY, RUN, ERR (8BVI, 8BVP, 8B0P) - LED status indicators" on page 21
	RUN	Orange	Run	
	ERR	Red	Error	
Status of backup battery	BAT	Green/red	Ready/Error	see "LED Status indicators - Backup battery" on page 21
Supply voltage	24V	Green	24 V OK	The 24V module supply voltage is within the tolerance range.
Encoder SLOT1	UP	Orange	Encoder direction of rotation +	The encoder position of the connected encoder changed in the positive direction. The faster the encoder position changes, the brighter the LED is lit.
	DN		Encoder direction of rotation -	
Encoder SLOT2	UP	Orange	Encoder direction of rotation +	see Encoder SLOT1
	DN		Encoder direction of rotation -	
Status of SafeMC module axis 1	R/E	Green/red	Ready/Error	see "SafeMC module - LED status indicators" on page 22
Safety status of SafeMC module 1	SE	Red	Safe/Error	

Table 6: LED Status indicators - 8BVI inverter modules with SafeMC (single-axis modules)

## 2.1.2 Dual-axis modules




Figure 3: Indicator groups for 8BVI inverter modules with SafeMC (two-axis modules)

### 2.1.2.1 LED Status indicators

Indicator group	Labeling	Color	Function	Description
POWERLINK	R/E	Green/red	Ready/Error	see "POWERLINK - LED status indicators" on page 21
	L/D1	Green	Link/Data activity on Port 1	
	L/D2		Link/Data activity on Port 2	
Inverter axis 1	RDY	Green	Ready	see "RDY, RUN, ERR (8BVI, 8BVP, 8B0P) - LED status indicators" on page 21
	RUN	Orange	Run	
	ERR	Red	Error	
Inverter axis 2	RDY	Green	Ready	See inverter axis 1
	RUN	Orange	Run	
	ERR	Red	Error	
Status of backup battery	BAT	Green/red	Ready/Error	see "LED Status indicators - Backup battery" on page 21
Supply voltage	24V	Green	24 V OK	The 24V module supply voltage is within the tolerance range.
Encoder SLOT1	UP	Orange	Encoder direction of rotation +	The encoder position of the connected encoder changed in the positive direction. The faster the encoder position changes, the brighter the LED is lit.
	DN		Encoder direction of rotation -	
Encoder SLOT2	UP	Orange	Encoder direction of rotation +	see Encoder SLOT1
	DN		Encoder direction of rotation -	
Status of SafeMC module axis 1	R/E	Green/red	Ready/Error	see "SafeMC module - LED status indicators" on page 22
Safety status of SafeMC module 1	SE	Red	Safe/Error	
Status of SafeMC module axis 2	R/E	Green/red	Ready/Error	
Safety status of SafeMC module 2	SE	Red	Safe/Error	

Table 7: LED Status indicators - 8BVI inverter modules with SafeMC (two-axis modules)



### 2.1.3 RDY, RUN, ERR (8BVI, 8BVP, 8B0P) - LED status indicators

Labeling	Color	Function	Description	
RDY	Green	Ready	Green (lit)	The module is operational and the power stage can be enabled (operating system present and booted, no permanent or temporary errors).
			Green (blinking) <sup>1)</sup>	The module is not ready for operation. <b>Examples:</b> <ul style="list-style-type: none"> <li>No signal on one or both enable inputs</li> <li>DC bus voltage outside the tolerance range</li> <li>Overtemperature on the motor (temperature sensor)</li> <li>Motor feedback not connected or defective</li> <li>Motor temperature sensor not connected or defective</li> <li>Overtemperature on the module (IGBT junction, heat sink, etc.)</li> <li>Disturbance on network</li> </ul>
RUN	Orange	Run	Orange (lit)	The module's power stage is enabled.
ERR	Red	Error	Red (lit) <sup>1)</sup>	There is a permanent error on the module. <b>Examples:</b> <ul style="list-style-type: none"> <li>Permanent overcurrent</li> <li>Invalid data in EPROM</li> </ul>

Table 8: RDY, RUN, ERR (8BVI, 8BVP, 8B0P) - LED status indicators

<sup>1)</sup> Firmware V2.130 and higher

### 2.1.4 POWERLINK - LED status indicators

Labeling	Color	Function	Description	
R/E	Green/Red	Ready/Error	LED not lit	The module is not receiving power or initialization of the network interface has failed.
			Red (lit)	The POWERLINK station number of the module is 0.
			Red/green, blinking	The client is in an error state (drops out of cyclic operation).
			Green (blinking) (single)	The client detects a valid POWERLINK frame on the network.
			Green (blinking) (2x)	Cyclic operation on the network is taking place, but the client itself is not yet a participant.
			Green (blinking) (3x)	Cyclic operation of the client is in preparation.
			Green (lit)	The client is participating in cyclic operation.
			Green (flickering)	The client is not participating in cyclic operation and also does not detect any other stations on the network participating in cyclic operation.
L/D1	Green	Link/data Port 1 activity -	Green (lit)	A physical connection has been established to another station on the network.
			Green (blinking)	Activity on port 1
L/D2	Green	Link/data Port 2 activity -	Green (lit)	A physical connection has been established to another station on the network.
			Green (blinking)	Activity on port 2

Table 9: POWERLINK - LED status indicators

### 2.1.5 LED Status indicators - Backup battery

Labeling	Color	Function	Description	
BAT	Green/red	Ready/Error	LED not lit	<b>Possible causes:</b> <ul style="list-style-type: none"> <li>The voltage of the installed backup battery is within the tolerance range, but an EnDat encoder with backup battery is not connected</li> <li>An EnDat encoder with backup battery is connected and registering "Battery ok", but the module's firmware version does not support EnDat encoders with battery backup.</li> </ul>
			Green (lit)	An EnDat encoder with battery backup is connected and registering "Battery ok" (voltage of the installed backup battery is within the tolerance range).
			Red (lit)	An EnDat encoder with battery backup is connected and registering "Battery not ok". <b>Possible causes:</b> <ul style="list-style-type: none"> <li>Voltage of the installed backup battery outside of tolerance range</li> <li>No backup battery installed in module</li> </ul>

Table 10: LED Status indicators - Backup battery

## 2.1.6 SafeMC module - LED status indicators

Opening the front cover of an ACOPOSmulti with SafeMC reveals 3 additional LEDs for each safe axis:




Figure 4: Single-axis modules




Figure 5: Dual-axis modules


LED	Color		Description
R/E	Green	Red	
	Off	Off	Module not supplied with current, no communication
	Single flash		Unlink mode
	Double flash		Updating firmware
	Blinking		PREOPERATIONAL mode
	On		RUN mode
	On	Single flash, inverse	Safety-related firmware invalid
		Triple flash, inverse	Update of safety-related firmware
LED status indicators Pulse disabling output, high-side	Off	On	Communication error
	Off	On	Error
	Red		Warning / error on the channel During the start-up phase, the channel LEDs are always lit constantly red
LED status indicators Pulse disabling output, low-side	Orange		24 V on the output
	Off		0 V on the output
	Off		0 V on the output
LED status indicators Motor holding brake output	Red		Warning / error on the channel During the start-up phase, the channel LEDs are always lit constantly red
	Orange		24 V on the output
	Off		0 V on the output
SE	Red	Off	RUN mode
			
		On	Non-acknowledgeable error state, Fail Safe status
The two "SE" indicators are two separate LEDs that show the states of safety processor 1 and safety processor 2. However, this is only distinguishable when the front cover is open.			

Table 11: SafeMC module - LED status indicators

### Danger!

Constantly lit LEDs "SE" indicate a fail safe state that cannot be acknowledged. The cause of this could be a defective module or faulty configuration.

Check the entries in the logbook! If you are able to rule out a faulty configuration, then the module is defective and must be replaced immediately.

It is the user's responsibility to ensure that all necessary repair measures or corrections in the configuration are initiated after an error occurs since subsequent errors can result in dangerous situations!

### 2.1.7 Status changes when booting the operating system loader

The following timing is used for the LED status indicators:

Block size: 50 ms

Repeats after: 3,000 ms

Status	LED	Indicator
1. Boot procedure for base hardware active	RDY	
	RUN	
	ERR	
2. Network configuration active	RDY	
	RUN	
	ERR	
3. Waiting for network telegram	RDY	
	RUN	
	ERR	
4. Network communication active	RDY	
	RUN	
	ERR	
5. Transferring/Burning the ACOPOS operating system <sup>1)</sup>	RDY	
	RUN	
	ERR	

Table 12: Status changes when booting the operating system loader

1) Firmware V2.140 and higher.

### 2.1.8 Setting the POWERLINK station number

The POWERLINK station number can be set using two HEX code switches that are located behind the black cover of the module:


Figure	Switch	POWERLINK station number
Cover closed		
Cover open		
	1	Position 16
	2	Position 1
The POWERLINK station number change takes effect the next time the ACOPOSmulti drive system is switched on.		
<b>Information:</b> Station numbers in the range from 0x01 to 0xFD are allowed. <i>Recommendation:</i> For compatibility reasons, avoid station numbers between 0xF0 and 0xFD, because they are intended for future system expansions. Station numbers 0x00, 0xFE and 0xFF are reserved and are therefore not allowed to be set.		

Table 13: Setting the POWERLINK station number

## 3 Data sheets

### 3.1 Module overview

#### Safe single-width inverter modules (single-axis modules)

Product ID	Short description	on page
8BVI0014HCSS.000-1	ACOPOSmulti inverter module 1.9 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	25
8BVI0014HWSS.000-1	ACOPOSmulti inverter module, 1.9 A, HV, wall mounting, SafeMC EnDat 2.2	25
8BVI0028HCSS.000-1	ACOPOSmulti inverter module 3.8 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	29
8BVI0028HWSS.000-1	ACOPOSmulti inverter unit, 3.8 A, HV, wall mounting, SafeMC EnDat 2.2	29
8BVI0055HCSS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, cold plate or feed through mounting, SafeMC EnDat 2.2	34
8BVI0055HWSS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, wall mounting, SafeMC EnDat 2.2	34
8BVI0110HCSS.000-1	ACOPOSmulti inverter module 15.1 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	38
8BVI0110HWSS.000-1	ACOPOSmulti inverter module, 15.1 A, HV, wall mounting, SafeMC EnDat 2.2	38

#### Safe double-width inverter modules (single-axis modules)

Product ID	Short description	on page
8BVI0220HCSS.000-1	ACOPOSmulti inverter module 22 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	46
8BVI0220HWSS.000-1	ACOPOSmulti inverter module, 22 A, HV, wall mounting, SafeMC EnDat 2.2	46
8BVI0330HCSS.000-1	ACOPOSmulti inverter module 33 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	50
8BVI0330HWSS.000-1	ACOPOSmulti inverter module, 33 A, HV, wall mounting, SafeMC EnDat 2.2	50
8BVI0440HCSS.000-1	ACOPOSmulti inverter module 44 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	55
8BVI0440HWSS.000-1	ACOPOSmulti inverter module, 44 A, HV, wall mounting, SafeMC EnDat 2.2	55

#### Safe 4x width inverter modules (single-axis modules)

Product ID	Short description	on page
8BVI0660HCSS.000-1	ACOPOSmulti inverter module 66 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	95
8BVI0660HWSS.000-1	ACOPOSmulti inverter module, 66 A, HV, wall mounting, SafeMC EnDat 2.2	95
8BVI0880HCSS.004-1	ACOPOSmulti inverter module 88 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	99
8BVI0880HWSS.004-1	ACOPOSmulti inverter module, 88 A, HV, wall mounting, SafeMC EnDat 2.2	99

#### Safe 8x width inverter modules (single-axis modules)

Product ID	Short description	on page
8BVI1650HCSS.000-1	ACOPOSmulti inverter module 165 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	109

#### Safe single-width inverter modules (dual-axis modules)

Product ID	Short description	on page
8BVI0014HCDS.000-1	ACOPOSmulti inverter module, 1.9 A, HV, cold plate or feed-through mounting, 2 axes, SafeMC	63
8BVI0014HWDS.000-1	ACOPOSmulti inverter module, 1.9 A, HV, wall mounting, 2 axes, SafeMC	63
8BVI0028HCDS.000-1	ACOPOSmulti inverter module, 3.8 A, HV, cold plate or feed-through mounting, 2 axes, SafeMC	67
8BVI0028HWDS.000-1	ACOPOSmulti inverter unit, 3.8 A, HV, wall mounting, 2 axes, SafeMC	67
8BVI0055HCDS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, cold plate or feed through mounting, 2 axes, SafeMC	71
8BVI0055HWDS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, wall mounting, 2 axes, SafeMC	71

#### Safe double-width inverter modules (dual-axis modules)

Product ID	Short description	on page
8BVI0110HCDS.000-1	ACOPOSmulti inverter unit, 15.1 A, HV, cold plate or feed through mounting, 2 axes, SafeMC	81
8BVI0110HWDS.000-1	ACOPOSmulti inverter module, 15.1 A, HV, wall mounting, 2 axes, SafeMC	81
8BVI0220HCDS.000-1	ACOPOSmulti inverter module, 22 A, HV, cold plate or feed-through mounting, 2 axes, SafeMC	85
8BVI0220HWDS.000-1	ACOPOSmulti inverter module, 22 A, HV, wall mounting, 2 axes, SafeMC	85

## 3.2 Safe single-width inverter modules (single-axis modules)

### 3.2.1 8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1

#### 3.2.1.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

#### 3.2.1.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0014HCSS.000-1	ACOPOSMulti inverter module 1.9 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0014HWSS.000-1	ACOPOSMulti inverter module, 1.9 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0055SS.000-1A	Screw clamp set for ACOPOSMulti 8BVI00xxHxSS and 8BVI00xxHxSA modules: 1x 8TB3104.204G-11, 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSMulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSMulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	

Table 14: 8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.2.1.3 Technical data**

Product ID	8BVI0014HCSS.000-1	8BVI0014HWSS.000-1
General information		
B&R ID code	0xAA0C	0xAA0E
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	1.46 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.6*I <sub>M</sub> <sup>2</sup> +1.3*I <sub>M</sub> +60] W	
Switching frequency 10 kHz	[0.97*I <sub>M</sub> <sup>2</sup> +0.5*I <sub>M</sub> +110] W	
Switching frequency 20 kHz	[1.7*I <sub>M</sub> <sup>2</sup> -0.7*I <sub>M</sub> +225] W	
DC bus capacitance	165 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	18 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + P <sub>Fan8BOM...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	1	
Continuous power per motor connection <sup>2)</sup>	1.4 kW	
Continuous current per motor connection <sup>2)</sup>	1.9 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>22)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	No reduction
Switching frequency 20 kHz	-	0.11 A/K (from 33°C) <sup>23)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	No reduction <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	No reduction	-
Feed-through mounting	No reduction	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.13 A/K (from 46°C)	-
Feed-through mounting	0.1 A/K (from 41°C)	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	0.19 A <sub>eff</sub> per 1000 m	
Peak current	4.7 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>9)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>10)</sup>	Limit value curve A	

Table 15: 8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1 - Technical data

Product ID	8BVI0014HCSS.000-1	8BVI0014HWSS.000-1
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>11)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.25 to 4 mm²	
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>12)</sup>	24 VDC +5.8% / -0% <sup>13)</sup>	
Continuous current	1.1 A	
Max. internal resistance	0.5 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	1.5 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.25 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>14)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>15)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>16)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>17)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.14 μF	

Table 15: 8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1 - Technical data

Product ID	8BVI0014HCSS.000-1		8BVI0014HWSS.000-1
Operating conditions			
Permitted mounting orientations			
Hanging vertically	Yes		
Lying horizontally	Yes		
Standing horizontally	No		
Installation at elevations above sea level			
Nominal	0 to 500 m		
Maximum <sup>18)</sup>	4000 m		
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)		
Overvoltage category in accordance with IEC 60364-4-443:1999	III		
EN 60529 protection	IP20 <sup>19)</sup>		
Environmental conditions			
Temperature			
Operation			
Nominal	5 to 40°C		
Maximum <sup>20)</sup>	55°C		
Storage	-25 to 55°C		
Transport	-25 to 70°C		
Relative humidity			
Operation	5 to 85%		
Storage	5 to 95%		
Transport	Max. 95% at 40°C		
Mechanical characteristics			
Dimensions <sup>21)</sup>			
Width	53 mm		
Height	317 mm		
Depth			
Wall mounting	-	263 mm	
Cold plate	212 mm	-	
Feed-through mounting	209 mm	-	
Weight	Approx. 2.1 kg		Approx. 2.6 kg
Module width	1		

Table 15: 8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1 - Technical data

- SLOT 2 is not occupied. SLOT 1 of the ACOPOSMulti module is occupied by the SafeMC module.
- Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- $I_M$  ... Current on the motor connection [A].
- $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- B&R 8BCM motor cables must be used when cabling the motor connections.
- Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- The temperature specifications refer to the return temperature of the cold plate mounting plate.
- Value for the nominal switching frequency.
- B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- An EnDat 2.2 functional safety encoder is required when using ACOPOSMulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):  

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$
 $I_G$  ... Max. current consumption of the encoder [A]  
 $A$  ... Cross section of the supply wire [mm<sup>2</sup>]  
 $\rho$  ... Specific resistance [Ωmm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )
- $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].
- Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!



- 20) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 21) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 22) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.
- 23) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.

### 3.2.1.4 Wiring

For details, see section 3.2.5 "Wiring: Safe single-width inverter modules (single-axis modules)" on page 43

For general information, please see section 6 "Wiring" on page 120

### 3.2.2 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1

#### 3.2.2.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

#### 3.2.2.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0028HCSS.000-1	ACOPOSmulti inverter module 3.8 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0028HWSS.000-1	ACOPOSmulti inverter unit, 3.8 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0055SS.000-1A	Screw clamp set for ACOPOSmulti 8BVI00xxHxSS and 8BVI00xxHxSA modules: 1x 8TB3104.204G-11, 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSmulti fan module, replacement fan for ACOPOSmulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSmulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSmulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSmulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSmulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSmulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSmulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSmulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSmulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSmulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSmulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSmulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSmulti input module, 4 analog inputs ±10 V	
8BAC0133.000-1	ACOPOSmulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	

Table 16: 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Order data

Model number	Short description	Figure
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	

Table 16: 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.2.2.3 Technical data**

Product ID	8BVI0028HCSS.000-1	8BVI0028HWSS.000-1
<b>General information</b>		
B&R ID code	0xAA10	0xAA12
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	2 <sup>24)</sup>
Certification		
CE		Yes
cULus		Yes
KC		Yes
FSC		Yes
<b>DC bus connection</b>		
Voltage		
Nominal		750 VDC
Continuous power consumption <sup>2)</sup>		2.87 kW
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz		$[0.6 \cdot I_M^2 + 1.3 \cdot I_M + 60] \text{ W}$
Switching frequency 10 kHz		$[0.97 \cdot I_M^2 + 0.5 \cdot I_M + 110] \text{ W}$
Switching frequency 20 kHz		$[1.7 \cdot I_M^2 - 0.7 \cdot I_M + 225] \text{ W}$
DC bus capacitance		165 µF
Design		ACOPOSMulti backplane
<b>24 VDC supply</b>		
Input voltage		25 VDC ±1.6%
Input capacitance		23.5 µF
Max. power consumption	$18 \text{ W} + P_{SMC1} + P_{SLOT2} + P_{24V Out} + P_{HoldingBrake} + P_{Fan8B0M...}^{4)}$	$18 \text{ W} + P_{SMC1} + P_{SLOT2} + P_{24V Out} + P_{HoldingBrake} + P_{Fan8B0M...}^{25)}$
Design		ACOPOSMulti backplane
<b>24 VDC output</b>		
Quantity		2
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC		25 VDC * (U <sub>DC</sub> /315)
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC		24 VDC ±6%
Fuse protection		250 mA (slow-blow) electronic, automatic reset
<b>Motor connection <sup>5)</sup></b>		
Quantity		1
Continuous power per motor connection <sup>2)</sup>		2.8 kW
Continuous current per motor connection <sup>2)</sup>		3.8 A <sub>eff</sub>
Reduction of continuous current depending on the switching frequency <sup>26)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	No reduction
Switching frequency 20 kHz	-	0.12 A/K (from 33 °C) <sup>10)</sup>

Table 17: 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Technical data

Product ID	8BVI0028HCSS.000-1	8BVI0028HWSS.000-1
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	No reduction <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.6 A/K (from 58°C)	-
Feed-through mounting	No reduction	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.1 A/K (from 34°C) <sup>9)</sup>	-
Feed-through mounting	0.09 A/K (from 18°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	0.38 A <sub>eff</sub> per 1000 m	
Peak current	9.5 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	600 Hz <sup>27)</sup>
Design		
U, V, W, PE	Connector	Plug
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines	0.25 to 4 mm²	
With wire end sleeves		
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	24 VDC +5.8% / -0% <sup>28)</sup>
Continuous current	1.1 A	
Max. internal resistance	0.5 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	1.5 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.25 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>17)</sup>	EnDat 2.2 <sup>29)</sup>
Connections	9-pin DSUB connector	9-pin DSUB socket
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m Depends on the cross section of the encoder's supply wires <sup>18)</sup>	100 m Depending on the cross section of the supply wires on the encoder cable <sup>18)</sup>
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	

Table 17: 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Technical data

Product ID	8BVI0028HCSS.000-1		8BVI0028HWSS.000-1	
Trigger inputs				
Quantity	2			
Wiring	Sink			
Electrical isolation				
Input - Inverter module	Yes			
Input - Input	Yes			
Input voltage				
Nominal	24 VDC			
Maximum	30 VDC			
Switching threshold				
Low	<5 V			
High	>15 V			
Input current at nominal voltage	Approx. 10 mA			
Switching delay				
Positive edge	52 μs ± 0.5 μs (digitally filtered)			
Negative edge	53 μs ± 0.5 μs (digitally filtered)			
Modulation compared to ground potential	Max. ±38 V			
Electrical characteristics				
Discharge capacitance	0.14 μF			
Operating conditions				
Permitted mounting orientations				
Hanging vertically	Yes			
Lying horizontally	Yes			
Standing horizontally	No			
Installation at elevations above sea level				
Nominal	0 to 500 m			
Maximum <sup>20)</sup>	4000 m			
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)			
Overvoltage category in accordance with IEC 60364-4-443:1999	III			
EN 60529 protection	IP20 <sup>21)</sup>			
Environmental conditions				
Temperature				
Operation				
Nominal	5 to 40°C			
Maximum <sup>22)</sup>	55°C			
Storage	-25 to 55°C			
Transport	-25 to 70°C			
Relative humidity				
Operation	5 to 85%			
Storage	5 to 95%			
Transport	Max. 95% at 40°C			
Mechanical characteristics				
Dimensions <sup>23)</sup>				
Width	53 mm			
Height	317 mm			
Depth				
Wall mounting	-		263 mm	
Cold plate	212 mm		-	
Feed-through mounting	209 mm		-	
Weight	Approx. 2.1 kg		Approx. 2.6 kg	
Module width	1			

Table 17: 8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSmulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{8BAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24 V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.

- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:
  - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.
  - If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 18) The maximum encoder cable length  $l_{\max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{\max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{\text{Encoder}}$  ... Max. power consumption of the connected encoder [A].
- 20) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 21) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!
- 22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 23) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 24) SLOT 1 of the ACOPOSmulti module is occupied by the encoder interface.
- 25)  $P_{\text{SMC1}}$  ... Max. power consumption  $P_{\text{SMC}}$  [W] of the SafeMC module in SLOT1 (see the section "Encoder interfaces")  
 $P_{\text{SLOT2}}$  ... Max. power consumption  $P_{\text{BBAC}}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24 \text{ V Out}}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{\text{Fan8B0M...}}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module)
- 26) Valid in the following conditions: DC bus voltage 750 VDC The temperature specifications are based on the ambient temperature.
- 27) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual-use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current motion is aborted and error 6060 is output (Power element: Limit speed exceeded).
- 28) The specified values is only valid under the following conditions:
  - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.
  - If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be deactivated.
- 29) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the timing of the functions STO, SBC and SS1 is monitored!

### 3.2.2.4 Wiring

For details, see section 3.2.5 "Wiring: Safe single-width inverter modules (single-axis modules)" on page 43

For general information, please see section 6 "Wiring" on page 120

## 3.2.3 8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1

### 3.2.3.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

## 3.2.3.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0055HCSS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, cold plate or feed through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0055HWSS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0055SS.000-1A	Screw clamp set for ACOPOSmulti 8BVI00xxHxSS and 8BVI00xxHxSA modules: 1x 8TB3104.204G-11, 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSmulti fan module, replacement fan for ACOPOSmulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSmulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSmulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSmulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSmulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSmulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSmulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSmulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSmulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSmulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSmulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSmulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSmulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSmulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSmulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSmulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSmulti shield component set: 1x ACOPOSmulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	

Table 18: 8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

## 3.2.3.3 Technical data

Product ID	8BVI0055HCSS.000-1	8BVI0055HWSS.000-1
General information		
B&R ID code	0xAA14	0xAA16
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	5.6 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.6*I <sub>M</sub> <sup>2</sup> +1.3*I <sub>M</sub> +60] W	
Switching frequency 10 kHz	[0.97*I <sub>M</sub> <sup>2</sup> +0.5*I <sub>M</sub> +110] W	
Switching frequency 20 kHz	[1.7*I <sub>M</sub> <sup>2</sup> -0.7*I <sub>M</sub> +225] W	
DC bus capacitance	165 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	18 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + P <sub>Fan8BOM...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	1	
Continuous power per motor connection <sup>2)</sup>	5.5 kW	
Continuous current per motor connection <sup>2)</sup>	7.6 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>24)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	0.2 A/K (from 49 °C)
Switching frequency 20 kHz	-	0.13 A/K (from 4 °C) <sup>9)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.65 A/K (from 57 °C) <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.28 A/K (from 46 °C)	-
Feed-through mounting	0.15 A/K (from 34 °C) <sup>9)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.14 A/K (from 5 °C) <sup>10)</sup>	-
Feed-through mounting	0.08 A/K (from -33 °C) <sup>9)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	0.76 A <sub>eff</sub> per 1000 m	
Peak current	18.9 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	Plug	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines	0.25 to 4 mm²	
With wire end sleeves		
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	

Table 19: 8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1 - Technical data

Product ID	8BVI0055HCSS.000-1	8BVI0055HWSS.000-1
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	
Continuous current	1.1 A	
Max. internal resistance	0.5 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	1.5 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.25 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>17)</sup>	
Connections	9-pin DSUB socket	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depending on the cross section of the supply wires on the encoder cable <sup>18)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.14 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>21)</sup>	

Table 19: 8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1 - Technical data



Product ID	8BVI0055HCSS.000-1	8BVI0055HWSS.000-1
<b>Environmental conditions</b>		
Temperature		
Operation		
Nominal		5 to 40°C
Maximum <sup>22)</sup>		55°C
Storage		-25 to 55°C
Transport		-25 to 70°C
Relative humidity		
Operation		5 to 85%
Storage		5 to 95%
Transport		Max. 95% at 40°C
<b>Mechanical characteristics</b>		
Dimensions <sup>23)</sup>		
Width		53 mm
Height		317 mm
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 2.2 kg	Approx. 2.7 kg
Module width		1

Table 19: 8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1 - Technical data

- 1) SLOT 1 of the ACOPOSmulti module is occupied by the encoder interface.
- 2) Valid in the following conditions: Bus voltage 750 VDC, switching frequency 5 kHz, 40°C ambient temperature, installation altitudes <500 m above sea level, no derating dependent on cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the section "Encoder interfaces")  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24 V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module)
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications are based on the return temperature of the cold-plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 11) B&R recommends operating the module at nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual-use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current motion is aborted and error 6060 is output (Power element: Limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be deactivated.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the timing of the functions STO, SBC and SS1 is monitored!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9/I_G \cdot A \cdot 1/(2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm²]

$\rho$  ... Specific resistance [ $\Omega$ mm²/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{encoder}$  ... Max. power consumption of the connected encoder [A].

- 20) Continuous operation at altitudes ranging from 500 m to 4,000 m above sea level is possible (taking the continuous current reductions listed into consideration).
- 21) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!
- 22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the continuous current reductions listed into consideration), but results in a shorter lifespan.
- 23) The dimensions define the true device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 24) Valid in the following conditions: DC bus voltage 750 VDC The temperature specifications are based on the ambient temperature.

### 3.2.3.4 Wiring

For details, see section 3.2.5 "Wiring: Safe single-width inverter modules (single-axis modules)" on page 43

For general information, please see section 6 "Wiring" on page 120

## 3.2.4 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1

### 3.2.4.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

### 3.2.4.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0110HCSS.000-1	ACOPOSMulti inverter module 15.1 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0110HWSS.000-1	ACOPOSMulti inverter module, 15.1 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0110SS.000-1A	Screw clamp set for ACOPOSMulti 8BVI0110HxSS and 8BVI0110HxSA modules: 1x 8TB3104.204G-11, 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSMulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSMulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	

Table 20: 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Order data

Model number	Short description	Figure
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	

Table 20: 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.2.4.3 Technical data**

Product ID	8BVI0110HCSS.000-1	8BVI0110HWSS.000-1
General information		
B&R ID code	0xAA18	0xAA1A
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	11.2 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.16*I <sub>M</sub> <sup>2</sup> +5.6*I <sub>M</sub> +55] W	
Switching frequency 10 kHz	[0.49*I <sub>M</sub> <sup>2</sup> +4.7*I <sub>M</sub> +95] W	
Switching frequency 20 kHz	[0.87*I <sub>M</sub> <sup>2</sup> +10*I <sub>M</sub> +200] W	
DC bus capacitance	330 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	18 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	1	
Continuous power per motor connection <sup>2)</sup>	11 kW	
Continuous current per motor connection <sup>2)</sup>	15.1 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>24)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	0.26 A/K (from 33°C) <sup>25)</sup>
Switching frequency 20 kHz	-	0.15 A/K (from -28°C) <sup>25)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.73 A/K (from 55°C) <sup>8)</sup>	-
Feed-through mounting	0.29 A/K (from 49°C) <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.32 A/K (from 35°C) <sup>9)</sup>	-
Feed-through mounting	0.17 A/K (from 11°C) <sup>10)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.18 A/K (from -13°C) <sup>9)</sup>	-
Feed-through mounting	0.11 A/K (from -73°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	1.51 A <sub>eff</sub> per 1000 m	

Table 21: 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Technical data

Product ID	8BVI0110HCSS.000-1	8BVI0110HWSS.000-1
Peak current	37.7 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.25 to 4 mm²	
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	
Continuous current	2.1 A	
Max. internal resistance	0.3 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>17)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>18)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	

Table 21: 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Technical data

Product ID	8BVI0110HCSS.000-1	8BVI0110HWSS.000-1
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.14 µF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>21)</sup>	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>22)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>23)</sup>		
Width	53 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 2.4 kg	Approx. 2.9 kg
Module width	1	

Table 21: 8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSmulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot p)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].
- 20) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 21) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!
- 22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 23) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 24) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.
- 25) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.

### 3.2.4.4 Wiring

For details, see section 3.2.5 "Wiring: Safe single-width inverter modules (single-axis modules)" on page 43

For general information, please see section 6 "Wiring" on page 120

3.2.5 Wiring: Safe single-width inverter modules (single-axis modules)

3.2.5.1 Pinout overview




Figure 6: Overview of pin assignments

3.2.5.2 X2 connector - Pinout

X2		Pin	Name	Function
	1	1	Trigger 1	Trigger 1
	2	2	COM (1)	Trigger 1 0 V
	3	3	COM (2)	+24 V output 1 0 V
	4	4	+24V Out 1	+24 V output 1
	5	5	Trigger 2	Trigger 2
	6	6	COM (5)	Trigger 2 0 V
	7	7	COM (8)	+24 V output 2 0 V
	8	8	+24V Out 2	+24 V output 2

Table 22: X2 connector - Pinout

## 3.2.5.3 X3A, X3B connectors - Pinout


X3A, X3B	Pin	Name	Function
	1	RXD	Receive signal
	2	RXD\	Receive signal inverted
	3	TXD	Transmit signal
	4	Shield	Shield
	5	Shield	Shield
	6	TXD\	Transmit signal inverted
	7	Shield	Shield
	8	Shield	Shield

Table 23: X3A, X3B connectors - Pinout

## 3.2.5.4 X4A connector - Pinout


X4A	Name	Function
	T-	Axis 1: Temperature sensor -
	T+	Axis 1: Temperature sensor +
	B- <sup>1)</sup>	Axis 1: Brake -
	B+ <sup>1)</sup>	Axis 1: Brake +

Table 24: X4A connector - Pinout

1) Wiring is not permitted to exceed a total length of 3 m.

**Danger!**

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

**Danger!**

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

**Danger!**

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

**Information:**

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!

**Danger!**

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.



## Caution!

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSmulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## Warning!

Temperature sensors are only permitted to be connected to the X4A/T+ and X4A/T- connectors on an ACOPOSmulti module under the following conditions:

- There is no ACOPOSmulti plug-in module in SLOT1 on the ACOPOSmulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSmulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSmulti module to be destroyed!

### 3.2.5.5 X5A connector - Pinout




X5A		Name	Function
		⊕	Axis 1: Protective ground conductor
		W	Axis 1: Motor connection W
		V	Axis 1: Motor connection V
		U	Axis 1: Motor connection U

Table 25: X5A connector - Pinout

## Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections.

### 3.2.5.6 SafeMC module - Pinout

Figure	X11 (X12)	Pin	Name	Function
		1	U+	Encoder supply +12.5 V
		2	---	---
		3	---	---
		4	D	Data input
		5	T	Clock output
		6	COM (1)	Encoder supply 0 V
		7	---	---
		8	D\	Data input inverted
		9	T\	Clock output inverted

## Information:

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

## Information:

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

### 3.3 Safe double-width inverter modules (single-axis modules)

#### 3.3.1 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1

##### 3.3.1.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

##### 3.3.1.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0220HCSS.000-1	ACOPOSmulti inverter module 22 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0220HWSS.000-1	ACOPOSmulti inverter module, 22 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0220SS.000-1A	Screw clamp set for ACOPOSmulti 8BVI0220HxSS and 8BVI0220HxSA modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB4104.204G-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSmulti fan module, replacement fan for ACOPOSmulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSmulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSmulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSmulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSmulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSmulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSmulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSmulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSmulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSmulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSmulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSmulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSmulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSmulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSmulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSmulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSmulti shield component set: 1x ACOPOSmulti holding plate SK8-14; 1x shield terminal SK14	
8SCS010.0000-00	ACOPOSmulti shield component set: 1x ACOPOSmulti holding plate SK14-20; 1x shield terminal SK20	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	

Table 26: 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Order data

Model number	Short description	Figure
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB4104.204G-00	Screw clamp terminal block 4-pin, single-row, pitch: 10.16mm, labeling 4: PE W V U, coding G: 0110	

Table 26: 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.3.1.3 Technical data**

Product ID	8BVI0220HCSS.000-1	8BVI0220HWSS.000-1
General information		
B&R ID code	0xAA1C	0xAA1E
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	16.2 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.13*I <sub>M</sub> <sup>2</sup> +5.5*I <sub>M</sub> +40] W	
Switching frequency 10 kHz	[0.43*I <sub>M</sub> <sup>2</sup> +3.7*I <sub>M</sub> +110] W	
Switching frequency 20 kHz	[1.4*I <sub>M</sub> <sup>2</sup> +1.97*I <sub>M</sub> +230] W	
DC bus capacitance	495 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	32.9 µF	
Max. power consumption	26 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + 2 * P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	1	
Continuous power per motor connection <sup>2)</sup>	16 kW	
Continuous current per motor connection <sup>2)</sup>	22 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>24)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	0.4 A/K (from 31°C) <sup>10)</sup>
Switching frequency 20 kHz	-	0.31 A/K (from -16°C) <sup>10)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	No reduction <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.36 A/K (from 5°C) <sup>9)</sup>	-
Feed-through mounting	0.39 A/K (from 26°C) <sup>10)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.5 A/K (from 49°C)	-
Feed-through mounting	0.15 A/K (from -59°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	2.2 A <sub>eff</sub> per 1000 m	

Table 27: 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Technical data

Product ID	8BVI0220HCSS.000-1	8BVI0220HWSS.000-1
Peak current	55 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.5 to 6 mm²	
Approbation data		
UL/C-UL-US	20 to 8	
CSA	20 to 8	
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	25 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	
Continuous current	4.2 A	
Max. internal resistance	0.15 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>17)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>18)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	

Table 27: 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Technical data

Product ID	8BVI0220HCSS.000-1	8BVI0220HWSS.000-1
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.22 µF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>21)</sup>	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>22)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>23)</sup>		
Width	106.5 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 3.9 kg	Approx. 5.2 kg
Module width	2	

Table 27: 8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSmulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot p)$$

$I_G$  ... Max. current consumption of the encoder [A]

A ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

19)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].

20) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).

21) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!

22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.

23) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.

24) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.

### 3.3.1.4 Wiring

For details, see section 3.3.4 "Wiring: Safe double-width inverter modules (single-axis modules)" on page 59

For general information, please see section 6 "Wiring" on page 120

## 3.3.2 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1

### 3.3.2.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

### 3.3.2.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0330HCSS.000-1	ACOPoSMulti inverter module 33 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0330HWSS.000-1	ACOPoSMulti inverter module, 33 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0440SS.000-1A	Screw clamp set for ACOPoSMulti 8BVI0440HxSS and 8BVI0440HxSA modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB4104.204G-10	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPoSMulti fan module, replacement fan for ACOPoSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPoSMulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPoSMulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPoSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPoSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPoSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPoSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPoSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPoSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPoSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPoSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	

Table 28: 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Order data

Model number	Short description	Figure
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs ±10 V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	Shield component sets	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS007.0000-00	ACOPOSMulti shield component set: 1x shield mounting plate 2x 45°; 4x screws	
8SCS008.0000-00	ACOPOSMulti shield component set: 1x shield plate 2x type 0; 1x hose clamp, B 9 mm, D 23-35 mm	
8SCS010.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK14-20; 1x shield terminal SK20	
	Terminal blocks	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB4104.204G-10	Screw clamp 4-pin, single row, spacing: 10.16 mm, label 4: PE W V U, G keying: 0110	

Table 28: 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.3.2.3 Technical data**

Product ID	8BVI0330HCSS.000-1	8BVI0330HWSS.000-1
General information		
B&R ID code	0xADC3	0xADC4
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	24.4 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.07*I <sub>M</sub> <sup>2</sup> +7.3*I <sub>M</sub> +40] W	
Switching frequency 10 kHz	[0.2*I <sub>M</sub> <sup>2</sup> +11.1*I <sub>M</sub> +130] W	
Switching frequency 20 kHz	[1.85*I <sub>M</sub> <sup>2</sup> +3.8*I <sub>M</sub> +300] W	
DC bus capacitance	990 µF	
Design	ACOPOSmulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	32.9 µF	
Max. power consumption	31 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + 2 * P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSmulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	1	
Continuous power per motor connection <sup>2)</sup>	24 kW	
Continuous current per motor connection <sup>2)</sup>	33 A <sub>eff</sub>	

Table 29: 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Technical data

Product ID	8BVI0330HCSS.000-1	8BVI0330HWSS.000-1
Reduction of continuous current depending on the switching frequency <sup>24)</sup>		
Switching frequency 5 kHz	-	1.57 A/K (from 40°C) <sup>8)</sup>
Switching frequency 10 kHz	-	0.5 A/K (from -10°C) <sup>10)</sup>
Switching frequency 20 kHz	-	0.36 A/K (from -77°C) <sup>10)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.8 A/K (from 45°C) <sup>8)</sup>	-
Feed-through mounting	1.26 A/K (from 40°C) <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.62 A/K (from 6°C) <sup>9)</sup>	-
Feed-through mounting	0.37 A/K (from -36°C) <sup>10)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.32 A/K (from -82°C) <sup>9)</sup>	-
Feed-through mounting	0.24 A/K (from -137°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	3.3 A <sub>eff</sub> per 1000 m	
Peak current	83 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.5 to 16 mm²	
Approbation data		
UL/C-UL-US	20 to 6	
CSA	20 to 6	
Terminal cable cross section dimension of the shield connection	23 to 35 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	25 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	
Continuous current	4.2 A	
Max. internal resistance	0.15 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>17)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>18)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	

Table 29: 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Technical data



Product ID	8BVI0330HCSS.000-1	8BVI0330HWSS.000-1
Synchronous serial interface	RS485	
Signal transmission	6.25 Mbit/s	
Data transfer rate		
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.22 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>21)</sup>	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>22)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>23)</sup>		
Width	106.5 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 4.3 kg	Approx. 5.4 kg
Module width	2	

Table 29: 8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSmulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24 V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.

- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:
  - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.
  - If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPoSMulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].
- 20) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 21) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!
- 22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 23) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 24) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.

### 3.3.2.4 Wiring

For details, see section 3.3.4 "Wiring: Safe double-width inverter modules (single-axis modules)" on page 59

For general information, please see section 6 "Wiring" on page 120

### 3.3.3 8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1

#### 3.3.3.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

## 3.3.3.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0440HCSS.000-1	ACOPOSMulti inverter module 44 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0440HWSS.000-1	ACOPOSMulti inverter module, 44 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0440SS.000-1A	Screw clamp set for ACOPOSMulti 8BVI0440HxSS and 8BVI0440HxSA modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB4104.204G-10	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSMulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSMulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS007.0000-00	ACOPOSMulti shield component set: 1x shield mounting plate 2x 45°; 4x screws	
8SCS008.0000-00	ACOPOSMulti shield component set: 1x shield plate 2x type 0; 1x hose clamp, B 9 mm, D 23-35 mm	
8SCS010.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK14-20; 1x shield terminal SK20	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB4104.204G-10	Screw clamp 4-pin, single row, spacing: 10.16 mm, label 4: PE W V U, G keying: 0110	

Table 30: 8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

## 3.3.3.3 Technical data

Product ID	8BVI0440HCSS.000-1	8BVI0440HWSS.000-1
General information		
B&R ID code	0xAA1F	0xAA20
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	32.5 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.07*I <sub>M</sub> <sup>2</sup> +7.3*I <sub>M</sub> +40] W	
Switching frequency 10 kHz	[0.2*I <sub>M</sub> <sup>2</sup> +11.1*I <sub>M</sub> +130] W	
Switching frequency 20 kHz	[1.85*I <sub>M</sub> <sup>2</sup> +3.8*I <sub>M</sub> +300] W	
DC bus capacitance	990 µF	
Design	ACOPOSmulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	32.9 µF	
Max. power consumption	31 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + 2 * P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSmulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	1	
Continuous power per motor connection <sup>2)</sup>	32 kW	
Continuous current per motor connection <sup>2)</sup>	44 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>24)</sup>		
Switching frequency 5 kHz	-	1.57 A/K (from 40°C) <sup>8)</sup>
Switching frequency 10 kHz	-	0.5 A/K (from -10°C) <sup>10)</sup>
Switching frequency 20 kHz	-	0.36 A/K (from -77°C) <sup>10)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.8 A/K (from 45°C) <sup>8)</sup>	-
Feed-through mounting	1.26 A/K (from 40°C) <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.62 A/K (from 6°C) <sup>9)</sup>	-
Feed-through mounting	0.37 A/K (from -36°C) <sup>10)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.32 A/K (from -82°C) <sup>9)</sup>	-
Feed-through mounting	0.24 A/K (from -137°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	4.4 A <sub>eff</sub> per 1000 m	
Peak current	88 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.5 to 16 mm²	
Approbation data		
UL/C-UL-US	20 to 6	
CSA	20 to 6	

Table 31: 8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1 - Technical data

Product ID	8BVI0440HCSS.000-1	8BVI0440HWSS.000-1
Terminal cable cross section dimension of the shield connection	23 to 35 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	25 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	
Continuous current	4.2 A	
Max. internal resistance	0.15 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>17)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>18)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.22 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>21)</sup>	

Table 31: 8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1 - Technical data

Product ID	8BVI0440HCSS.000-1	8BVI0440HWSS.000-1
<b>Environmental conditions</b>		
Temperature		
Operation		
Nominal		5 to 40°C
Maximum <sup>22)</sup>		55°C
Storage		-25 to 55°C
Transport		-25 to 70°C
Relative humidity		
Operation		5 to 85%
Storage		5 to 95%
Transport		Max. 95% at 40°C
<b>Mechanical characteristics</b>		
Dimensions <sup>23)</sup>		
Width		106.5 mm
Height		317 mm
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 4.3 kg	Approx. 5.4 kg
Module width		2

Table 31: 8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSMulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSMulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9/I_G \cdot A \cdot 1/(2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{encoder}$  ... Max. power consumption of the connected encoder [A].

- 20) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).

- 21) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!

- 22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.

- 23) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.

- 24) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.

### 3.3.3.4 Wiring

For details, see section 3.3.4 "Wiring: Safe double-width inverter modules (single-axis modules)" on page 59

For general information, please see section 6 "Wiring" on page 120

### 3.3.4 Wiring: Safe double-width inverter modules (single-axis modules)

#### 3.3.4.1 Pinout overview




Figure 7: Overview of pin assignments

### 3.3.4.2 X2 connector - Pinout


X2	Pin	Name	Function
	1	Trigger 1	Trigger 1
	2	COM (1)	Trigger 1 0 V
	3	COM (2)	+24 V output 1 0 V
	4	+24V Out 1	+24 V output 1
	5	Trigger 2	Trigger 2
	6	COM (5)	Trigger 2 0 V
	7	COM (8)	+24 V output 2 0 V
	8	+24V Out 2	+24 V output 2

Table 32: X2 connector - Pinout

### 3.3.4.3 X3A, X3B connectors - Pinout


X3A, X3B	Pin	Name	Function
	1	RXD	Receive signal
	2	RXD\	Receive signal inverted
	3	TXD	Transmit signal
	4	Shield	Shield
	5	Shield	Shield
	6	TXD\	Transmit signal inverted
	7	Shield	Shield
	8	Shield	Shield

Table 33: X3A, X3B connectors - Pinout

### 3.3.4.4 X4A connector - Pinout


X4A	Name	Function
	T-	Axis 1: Temperature sensor -
	T+	Axis 1: Temperature sensor +
	B- <sup>1)</sup>	Axis 1: Brake -
	B+ <sup>1)</sup>	Axis 1: Brake +

Table 34: X4A connector - Pinout

1) Wiring is not permitted to exceed a total length of 3 m.

## Danger!

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

## Danger!

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!



**Danger!**

Only an output voltage of  $\leq 5\text{ V}$  can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

**Information:**

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu\text{s}$ .

This must be taken into consideration when choosing the motor holding brake!

**Danger!**

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

**Caution!**

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSMulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

**Warning!**

Temperature sensors are only permitted to be connected to the X4A/T+ and X4A/T- connectors on an ACOPOSMulti module under the following conditions:

- There is no ACOPOSMulti plug-in module in SLOT1 on the ACOPOSMulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSMulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSMulti module to be destroyed!

3.3.4.5 X5A connector - Pinout




X5A		Name	Function
		$\oplus$	Axis 1: Protective ground conductor
		W	Axis 1: Motor connection W
		V	Axis 1: Motor connection V
		U	Axis 1: Motor connection U

Table 35: X5A connector - Pinout

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections.

## 3.3.4.6 SafeMC module - Pinout

Figure	X11 (X12)	Pin	Name	Function
		1	U+	Encoder supply +12.5 V
		2	---	---
		3	---	---
		4	D	Data input
		5	T	Clock output
		6	COM (1)	Encoder supply 0 V
		7	---	---
		8	D\	Data input inverted
		9	T\	Clock output inverted

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

**Information:**

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

### 3.4 Safe single-width inverter modules (dual-axis modules)

#### 3.4.1 8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1

##### 3.4.1.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design
- Complete safety functionality in two-axis modules as well

##### 3.4.1.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0014HCDS.000-1	ACOPOSMulti inverter module, 1.9 A, HV, cold plate or feed-through mounting, 2 axes, SafeMC	
	<b>Wall mounting</b>	
8BVI0014HWDS.000-1	ACOPOSMulti inverter module, 1.9 A, HV, wall mounting, 2 axes, SafeMC	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0055DS.000-1A	Screw clamp set for ACOPOSMulti 8BVI00xxHxDS modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB2104.203F-00, 1x 8TB3104.204G-11, 1x 8TB3104.204K-11	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203F-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, F keying: 0101	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	
8TB3104.204K-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, K keying: 1001	

Table 36: 8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1 - Order data

#### Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections!

#### Information:

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

## 3.4.1.3 Technical data

Product ID	8BVI0014HCDS.000-1	8BVI0014HWDS.000-1
General information		
B&R ID code	0xAA0B	0xAA0D
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	2.91 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[1.2*I <sub>M</sub> <sup>2</sup> +2.62*I <sub>M</sub> +100] W	
Switching frequency 10 kHz	[2.56*I <sub>M</sub> <sup>2</sup> +2.8*I <sub>M</sub> +200] W	
Switching frequency 20 kHz	[6*I <sub>M</sub> <sup>2</sup> -9.4*I <sub>M</sub> +430] W	
DC bus capacitance	165 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	28 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake(s)</sub> + P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	2	
Continuous power per motor connection <sup>2)</sup>	1.4 kW	
Continuous current per motor connection <sup>2)</sup>	1.9 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>22)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	No reduction
Switching frequency 20 kHz	-	0.11 A/K (from 15°C) <sup>9)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	No reduction <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	No reduction	-
Feed-through mounting	No reduction	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.13 A/K (from 45°C)	-
Feed-through mounting	0.14 A/K (from 32°C) <sup>9)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	0.19 A <sub>eff</sub> per 1000 m	
Peak current per motor connection	4.7 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>10)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>11)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>12)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.25 to 4 mm²	
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	

Table 37: 8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1 - Technical data

Product ID	8BVI0014HCDS.000-1	8BVI0014HWDS.000-1
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	2	
Output voltage <sup>13)</sup>	24 VDC +5.8% / -0% <sup>14)</sup>	
Continuous current	1.1 A	
Max. internal resistance	0.5 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	1.5 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.25 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>15)</sup>		
Quantity	2	
Type	EnDat 2.2 <sup>16)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>17)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>18)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.2 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>19)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20	

Table 37: 8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1 - Technical data

Product ID	8BVI0014HCDS.000-1	8BVI0014HWDS.000-1
<b>Environmental conditions</b>		
Temperature		
Operation		
Nominal		5 to 40°C
Maximum <sup>20)</sup>		55°C
Storage		-25 to 55°C
Transport		-25 to 70°C
Relative humidity		
Operation		5 to 85%
Storage		5 to 95%
Transport		Max. 95% at 40°C
<b>Mechanical characteristics</b>		
Dimensions <sup>21)</sup>		
Width		53 mm
Height		317 mm
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 2.3 kg	Approx. 2.8 kg
Module width		1

Table 37: 8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1 - Technical data

- 1) SLOT 1 and SLOT 2 of the ACOPOSmulti module are occupied by the encoder interfaces.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Average value of the currents on both motor connectors [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24VOut}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 10) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load. When using dual-axis modules, the increased CPU load reduces the functionality of the drive; if this is not taken into consideration, the computing time can be exceeded in extreme cases.
- 11) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 12) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 13) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 14) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 15) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 16) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 17) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):  

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$
 $I_G$  ... Max. current consumption of the encoder [A]  
 $A$  ... Cross section of the supply wire [mm<sup>2</sup>]  
 $\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )
- 18)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].
- 19) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 20) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 21) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 22) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.

### 3.4.1.4 Wiring

For details, see section 3.4.4 "Wiring: Safe single-width inverter modules (dual-axis modules)" on page 76

For general information, please see section 6 "Wiring" on page 120

### 3.4.2 8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1

#### 3.4.2.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design
- Complete safety functionality in two-axis modules as well

#### 3.4.2.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0028HCDS.000-1	ACOPOSMulti inverter module, 3.8 A, HV, cold plate or feed-through mounting, 2 axes, SafeMC	
	<b>Wall mounting</b>	
8BVI0028HWDS.000-1	ACOPOSMulti inverter unit, 3.8 A, HV, wall mounting, 2 axes, SafeMC	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0055DS.000-1A	Screw clamp set for ACOPOSMulti 8BVI00xxHxDS modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB2104.203F-00, 1x 8TB3104.204G-11, 1x 8TB3104.204K-11	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203F-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, F keying: 0101	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	
8TB3104.204K-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, K keying: 1001	

Table 38: 8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1 - Order data

#### Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections!

#### Information:

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

## 3.4.2.3 Technical data

Product ID	8BVI0028HCDS.000-1	8BVI0028HWDS.000-1
General information		
B&R ID code	0xAA0F	0xAA11
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	5.73 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[1.2*I <sub>M</sub> <sup>2</sup> +2.62*I <sub>M</sub> +100] W	
Switching frequency 10 kHz	[2.56*I <sub>M</sub> <sup>2</sup> +2.8*I <sub>M</sub> +200] W	
Switching frequency 20 kHz	[6*I <sub>M</sub> <sup>2</sup> -9.4*I <sub>M</sub> +430] W	
DC bus capacitance	165 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	28 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V</sub> Out + P <sub>HoldingBrake(s)</sub> + P <sub>Fan8B0M...</sub> <sup>4)</sup>	28 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V</sub> Out + P <sub>HoldingBrake(s)</sub> + P <sub>Fan8B0M...</sub> <sup>23)</sup>
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	2	
Continuous power per motor connection <sup>2)</sup>	2.8 kW	
Continuous current per motor connection <sup>2)</sup>	3.8 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>24)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	No reduction
Switching frequency 20 kHz	-	0.12 A/K (from 13 °C) <sup>10)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	No reduction <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.6 A/K (from 57°C)	-
Feed-through mounting	No reduction	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.12 A/K (from 34°C) <sup>9)</sup>	-
Feed-through mounting	0.09 A/K (from 6°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	0.38 A <sub>eff</sub> per 1000 m	
Peak current per motor connection	9.5 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	600 Hz <sup>25)</sup>
Design		
U, V, W, PE	Connector	Plug
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines	0.25 to 4 mm²	
With wire end sleeves		
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	

Table 39: 8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1 - Technical data



Product ID	8BVI0028HCDS.000-1	8BVI0028HWDS.000-1
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	2	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	24 VDC +5.8% / -0% <sup>26)</sup>
Continuous current	1.1 A	
Max. internal resistance	0.5 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	1.5 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.25 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	2	
Type	EnDat 2.2 <sup>17)</sup>	EnDat 2.2 <sup>27)</sup>
Connections	9-pin DSUB connector	9-pin DSUB socket
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m Depends on the cross section of the encoder's supply wires <sup>18)</sup>	100 m Depending on the cross section of the supply wires on the encoder cable <sup>28)</sup>
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.14 μF	0.2 μF
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20	

Table 39: 8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1 - Technical data

Product ID	8BVI0028HCDS.000-1	8BVI0028HWDS.000-1
<b>Environmental conditions</b>		
Temperature		
Operation		
Nominal		5 to 40°C
Maximum <sup>21)</sup>		55°C
Storage		-25 to 55°C
Transport		-25 to 70°C
Relative humidity		
Operation		5 to 85%
Storage		5 to 95%
Transport		Max. 95% at 40°C
<b>Mechanical characteristics</b>		
Dimensions <sup>22)</sup>		
Width		53 mm
Height		317 mm
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 2.3 kg	Approx. 2.8 kg
Module width		1

Table 39: 8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1 - Technical data

- 1) SLOT 1 and SLOT 2 of the ACOPOSmulti module are occupied by the encoder interfaces.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Average value of the currents on both motor connectors [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24 V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load. When using dual-axis modules, the increased CPU load reduces the functionality of the drive; if this is not taken into consideration, the computing time can be exceeded in extreme cases.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):  

$$l_{max} = 7.9 / I_G * A * 1 / (2 * \rho)$$
 $I_G$  ... Max. current consumption of the encoder [A]  
 $A$  ... Cross section of the supply wire [mm<sup>2</sup>]  
 $\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )
- 19)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].
- 20) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 21) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 22) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.

- 23)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the section "Encoder interfaces")  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module)
- 24) Valid in the following conditions: DC bus voltage 750 VDC The temperature specifications are based on the ambient temperature.
- 25) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual-use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current motion is aborted and error 6060 is output (Power element: Limit speed exceeded).
- 26) The specified values is only valid under the following conditions:  
 - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
 If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be deactivated.
- 27) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the timing of the functions STO, SBC and SS1 is monitored!
- 28) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

### 3.4.2.4 Wiring

For details, see section 3.4.4 "Wiring: Safe single-width inverter modules (dual-axis modules)" on page 76

For general information, please see section 6 "Wiring" on page 120

### 3.4.3 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1

#### 3.4.3.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design
- Complete safety functionality in two-axis modules as well

#### 3.4.3.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0055HCDS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, cold plate or feed through mounting, 2 axes, SafeMC	
	<b>Wall mounting</b>	
8BVI0055HWDS.000-1	ACOPOSmulti inverter unit, 7.6 A, HV, wall mounting, 2 axes, SafeMC	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0055DS.000-1A	Screw clamp set for ACOPOSmulti 8BVI00xxHxDS modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB2104.203F-00, 1x 8TB3104.204G-11, 1x 8TB3104.204K-11	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSmulti fan module, replacement fan for ACOPOSmulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSmulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSmulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSmulti shield component set: 1x ACOPOSmulti holding plate SK8-14; 1x shield terminal SK14	

Table 40: 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Order data

Model number	Short description	Figure
	<b>Terminal blocks</b>	
8TB2104.203F-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, F keying: 0101	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	
8TB3104.204K-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, K keying: 1001	

Table 40: 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.4.3.3 Technical data**

Product ID	8BVI0055HCDS.000-1	8BVI0055HWDS.000-1
General information		
B&R ID code	0xAA13	0xAA15
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	11.19 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[1.2*I <sub>M</sub> <sup>2</sup> +2.62*I <sub>M</sub> +100] W	
Switching frequency 10 kHz	[2.56*I <sub>M</sub> <sup>2</sup> +2.8*I <sub>M</sub> +200] W	
Switching frequency 20 kHz	[6*I <sub>M</sub> <sup>2</sup> -9.4*I <sub>M</sub> +430] W	
DC bus capacitance	330 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	28 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake(s)</sub> + P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	2	
Continuous power per motor connection <sup>2)</sup>	5.5 kW	
Continuous current per motor connection <sup>2)</sup>	7.6 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>23)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	0.22 A/K (from 43 °C)
Switching frequency 20 kHz	-	0.15 A/K (from -14 °C) <sup>9)</sup>

Table 41: 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Technical data

Product ID	8BVI0055HCDS.000-1	8BVI0055HWDS.000-1
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.72 A/K (from 56 °C) <sup>8)</sup>	-
Feed-through mounting	No reduction <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.28 A/K (from 43 °C)	-
Feed-through mounting	0.17 A/K (from 23°C) <sup>9)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.13 A/K (from 3 °C) <sup>10)</sup>	-
Feed-through mounting	0.12 A/K (from -21°C) <sup>9)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	0.76 A <sub>eff</sub> per 1000 m	
Peak current per motor connection	18.9 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	Plug	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.25 to 4 mm²	
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	2	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	
Continuous current	1.1 A	
Max. internal resistance	0.5 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	1.5 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.25 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	2	
Type	EnDat 2.2 <sup>17)</sup>	
Connections	9-pin DSUB socket	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depending on the cross section of the supply wires on the encoder cable <sup>18)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	

Table 41: 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Technical data

Product ID	8BVI0055HCDS.000-1	8BVI0055HWDS.000-1
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.2 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>21)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>22)</sup>		
Width	53 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 2.3 kg	Approx. 2.9 kg
Module width	1	

Table 41: 8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Technical data

- 1) SLOT 1 and SLOT 2 of the ACOPOSmulti module are occupied by the encoder interfaces.
- 2) Valid in the following conditions: Bus voltage 750 VDC, switching frequency 5 kHz, 40°C ambient temperature, installation altitudes <500 m above sea level, no derating dependent on cooling type.
- 3)  $I_M$  ... Average value of the currents on both motor connectors [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the section "Encoder interfaces")  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module)
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: DC bus voltage 750 VDC, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications are based on the return temperature of the cold-plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow-temperatures and low return-temperatures.
- 11) B&R recommends operating the module at nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load. When using double-axis modules, the increased CPU load causes a reduction of the functional range in the drive; if this is not taken into consideration, then it can cause the computing time to be exceeded in extreme cases.

- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner ([www.schaffner.com](http://www.schaffner.com)) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual-use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current motion is aborted and error 6060 is output (Power element: Limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be deactivated.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPoSMulti with SafeMC! With standard EnDat 2.2 encoders, only the timing of the functions STO, SBC and SS1 is monitored!
- 18) The maximum encoder cable length  $l_{\max}$  can be calculated as follows (the maximum permissible encoder length of 100 m must not be exceeded):

$$l_{\max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{\text{Encoder}}$  ... Max. power consumption of the connected encoder [A].
- 20) Continuous operation at altitudes ranging from 500 m to 4,000 m above sea level is possible (taking the continuous current reductions listed into consideration).
- 21) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the continuous current reductions listed into consideration), but results in a shorter lifespan.
- 22) The dimensions define the true device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 23) Valid in the following conditions: DC bus voltage 750 VDC The temperature specifications are based on the ambient temperature.

### 3.4.3.4 Wiring

For details, see section 3.4.4 "Wiring: Safe single-width inverter modules (dual-axis modules)" on page 76

For general information, please see section 6 "Wiring" on page 120

### 3.4.4 Wiring: Safe single-width inverter modules (dual-axis modules)

#### 3.4.4.1 Pinout overview




Figure 8: Overview of pin assignments

#### 3.4.4.2 X2 connector - Pinout


X2		Pin	Name	Function
	1	1	Trigger 1	Trigger 1
	2	2	COM (1)	Trigger 1 0 V
	3	3	COM (2)	+24 V output 1 0 V
	4	4	+24V Out 1	+24 V output 1
	5	5	Trigger 2	Trigger 2
	6	6	COM (5)	Trigger 2 0 V
	7	7	COM (8)	+24 V output 2 0 V
	8	8	+24V Out 2	+24 V output 2

Table 42: X2 connector - Pinout



## 3.4.4.3 X3A, X3B connectors - Pinout


X3A, X3B	Pin	Name	Function
	1	RXD	Receive signal
	2	RXD\	Receive signal inverted
	3	TXD	Transmit signal
	4	Shield	Shield
	5	Shield	Shield
	6	TXD\	Transmit signal inverted
	7	Shield	Shield
	8	Shield	Shield

Table 43: X3A, X3B connectors - Pinout

## 3.4.4.4 X4A connector - Pinout


X4A	Name	Function
	T-	Axis 1: Temperature sensor -
	T+	Axis 1: Temperature sensor +
	B- <sup>1)</sup>	Axis 1: Brake -
	B+ <sup>1)</sup>	Axis 1: Brake +

Table 44: X4A connector - Pinout

1) Wiring is not permitted to exceed a total length of 3 m.

**Danger!**

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

For a double-axis module, it is therefore especially important to prevent a cross-circuit between the two B+ connections of the two axes!

**Danger!**

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

**Danger!**

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

**Information:**

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!

**Danger!**

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

## Caution!

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSmulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## Warning!

Temperature sensors are only permitted to be connected to the X4A/T+ and X4A/T- connectors on an ACOPOSmulti module under the following conditions:

- There is no ACOPOSmulti plug-in module in SLOT1 on the ACOPOSmulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSmulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSmulti module to be destroyed!

### 3.4.4.5 X4B connector - Pinout


X4B	Name	Function
	T-	Axis 2: Temperature sensor -
	T+	Axis 2: Temperature sensor +
	B- <sup>1)</sup>	Axis 2: Brake -
	B+ <sup>1)</sup>	Axis 2: Brake +

Table 45: Pin assignments X4B plug

- 1) The wiring is not permitted to exceed a total length of 3 m.

## Danger!

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

For a double-axis module, it is therefore especially important to prevent a cross-circuit between the two B+ connections of the two axes!

## Danger!

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

## Danger!

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

## Information:

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!

## Danger!

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

## Caution!

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSmulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## Warning!

Temperature sensors are only permitted to be connected to X4B/T+ and X4B/T- on an ACOPOSmulti module under the following conditions:

- There is no ACOPOSmulti plug-in module in SLOT2 on the ACOPOSmulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSmulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSmulti module to be destroyed!

### 3.4.4.6 X5A connector - Pinout


X5A		Name	Function
	⊕		Axis 1: Protective ground conductor
	W		Axis 1: Motor connection W
	V		Axis 1: Motor connection V
	U		Axis 1: Motor connection U

Table 46: X5A connector - Pinout

## Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections.

### 3.4.4.7 X5B connector - Pinout




X5B		Name	Function
	⊕		Axis 2: Protective ground conductor
	W		Axis 2: Motor connection W
	V		Axis 2: Motor connection V
	U		Axis 2: Motor connection U

Table 47: X5B connector - Pinout

## Warning!

B&R 8BCM motor cables must be used when cabling the motor connections.

## 3.4.4.8 SafeMC module - Pinout

Figure	X11 (X12)	Pin	Name	Function
		1	U+	Encoder supply +12.5 V
		2	---	---
		3	---	---
		4	D	Data input
		5	T	Clock output
		6	COM (1)	Encoder supply 0 V
		7	---	---
		8	D\	Data input inverted
		9	T\	Clock output inverted

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

**Information:**

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

### 3.5 Safe double-width inverter modules (dual-axis modules)

#### 3.5.1 8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1

##### 3.5.1.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design
- Complete safety functionality in two-axis modules as well

##### 3.5.1.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0110HCDS.000-1	ACOPOSMulti inverter unit, 15.1 A, HV, cold plate or feed through mounting, 2 axes, SafeMC	
	<b>Wall mounting</b>	
8BVI0110HWDS.000-1	ACOPOSMulti inverter module, 15.1 A, HV, wall mounting, 2 axes, SafeMC	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0110DS.000-1A	Screw clamp set for ACOPOSMulti 8BVI0110HxDS modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB2104.203F-00, 1x 8TB3104.204G-11, 1x 8TB3104.204K-11	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	
	<b>Terminal blocks</b>	
8TB2104.203F-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, F keying: 0101	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	
8TB3104.204K-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, K keying: 1001	

Table 48: 8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1 - Order data

#### Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections!

#### Information:

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

## 3.5.1.3 Technical data

Product ID	8BVI0110HCDS.000-1	8BVI0110HWDS.000-1
General information		
B&R ID code	0xAA17	0xAA19
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	22.3 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.33*I <sub>M</sub> <sup>2</sup> +11*I <sub>M</sub> +90] W	
Switching frequency 10 kHz	[0.97*I <sub>M</sub> <sup>2</sup> +9.5*I <sub>M</sub> +170] W	
Switching frequency 20 kHz	[1.66*I <sub>M</sub> <sup>2</sup> +21*I <sub>M</sub> +380] W	
DC bus capacitance	660 µF	
Design	ACOPOSmulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	32 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake(s)</sub> + 2 * P <sub>Fan8B0M...</sub> <sup>4)</sup>	32 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake(s)</sub> + 2 * P <sub>Fan8B0M...</sub> <sup>23)</sup>
Design	ACOPOSmulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	2	
Continuous power per motor connection <sup>2)</sup>	11 kW	
Continuous current per motor connection <sup>2)</sup>	15.1 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>6)</sup>		
Switching frequency 5 kHz	-	No reduction <sup>8)</sup>
Switching frequency 10 kHz	-	0.19 A/K (from 29°C) <sup>10)</sup>
Switching frequency 20 kHz	-	0.15 A/K (from -38°C) <sup>10)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.38 A/K (from 51°C) <sup>8)</sup>	-
Feed-through mounting	0.27 A/K (from 46°C) <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.25 A/K (from 24°C) <sup>9)</sup>	-
Feed-through mounting	0.16 A/K (from 2°C) <sup>10)</sup>	-
Switching frequency 20 kHz		
Cold plate mounting <sup>7)</sup>	0.19 A/K (from -14°C) <sup>9)</sup>	-
Feed-through mounting	0.14 A/K (from -74°C) <sup>10)</sup>	-
Reduction of continuous current depending on the installation elevation		
Starting at 500 m above sea level	1.51 A <sub>eff</sub> per 1000 m	
Peak current per motor connection	37.7 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	600 Hz <sup>24)</sup>
Design		
U, V, W, PE	Plug	Connector
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines	0.25 to 4 mm²	
With wire end sleeves		
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	

Table 49: 8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1 - Technical data

Product ID	8BVI0110HCDS.000-1	8BVI0110HWDS.000-1
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	10 m	
Motor holding brake connection		
Quantity	2	
Output voltage <sup>14)</sup>	24 VDC +5.8% / -0% <sup>15)</sup>	24 VDC +5.8% / -0% <sup>25)</sup>
Continuous current	2.1 A	
Max. internal resistance	0.3 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>16)</sup>		
Quantity	2	
Type	EnDat 2.2 <sup>17)</sup>	EnDat 2.2 <sup>26)</sup>
Connections	9-pin DSUB socket	9-pin DSUB connector
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m Depending on the cross section of the supply wires on the encoder cable <sup>18)</sup>	100 m Depends on the cross section of the encoder's supply wires <sup>27)</sup>
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>19)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	No	Yes
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.44 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>20)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20	

Table 49: 8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1 - Technical data

Product ID	8BVI0110HCDS.000-1	8BVI0110HWDS.000-1
<b>Environmental conditions</b>		
Temperature		
Operation		
Nominal		5 to 40°C
Maximum <sup>21)</sup>		55°C
Storage		-25 to 55°C
Transport		-25 to 70°C
Relative humidity		
Operation		5 to 85%
Storage		5 to 95%
Transport		Max. 95% at 40°C
<b>Mechanical characteristics</b>		
Dimensions <sup>22)</sup>		
Width		106.5 mm
Height		317 mm
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 4.1 kg	Approx. 5.3 kg
Module width		2

Table 49: 8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1 - Technical data

- 1) SLOT 1 and SLOT 2 of the ACOPOSmulti module are occupied by the encoder interfaces.
- 2) Valid in the following conditions: Bus voltage 750 VDC, switching frequency 5 kHz, 40°C ambient temperature, installation altitudes <500 m above sea level, no derating dependent on cooling type.
- 3)  $I_M$  ... Average value of the currents on both motor connectors [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the section "Encoder interfaces")  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module)
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min). The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load. When using double-axis modules, the increased CPU load causes a reduction of the functional range in the drive; if this is not taken into consideration, then it can cause the computing time to be exceeded in extreme cases.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase dU/dt choke from Schaffner ([www.schaffner.com](http://www.schaffner.com)) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency ( $SCTRL\_SPEED\_ACT * MOTOR\_POLEPAIRS$ ) is monitored to protect against dual-use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current motion is aborted and error 6060 is output (Power element: Limit speed exceeded).
- 14) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 15) The specified values is only valid under the following conditions:  
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be deactivated.
- 16) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 17) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the timing of the functions STO, SBC and SS1 is monitored!
- 18) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G * A * 1 / (2 * \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 19)  $I_{encoder}$  ... Max. power consumption of the connected encoder [A].

- 20) Continuous operation at altitudes ranging from 500 m to 4,000 m above sea level is possible (taking the continuous current reductions listed into consideration).

- 21) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the continuous current reductions listed into consideration), but results in a shorter lifespan.

- 22) The dimensions define the true device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.



- 23)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24\text{ V Out}}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 24) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 25) The specified values is only valid under the following conditions:  
 - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
 If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 26) An EnDat 2.2 functional safety encoder is required when using ACOPOSMulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 27) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

### 3.5.1.4 Wiring

For details, see section 3.5.3 "Wiring: Safe double-width inverter modules (dual-axis modules)" on page 90

For general information, please see section 6 "Wiring" on page 120

## 3.5.2 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1

### 3.5.2.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design
- Complete safety functionality in two-axis modules as well

### 3.5.2.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0220HCDS.000-1	ACOPOSMulti inverter module, 22 A, HV, cold plate or feed-through mounting, 2 axes, SafeMC	
	<b>Wall mounting</b>	
8BVI0220HWDS.000-1	ACOPOSMulti inverter module, 22 A, HV, wall mounting, 2 axes, SafeMC	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI0220DS.000-1A	Screw clamp set for ACOPOSMulti 8BVI0220HxDS modules: 1x 8TB2108.2010-00, 1x 8TB2104.203L-00, 1x 8TB2104.203F-00, 1x 8TB3104.204G-11, 1x 8TB3104.204K-11	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Shield component sets</b>	
8SCS000.0000-00	ACOPOSMulti shielding components set: 1x shielding plate 1fold type 0; 1x hose clamp, W 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS009.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK8-14; 1x shield terminal SK14	

Table 50: 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Order data

Model number	Short description	Figure
	<b>Terminal blocks</b>	
8TB2104.203F-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, F keying: 0101	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB3104.204G-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, G coding: 0110	
8TB3104.204K-11	Screw clamp 4-pin, single row, spacing: 7.62 mm, label 4: PE W V U, K keying: 1001	

Table 50: 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.5.2.3 Technical data**

Product ID	8BVI0220HCDS.000-1	8BVI0220HWDS.000-1
General information		
B&R ID code	0xAA1B	0xAA1D
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	In preparation	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	In preparation	
Switching frequency 10 kHz	In preparation	
DC bus capacitance	1320 µF	
Design	ACOPOSMulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	23.5 µF	
Max. power consumption	32 W + P <sub>SMC1</sub> + P <sub>SMC2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake(s)</sub> + 2 * P <sub>Fan8B0M...</sub> <sup>4)</sup>	
Design	ACOPOSMulti backplane	
24 VDC output		
Quantity	2	
Output voltage		
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)	
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%	
Fuse protection	250 mA (slow-blow) electronic, automatic reset	
Motor connection <sup>5)</sup>		
Quantity	2	
Continuous power per motor connection <sup>2)</sup>	16 kW	
Continuous current per motor connection <sup>2)</sup>	22 A <sub>eff</sub>	
Reduction of continuous current depending on the switching frequency <sup>6)</sup>		
Switching frequency 5 kHz	-	0.33 A/K (from 40°C) <sup>8)</sup>
Switching frequency 10 kHz	-	0.17 A/K (from -25°C) <sup>10)</sup>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>		
Switching frequency 5 kHz		
Cold plate mounting <sup>7)</sup>	0.99 A/K (from 40°C) <sup>8)</sup>	-
Feed-through mounting	0.52 A/K (from 40°C) <sup>8)</sup>	-
Switching frequency 10 kHz		
Cold plate mounting <sup>7)</sup>	0.29 A/K (from 10°C) <sup>9)</sup>	-
Feed-through mounting	0.23 A/K (from 0°C) <sup>10)</sup>	-

Table 51: 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Technical data

Product ID	8BVI0220HCDS.000-1	8BVI0220HWDS.000-1
Reduction of continuous current depending on the installation elevation Starting at 500 m above sea level	2.2 A <sub>eff</sub> per 1000 m	
Peak current per motor connection	55 A <sub>eff</sub> <sup>(11)</sup>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>(12)</sup>	5/10 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>(13)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>(14)</sup>	
Design		
U, V, W, PE	Connector	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	0.25 to 4 mm²	
Approbation data		
UL/C-UL-US	30 to 10	
CSA	28 to 10	
Terminal cable cross section dimension of the shield connection	12 to 22 mm	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Motor holding brake connection		
Quantity	2	
Output voltage <sup>(15)</sup>	24 VDC +5.8% / -0% <sup>(16)</sup>	
Continuous current	2.1 A	
Max. internal resistance	0.3 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>(17)</sup>		
Quantity	2	
Type	EnDat 2.2 <sup>(18)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>(19)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>(20)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	

Table 51: 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Technical data

Product ID	8BVI0220HCDS.000-1	8BVI0220HWDS.000-1
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.44 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>21)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>22)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>23)</sup>		
Width	106.5 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 4.4 kg	Approx. 5.7 kg
Module width	2	

Table 51: 8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Technical data

- 1) SLOT 1 and SLOT 2 of the ACOPOSMulti module are occupied by the encoder interfaces.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Average value of the currents on both motor connectors [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SMC2}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT2 (see the section "Encoder interfaces")  
 $P_{24 \text{ V Out}}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min). The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) The thermal pulse load capacity is lower than for the 8BVI0220HxS0.000-1 single-axis module. It is therefore not possible to simply replace two 8BVI0220HxS0.000-1 single-axis modules with one 8BVI0220HxD0.000-1 dual-axis module. If this is required, the load cycle must be examined in detail.
- 12) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load. When using dual-axis modules, the increased CPU load reduces the functionality of the drive; if this is not taken into consideration, the computing time can be exceeded in extreme cases.
- 13) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase dU/dt choke from Schaffner ([www.schaffner.com](http://www.schaffner.com)) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 14) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 15) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.

- 16) The specified values is only valid under the following conditions:  
 - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.  
 If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- 17) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 18) An EnDat 2.2 functional safety encoder is required when using ACOPoSMulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 19) The maximum encoder cable length  $l_{\max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{\max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 20)  $I_{\text{Encoder}}$  ... Max. power consumption of the connected encoder [A].
- 21) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 22) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 23) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.

### 3.5.2.4 Wiring

For details, see section 3.5.3 "Wiring: Safe double-width inverter modules (dual-axis modules)" on page 90

For general information, please see section 6 "Wiring" on page 120

### 3.5.3 Wiring: Safe double-width inverter modules (dual-axis modules)

#### 3.5.3.1 Pinout overview




Figure 9: Overview of pin assignments

#### 3.5.3.2 X2 connector - Pinout


X2		Pin	Name	Function
	1	1	Trigger 1	Trigger 1
	2	2	COM (1)	Trigger 1 0 V
	3	3	COM (2)	+24 V output 1 0 V
	4	4	+24V Out 1	+24 V output 1
	5	5	Trigger 2	Trigger 2
	6	6	COM (5)	Trigger 2 0 V
	7	7	COM (8)	+24 V output 2 0 V
	8	8	+24V Out 2	+24 V output 2

Table 52: X2 connector - Pinout

## 3.5.3.3 X3A, X3B connectors - Pinout


X3A, X3B	Pin	Name	Function
	1	RXD	Receive signal
	2	RXD\	Receive signal inverted
	3	TXD	Transmit signal
	4	Shield	Shield
	5	Shield	Shield
	6	TXD\	Transmit signal inverted
	7	Shield	Shield
	8	Shield	Shield

Table 53: X3A, X3B connectors - Pinout

## 3.5.3.4 X4A connector - Pinout


X4A	Name	Function
	T-	Axis 1: Temperature sensor -
	T+	Axis 1: Temperature sensor +
	B- <sup>1)</sup>	Axis 1: Brake -
	B+ <sup>1)</sup>	Axis 1: Brake +

Table 54: X4A connector - Pinout

1) Wiring is not permitted to exceed a total length of 3 m.

**Danger!**

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

For a double-axis module, it is therefore especially important to prevent a cross-circuit between the two B+ connections of the two axes!

**Danger!**

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

**Danger!**

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

**Information:**

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!

**Danger!**

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

## Caution!

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSmulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## Warning!

Temperature sensors are only permitted to be connected to the X4A/T+ and X4A/T- connectors on an ACOPOSmulti module under the following conditions:

- There is no ACOPOSmulti plug-in module in SLOT1 on the ACOPOSmulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSmulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSmulti module to be destroyed!

### 3.5.3.5 X4B connector - Pinout


X4B	Name	Function
	T-	Axis 2: Temperature sensor -
	T+	Axis 2: Temperature sensor +
	B- <sup>1)</sup>	Axis 2: Brake -
	B+ <sup>1)</sup>	Axis 2: Brake +

Table 55: Pin assignments X4B plug

- 1) The wiring is not permitted to exceed a total length of 3 m.

## Danger!

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

For a double-axis module, it is therefore especially important to prevent a cross-circuit between the two B+ connections of the two axes!

## Danger!

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

## Danger!

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

## Information:

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!



## Danger!

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

## Caution!

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSmulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## Warning!

Temperature sensors are only permitted to be connected to X4B/T+ and X4B/T- on an ACOPOSmulti module under the following conditions:

- There is no ACOPOSmulti plug-in module in SLOT2 on the ACOPOSmulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSmulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSmulti module to be destroyed!

### 3.5.3.6 X5A connector - Pinout


X5A	Name	Function
	⊕	Axis 1: Protective ground conductor
	W	Axis 1: Motor connection W
	V	Axis 1: Motor connection V
	U	Axis 1: Motor connection U

Table 56: X5A connector - Pinout

## Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections.

### 3.5.3.7 X5B connector - Pinout




X5B	Name	Function
	⊕	Axis 2: Protective ground conductor
	W	Axis 2: Motor connection W
	V	Axis 2: Motor connection V
	U	Axis 2: Motor connection U

Table 57: X5B connector - Pinout

## Warning!

B&R 8BCM motor cables must be used when cabling the motor connections.

## 3.5.3.8 SafeMC module - Pinout

Figure	X11 (X12)	Pin	Name	Function
		1	U+	Encoder supply +12.5 V
		2	---	---
		3	---	---
		4	D	Data input
		5	T	Clock output
		6	COM (1)	Encoder supply 0 V
		7	---	---
		8	D\	Data input inverted
		9	T\	Clock output inverted

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

**Information:**

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

### 3.6 Safe 4x width inverter modules (single-axis modules)

#### 3.6.1 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1

##### 3.6.1.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

##### 3.6.1.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI0660HCSS.000-1	ACOPOSMulti inverter module 66 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0660HWSS.000-1	ACOPOSMulti inverter module, 66 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI1650SS.000-1A	Screw clamp set for ACOPOSMulti 8BVI0660HxSS, 8BVI0880HxSS, 8BVI1650HxSS, 8BVI0660HxSA, 8BVI0880HxSA and 8BVI1650HxSA modules: 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSMulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSMulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>Shield component sets</b>	
8SCS001.0000-00	ACOPOSMulti shield component set: 1x shield plate 4x type 1; 1x hose clamp, B 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS003.0000-00	ACOPOSMulti shield component set: 1x shield mounting plate 4x 45°; 8x screws	
8SCS004.0000-00	ACOPOSMulti shield component set: 1x shield plate 4x type 0; 2x hose clamps, B 9 mm, D 32-50 mm	
8SCS010.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK14-20; 1x shield terminal SK20	
	<b>Terminal blocks</b>	

Table 58: 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Order data

Model number	Short description	Figure
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2106.2010-00	Screw clamp 6-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	

Table 58: 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.6.1.3 Technical data**

Product ID	8BVI0660HCSS.000-1		8BVI0660HWSS.000-1	
General information				
B&R ID code	0xBE89		0xBE8B	
Cooling and mounting method	Cold plate or feed-through mounting		Wall mounting	
Slots for plug-in modules	2 <sup>1)</sup>			
Certification				
CE			Yes	
cULus			Yes	
KC			Yes	
FSC			Yes	
DC bus connection				
Voltage				
Nominal	750 VDC			
Continuous power consumption <sup>2)</sup>	48.8 kW			
Power loss depending on the switching frequency <sup>3)</sup>				
Switching frequency 5 kHz			[0.03*I <sub>M</sub> <sup>2</sup> +7.9*I <sub>M</sub> +90] W	
Switching frequency 10 kHz			[0.11*I <sub>M</sub> <sup>2</sup> +11*I <sub>M</sub> +185] W	
Switching frequency 20 kHz			[0.17*I <sub>M</sub> <sup>2</sup> +27*I <sub>M</sub> +310] W	
DC bus capacitance	1980 µF			
Design	ACOPOSMulti backplane			
24 VDC supply				
Input voltage	25 VDC ±1.6%			
Input capacitance	32.9 µF			
Max. power consumption	33 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + 4 * P <sub>Fan8B0M...</sub> <sup>4)</sup>			
Design	ACOPOSMulti backplane			
24 VDC output				
Quantity	2			
Output voltage				
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	25 VDC * (U <sub>DC</sub> /315)			
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC	24 VDC ±6%			
Fuse protection	250 mA (slow-blow) electronic, automatic reset			
Motor connection <sup>5)</sup>				
Quantity	1			
Continuous power per motor connection <sup>2)</sup>	48 kW			
Continuous current per motor connection <sup>2)</sup>	66 A <sub>eff</sub>			
Reduction of continuous current depending on the switching frequency <sup>26)</sup>				
Switching frequency 5 kHz	-		1.4 A/K (from 41°C) <sup>8)</sup>	
Switching frequency 10 kHz	-		0.92 A/K (from -5°C) <sup>10)</sup>	
Switching frequency 20 kHz	-		0.56 A/K (from -90°C) <sup>10)</sup>	
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>				
Switching frequency 5 kHz				
Cold plate mounting <sup>7)</sup>	1.9 A/K (from 58°C) <sup>8)</sup>		-	
Feed-through mounting	1.82 A/K (from 40°C) <sup>8)</sup>		-	
Switching frequency 10 kHz				
Cold plate mounting <sup>7)</sup>	1.36 A/K (from 27°C) <sup>9)</sup>		-	
Feed-through mounting	0.88 A/K (from -12°C) <sup>10)</sup>		-	
Switching frequency 20 kHz				
Cold plate mounting <sup>7)</sup>	0.75 A/K (from -37°C) <sup>9)</sup>		-	
Feed-through mounting	0.54 A/K (from -106°C) <sup>10)</sup>		-	

Table 59: 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Technical data

Product ID	8BVI0660HCSS.000-1	8BVI0660HWSS.000-1
Reduction of continuous current depending on the installation elevation Starting at 500 m above sea level	6.6 A <sub>eff</sub> per 1000 m	
Peak current	132 A <sub>eff</sub>	
Nominal switching frequency	5 kHz	
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz	
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A	
Protective measures		
Overload protection	Yes	
Short circuit and ground fault protection	Yes	
Max. output frequency	600 Hz <sup>13)</sup>	
Design		
U, V, W, PE	M8 threaded bolt	
Shield connection	Yes	
Terminal connection cross section		
Flexible and fine wire lines		
With wire end sleeves	6 to 50 mm <sup>2</sup> <sup>14)</sup>	
Approbation data		
UL/C-UL-US	In preparation	
CSA	In preparation	
Terminal cable cross section dimension of the shield connection	12 to 50 mm <sup>15)</sup>	
Max. motor line length depending on the switching frequency		
Switching frequency 5 kHz	25 m	
Switching frequency 10 kHz	25 m	
Switching frequency 20 kHz	25 m	
Motor holding brake connection		
Quantity	1	
Output voltage <sup>16)</sup>	24 VDC +5.8% / -0% <sup>17)</sup>	
Continuous current	4.2 A	
Max. internal resistance	0.15 Ω	
Extinction potential	Approx. 30 V	
Max. extinction energy per switching operation	3 Ws	
Max. switching frequency	0.5 Hz	
Protective measures		
Overload and short circuit protection	Yes	
Open line monitoring	Yes	
Undervoltage monitoring	Yes	
Response threshold for open line monitoring	Approx. 0.5 A	
Response threshold for undervoltage monitoring	24 VDC +0% / -4%	
Encoder interfaces <sup>18)</sup>		
Quantity	1	
Type	EnDat 2.2 <sup>19)</sup>	
Connections	9-pin DSUB connector	
Status indicators	UP/DN LEDs	
Electrical isolation		
Encoder - ACOPOSMulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>20)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>21)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	

Table 59: 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Technical data

Product ID	8BVI0660HCSS.000-1	8BVI0660HWSS.000-1
Switching delay		
Positive edge	52 μs ± 0.5 μs (digitally filtered)	
Negative edge	53 μs ± 0.5 μs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.45 μF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>22)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>23)</sup>	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>24)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>25)</sup>		
Width	213.5 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 8 kg	Approx. 10.2 kg
Module width	4	

Table 59: 8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Technical data

- SLOT 2 is not occupied. SLOT 1 of the ACOPOSMulti module is occupied by the SafeMC module.
- Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- $I_M$  ... Current on the motor connection [A].
- $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{BBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24 \text{ V Out}}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- B&R 8BCM motor cables must be used when cabling the motor connections.
- Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- The temperature specifications refer to the return temperature of the cold plate mounting plate.
- Value for the nominal switching frequency.
- The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase dU/dt choke from Schaffner ([www.schaffner.com](http://www.schaffner.com)) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- The connection is made with cable lugs using an M8 threaded bolt.
- The maximum diameter that can be clamped depends on the shield component set.
- During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.

- 17) The specified values is only valid under the following conditions:
- The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.
  - Connection between S1 and S2 (activation of the external holding brake) using a jumper with a max. length of 10 cm.
- If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.
- If jumpers longer than 10 cm are used to connect S1 and S2, then the output voltage is reduced because of voltage drops on the jumpers.
- 18) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 19) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 20) The maximum encoder cable length  $l_{\max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{\max} = 7.9 / I_G \cdot A \cdot 1 / (2 \cdot \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [ $\Omega$ mm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 21)  $I_{\text{Encoder}}$  ... Max. power consumption of the connected encoder [A].
- 22) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 23) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!
- 24) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 25) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 26) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.

### 3.6.1.4 Wiring

For details, see section 3.6.3 "Wiring: Safe 4x width inverter modules (single-axis modules)" on page 104

For general information, please see section 6 "Wiring" on page 120

## 3.6.2 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1

### 3.6.2.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

### 3.6.2.2 Order data


Model number	Short description	Figure
8BVI0880HCSS.004-1	ACOPOSmulti inverter module 88 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Wall mounting</b>	
8BVI0880HWSS.004-1	ACOPOSmulti inverter module, 88 A, HV, wall mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZV11650SS.000-1A	Screw clamp set for ACOPOSmulti 8BVI0660HxSS, 8BVI0880HxSS, 8BVI1650HxSS, 8BVI0660HxSA, 8BVI0880HxSA and 8BVI1650HxSA modules: 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSmulti fan module, replacement fan for ACOPOSmulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSmulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSmulti plug-in module, EnDat 2.2 interface	

Table 60: 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Order data

Model number	Short description	Figure
8BAC0121.000-1	ACOPOSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62,5 kHz, 4 digital outputs, 500 mA, max. 1,25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs ±10 V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	Shield component sets	
8SCS001.0000-00	ACOPOSMulti shield component set: 1x shield plate 4x type 1; 1x hose clamp, B 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS003.0000-00	ACOPOSMulti shield component set: 1x shield mounting plate 4x 45°; 8x screws	
8SCS004.0000-00	ACOPOSMulti shield component set: 1x shield plate 4x type 0; 2x hose clamps, B 9 mm, D 32-50 mm	
8SCS010.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK14-20; 1x shield terminal SK20	
	Terminal blocks	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2106.2010-00	Screw clamp 6-pin, single row, spacing: 5.08 mm, label 1: numbered serially	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	

Table 60: 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.6.2.3 Technical data**

Product ID	8BVI0880HCSS.004-1	8BVI0880HWSS.004-1
General information		
B&R ID code	0xB450	0xB451
Cooling and mounting method	Cold plate or feed-through mounting	Wall mounting
Slots for plug-in modules	2 <sup>1)</sup>	
Certification		
CE	Yes	
cULus	Yes	
KC	Yes	
FSC	Yes	
DC bus connection		
Voltage		
Nominal	750 VDC	
Continuous power consumption <sup>2)</sup>	65 kW	
Power loss depending on the switching frequency <sup>3)</sup>		
Switching frequency 5 kHz	[0.03*I <sub>M</sub> <sup>2</sup> +7.9*I <sub>M</sub> +90] W	
Switching frequency 10 kHz	[0.11*I <sub>M</sub> <sup>2</sup> +11*I <sub>M</sub> +185] W	
Switching frequency 20 kHz	[0.17*I <sub>M</sub> <sup>2</sup> +27*I <sub>M</sub> +310] W	
DC bus capacitance	1980 µF	
Design	ACOPOSmulti backplane	
24 VDC supply		
Input voltage	25 VDC ±1.6%	
Input capacitance	32.9 µF	

Table 61: 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Technical data



Product ID	8BVI0880HCSS.004-1		8BVI0880HWSS.004-1	
Max. power consumption	33 W + P <sub>SMC1</sub> + P <sub>SLOT2</sub> + P <sub>24 V Out</sub> + P <sub>HoldingBrake</sub> + 4 * P <sub>Fan8B0M...</sub> <sup>4)</sup>			
Design	ACOPOSMulti backplane			
24 VDC output				
Quantity	2			
Output voltage	25 VDC * (U <sub>DC</sub> /315)			
DC bus voltage (U <sub>DC</sub> ): 260 to 315 VDC	24 VDC ±6%			
DC bus voltage (U <sub>DC</sub> ): 315 to 800 VDC				
Fuse protection	250 mA (slow-blow) electronic, automatic reset			
Motor connection <sup>5)</sup>				
Quantity	1			
Continuous power per motor connection <sup>2)</sup>	64 kW			
Continuous current per motor connection <sup>2)</sup>	88 A <sub>eff</sub>			
Reduction of continuous current depending on the switching frequency <sup>26)</sup>				
Switching frequency 5 kHz	-		1.4 A/K (from 41°C) <sup>8)</sup>	
Switching frequency 10 kHz	-		0.92 A/K (from -5°C) <sup>10)</sup>	
Switching frequency 20 kHz	-		0.56 A/K (from -90°C) <sup>10)</sup>	
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>				
Switching frequency 5 kHz				
Cold plate mounting <sup>7)</sup>	1.9 A/K (from 58°C) <sup>8)</sup>		-	
Feed-through mounting	1.82 A/K (from 40°C) <sup>8)</sup>		-	
Switching frequency 10 kHz				
Cold plate mounting <sup>7)</sup>	1.36 A/K (from 27°C) <sup>9)</sup>		-	
Feed-through mounting	0.88 A/K (from -12°C) <sup>10)</sup>		-	
Switching frequency 20 kHz				
Cold plate mounting <sup>7)</sup>	0.75 A/K (from -37°C) <sup>9)</sup>		-	
Feed-through mounting	0.54 A/K (from 106°C) <sup>10)</sup>		-	
Reduction of continuous current depending on the installation elevation				
Starting at 500 m above sea level	8.8 A <sub>eff</sub> per 1000 m			
Peak current	176 A <sub>eff</sub>			
Nominal switching frequency	5 kHz			
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz			
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A			
Protective measures				
Overload protection	Yes			
Short circuit and ground fault protection	Yes			
Max. output frequency	600 Hz <sup>13)</sup>			
Design				
U, V, W, PE	M8 threaded bolt			
Shield connection	Yes			
Terminal connection cross section				
Flexible and fine wire lines				
With wire end sleeves	6 to 50 mm <sup>2</sup> <sup>14)</sup>			
Approbation data				
UL/C-UL-US	In preparation			
CSA	In preparation			
Terminal cable cross section dimension of the shield connection	12 to 50 mm <sup>15)</sup>			
Max. motor line length depending on the switching frequency				
Switching frequency 5 kHz	25 m			
Switching frequency 10 kHz	25 m			
Switching frequency 20 kHz	25 m			
Motor holding brake connection				
Quantity	1			
Output voltage <sup>16)</sup>	24 VDC +5.8% / -0% <sup>17)</sup>			
Continuous current	4.2 A			
Max. internal resistance	0.15 Ω			
Extinction potential	Approx. 30 V			
Max. extinction energy per switching operation	3 Ws			
Max. switching frequency	0.5 Hz			
Protective measures				
Overload and short circuit protection	Yes			
Open line monitoring	Yes			
Undervoltage monitoring	Yes			
Response threshold for open line monitoring	Approx. 0.5 A			
Response threshold for undervoltage monitoring	24 VDC +0% / -4%			
Encoder interfaces <sup>18)</sup>				
Quantity	1			
Type	EnDat 2.2 <sup>19)</sup>			
Connections	9-pin DSUB connector			
Status indicators	UP/DN LEDs			

Table 61: 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Technical data

Product ID	8BVI0880HCSS.004-1	8BVI0880HWSS.004-1
Electrical isolation		
Encoder - ACOPOSmulti	No	
Encoder monitoring	Yes	
Max. encoder cable length	100 m	
	Depends on the cross section of the encoder's supply wires <sup>20)</sup>	
Encoder supply		
Output voltage	Typ. 12.5 V	
Load capability	350 mA	
Protective measures		
Short circuit protection	Yes	
Overload protection	Yes	
Synchronous serial interface		
Signal transmission	RS485	
Data transfer rate	6.25 Mbit/s	
Max. power consumption per encoder interface	P <sub>SMC</sub> [W] = 19 V * I <sub>Encoder</sub> [A] <sup>21)</sup>	
Trigger inputs		
Quantity	2	
Wiring	Sink	
Electrical isolation		
Input - Inverter module	Yes	
Input - Input	Yes	
Input voltage		
Nominal	24 VDC	
Maximum	30 VDC	
Switching threshold		
Low	<5 V	
High	>15 V	
Input current at nominal voltage	Approx. 10 mA	
Switching delay		
Positive edge	52 µs ± 0.5 µs (digitally filtered)	
Negative edge	53 µs ± 0.5 µs (digitally filtered)	
Modulation compared to ground potential	Max. ±38 V	
Electrical characteristics		
Discharge capacitance	0.45 µF	
Operating conditions		
Permitted mounting orientations		
Hanging vertically	Yes	
Lying horizontally	Yes	
Standing horizontally	No	
Installation at elevations above sea level		
Nominal	0 to 500 m	
Maximum <sup>22)</sup>	4000 m	
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)	
Overvoltage category in accordance with IEC 60364-4-443:1999	III	
EN 60529 protection	IP20 <sup>23)</sup>	
Environmental conditions		
Temperature		
Operation		
Nominal	5 to 40°C	
Maximum <sup>24)</sup>	55°C	
Storage	-25 to 55°C	
Transport	-25 to 70°C	
Relative humidity		
Operation	5 to 85%	
Storage	5 to 95%	
Transport	Max. 95% at 40°C	
Mechanical characteristics		
Dimensions <sup>25)</sup>		
Width	213.5 mm	
Height	317 mm	
Depth		
Wall mounting	-	263 mm
Cold plate	212 mm	-
Feed-through mounting	209 mm	-
Weight	Approx. 8 kg	Approx. 10.2 kg
Module width	4	

Table 61: 8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSMulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].

- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{SBAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
 Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner (www.schaffner.com) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) The connection is made with cable lugs using an M8 threaded bolt.
- 15) The maximum diameter that can be clamped depends on the shield component set.
- 16) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 17) The specified values is only valid under the following conditions:
  - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.
  - Connection between S1 and S2 (activation of the external holding brake) using a jumper with a max. length of 10 cm.
 If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.  
 If jumpers longer than 10 cm are used to connect S1 and S2, then the output voltage is reduced because of voltage drops on the jumpers.
- 18) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 19) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 20) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):
 
$$l_{max} = 7.9 / I_G * A * 1 / (2 * \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]  
 $A$  ... Cross section of the supply wire [mm<sup>2</sup>]  
 $\rho$  ... Specific resistance [Ωmm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )
- 21)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].
- 22) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).
- 23) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!
- 24) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 25) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.
- 26) Valid in the following conditions: 750 VDC DC bus voltage. The temperature specifications refer to the ambient temperature.

### 3.6.2.4 Wiring

For details, see section 3.6.3 "Wiring: Safe 4x width inverter modules (single-axis modules)" on page 104

For general information, please see section 6 "Wiring" on page 120

### 3.6.3 Wiring: Safe 4x width inverter modules (single-axis modules)

#### 3.6.3.1 Overview of pin assignments




Figure 10: Overview of pin assignments

#### 3.6.3.2 X2 connector - Pinout


X2		Pin	Name	Function
	1	1	Trigger 1	Trigger 1
	2	2	COM (1)	Trigger 1 0 V
	3	3	COM (2)	+24 V output 1 0 V
	4	4	+24V Out 1	+24 V output 1
	5	5	Trigger 2	Trigger 2
	6	6	COM (5)	Trigger 2 0 V
	7	7	COM (8)	+24 V output 2 0 V
	8	8	+24V Out 2	+24 V output 2

Table 62: X2 connector - Pinout

### 3.6.3.3 X3A, X3B connectors - Pinout


X3A, X3B	Pin	Name	Function
	1	RXD	Receive signal
	2	RXD\	Receive signal inverted
	3	TXD	Transmit signal
	4	Shield	Shield
	5	Shield	Shield
	6	TXD\	Transmit signal inverted
	7	Shield	Shield
	8	Shield	Shield

Table 63: X3A, X3B connectors - Pinout

### 3.6.3.4 X4A connector - Pinout


X4A	Name	Function
	T-	Axis 1: Temperature sensor -
	T+	Axis 1: Temperature sensor +
	B- <sup>1)</sup>	Axis 1: Brake -
	B+ <sup>1)</sup>	Axis 1: Brake +

Table 64: X4A connector - Pinout

1) Wiring is not permitted to exceed a total length of 3 m.

## Danger!

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

## Danger!

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

## Danger!

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

## Information:

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!

## Danger!

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

## Caution!

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSMulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## Warning!

Temperature sensors are only permitted to be connected to the X4A/T+ and X4A/T- connectors on an ACOPOSMulti module under the following conditions:

- There is no ACOPOSMulti plug-in module in SLOT1 on the ACOPOSMulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSMulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSMulti module to be destroyed!

3.6.3.5 X5A connector - Pinout

X5A	Name		Function
	1		Axis 1: Protective ground conductor
	2		Axis 1: Motor connection W
	3		Axis 1: Motor connection V
	4		Axis 1: Motor connection U

Table 65: X5A connector - Pinout

Information:

Only 8BCM motor cables from B&R may be used to cable the motor connections.

Motor connections U, V, W - Cable installation




Figure 11: X5A - Cable installation

PE connection (1-wire) - Cable installation




Table 66: PE connection (1-wire) - Cable installation

PE connection (3-wire) - Cable installation




Table 67: PE connection (3-wire) - Cable installation

3.6.3.6 SafeMC module - Pinout

Figure	X11 (X12)	Pin	Name	Function
		1	U+	Encoder supply +12.5 V
		2	---	---
		3	---	---
		4	D	Data input
		5	T	Clock output
		6	COM (1)	Encoder supply 0 V
		7	---	---
		8	D\	Data input inverted
		9	T\	Clock output inverted

Information:

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

Information:

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.



### 3.7 Safe 8x width inverter modules (single-axis modules)

#### 3.7.1 8BVI1650HCSS.000-1

##### 3.7.1.1 General Information

- Clearly structured, straightforward implementation via network-based safety technology
- Modular expandability through virtual wiring
- Immediate triggering of safety function thanks to short cycle times
- Easy implementation with transparent control and status information in the standard application as well
- Compact design

##### 3.7.1.2 Order data


Model number	Short description	Figure
	<b>Cold plate or feed-through mounting</b>	
8BVI1650HCSS.000-1	ACOPOSMulti inverter module 165 A, HV, cold plate or feed-through mounting, SafeMC EnDat 2.2	
	<b>Required accessories</b>	
	<b>Terminal block sets</b>	
8BZVI1650SS.000-1A	Screw clamp set for ACOPOSMulti 8BVI0660HxSS, 8BVI0880HxSS, 8BVI1650HxSS, 8BVI0660HxSA, 8BVI0880HxSA and 8BVI1650HxSA modules: 1x 8TB2104.203L-00, 1x 8TB2108.2010-00	
	<b>Optional accessories</b>	
	<b>Fan modules</b>	
8BXF001.0000-00	ACOPOSMulti fan module, replacement fan for ACOPOSMulti modules (8BVP / 8B0C / 8BVI / 8BVE / 8B0K)	
	<b>Plug-in modules</b>	
8BAC0120.000-1	ACOPOSMulti plug-in module, EnDat 2.1 interface	
8BAC0120.001-2	ACOPOSMulti plug-in module, EnDat 2.2 interface	
8BAC0121.000-1	ACOPOSMulti plug-in module, HIPERFACE interface	
8BAC0122.000-1	ACOPOSMulti plug-in module, resolver interface 10 kHz	
8BAC0123.000-1	ACOPOSMulti plug-in module, incremental encoder and SSI absolute encoder interface for RS422 signals	
8BAC0123.001-1	ACOPOSMulti plug-in module, incremental encoder interface for 5 V single-ended and 5 V differential signals	
8BAC0123.002-1	ACOPOSMulti plug-in module, incremental encoder interface for 24 V single-ended and 24 V differential signals	
8BAC0124.000-1	ACOPOSMulti plug-in module, SinCos interface	
8BAC0125.000-1	ACOPOSMulti plug-in module, SinCos EnDat 2.1/SSI interface	
8BAC0130.000-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz, 2 digital inputs 24 VDC	
8BAC0130.001-1	ACOPOSMulti plug-in module, 2 digital outputs, 50 mA, max. 62.5 kHz, 4 digital outputs, 500 mA, max. 1.25 kHz	
8BAC0132.000-1	ACOPOSMulti input module, 4 analog inputs $\pm 10$ V	
8BAC0133.000-1	ACOPOSMulti plug-in module, 3 RS422 outputs for ABR encoder emulation, 1 Mhz	
	<b>POWERLINK cables</b>	
X20CA0E61.00020	POWERLINK connection cable, RJ45 to RJ45, 0.20 m	
X20CA0E61.00025	POWERLINK connection cable, RJ45 to RJ45, 0.25 m	
X20CA0E61.00030	POWERLINK connection cable, RJ45 to RJ45, 0.30 m	
X20CA0E61.00035	POWERLINK connection cable, RJ45 to RJ45, 0.35 m	
X20CA0E61.00050	POWERLINK connection cable, RJ45 to RJ45, 0.50 m	
X20CA0E61.00100	POWERLINK connection cable, RJ45 to RJ45, 1.00 m	
	<b>Shield component sets</b>	
8SCS001.0000-00	ACOPOSMulti shield component set: 1x shield plate 4x type 1; 1x hose clamp, B 9 mm, D 12-22 mm	
8SCS002.0000-00	ACOPOSMulti shield component set: 1x clamping plate; 2x clamps D 4-13.5 mm; 4x screws	
8SCS003.0000-00	ACOPOSMulti shield component set: 1x shield mounting plate 4x 45°; 8x screws	
8SCS004.0000-00	ACOPOSMulti shield component set: 1x shield plate 4x type 0; 2x hose clamps, B 9 mm, D 32-50 mm	
8SCS010.0000-00	ACOPOSMulti shield component set: 1x ACOPOSMulti holding plate SK14-20; 1x shield terminal SK20	
	<b>Terminal blocks</b>	
8TB2104.203L-00	Screw clamp 4-pin, single row, spacing: 5.08 mm, label 3: T- T + B- B+, L keying: 1010	
8TB2108.2010-00	Screw clamp 8-pin, single row, spacing: 5.08 mm, label 1: numbered serially	

Table 68: 8BVI1650HCSS.000-1 - Order data

**Information:**

Only 8BCM motor cables from B&R may be used to cable the motor connections!

**Information:**

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

For details, see 1.2 "Safe power transmission" on page 138.

**3.7.1.3 Technical data**

Product ID	8BVI1650HCSS.000-1
<b>General information</b>	
B&R ID code	0xB878
Cooling and mounting method	Cold plate or feed-through mounting
Slots for plug-in modules	2 <sup>1)</sup>
Certification	
CE	Yes
cULus	Yes
KC	Yes
FSC	Yes
<b>DC bus connection</b>	
Voltage	
Nominal	750 VDC
Continuous power consumption <sup>2)</sup>	121.8 kW
Power loss depending on the switching frequency <sup>3)</sup>	
Switching frequency 5 kHz	$[0.001 \cdot I_M^2 + 9.9 \cdot I_M + 165] \text{ W}$
Switching frequency 10 kHz	$[0.17 \cdot I_M^2 + 10.8 \cdot I_M + 320] \text{ W}$
Switching frequency 20 kHz	In preparation
DC bus capacitance	3630 $\mu\text{F}$
Design	ACOPoSMulti backplane
<b>24 VDC supply</b>	
Input voltage	25 VDC $\pm 1.6\%$
Input capacitance	32.9 $\mu\text{F}$
Max. power consumption	$43 \text{ W} + P_{\text{SMC1}} + P_{\text{SLOT2}} + P_{24 \text{ V Out}} + P_{\text{Holding Brake}} + 4 \cdot P_{\text{Fan8B0M...}}^{4)}$
Design	ACOPoSMulti backplane
<b>24 VDC output</b>	
Quantity	2
Output voltage	
DC bus voltage ( $U_{\text{DC}}$ ): 260 to 315 VDC	25 VDC $\cdot (U_{\text{DC}}/315)$
DC bus voltage ( $U_{\text{DC}}$ ): 315 to 800 VDC	24 VDC $\pm 6\%$
Fuse protection	250 mA (slow-blow) electronic, automatic reset
<b>Motor connection <sup>5)</sup></b>	
Quantity	1
Continuous power per motor connection <sup>2)</sup>	120 kW
Continuous current per motor connection <sup>2)</sup>	165 A <sub>eff</sub>
Reduction of continuous current depending on the switching frequency and mounting method <sup>6)</sup>	
Switching frequency 5 kHz	
Cold plate mounting <sup>7)</sup>	3.1 A/K (from 53°C) <sup>8)</sup>
Feed-through mounting	2.82 A/K (from 40°C) <sup>8)</sup>
Switching frequency 10 kHz	
Cold plate mounting <sup>7)</sup>	1.8 A/K (from 17°C) <sup>9)</sup>
Feed-through mounting	1.5 A/K (from -13°C) <sup>10)</sup>
Switching frequency 20 kHz	
Cold plate mounting <sup>7)</sup>	1.2 A/K (from -60°C) <sup>9)</sup>
Feed-through mounting	0.72 A/K (from 141°C) <sup>10)</sup>
Reduction of continuous current depending on the installation elevation	
Starting at 500 m above sea level	16.5 A <sub>eff</sub> per 1000 m
Peak current	330 A <sub>eff</sub>
Nominal switching frequency	5 kHz
Possible switching frequencies <sup>11)</sup>	5/10/20 kHz
Electrical stress of the connected motor in accordance with IEC TS 60034-25 <sup>12)</sup>	Limit value curve A
Protective measures	
Overload protection	Yes
Short circuit and ground fault protection	Yes
Max. output frequency	600 Hz <sup>13)</sup>
Design	
U, V, W, PE	M8 threaded bolt
Shield connection	Yes

Table 69: 8BVI1650HCSS.000-1 - Technical data

Product ID	8BVI1650HCSS.000-1
Terminal connection cross section Flexible and fine wire lines With wire end sleeves	6 to 95 mm <sup>2</sup> <sup>14)</sup>
Approbation data UL/C-UL-US CSA	In preparation In preparation
Terminal cable cross section dimension of the shield connection	12 to 50 mm <sup>15)</sup>
Max. motor line length depending on the switching frequency	
Switching frequency 5 kHz	25 m
Switching frequency 10 kHz	25 m
Switching frequency 20 kHz	25 m
<b>Motor holding brake connection</b>	
Quantity	1
Output voltage <sup>16)</sup>	24 VDC +5.8% / -0% <sup>17)</sup>
Continuous current	4.2 A
Max. internal resistance	0.15 Ω
Extinction potential	Approx. 30 V
Max. extinction energy per switching operation	3 Ws
Max. switching frequency	0.5 Hz
Protective measures	
Overload and short circuit protection	Yes
Open line monitoring	Yes
Undervoltage monitoring	Yes
Response threshold for open line monitoring	Approx. 0.5 A
Response threshold for undervoltage monitoring	24 VDC +0% / -4%
<b>Encoder interfaces <sup>18)</sup></b>	
Quantity	1
Type	EnDat 2.2 <sup>19)</sup>
Connections	9-pin DSUB connector
Status indicators	UP/DN LEDs
Electrical isolation	
Encoder - ACOPOSMulti	No
Encoder monitoring	Yes
Max. encoder cable length	100 m
	Depends on the cross section of the encoder's supply wires <sup>20)</sup>
Encoder supply	
Output voltage	Typ. 12.5 V
Load capability	350 mA
Protective measures	
Short circuit protection	Yes
Overload protection	Yes
Synchronous serial interface	
Signal transmission	RS485
Data transfer rate	6.25 Mbit/s
Max. power consumption per encoder interface	$P_{SMC} [W] = 19 V * I_{Encoder} [A]$ <sup>21)</sup>
<b>Trigger inputs</b>	
Quantity	2
Wiring	Sink
Electrical isolation	
Input - Inverter module	Yes
Input - Input	Yes
Input voltage	
Nominal	24 VDC
Maximum	30 VDC
Switching threshold	
Low	<5 V
High	>15 V
Input current at nominal voltage	Approx. 10 mA
Switching delay	
Positive edge	52 μs ± 0.5 μs (digitally filtered)
Negative edge	53 μs ± 0.5 μs (digitally filtered)
Modulation compared to ground potential	Max. ±38 V
<b>Electrical characteristics</b>	
Discharge capacitance	0.9 μF
<b>Operating conditions</b>	
Permitted mounting orientations	
Hanging vertically	Yes
Lying horizontally	Yes
Standing horizontally	No
Installation at elevations above sea level	
Nominal	0 to 500 m
Maximum <sup>22)</sup>	4000 m

Table 69: 8BVI1650HCSS.000-1 - Technical data

Product ID	8BV11650HCSS.000-1
Degree of pollution in accordance with EN 60664-1	2 (non-conductive pollution)
Overvoltage category in accordance with IEC 60364-4-443:1999	III
EN 60529 protection	IP20 <sup>23)</sup>
Environmental conditions	
Temperature	
Operation	
Nominal	5 to 40°C
Maximum <sup>24)</sup>	55°C
Storage	-25 to 55°C
Transport	-25 to 70°C
Relative humidity	
Operation	5 to 85%
Storage	5 to 95%
Transport	Max. 95% at 40°C
Mechanical characteristics	
Dimensions <sup>25)</sup>	
Width	427.5 mm
Height	317 mm
Depth	
Cold plate	212 mm
Feed-through mounting	209 mm
Weight	Approx. 19.5 kg
Module width	8

Table 69: 8BV11650HCSS.000-1 - Technical data

- 1) SLOT 2 is not occupied. SLOT 1 of the ACOPOSmulti module is occupied by the SafeMC module.
- 2) Valid in the following conditions: 750 VDC DC bus voltage, 5 kHz switching frequency, 40°C ambient temperature, installation altitude <500 m above sea level, no derating due to cooling type.
- 3)  $I_M$  ... Current on the motor connection [A].
- 4)  $P_{SMC1}$  ... Max. power consumption  $P_{SMC}$  [W] of the SafeMC module in SLOT1 (see the "Encoder interfaces" section).  
 $P_{SLOT2}$  ... Max. power consumption  $P_{8BAC}$  [W] of the plug-in module in SLOT2 (see the technical data for the respective plug-in module)  
 $P_{24V Out}$  ... Power [W] that is output to the connections X2/+24 V Out 1 and X2/+24 V Out 2 on the module (max. 10 W)  
 $P_{Fan8B0M...}$  ... Portion of the power [W] that is used by the fan modules in the mounting plate or the 8B0M0040HFF0.000-1 fan module (see the technical data for the respective 8B0M... mounting plate / 8B0M0040HFF0.000-1 fan module).
- 5) B&R 8BCM motor cables must be used when cabling the motor connections.
- 6) Valid in the following conditions: 750 VDC DC bus voltage, minimum permissible coolant flow volume (3 l/min).
- 7) The temperature specifications refer to the return temperature of the cold plate mounting plate.
- 8) Value for the nominal switching frequency.
- 9) The module cannot supply the full continuous current at this switching frequency. This unusual value for the return temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.  
Caution! Condensation can occur at low flow temperatures and return temperatures.
- 10) The module cannot supply the full continuous current at this switching frequency. This unusual value for the ambient temperature, at which a derating of the continuous current must be accounted for, ensures that the derating of the continuous current can be determined in the same manner as at other switching frequencies.
- 11) B&R recommends operating the module at its nominal switching frequency. Operating the module at a higher switching frequency for application-specific reasons reduces the continuous current and increases the CPU load.
- 12) If necessary, the stress of the motor isolation system be reduced by an additional externally-wired dU/dt choke. For example, the RWK 305 three-phase du/dt choke from Schaffner ([www.schaffner.com](http://www.schaffner.com)) can be used. IMPORTANT: Even when using a dU/dt choke, it is necessary to ensure that an EMC-compatible, low inductance shield connection is used!
- 13) The module's electrical output frequency (SCTRL\_SPEED\_ACT \* MOTOR\_POLEPAIRS) is monitored to protect against dual use in accordance with EC 428/2009 | 3A225. If the electrical output frequency of the module exceeds the limit value of 600 Hz uninterrupted for more than 0.5 s, then the current movement is aborted and error 6060 is output (power unit: limit speed exceeded).
- 14) The connection is made with cable lugs using an M8 threaded bolt.
- 15) The maximum diameter that can be clamped depends on the shield component set.
- 16) During project development, it is necessary to check if the minimum voltage can be maintained on the holding brake with the specified wiring. The operating voltage range of the holding brake can be found in the user's manual for the respective motor.
- 17) The specified values is only valid under the following conditions:
  - The 24 VDC supply for the module is provided by an 8B0C auxiliary supply module installed on the same mounting plate.
  - Connection between S1 and S2 (activation of the external holding brake) using a jumper with a max. length of 10 cm.
If the 24 VDC supply for the module is applied to the mounting plate using an 8BVE expansion module, then the output voltage is reduced because of voltage drops on the expansion cable. In this case, undervoltage monitoring must be disabled.  
If jumpers longer than 10 cm are used to connect S1 and S2, then the output voltage is reduced because of voltage drops on the jumpers.
- 18) B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.
- 19) An EnDat 2.2 functional safety encoder is required when using ACOPOSmulti with SafeMC! With standard EnDat 2.2 encoders, only the STO, SBC and SS1 functions are monitored with respect to timing!
- 20) The maximum encoder cable length  $l_{max}$  can be calculated as follows (the maximum permissible encoder cable length of 100 m must not be exceeded):

$$l_{max} = 7.9 / I_G * A * 1 / (2 * \rho)$$

$I_G$  ... Max. current consumption of the encoder [A]

$A$  ... Cross section of the supply wire [mm<sup>2</sup>]

$\rho$  ... Specific resistance [Ωmm<sup>2</sup>/m] (e.g. for copper:  $\rho = 0.0178$ )

- 21)  $I_{Encoder}$  ... Max. power consumption of the connected encoder [A].

- 22) Continuous operation at altitudes ranging from 500 m to 4000 m above sea level is possible (taking the specified continuous current reductions into consideration).

- 23) This value only applies with the factory settings (SLOT2 of the module is sealed by a slot cover shield plate). If SLOT2 on the module is not sealed, then the protection level is reduced to IP10. It is important to note that a 8SCS005.0000-00 shield set (cover/shield plate) or a plug-in module must always be inserted!

- 24) Continuous operation at ambient temperatures ranging from 40°C to max. 55°C is possible (taking the specified continuous current reductions into consideration), but this will result in a shorter service life.
- 25) These dimensions refer to the actual device dimensions including the respective mounting plate. Make sure to leave additional space above and below the devices for mounting, connections and air circulation.

### 3.7.1.4 Wiring

For details, see section 3.7.2 "Wiring: Safe 8x-width inverter modules (single-axis modules)" on page 113

For general information, please see section 6 "Wiring" on page 120

### 3.7.2 Wiring: Safe 8x-width inverter modules (single-axis modules)

#### 3.7.2.1 Pinout overview




Figure 12: Pinout overview

### 3.7.2.2 X2 connector - Pinout


X2	Pin	Name	Function
	1	Trigger 1	Trigger 1
	2	COM (1)	Trigger 1 0 V
	3	COM (2)	+24 V output 1 0 V
	4	+24V Out 1	+24 V output 1
	5	Trigger 2	Trigger 2
	6	COM (5)	Trigger 2 0 V
	7	COM (8)	+24 V output 2 0 V
	8	+24V Out 2	+24 V output 2

Table 70: X2 connector - Pinout

### 3.7.2.3 X3A, X3B connectors - Pinout


X3A, X3B	Pin	Name	Function
	1	RXD	Receive signal
	2	RXD\	Receive signal inverted
	3	TXD	Transmit signal
	4	Shield	Shield
	5	Shield	Shield
	6	TXD\	Transmit signal inverted
	7	Shield	Shield
	8	Shield	Shield

Table 71: X3A, X3B connectors - Pinout

### 3.7.2.4 X4A connector - Pinout


X4A	Name	Function
	T-	Axis 1: Temperature sensor -
	T+	Axis 1: Temperature sensor +
	B- <sup>1)</sup>	Axis 1: Brake -
	B+ <sup>1)</sup>	Axis 1: Brake +

Table 72: X4A connector - Pinout

1) Wiring is not permitted to exceed a total length of 3 m.

## Danger!

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

## Danger!

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

## **Danger!**

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

## **Information:**

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

This must be taken into consideration when choosing the motor holding brake!

## **Danger!**

The connections for the motor temperature sensors and the motor holding brake are safely isolated circuits. These connections are therefore only permitted to be connected to devices or components with safe electrical isolation in accordance with IEC 60364-4-41 or EN 61800-5-1.

## **Caution!**

If B+ and B- are swapped when connecting the permanent magnet holding brakes, then the brakes cannot be opened! ACOPOSMulti inverter modules cannot determine if a holding brake is connected with reverse polarity!

## **Warning!**

Temperature sensors are only permitted to be connected to the X4A/T+ and X4A/T- connectors on an ACOPOSMulti module under the following conditions:

- There is no ACOPOSMulti plug-in module in SLOT1 on the ACOPOSMulti module with a temperature sensor connected to T+ and T-.

Otherwise, the temperature monitoring functions on the ACOPOSMulti module may become ineffective, which in extreme cases can cause the hardware (e.g. motors) connected to the ACOPOSMulti module to be destroyed!

3.7.2.5 X5A connector - Pinout


X5A	Pin	Name	Function
	1	PE	Axis 1: Protective ground conductor
	2	W	Axis 1: Motor connection W
	3	V	Axis 1: Motor connection V
	4	U	Axis 1: Motor connection U
Holding torque for the M8 nuts: 12 Nm			

Table 73: X5A connector - Pinout

Information:

B&R 8BCM motor cables must be used when cabling the motor connections.

Motor connections U, V, W - Cable installation




Figure 13: X5A - Cable installation

PE connection (1-wire) - Cable installation




Table 74: PE connection (1-wire) - Cable installation



PE connection (3-wire) - Cable installation




Table 75: PE connection (3-wire) - Cable installation

3.7.2.6 SafeMC module - Pinout

Figure	X11 (X12)	Pin	Name	Function
		1	U+	Encoder supply +12.5 V
		2	---	---
		3	---	---
		4	D	Data input
		5	T	Clock output
		6	COM (1)	Encoder supply 0 V
		7	---	---
		8	D\	Data input inverted
		9	T\	Clock output inverted

Information:

Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.

Information:

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

## 4 Installation

See ACOPOSMulti User's Manual MAACPM-ENG, "Installation" chapter.

## 5 Dimensioning

See ACOPOSMulti User's Manual MAACPM-ENG, "Dimensioning" chapter.

## 6 Wiring

### 6.1 General information

#### 6.1.1 EMC-compatible installation

##### General information

If the directives for electromagnetic compatibility of the installation are followed, the ACOPOSMulti drive system meets the EMC directive 2004/108/EC and low-voltage directives 2006/95/CE. It meets the requirements for harmonized EMC product standard IEC 61800-3:2004 for industry (second environment).

Additional EMC measures must be implemented by the machine or system manufacturer in the event that the product standard for the machine includes lower limit values or the machine conforms to the basic standard IEC 61000-6-4. Proof of conformity to required limit values must be provided by the manufacturer or distributor of the machine or system in accordance with the guidelines for implementing the EMC directive.

Additional EMC measures are required when operating ACOPOSMulti drive systems in a residential area or when connecting ACOPOSMulti drive systems to a low voltage system that supplies buildings in a residential area (first environment) without an intermediate transformer.

##### Installation notes

1. The control cabinet or system must be constructed properly.
2. To prevent the effects of disturbances, the following lines must be properly shielded:
  - Motor cables
  - Encoder cables
  - Control cables
  - Data cables
3. Inductive switching elements such as contactors or relays must be equipped with corresponding suppressor elements such as varistors, RC elements or damping diodes.
4. All electrical connections must be kept as short as possible.
5. Cable shields must be attached to designated shield terminals and the male connector housing.
6. Shielded cables with copper mesh or tinned copper mesh must be used. Twisting or extending the protective mesh using single conductors is not permitted.
7. Unused cable conductors must be grounded on both sides whenever possible.

## 6.1.2 Overview

### Passive power supply




Figure 14: Overview of ground/shield for ACOPOSMulti drive system (passive power supply)

- 1 Shielding connection via module-specific shield component set
- 2 Central grounding point
- 3 8B0M mounting plate, large-surface conductive connection with control cabinet mounting wall
- 4 One of the two COM connections (1, 2) on the X3 plug must be grounded to achieve a defined relationship between the signal ground and ground potential. Otherwise, the Safe Brake Control (SBC) safety function could fail if an error occurs (ground fault).
- 5 The power mains line inside the control cabinet must be kept as short as possible.
- 6 The connection between the line filter and power supply module is never shielded. To prevent disturbances on the power mains (⚡), they cannot be routed parallel to the connection between the line filter and power supply module.
- 7 An additional PE connection must be made between two 8BVE expansion modules in order to meet the conditions necessary for the ACOPOSMulti drive systems power mains connection on all 8B0M mounting plates that are connected using 8BVE expansion modules. This additional PE connection must be made with the same wire cross section as the PE wire (⚡) routed in the expansion cable (at least 2.5 mm<sup>2</sup> with protected wiring or 4 mm<sup>2</sup> with unprotected wiring).
- 9 B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.

## Active power supply




Figure 15: Overview of ground/shield for ACOPOSmulti drive system (active power supply)

- 1 Shielding connection via module-specific shield component set  
2 Central grounding point  
3 8B0M mounting plate, large-surface conductive connection with control cabinet mounting wall  
4 One of the two COM connections (1, 2) on the X3 plug must be grounded to achieve a defined relationship between the signal ground and ground potential.  
5 Otherwise, the Safe Brake Control (SBC) safety function could fail if an error occurs (ground fault).  
6 The power mains line inside the control cabinet must be kept as short as possible.  
7 The connection between the line filter and power supply module is never shielded. To prevent disturbances on the power mains (⚡), they cannot be routed parallel to the connection between the line filter and power supply module.  
8 An additional PE connection must be made between two 8BVE expansion modules in order to meet the conditions necessary for the ACOPOS multi drive systems power mains connection on all 8B0M mounting plates that are connected using 8BVE expansion modules. This additional PE connection must be made with the same wire cross section as the PE wire (⚡) routed in the expansion cable (at least 2.5 mm<sup>2</sup> with protected wiring or 4 mm<sup>2</sup> with unprotected wiring).  
9 B&R 8BCF EnDat 2.2 cables must be used when cabling the encoder interfaces.

## Danger!

One of the two COM connections (1, 2) on the X3 plug must be grounded to achieve a defined relationship between the signal ground and ground potential. Otherwise, the Safe Brake Control (SBC) safety function could fail if an error occurs (ground fault).

### Caution!

**No additional consumers/components are permitted to be connected between the 8BVF line filter, 8BVR regeneration choke and the 8BVP power supply module!**

## Warning!

**ACOPOSmulti drive systems are only permitted to be used with specially designed line filters. Third-party line filters are not permitted to be used, it is possible that they will be damaged!**

### 6.1.2.1 Additional PE connection on 8BVE expansion modules

When connecting two or more 8BVE expansion modules, the PE connection must always be made between the first and last 8BVE expansion module.

#### Connection between two 8BVE expansion modules




Figure 16: Connection between two 8BVE expansion modules

#### Connection between several 8BVE expansion modules




Figure 17: Connection between several 8BVE expansion modules

### 6.1.3 Connection diagrams for ground and shield connections

#### 6.1.3.1 8BVI inverter modules with SafeMC (single-axis modules)




Figure 18: Ground connections and shield connections for 8BVI inverter modules with SafeMC

1. Both trigger inputs are only filtered internally with approx. 50  $\mu$ s. Make sure the cable shield is grounded properly. The optional shield set 8SCS002.0000-00 can be used with this.
2. The cable shield must be attached to the shield connector.
3. All mounting brackets on ACOPOSmulti plug-in modules automatically come in contact with the housing when inserted in the module slot.  
By default, open module slots on ACOPOSmulti inverter modules with SafeMC are closed with the shielding set 8SCS005.0000-00.





Figure 19: Use of the shield set 8SCS005.0000-00

#### 4. Cable connection via DSUB plug:

The cable shield must be sufficiently connected using the designated clamp in the metallic or metal-plated DSUB plug housing. The DSUB plug fastening screws must be tightened.




Figure 20: Cable shielding in DSUB housing

#### Cable connection via terminals:

The cable shield must be connected to the ACOPOSMulti module housing using the optional shield set 8SCS002.0000-00.

#### Cable connection via RJ45 plug:

Grounding the cable shield as well provides an improvement in EMC properties. Grounding should take place on both sides, extensively and near to the connector. The optional shield set 8SCS002.0000-00, available from B&R, can be used on the ACOPOSMulti module.




Figure 21: Grounding the POWERLINK cable shielding

### Information:

**When cabling POWERLINK networks with B&R POWERLINK cables, no additional grounding of the cable shield is required to ensure resistance to disturbances in accordance with EN 61800-3!**

5. The cable shield can be connected with the ACOPOSMulti module housing using the optional shield sets available from B&R.
6. On the motor side, the cable shield of the motor line is connected to the motor housing using the motor plug and connected to ground via the machine.
7. On the motor side, the encoder cable shield must be connected to the motor housing using the encoder plug and connected to ground via the machine.

For external encoders, the cable shield of the encoder cable must be connected (on the encoder side) with the machine and therefore with ground using the encoder plug.

## 6.1.4 Insulation and high voltage testing

### 6.1.4.1 Insulation resistance testing in accordance with EN 60204

In accordance with EN 60204, the insulation resistance of electrical equipment is measured with 500 VDC between the main circuit conductors and the protective ground conductor system and is not permitted to be below a value of 1 MΩ. Testing individual sections of the system is permitted.

#### Motor connection of ACOPOSmulti inverter modules (X5A / X5B)

##### **Warning!**

**An insulation test is not permitted to be carried out on the motor connection (X5A / X5B) of ACOPOS-multi inverter modules because that would destroy the ACOPOSmulti inverter modules!**

**The motor cable must be removed from the motor connection (X5A / X5B) of the ACOPOSmulti inverter module before the insulation resistance is measured!**

#### B&R motors and B&R motor cables

In principle, an insulation resistance measurement can be carried out on B&R motor cables and B&R motors. However, the insulation resistance can be lower than 1 MΩ depending on the motor that is connected. The 50 kΩ minimum value required as specified in EN 60204, Section 18.3 is exceeded anyway.

##### **Warning!**

**An insulation test is not permitted to be carried out on the motor connection (X5A / X5B) of ACOPOS-multi inverter modules because that would destroy the ACOPOSmulti inverter modules!**

**The motor cable must be removed from the motor connection (X5A / X5B) of the ACOPOSmulti inverter module before the insulation resistance is measured!**

### 6.1.4.2 High voltage testing

In accordance with EN 60204, the electrical equipment must be able to withstand a test voltage connected between the conductors of all circuits and the protective ground conductor system for at least 1 s (exception: all circuits with a voltage < PELV voltage). The test voltage must be twice the rated voltage for the equipment, and at least 1000VAC (50 / 60 Hz). Components that cannot handle this test voltage must be disconnected before carrying out the high voltage test.

#### Motor connection of ACOPOSmulti inverter modules (X5A / X5B)

##### **Warning!**

**A high voltage test is not permitted to be carried out on the motor connection (X5A / X5B) of ACOPOS-multi inverter modules because that would destroy the ACOPOSmulti inverter modules!**

#### B&R motors and B&R motor cables

In principle, high voltage testing can be carried out on B&R motor cables and B&R motors. Depending on the size of the motor and length of the motor cable, increased measurement currents can occur because of capacitive coupling.

##### **Warning!**

**A high voltage test is not permitted to be carried out on the motor connection (X5A / X5B) of ACOPOS-multi inverter modules because that would destroy the ACOPOSmulti inverter modules!**

**The motor cable must be removed from the motor connection (X5A / X5B) of the ACOPOSmulti inverter module before the high voltage measurement is made!**

### 6.1.4.3 Typical procedure

#### Isolation test

- a) Remove the motor cable from the X5A / X5B connection of the ACOPOSmulti inverter module.
- b) Perform the insulation test on the X1 power mains connection (mains side) of the ACOPOSmulti line filter.

- c) Perform the insulation test on the B&R motor.

### High voltage testing

- a) Remove the connection cable between the X2 connection of the ACOPOSMulti line filter and the U1 / V1 / W1 connections of the ACOPOSMulti regeneration choke on the X2 connection of the ACOPOSMulti line filter.
- b) Remove the connection cable between the X5A connection of the ACOPOSMulti power supply module and the U2 / V2 / W2 connections of the ACOPOSMulti regeneration choke on the X5A connection of the ACOPOSMulti power supply module.
- c) Perform the high voltage test on the U1 / V1 / W1 connections of the ACOPOSMulti regeneration choke.
- d) Remove the motor cable from the X5A / X5B connection of the ACOPOSMulti inverter module.
- e) Perform the high voltage test on the B&R motor.

## Chapter 3 • System features

### 1 SafeMC Module

#### 1.1 General Information

The SafeMC module is an integrated part of the safe ACOPOSmulti with SafeMC.

One SafeMC module is integrated for each safe axis in the safe drive; this means that one SafeMC module is built into a safe single-axis module, or two SafeMC modules in a safe double-axis module!

One SafeMC module corresponds with one safe node and performs the safety functions on the drive.

#### Information:

**A safe double-axis module contains two SafeMC modules. This corresponds with one POWERLINK node and two safe nodes. This should be taken into consideration when designing the system.**

#### Information:

**The user is not able to connect or disconnect the SafeMC module! This means that a standard ACOPOS-multi axis cannot be retrofitted!**

#### 1.2 Safety functions

The following safety functions are supported by the SafeMC module:

Safety function	Starting safety lease	in re-	EN ISO 13849-1	EN 61508/EN 62061	Safe encoder evaluation required
Safe Torque Off (STO)	R 1.3		Pl e	SIL 3	No
Safe Torque Off One Channel (STO1)	R 1.3		Pl d	SIL 2	No
Safe Operation Stop (SOS)	R 1.3		Pl d	SIL 2	Yes
Safe Stop 1 (SS1)	R 1.3		PL e (time-monitored) Pl d	SIL 3 (time-monitored) SIL 2	No (time-monitored) Yes
Safe Stop 2 (SS2)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Speed (SLS)	R 1.3		Pl d	SIL 2	Yes
Safe Maximum Speed (SMS)	R 1.3		Pl d	SIL 2	Yes
Safe Direction (SDI)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Increment (SLI)	R 1.3		Pl d	SIL 2	Yes
Safe Brake Control (SBC)	R 1.3		Pl d	SIL 2	No
Safely Limited Position (SLP)	R 1.4		Pl d	SIL 2	Yes
Safe Maximum Position (SMP)	R 1.4		Pl d	SIL 2	Yes
Safe Homing	R 1.4		Pl d	SIL 2	Yes

Table 76: Safety functions and corresponding safety levels

Details about the individual safety functions can be found in section 4 "Safety technology" on page 138!

### 2 Integrated safety technology

Seamless integration of safety technology in the standard application is a reality with B&R's safety technology products. This allows fixed wiring to be replaced by safe data transfer via the existing machine bus system. Flexibly configured or programmed safety behavior can be adapted optimally to various safety situations. Complete diagnostics of safety components via the machine bus system provide detailed information about the status of the machine.

Insufficient safety regarding manipulation and the inadequacy of current safety solutions allow dangerous behavior when operating the machine. New safety technology possibilities provide considerable potential for improvement here. While working to improve the safety of machines, safety technology guidelines are continually updated according to the current technological situation. Consequently, improvements become mandatory. B&R's integrated safety technology is state-of-the-art and meets current and expected future demands on safety components.

Safety shut-offs do not always have to involve a full machine shutdown. When opening a protective cover, it is often sufficient to reduce the speed. Smart, safe reactions to various situations provide safety without having to stop the production process. The machine does not need to be emptied and set up again, and manipulation is not necessary. This results in real advantages for the user that can be implemented with programmable safety behavior.

Integrated Safety Technology products can be used in safety applications up to:

- EN ISO 13849, PL<sub>e</sub> / CAT 4
- IEC 62061, SIL 3
- IEC 61508, SIL 3
- IEC 61511, SIL 3

The actual level of safety achieved depends on the respective safety function and the components being used!

A cycle time of 200 µs for SIL 3 safety applications is a new feature for safety communication. Response times decrease by a factor of 10, and the advantages of hard-wired solutions are combined with the possibilities of modern, integrated and intelligent safety bus technology. POWERLINK and openSAFETY accomplish this all using standard Ethernet mechanisms. This allows these protocols to be combined with all conventional and, more importantly, newer Ethernet profiles. openSAFETY is the fastest and most flexible real-time safety bus system on the market.

The reduction to one cable allows for transfer of safe data using the existing infrastructure. Additional cabling of a safe line is not necessary. Transparent and non-reactive access of secure data is an integral part of functional machine control. Complicated communication mechanisms between safe and standard applications are things of the past. Smart-safe reactions instead of hard machine stops provide advantages for processes, help to avoid manipulation and increase the value of machines.




Figure 22: Integrated Safety Technology - Topology

### 3 System requirements

Integrated safety technology requires use of the following software and hardware:

- POWERLINK V2
- Automation Studio V 3.0.80 or higher
- Automation Runtime V 3.00 or higher
- ACP10 software V 2.180 or higher (for Safety Release R 1.3 ACOPOSMulti with SafeMC EnDat 2.2)
- ACP10 software V 2.250 or higher (from Safety Release R 1.4 ACOPOSMulti with SafeMC EnDat 2.2)
- SG4 CPUs

## 4 System limits

The following limitations exist when using SafeMC modules:

- One SafeMC module corresponds with one safe node. One SafeMC module is integrated in a single-axis inverter module, which means **one safe node**. Two SafeMC modules are integrated in a dual-axis inverter module, which means **two safe nodes**. Additionally, each inverter module corresponds with **one POWERLINK node**.
- A SafeMC module can only safely communicate with one (1) SafeLOGIC device with SafeMC support (see SafeLOGIC data sheets X20SL80xx at [www.br-automation.com](http://www.br-automation.com)). It is not possible for a SafeMC module to safely communicate with several SafeLOGIC modules or with other safe modules (other SafeIO, SafeMC, etc.).
- The output side payload size of the SafeLOGIC is limited to 1490 bytes. Among other things, this limitation reduces the resulting number of usable SafeIO or SafeMC modules during SafeLOGIC to SafeLOGIC communication.
- The safe state is always initiated in the B&R safety modules by shutting off the output. This property is constructively implemented in the modules and cannot be changed.  
This is particularly important for SafeMC modules because the safe state cuts off the torque on the motor!

### Danger!

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!  
If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!**

## 5 Safe response time

The safe response time is the time between the arrival of the signal on the input channel and the output of the cutoff signal on the output.




Figure 23: Total lag time

As illustrated in the figure, the safe response time in the B&R system is composed of the following partial response times:

- Signal processing on the safe B&R input module
- Data runtime on the bus (Input → SafeLOGIC)
- Data runtime on the bus (SafeLOGIC → Output)
- Signal processing on the safe B&R output module

## Danger!

The following sections are dedicated exclusively to the safe response time in the B&R system. To observe the complete safety response time, the user must include signal processing in the sensor as well as the time until the actuator comes to a standstill.

Be sure to validate the total lag time on the system!

### 5.1 Signal processing on the safe B&R input module

For signal processing on the safe B&R input module, the following values must be added:

- The filter value of the switch-off filter
- 5000 µs when "Pulse\_Mode = external" is configured
- 400 ms when using safe analog input channels or safe temperature inputs
- "Timebase" parameter + I/O update time for safe counter channels

### 5.2 Data runtime on the bus

The following relationship must be taken into consideration for the data runtime on the bus:

- The time needed to transfer data from the input to the SafeLOGIC controller or to the output depends on the sum of the cycle times and CPU copy times in effect on the transfer line.
- The POWERLINK MN (managing node, standard CPU) settings are important for the actual timing on the bus, but they cannot be used from a safety standpoint because the values can be changed at any time in the course of modifications made outside of the safety application.
- In the SafeLOGIC controller, data runtimes are monitored on the bus using openSAFETY services. The time needed to process the application on the SafeLOGIC controller is accounted for in this test (system dependent). Monitoring is defined in SafeDESIGNER using the parameters in the "Safety\_Response\_Time" parameter group.

#### Information:

The safety components located in this network segment could be cut off by the SafeLOGIC controller if modified parameters in POWERLINK MN alter the data runtimes on the bus so that they lie outside of the SafeDESIGNER parameters defined in the parameter group "Safety\_Response\_Time".

#### Information:

The safety components located in this network segment could be cut off by the SafeLOGIC controller if EMC disturbances cause data failures that lie outside of the SafeDESIGNER parameters defined in the parameter group "Safety\_Response\_Time".

### 5.3 Signal processing on the safe B&R output module

The duration of signal processing on the safe B&R output module amounts to the following:

- Max. 800 µs with FET (field effect transistor) technology
- Max. 50 ms with relay channels

### 5.4 Signal processing on the safe B&R SafeMC module

The duration of signal processing in the event of a function request is 800 µs in the SafeMC module.

However, in addition to the signal processing, the duration of the communication between the POWERLINK interface and the SafeMC module must also be accounted for. In the worst case, this can be 1600 µs.

#### Safe error response time

In addition to the signal processing duration in functional situations, the safe error response time is also relevant when setting up the safety measures.






Figure 24: Safe error response time

The safe error response time comes into play if the currently monitored limit is exceeded while a safety function is activated on the SafeMC module.

The safe error response time includes:

- Error detection time (encoder evaluation + processing time on the SafeMC module)
- Switching delay

## Danger!

In the worst case, the safe error response time on the SafeMC module is 7200 μs.

When setting up the safety measures, it must be assumed that the drive will accelerate to its maximum within this amount of time.

The speed resulting from this must be considered together with the speed when the safety function is violated in order to determine the maximum possible speed at the time of spin-out!

Furthermore, if an error occurs, the error response time must be used when determining the remaining distance, in order to determine the maximum distance by which a monitored position limit can be exceeded!

## 5.5 Calculating the safe response time

The safe response time can be calculated using the response time calculator. Dieser lässt sich über folgenden Pfad "Projekt" → "Reaktionszeitrechner" öffnen.

**Response Time Calculator**

**Signal Input**  
Module: SL1.SM3  
Channel: SafeDigitalInput04

**SafeDESIGNER Parameters**  
Manual configuration: no  
Synchronous Network Only: yes  
X2X Cycle Time: 200 - 5.000 µs  
POWERLINK Cycle Time: 200 - 5.000 µs  
CPU Cross Link Task Cycle Time: 0 - 5.000 µs  
Worst Case Response Time: 50.000 µs  
Filter Off: 0 µs  
Pulse Mode: internal

**SafeLOGIC**  
SafeDESIGNER Parameters  
SafeLOGIC cycle time: 2.000 µs

**Signal Output**  
Module: SL1.SM4

**SafeDESIGNER Parameters**  
Manual configuration: no  
Synchronous Network Only: yes  
X2X Cycle Time: 200 - 5.000 µs  
POWERLINK Cycle Time: 200 - 5.000 µs  
CPU Cross Link Task Cycle Time: 0 - 5.000 µs  
Worst Case Response Time: 50.000 µs

**Results**  
Tolerated Network Packages Loss: 1  
Over All Worst Case Response Time: 67.497 µs

**Info**

Help Cancel Update

Figure 25: Response time calculator

This tool takes the values set in SafeDESIGNER and uses them to calculate the entire response time and the tolerated packet loss on the network.

The modules relevant for the calculation can be selected in the 'Signal input' and 'Signal output' section. The values that are set accordingly are automatically shown in SafeDESIGNER and the entire response time is calculated.

If the values set in SafeDESIGNER for the response time calculation result in a longer maximum response time than is set in SafeDESIGNER, the calculation is canceled and the error is shown in the "Info" field.

SafeDESIGNER parameters can also be changed with the dialog box window open. The values are applied either after changing which inputs/outputs are selected or after updating using the 'Refresh' button.

Input fields:

Input field	Value	Description	Corresponding SafeDESIGNER parameters
Only synchronous networks	Yes	All networks involved in data transfer are synchronous.	Synchronous_Network_Only = Yes
	No	At least one of the networks involved in data transfer is not synchronous.	Synchronous_Network_Only = No
X2X cycle time	200–30,000 µs	X2X cycle time entry for checking the data runtime on the SafeLOGIC controller.	Min_X2X_CycleTime_us Max_X2X_CycleTime_us
POWERLINK cycle time	200–30,000 µs	POWERLINK cycle time entry for checking the data runtime on the SafeLOGIC controller.	Min_Powerlink_CycleTime_us - Max_Powerlink_CycleTime_us
CPU cross-communication cycle time	0–30,000 µs	Cycle time entry of the CPU cross link task for checking the data runtime in the SafeLOGIC controller. See the table below.	Min_CPU_CrossLinkTask_CycleTime_us - Max_CPU_CrossLinkTask_CycleTime_us
Response time	3000-500,000 µs	Limit value for monitoring the data runtime on the bus	Worst_Case_Response_Time_us
Filter off	0	A switch-off filter is not used on the input module.	Filter_Off_us
	1-500,000 µs	A switch-off filter is used on the input module.	
External pulse	External	"External clock signals" mode is used on the input module.	Pulse_Mode = external
	Internal	"External clock signals" mode is used on the input module.	Pulse_Mode = internal
	None	"External clock signals" mode is not used on the input module.	Pulse_Mode = no clock
SafeLOGIC cycle time	800-20,000 µs	SafeLOGIC cycle time parameter "Cycle_Time_us" from SafeDESIGNER in µs.	Cycle_Time_us

Table 77: Fields in the "Response time calculator"

If the SafeLOGIC controller is on a different POWERLINK interface than the SafeIO modules, then the data must be copied to the CPU on its way from the SafeIO modules the SafeLOGIC controller. An internal system task (CPU\_CrossLinkTask) handles this copy procedure. The cycle time of this task is automatically assigned by the system.

It is important to know the configuration possibilities of the CPU\_CrossLinkTask for monitoring the runtime of the SafeLOGIC controller:

Min. CPU Cross Link Task	Max. CPU Cross Link Task	Description
Value > 0	Value > 0	Data is always copied via the CPU. Application situations where data is not copied are detected by the SafeLOGIC controller and registered as errors due to the very short runtime.
Value > 0	0	Not a valid combination.
No	Value > 0	Runtime monitoring in the SafeLOGIC controller accepts application situations where data is copied as well as application situations where it is not.
0	0	Data is never copied via the CPU. Application situations where data is copied are detected by the SafeLOGIC controller and registered as errors due to the very long runtime.

Table 78: Meaning of the min./max. CPU parameters

Output fields:

Output field	Value	Description	Corresponding SafeDESIGNER parameters
Package loss on the network	0-10	Number of lost packets that are tolerated without switching off the safety application.	-
Total response time	--	Resulting safe response time in the B&R system.	-

Table 79: Output fields in the "Response time calculator"

## 5.6 Parameters for the safe response time in SafeDESIGNER

Generally, the parameters for safe response time are configured the same for all stations involved in the application. This is why these parameters are configured for the SafeLOGIC controller in the SafeDESIGNER.

For application situations in which individual safety functions require optimum response time behavior, the parameters for safe response time can be configured individually on the respective module.

The parameters and their limits for the SafeMC module are described below for each specific module.

Parameters	Description	Default value	Units
Manual_Configuration	Generally, the parameters for safe response time are configured the same for all stations involved in the application. This is why these parameters are configured for the SafeLOGIC controller in the SafeDESIGNER. For application situations in which individual safety functions require optimum response time behavior, the parameters for safe response time can be configured individually on the respective module.	No	-
Synchronous_Network_Only	This parameter determines the synchronization properties of the underlying network.	Yes	-
Max_X2X_CycleTime_us	This parameter corresponds with the maximum duration of communication between the SafeMC module and the POWERLINK interface. • Permissible values: 200–30000 µs	1600	µs
Max_Powerlink_CycleTime_us	This parameter specifies the maximum POWERLINK cycle time used to calculate the safe response time. • Permissible values: 200–30000 µs	5000	µs
Max_CPU_CrossLink-Task_CycleTime_us	This parameter specifies the maximum cycle time for the copy task on the CPU used to calculate the safe response time. A value of 0 means that a copy task was not included for the response time. • Permissible values: 0–30000 µs	5000	µs
Min_X2X_CycleTime_us	This parameter corresponds with the minimum duration of communication between the SafeMC module and the POWERLINK interface. • Permissible values: 200–30000 µs	600	µs
Min_Powerlink_CycleTime_us	This parameter specifies the minimum POWERLINK cycle time used to calculate the safe response time. • Permissible values: 200–30000 µs	200	µs

Table 80: Parameters for the safe response time in SafeDESIGNER

Parameters	Description	Default value	Units
Min_CPU_CrossLinkTask_CycleTime_us	This parameter specifies the minimum cycle time for the copy task on the CPU used to calculate the safe response time. A value of 0 means that configurations without copy tasks were included for the response time. <ul style="list-style-type: none"> <li>Permissible values: 0–30000 µs</li> </ul>	0	µs
Worst_Case_Response_Time_us	This parameter specifies the limit value for monitoring the safe response time. <ul style="list-style-type: none"> <li>Permissible values: 3000 - 500000 µs</li> </ul>	50000	µs

Table 80: Parameters for the safe response time in SafeDESIGNER

## 5.7 Minimum signal lengths

The "Worst\_Case\_Response\_Time\_us" parameter in SafeDESIGNER influences the maximum number of data packets that can fail without triggering a safety response. This parameter therefore acts like a switch-off filter. If several data packets are lost within the tolerated amount, safety signals may not be detected if their low phase is shorter than the configured "Worst\_Case\_Response\_Time\_us".

### Danger!

**Lost signals can result in serious safety errors. Check all signals to determine the smallest possible pulse length and make sure that it is larger than the value configured for the "Worst\_Case\_Response\_Time\_us".**

Possible solution:

- The switch-on filter can be used to extend the low phase of a signal on the input module.
- Low phases of signals from the SafeLOGIC controller can be lengthened with restart inhibit functions or timer function blocks.

## 6 Detection of errors within the module


The red "SE" LED makes it possible to evaluate the following error states:

- Module error, e.g. defective RAM, defective CPU, etc.
- Overtemperature/Undertemperature
- Overvoltage/Undervoltage
- Incompatible firmware version
- Incorrect configuration

Errors that occur within the module are detected with the DC (Diagnostic Coverage) specified in the respective safety function in accordance with the requirements of the standards listed in the certificate. After this occurs, the module reverts back to a safe state within the safe error response time.

The internal module tests needed for this are only performed, however, if the module's firmware has been booted and the module is in either the preoperational state or the operational state. If this state is not reached, e.g. if the module in the application has not been configured, then the module will remain in the boot state.

The boot state is clearly indicated using the following SE-LED blink sequences:

LED	Color	Status
SE	Red	 <p>1s</p> <p>Boot phase or defective processor</p> <p>Boot phase Firmware error</p>

### Danger!

**Operating the safety module in boot mode is not permitted.**

## Chapter 4 • Safety technology

### 1 Integrated safety technology in the ACOPOSmulti with SafeMC

#### 1.1 General Information

Implementing the safety functions integrated in the drive opens up whole new possibilities for guaranteeing the safety of people while maintaining maximum availability of the machine.

The inverter modules with integrated safety technology - "ACOPOSmulti with SafeMC" - round off the B&R safety concept and make it possible to design an entire safety application using state-of-the-art products from B&R.

#### Information:

**Due to the internal cycle time of 800 µs on the SafeMC module, the POWERLINK cycle time on the ACOPOSmulti with SafeMC must be set to 800 µs or a whole-number multiple of 800 µs.**

The products are intended for use worldwide, in industries such as:

- Automotive industry
- Electrical industry
- Beverages industry
- Food stuffs industry
- Glass & cement building materials industry
- Handling robotics industry
- Metal industry
- Packaging Industry
- Paper printing industry
- Pharmaceutical industry
- Plastics industry
- Textile industry
- Transport systems
- Wood handling and processing industry

This list only shows the currently typical areas of use, and is not a complete list.

#### Danger!

**B&R drive systems and servo motors have been designed, developed and manufactured for conventional use in industrial environments. They were not designed, developed and manufactured for any use involving serious risks or hazards that could lead to death, injury, serious physical damage or loss of any kind without the implementation of exceptionally stringent safety precautions.**

**In particular, such risks and hazards include the use of these devices to monitor nuclear reactions in nuclear power plants, their use in flight control or flight safety systems as well as in the control of mass transportation systems, medical life support systems or weapons systems.**

#### 1.2 Safe power transmission

The safe power transmission consists mainly of a safe inverter module, an encoder cable, a motor cable and a motor with a position encoder that meets the requirements for use in integrated safety technology.




Figure 26: Safe power transmission

### Safe inverter module

The safe inverter module consists basically of a standard ACOPOSMulti inverter with an additional safe monitoring module - the SafeMC module - per axis.

This means that one safe single-axis module contains one SafeMC module and is equal to one POWERLINK node and one safe node.

On the other hand, one two-axis module contains two SafeMC modules and is therefore equal to one POWERLINK node and two safe nodes!

Just like before, actual control is via the standard application and not safety-oriented. However, the addition of the SafeMC module provides safety-oriented monitoring of specific limits based on the requirements. If these limits are exceeded, the SafeMC module activates safe pulse disabling and the motor holding brake output is switched to 0 V.

### Motor with safe position encoder

In order to be able to use all safety functions, an EnDat 2.2 functional safety encoder from Heidenhain absolutely must be used! With standard EnDat 2.2 encoders, only safety functions STO, SBC, and SS1 are available with time monitoring!

#### B&R safety motors (encoder option S0/S1)

For these motors, the EnDat 2.2 functional safety encoder is installed strictly according to Heidenhain's installation guidelines.

In this way, encoder slippage or encoder shaft breakage can be ruled out as a mechanical error.

### Danger!

**Encoders used with B&R safety motors (encoder option S0/S1) are only allowed to be replaced by B&R!**

**If the encoder is replaced but not by B&R, mechanical errors such as encoder slippage or shaft breakage can no longer subsequently be ruled out.**

#### B&R standard motors (encoder option D0/D1)

For these motors, the SafeMC module can sufficiently detect encoder slippage or encoder shaft breakage in some applications. To do this, the application must meet all requirements specified in section 2.3.2 "Encoder mounting without proof of fatigue strength - Safe lag error monitoring" on page 145, and all limitations listed in this section must be taken into consideration. Under these circumstances, B&R standard motors can also be used for safety applications!

### Encoder cables

The encoder cable is connected to the SafeMC module with a DSUB plug. Please note the instructions in the "Cable connection via DSUB plug" section under "6.1.3.1 Wiring / General information / Connection diagrams for ground and shield connections / 8BVI inverter modules with SafeMC (single-axis modules)" on page 124".

**Information:**

**Only 8BCF EnDat 2.2 cables from B&R may be used to connect the encoder interfaces.**

**Motor cable**

The motor cable is connected to the safe inverter module using the male motor connector.

**Information:**

**Only 8BCM motor cables from B&R may be used to cable the motor connections!**

**1.3 The closed-circuit principle**

Integrated safety technology in the ACOPOSmulti with SafeMC uses the closed-circuit principle. When there is a logical 0 at a controller input or the current is interrupted, the corresponding safety function or error response is executed.

The closed-circuit principle ensures that the system tends toward the safest possible result in case of failure.

This method is an example of the general principle referred to in engineering as a "fail-safe".

This is why the only safe function is the cut-off for the drive's energy and torque. The consequences that are described below are a result of the fail safe principle.

**Danger!**

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!  
If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!**

When there is a failure, torque and force are removed from the drive, and there are no electrical pulses transmitted to the motor. This is referred to as activating safe pulse disabling.

**Information:****Safe pulse disabling**

**Torque and power are switched off on the drive. No electrical pulses are transmitted from the drive to the motor.**

If the drive is in motion at the time of the error, then it will spin out. The residual movement and remaining time must be considered for the worst-case scenario when making all of the calculations for the machine's safety circuit.

**Danger!**

**An error can result in forward movement followed by spin-out. When estimating the distance and time that results from the forward movement / spin-out, the worst case scenario (i.e. the currently maximum possible speed) must always be assumed.**

**The maximum possible drive speed is calculated from the maximum possible acceleration and the error response time, plus the actively monitored speed limit.**



## 2 Principle - Implementing the safety functions

### **Danger!**

The C standards applicable to applications must be adhered to!

### **Danger!**

Note that a brief forward movement may occur in the event of an error. The maximum angle of rotation of the motor shaft  $\varphi$  during this forward movement depends on the motor being used.

For permanently excited synchronous motors,  $\varphi = 360^\circ/2p$  (for B&R standard motors,  $p=3$  so the angle is  $60^\circ$ ). For three-phase induction motors, there is a relatively small angle of rotation (between  $5^\circ$  and  $15^\circ$ ).

## 2.1 Safe pulse disabling

Safe pulse disabling is set up the same way in the ACOPOSmulti with SafeMC EnDat 2.2 modules and ACOPOS-multi with SafeMC SinCos modules as in standard ACOPOSmulti inverter modules.

The difference is that no external wiring is required. Instead, pulse disabling is activated internally by the SafeMC module. The function is controlled via two channels and tested by the SafeMC module.




Figure 27: Control of safe pulse disabling

### Information:

Safe pulse disabling of the ACOPOSmulti is controlled directly by the SafeMC module. External wiring is not possible. This also means it is not possible to make wiring errors!

## 2.2 Safe motor holding brake output




Figure 28: Connection of safe motor holding brake output

A wiring error that causes the output B+ to be shorted to 24 V, causes the actuator to remain turned on despite the acknowledgeable functional fail safe state being activated.

Error description	Effects	Safety function according to category 3 / SIL 2 / PL d maintained?
Short-circuit: B+ and B-	Error not detected by module-internal testing. However, this is not critical because the motor holding brake is not released in this case (remains engaged).	YES, The motor holding brake output remains in the safe state.
Short-circuit between 24 V and B+	Error detected by module-internal testing. The error detection causes the SafeMC module to change to the acknowledgeable error state. Safe pulse disabling is activated, the brake always remains open due to the short circuit to 24 V! <b>This is a critical error and therefore must be prevented through wiring.</b>	NO, Wiring error must be prevented through appropriate wiring!
Short-circuit between ground and B+	Error not detected by module-internal testing. However, this is not critical because the motor holding brake is not released in this case (remains engaged).	YES, The motor holding brake output remains in the safe state.

Table 81: Wiring error in safe motor holding brake output

**Danger!**

A short circuit between SBC output B+ and 24 V triggers the Functional Fail Safe state (i.e. safe pulse disabling is activated). However, the brake always remains open (disengaged) because of the short circuit to 24 V!

This can lead to dangerous situations, because the motor holding brake is not able to stop a spin-out movement or prevent a hanging load from dropping uncontrollably.

Appropriate wiring measures must be implemented to ensure that the SBC output B+ is not shorted to 24V!

**Danger!**

The SBC output

- is not permitted to be wired across multiple modules!
- is not permitted to be wired as an open emitter!
- is not permitted to be wired as an open collector!

**Danger!**

Only an output voltage of  $\leq 5$  V can be ensured for the safe motor holding brake output when shut off. When selecting the motor holding brake, the user must ensure that the required braking torque is reached at a pending voltage of 5 V.

**Information:**

The transistors of the SBC output stage are tested cyclically. When the output channels are active, this test emits low pulses on the output with a maximum length of 600  $\mu$ s.

Make sure to take this into consideration when selecting the respective motor holding brake.

**2.3 EnDat 2.2 functional safety encoder**

The concept of the integrated safety functions in the ACOPOSmulti with SafeMC includes the use of a Heidenhain EnDat 2.2 functional safety encoder.

The EnDat 2.2 safety encoder must be installed in such a manner as to eliminate the possibility of slippage or encoder shaft breakage. Please follow the installation guidelines from Heidenhain for doing this.

In some applications, the SafeMC module is able to sufficiently detect encoder slippage or encoder shaft breakage. Mechanical fault prevention is not necessary for these applications.

**Danger!**

Some safety-related measurement devices can only be used in the close control loop. This limitation is indicated in the technical data for the respective measurement device.

These sort of safety-related measurement devices can only be used in combination with ACOPOSmulti with SafeMC!

**Information:**

If safety functions are used that require a safe speed and/or position, then a Heidenhain EnDat 2.2 functional safety encoder must be used. Otherwise, the process data from the encoder will be set to the state, "Functional Fail Safe".

**2.3.1 Encoder mounting with proof of fatigue strength****Danger!**

To ensure safe operation up to and including the motor shaft, any errors on the connection between the motor shaft and encoder must be identified and prevented.

There are specific guidelines that must be followed when installing an EnDat 2.2 Functional Safety encoder from the company Heidenhain.

The motor manufacturer must ensure that these specifications are adhered to.

## Danger!

The frictional connection between the cone-shaped shaft of the rotor and EnDat measurement device is dimensioned for maximum rotor acceleration in accordance with the Heidenhain installation instructions. This acceleration value must not be exceeded in the worst case. The maximum acceleration is monitored on the SafeMC module and can be configured using the parameter "*Maximum acceleration*".

## Danger!

If the terminal screw for the coupling ring comes loose on installed measurement devices, then the form-fit pin will be the only thing holding the encoder to the motor housing. A movement in accordance with the installation tolerances is possible. The encoder is not able to record this movement. This remnant movement must be accounted for in the safety functions.

### 2.3.2 Encoder mounting without proof of fatigue strength - Safe lag error monitoring

In some applications, the proof of fatigue strength is not required for the encoder's mechanical mounting when safe "Encoder Monitoring" is enabled in the SafeMC module.

The following safety-related restrictions must be taken into consideration!

## Danger!

Only safety functions for which a safe absolute position is not being monitored can be used (STO, SBC, SOS, SS1, SS2, SLS, SMS, SLI, SDI, SBT (only available for ACOPOSmulti with SafeMC SinCos), SafeSPEED).

## Danger!

The application must meet the following requirements for safety-oriented monitoring of the encoder-motor connection:

- Encoder connection monitoring can only be used for encoders that are integrated in a position control.
- Encoder connection monitoring can only be used for drive systems with synchronous motors.
- The encoder must be protected against shearing in standstill (e.g. with encasement in the motor housing)!
- Monitoring for position lag errors, speed errors and set position change (Alive Testing) must be enabled in the safe application and sufficiently strict limits must be monitored!
- The safety functions SafePOSITION, SLP and/or SMP must not be used!
- Safe monitoring can only be guaranteed when closed loop control is enabled.

## Danger!

- An electrical offset of  $<90^\circ$  will not be detected sufficiently.
- There is no way to monitor the encoder connection if the set value remains constant.
- An encoder connection error or an error in the encoder evaluation is always assumed as the cause for the lag error.
- The error reaction in the standard application to a position lag error or speed error is disabled by the SafeMC module (overridden). When lag errors occur, only the error responses STO or STO1 are possible with induction stop.

## Danger!

Note that a brief forward movement may occur in the event of an error. The maximum angle of rotation of the motor shaft  $\varphi$  during this forward movement depends on the motor being used.

For permanently excited synchronous motors,  $\varphi = 360^\circ/2p$  (for B&R standard motors,  $p=3$  so the angle is  $60^\circ$ ). For three-phase induction motors, there is a relatively small angle of rotation (between  $5^\circ$  and  $15^\circ$ ).

The maximum speed of the forward movement can be calculated as follows:

$$n_{Jolt} = \frac{1}{2\pi} \sqrt{\frac{6a_{max}}{p_z}} \left[ \frac{U}{s} \right]$$

with the maximum acceleration  $a_{max} = \frac{M_{max}}{J} \left[ \frac{rad}{s^2} \right]$  and the number of motor pole pairs  $p_z$

## Danger!


When viewing the worst-case scenario for a safety function, the highest value of the maximum speed of the forward movement  $n_{Jolt}$  and the speed must be used as maximum speed due to the maximum error response time  $n_{T_{worstcase}}$ .

$$n_{max} = \max(n_{Jolt}, n_{T_{worstcase}}) = \max\left(\frac{1}{2\pi} \sqrt{\frac{6a_{max}}{p_z}}, \frac{T_{worstcase}}{2\pi} \cdot a_{max}\right)$$

with the maximum error response time  $T_{worstcase} = 7.2[ms]$

The maximum speed  $n_{max}$  resulting from this must be considered together with the speed when the safety function  $n_{LIM}$  is violated in order to determine the maximum possible speed  $n_{worstcase}$  at the time of spin-out!

$$n_{worstcase} = n_{LIM} + n_{max}$$



## Information:

In order to check the plausibility of the set value after each power-on, the axis must be moved by at least twice the configured lag error limit before the first request of a safety function, which requires a safe encoder evaluation, or at least within 15min.

If this is not done, then the module changes to the error state "Functional Fail Safe", which must be confirmed. The function block output  $S\_NotErrFUNC$  is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## Information:

A 24h timeout begins after successfully checking the plausibility of the set value.

The timeout is reset any time the set position changes by more than twice the position lag error tolerance.

If the set position does not change during 24h of continuous controller operation, then the module changes to the acknowledgeable error state "Functional Fail Safe". The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous.

The following parameters are relevant for safe monitoring of the encoder / motor shaft connection (Encoder Monitoring):

Parameter	Unit	Description	Default value
Encoder Unit System			
Maximum acceleration [rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	[rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	Maximum permissible encoder acceleration	100000
Encoder Monitoring			
Encoder Position Monitoring	Activated/ Deactivated	Activates/deactivates the monitoring of the position lag error generated on the SafeMC module.	Activated
Encoder Speed Monitoring	Activated/ Deactivated	Activates/deactivates the monitoring of the speed error generated on the SafeMC module.	Activated
Set position alive testing	Activated/ Deactivated	Activates/deactivates the monitor that detects whether the set position generated on the ACOPOSMulti is frozen.	Activated
Encoder Monitoring Tolerances			
Encoder Monitoring Position Tolerance	[units]	Position lag error tolerance for shaft breakage monitoring	0
Encoder Monitoring Speed Tolerance	[units/s]	Speed error tolerance for encoder monitoring	0

Table 82: Encoder Monitoring safety function parameters

## Danger!

The machine manufacturer is responsible for deciding whether or not the application is suited for safe encoder connection monitoring if there is no mechanical mechanism for detecting encoder shaft breakage.

The machine manufacturer is responsible for ensuring that the safe encoder monitoring has been configured correctly!

## Danger!

Encoder connection monitoring can only be used in a safety-related capacity if the aforementioned requirements for the application have been fulfilled!

### 2.3.2.1 Activation of monitoring

The following parameters must be set to "Activated" in SafeDESIGNER in order to enable safe encoder connection monitoring:

- *Encoder Position Monitoring* = Activated
- *Encoder Speed Monitoring* = Activated
- *Set position alive testing* = Activated

## Danger!

In order to ensure safety-related monitoring of the encoder/motor connection, all three parameters "*Encoder Position Monitoring*", "*Encoder Speed Monitoring*" and "*Set position alive testing*" must be set to "Activated"!

If this is not the case, then the monitoring system cannot be used for safety purposes and a mechanical solution for detecting errors must be implemented!

### 2.3.2.2 Configuration rule for position lag error limit

The position lag error limit must be set large enough to ensure availability. This can be done by first measuring the position lag error under the highest influence of disturbance variables and at maximum acceleration and then setting the position lag error limit accordingly higher.

**Danger!**

The position lag error limit cannot be higher than half of one pole length!

When the safety function is enabled, the size of the position lag error limit value  $ds_{lim}$  affects how long it will take to look for errors and therefore also the error response time and estimation of the remaining distance.

This must be accounted for by the machine manufacturer in the risk analysis!

**Information:**

Due to rounding errors, a reserve of 1 unit should be accounted for with the parameter "Encoder Monitoring Position Tolerance".

**2.3.2.3 Configuration rule for speed error limit**

The speed error limit must be set large enough to ensure availability.

This can be done by first measuring the speed error under the highest influence of disturbance variables and set values (e.g. at maximum acceleration) and then setting the speed error limit accordingly higher.

**Danger!**

When the safety function is enabled, the size of the speed error limit value  $ds_{lim}$  affects how long it will take to look for errors and therefore also the error response time and estimation of the remaining distance.

This must be accounted for by the machine manufacturer in the risk analysis!

**Information:**

Due to rounding errors, a reserve of 1 unit/s should be accounted for with the parameter "Encoder Monitoring Speed Tolerance".

**2.3.3 Safe encoder counting range**

The safe encoder counting range can be found in the data sheet of the respective encoder. On the rotary encoders ECN 1325 single-turn and EQN 1337 multi-turn, this range corresponds with the single-turn range. See excerpt from the data sheet:

Technische Kennwerte	Absolut	
	ECN 1325 Singletum	EQN 1337 Multitum
Funktionale Sicherheit für Anwendungen bis	<ul style="list-style-type: none"> <li>SIL 2 nach EN 61508 (weitere Prüfgrundlage: EN 61800-5-2)</li> <li>Kategorie 3 PL d nach EN ISO 13849-1:2008</li> </ul>	
	Sicher im Singleturn-Betrieb	

**Information:**

The manufacturer's latest data sheet is applicable. The user is responsible for obtaining this information from the manufacturer.



### 3 Safety-related characteristic values of integrated safety functions

The safety characteristics were calculated for the individual safety functions and grouped together in the following blocks:

- Safe Torque Off (STO), Safe Stop 1 (SS1) time-monitored  
→ The two safe pulse disabling channels and their activation are included in evaluation
- Safe Torque Off (STO) single-channel  
→ Only one safe pulse disabling channel and its activation are included in evaluation.
- Safe Brake Control (SBC)  
→ The safe motor brake output and its activation are included in evaluation. The actual brake must be calculated explicitly in the safety chain!
- Safe Operating Stop (SOS), Safe Stop 1 (SS1), Safe Stop 2 (SS2), Safely Limited Speed (SLS), Safe Direction (SDI), Safely Limited Increments (SLI), Safe Maximum Speed (SMS), Safely Limited Position (SLP), Safe Maximum Position (SMP), Safe Homing  
→ The two safe pulse disabling channels and their activation are included in evaluation. Safe evaluation of the encoder, safe position detection and the safe motor holding brake output and its activation are also accounted for.

The encoder's safety-related characteristics must also be taken into account!

safety function	Criteria	Characteristic dependent on module width <sup>1)</sup>			
		1	2	4	8
Safe Torque Off (STO) Safe Stop 1 (SS1), time-monitored	Maximum safety category in accordance with EN ISO 13849	Cat. 4			
	Maximum Performance Level in accordance with EN ISO 13849	PLe			
	Maximum Safety Integrity Level in accordance with IEC 62061	SIL 3			
	Maximum Safety Integrity Level in accordance with IEC 61508	SIL 3			
	PFH (probability of dangerous failure per hour)	<5*10 <sup>-10</sup>			
	PFD (probability of dangerous failure on demand) at a proof test interval of 20 years	<9*10 <sup>-05</sup>			
	PTI (proof test interval) <sup>2)</sup>	Max. 20 years			
	DC (diagnostic coverage)	>95%			
	MTTFd (mean time to dangerous failure) <sup>3)</sup>	2500 years			

Table 83: Safety characteristics Safe Torque Off (STO), Safe Stop 1 (SS1) time-monitored

- 1) ACOPOSmulti inverter modules have different module widths according to their performance class. Different components and/or switching elements are used depending on the performance class / module width, which has a direct effect on the characteristics of the safe pulse disabling. The module width is listed in the technical data for the respective ACOPOSmulti inverter module.
- 2) Corresponds to the mission time of the module
- 3) Values determined according to Apfeld, R.; Bömer, T.; Hauke, M.; Huelke, M.; Schaefer, M.: Practical experience with DIN EN ISO 13849-1. openautomation (2009) No. 6, pp. 34-37 ([www.dguv.de/ifa/de/pub/grl/pdf/2009\\_249.pdf](http://www.dguv.de/ifa/de/pub/grl/pdf/2009_249.pdf)).

safety function	Criteria	Characteristic dependent on module width <sup>1)</sup>			
		1	2	4	8
Safe Torque Off, single-channel (STO1)	Maximum safety category in accordance with EN ISO 13849	Cat. 3			
	Maximum Performance Level in accordance with EN ISO 13849	PLd			
	Maximum Safety Integrity Level in accordance with IEC 62061	SIL 2			
	Maximum Safety Integrity Level in accordance with IEC 61508	SIL 2			
	PFH (probability of dangerous failure per hour)	<8*10 <sup>-09</sup>			
	PFD (probability of dangerous failure on demand) at a proof test interval of 20 years	<1.4*10 <sup>-03</sup>			
	PTI (proof test interval) <sup>2)</sup>	Max. 20 years			
	DC (diagnostic coverage)	>94%			
	MTTFd (mean time to dangerous failure)	>167 years	>157 years	>143 years	>85 years

Table 84: Safety characteristics Safe Torque Off, single-channel (STO1)

- 1) ACOPOSmulti inverter modules have different module widths according to their performance class. Different components and/or switching elements are used depending on the performance class / module width, which has a direct effect on the characteristics of the safe pulse disabling. The module width is listed in the technical data for the respective ACOPOSmulti inverter module.
- 2) Corresponds to the mission time of the module

safety function	Criteria	Characteristic dependent on module width <sup>1)</sup>			
		1	2	4	8
Safe Brake Control (SBC)	Maximum safety category in accordance with EN ISO 13849	Cat. 3			
	Maximum Performance Level in accordance with EN ISO 13849	PLd			
	Maximum Safety Integrity Level in accordance with IEC 62061	SIL 2			
	Maximum Safety Integrity Level in accordance with IEC 61508	SIL 2			
	PFH (probability of dangerous failure per hour)	<1*10 <sup>-08</sup>			
	PFD (probability of dangerous failure on demand) at a proof test interval of 20 years	<1.75*10 <sup>-03</sup>			
	PTI (proof test interval) <sup>2)</sup>	Max. 20 years			
	DC (diagnostic coverage)	>95%			
	MTTFd (mean time to dangerous failure)	>153 years	>135 years	>117 years	>56 years

Table 85: Safety characteristics Safe Brake Control (SBC)

- 1) ACOPOSmulti inverter modules have different module widths according to their performance class. Different components and/or switching elements are used depending on the performance class / module width, which has a direct effect on the characteristics of the safe pulse disabling. The module width is listed in the technical data for the respective ACOPOSmulti inverter module.
- 2) Corresponds to the mission time of the module

safety function	Criteria	Characteristic dependent on module width <sup>1)</sup>			
		1	2	4	8
Safe Operating Stop (SOS) Safe Stop 1 (SS1) Safe Stop 2 (SS2) Safely Limited Speed (SLS) Safe Direction (SDI) Safely Limited Increments (SLI), Safe Maximum Speed (SMS) Safely Limited Position (SLP) Safe Maximum Position (SMP) Safe Homing	Maximum safety category in accordance with EN ISO 13849	Cat. 3			
	Maximum Performance Level in accordance with EN ISO 13849	PLd			
	Maximum Safety Integrity Level in accordance with IEC 62061	SIL 2			
	Maximum Safety Integrity Level in accordance with IEC 61508	SIL 2			
	PFH (probability of dangerous failure per hour)	<5*10 <sup>-9</sup>			
	PFD (probability of dangerous failure on demand) at a proof test interval of 20 years	<8.75*10 <sup>-04</sup>			
	PTI (proof test interval) <sup>2)</sup>	Max. 20 years			
	DC (diagnostic coverage)	>95%			
	MTTFd (mean time to dangerous failure)	>109 years	>100 years	>89 years	>49 years

Table 86: Safety characteristics Safe Operating Stop (SOS), Safe Stop 1 (SS1), Safe Stop 2 (SS2), Safely Limited Speed (SLS), Safe Direction (SDI), Safely Limited Increments (SLI), Safe Maximum Speed (SMS), Safely Limited Position (SLP), Safe Maximum Position (SMP), Safe Homing

- 1) ACOPOSmulti inverter modules have different module widths according to their performance class. Different components and/or switching elements are used depending on the performance class / module width, which has a direct effect on the characteristics of the safe pulse disabling. The module width is listed in the technical data for the respective ACOPOSmulti inverter module.
- 2) Corresponds to the mission time of the module

## Danger!

To determine the overall PFH value of the safety functions, the PFH value of the EnDat 2.2 FS encoder used must be taken into account.

$$PFH_{\text{Total}} = PFH_{\text{SOS,SS1,SS2,SLS,SMS,SDI,SLI,SLP,SMP}} + PFH_{\text{Encoder}}$$

The value  $PFH_{\text{SOS,SS1,SS2,SLS,SMS,SDI,SLI,SLP,SMP}}$  can be found in the table above. The value  $PFH_{\text{Encoder}}$  can be found in the encoder's data sheet or obtained from the encoder manufacturer!

## Danger!

If the technical documentation (product catalog / user's manual) for the measurement device explicitly specifies that the bit error rate must be verified, then the user needs to implement this verification procedure in the application. This verification is not necessary if using B&R EnDat 2.2 8BCF encoder cables and certain B&R motors (safety motors with encoder option S0/S1 or standard motors with encoder option D0/D1).

## 4 Integrated safety functions

### Information:

If a safety function is not used in the application, then the respective input variables must remain open.

The following functions are supported by the SafeMC module:

Safety function	Starting safety release	in re-	EN ISO 13849-1	EN 61508/EN 62061	Safe encoder evaluation required
Safe Torque Off (STO)	R 1.3		Pl e	SIL 3	No
Safe Torque Off One Channel (STO1)	R 1.3		Pl d	SIL 2	No
Safe Operation Stop (SOS)	R 1.3		Pl d	SIL 2	Yes
Safe Stop 1 (SS1)	R 1.3		PL e (time-monitored) Pl d	SIL 3 (time-monitored) SIL 2	No (time-monitored) Yes
Safe Stop 2 (SS2)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Speed (SLS)	R 1.3		Pl d	SIL 2	Yes
Safe Maximum Speed (SMS)	R 1.3		Pl d	SIL 2	Yes
Safe Direction (SDI)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Increment (SLI)	R 1.3		Pl d	SIL 2	Yes
Safe Brake Control (SBC)	R 1.3		Pl d	SIL 2	No
Safely Limited Position (SLP)	R 1.4		Pl d	SIL 2	Yes
Safe Maximum Position (SMP)	R 1.4		Pl d	SIL 2	Yes
Safe Homing	R 1.4		Pl d	SIL 2	Yes

Table 87: Safety functions and corresponding safety levels

### Information about using the integrated safety functions

At least the activate input and the S\_AxisID must be connected. Otherwise, the SafeMC module will not be operated by the SafeLOGIC. As a result, the pulse disabling and the motor holding brake output will be permanently set to 0 V, which means that the controller cannot be turned on.

### Danger!

All of the safety functions that are used must be tested.

A function is considered to be used if the respective input variable is connected or the safety function has been configured!

## 4.1 Fail-safe state

### 4.1.1 Parameters

None

### 4.1.2 Behavior

If an error in the hardware or firmware occurs, then the safe inverter module changes to a non-acknowledgeable error state – the fail-safe state. The log book entry in Automation Studio provides more detailed information about the pending error. This log book can also be evaluated in the standard application.

If there is a hardware defect, then the entire inverter module must be replaced.

### Information:

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

However, the error can also have been caused by a configuration mistake. If this is the case, then the safe configuration must be checked and reloaded to the SafeLOGIC controller. This must then be followed by a PowerOff/PowerOn cycle to get the module back to the "Operational" state.

### Danger!

Safe pulse disabling is always active in the fail-safe state (i.e. the motor is no longer supplied with power or generating torque). The motor holding brake output is always switched to 0 V in this state!

**Danger!**

Constantly lit LEDs "SE" indicate a fail safe state that cannot be acknowledged. The cause of this could be a defective module or faulty configuration.

Check the entries in the logbook! If you are able to rule out a faulty configuration, then the module is defective and must be replaced immediately.

It is the user's responsibility to ensure that all necessary repair measures or corrections in the configuration are initiated after an error occurs since subsequent errors can result in dangerous situations!

**Danger!**

The motor holding brake is engaged in Fail Safe state. The motor holding brake will suffer mechanical wear if the motor is in motion just before the safe state is triggered. This must be considered when selecting and dimensioning the motor holding brake (E-stop capability).

**4.2 Functional fail-safe state****4.2.1 Parameters**

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide
Behavior of Functional Fail Safe			
Behavior of Functional Fail Safe	STO/ STO1 and STO with time delay	In the Functional Fail Safe state, STO (SBC) is activated immediately or STO1 and then STO (SBC) after a delay	STO
Delay time for STO in Functional Fail Safe	[µs]	Delay time between STO1 and STO (and SBC) in the Functional Fail Safe state	0
Delay time until the brake engages	[µs]	Delay time before the brake engages The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.	0

Table 88: Functional Fail Safe state configuration parameters

**4.2.2 Behavior**

If a monitored limit is exceeded or an encoder error occurs during operation – and as long as the safe encoder is required for the safety functions being used – then the SafeMC module changes to an acknowledgeable error state – the functional fail-safe state.

Information about any errors that occur can be found in the logbook entry in Automation Studio. This log book can also be evaluated in the standard application.

**Danger!**

The motor holding brake is engaged in Functional Fail Safe state. The motor holding brake will suffer mechanical wear if the motor is in motion just before the safe state is triggered. This must be considered when selecting and dimensioning the motor holding brake (E-stop capability).

**Danger!**

The error response time described in the manual affects the remnant movement in the event of error! This must be accounted for when planning the safety equipment (e.g. distances, monitored limits, etc.)

**"Behavior of Functional Fail Safe" = "STO"**

Pulse disabling is requested (low and high side) immediately after the error is detected and the safe motor holding brake output is set to 0V.




Figure 29: Functional Fail Safe - Configuration of STO

**"Behavior of Functional Fail Safe" = "STO1 and STO with time delay"**

Either the low or high side of the pulse disabling is switched to 0V immediately after the error is detected. The safe motor holding brake output is set to 0 V after the configured time "Delay time for STO in Functional Fail Safe" (T (Delay Time for STO in FFS)) has expired.

The second channel of the pulse disabling is also switched to 0 V after the configured time "Delay time until the brake engages" (T (Delay Time until the brake engages)) has expired.




Figure 30: Functional Fail Safe - Configuration of STO1 and STO with time delay

This makes it possible for the drive to be decelerated via the short circuit braking integrated in the ACOPOSmulti for the amount of time in which just one pulse disabling channel is active.

In this case, the time value T (Delay Time until the brake engages) is used to incorporate this brake engage time. This means that the second pulse disabling channel will only be switched to 0V after the motor holding brake has actually engaged.

## Danger!

The short circuit braking in the ACOPOSmulti is not suitable for safety purposes and can therefore only be used to protect the machine. If loss of power on the motor could result in dangerous situations (e.g. with hanging loads), then a mechanical safeguard must also be installed.

## 4.3 Safe Position, Safe Speed

### 4.3.1 Parameters

Parameter	Unit	Description	Default value
<b>Encoder Unit System</b>			
Encoder type	Rotatory encoder / Linear encoder / Encoder not used	Determines the type of encoder being used: <ul style="list-style-type: none"> <li>Rotary encoder</li> <li>Linear encoder</li> <li>Encoder not used</li> </ul> <p>The parameter is only available for ACOPOSmulti with SafeMC SinCos!</p>	Rotary encoder
Number of signal periods	-	Number of encoder signal periods per rotation (rotary encoder) or per length of the physical reference system (linear encoder) The parameter is only available for ACOPOSmulti with SafeMC SinCos!	1
Count of physical reference system	-	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: y-reference lengths (Reference length = Length of the physical reference system)  Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1

Table 89: Unit system parameters

Parameter	Unit	Description	Default value
Units per count of physical reference system	[units]	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: y-reference lengths  Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1000
Counting direction	Standard / Inverse	Counting direction of the position or speed Standard: Encoder counting direction is equal to the counting direction of the unit system Inverse: Encoder counting direction is negative to the counting direction of the unit system	Standard
Length of physical reference system for linear encoder (nm)	[nm]	For linear measurement systems, the length of a physical reference system will be defined here. This value is not used for rotary encoders, where the reference system is a single rotation.	1000000000
Maximum speed to normalize the speed range (units/s)	[units/s]	Maximum speed to which the displayed speed should be normalized	32767
Maximum acceleration (rad/s <sup>2</sup> or mm/s <sup>2</sup> )	[rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	Maximum permissible encoder acceleration	100000

Table 89: Unit system parameters

### 4.3.2 Behavior

The parameters (see 4.3.1 "Table: "Unit system parameters"" on page 154) can be used to configure the safe unit system.

The safe speed and the safe position are transferred in the safety frame. The process data is only allowed to be used together with the respective status bit. If the respective status bit is FALSE, then the corresponding data is invalid.

Function blocks are available for linking the process data with a specific axis and using in the safe application!

#### Safe position

The safe position is transferred in [units] according to the configured unit system. Once homing is complete, the "SafePosition Valid" status bit is set.

#### **Danger!**

If the position signal is not validated, then an invalid position could be used in the safe application. This can result in hazardous situations!

#### **Danger!**

Safe encoder evaluation can only detect an error in the transfer or position

- if a distance is traversed that is greater than the angular deviation of the safe position specified in the product information provided by the manufacturer of the measuring device (*applies to ACOPOSMulti with SafeMC EnDat 2.2*).
- if a distance is traversed that is greater than  $\pm\frac{1}{2}$  signal period of the SinCos measurement device (*applies to ACOPOSMulti with SafeMC SinCos*).

The resulting maximum error in the safe position also depends on the length of the physical reference system (rotations, length of the scale, etc.).

This error affects the minimum distance required for the protection (e.g. of fingers) against crushing and must be accounted for when dimensioning the safety function.

#### **Danger!**

A frictionally engaged connection with fault exclusion requires no extra mechanical offset for the safe position.

If the fault exclusion is only achieved by implementing a mechanical stop with backlash, then this maximum possible offset must be calculated into the safe position. This is done by adding the values for the measuring instrument and for the mechanical link.

## Safe Speed

The safe speed is scaled to 2 bytes due to the limited Safety Frame bandwidth available. The scaled speed  $v_{scaled}$  is calculated as follows:

$$v_{scaled} = \frac{v_{physical} \cdot 32767}{\text{Maximum speed to normalize the speed range}} \left[ \frac{\text{scaled units}}{s} \right]$$

$v_{physical}$  (physical velocity) corresponds to the actual physical size and is calculated in the configured unit system in [units/s].

This means the scaled speed equals the physical speed for the default configuration of the parameter "Maximum speed to normalize the speed range" = 32767!

The maximum speed must never exceed the value configured for "Maximum speed to normalize the speed range" or else the module will switch to "Functional Fail Safe" state.

### Information:

The speed limits of the safety functions are configured in the physical speed [units/s]. The safety functions internally monitor the scaled speeds [scaled units / s] whereby scaling errors can occur.

### Example

The following configuration causes the speed tolerance for standstill monitoring to be scaled internally to 0 [scaled units / s].

Configuration:

"Maximum speed to normalize the speed range (units/s)" = 3276700

"Speed Tolerance (unit/s)" = 20

$$\text{Scaled Speed Tolerance} = \frac{\text{Speed Tolerance} \cdot \text{INT16MAX}}{\text{Maximum Speed to normalize the speed range}} = \frac{20 \cdot 32767}{3276700} = 0$$

If Safe Operating Stop is enabled, then a speed tolerance of 0 is monitored internally [scaled units / s]. This can result in a undesired speed violation during standstill.

### Information:

The configured unit system has significant influence on the maximum physical speed achieved.

If the unit system configuration is changed make sure to consider how this affects the parameter "Maximum speed to normalize the speed range".

### Danger!

If the module changes to the acknowledgeable error state "Functional Fail Safe", then the drive loses power and torque, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

### Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### Danger!

If the speed signal is not validated, then an invalid speed value could be used in the safe application. This can result in hazardous situations!



## Danger!

Safe encoder evaluation can only detect an error in the transfer or position

- if a distance is traversed that is greater than the angular deviation of the safe position specified in the product information provided by the manufacturer of the measuring device (*applies to ACOPOSmulti with SafeMC EnDat 2.2*).
- if a distance is traversed that is greater than  $\pm 1/2$  signal period of the SinCos measurement device (*applies to ACOPOSmulti with SafeMC SinCos*).

The resulting maximum error in the safe position also depends on the length of the physical reference system (rotations, length of the scale, etc.).

The error influences the error response time and must be accounted for when dimensioning the safety function.

### 4.4 STO - Safe Torque Off

#### 4.4.1 Parameters

None

#### 4.4.2 Behavior

STO is the fundamental safety function of the ACOPOSmulti with SafeMC, since it represents the "fail-safe" principle.

A request from the STO safety function activates safe pulse disabling and switches off the torque and power to the drive. Activation of safe pulse disabling is performed actively by the SafeMC module.

## Danger!

A STO request causes synchronized axes to no longer be synchronous.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!




Figure 31: STO - Safe Torque Off

**Information:**

The functional safe state of the STO function has been achieved when the pulse disabling outputs are switched to 0 V. The respective bit is set once the functional safe state has been achieved.

**Danger!**

The drive will spin out if it is in motion at the time of the STO request. The resulting remnant movement and time depends on the properties of the machine and must always be considered when dimensioning the safety equipment.

The maximum possible (worst case) movement must be assumed.

The maximum possible speed is determined by the current operating mode. If there is no active safety function, the maximum speed that is physically possible for the motor must be assumed.

**Danger!**

If the SMS or SLS function is active, the assumed maximum speed can be reduced to the currently active configured speed limit plus the maximum possible acceleration during the error response time.

**Information:**

The resulting remnant movement and time determines the intervals between the safety features that must be maintained and therefore the size of the machine as well.

**Information:**

The safety function Safe Torque Off does not require encoder evaluation.

**Danger!**

If the safety function STO is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

## 4.5 Single-channel Safe Torque Off, STO1

### 4.5.1 Parameters

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide

Table 90: STO1 safety function parameters

### 4.5.2 Behavior

The STO1 safety function works in the same way as STO. The sole difference is that either only the HighSide or only the LowSide IGBTs are switched off depending on the configuration.

**Information:**

The functional safe state of the STO1 safety function has been achieved when the configured pulse disabling output is switched to 0 V.

The respective bit is set once the functional safe state has been achieved.

**Information:**

The two-channel aspect is lost because either only the low side or only the high side of the pulse disabling is activated with the safety function STO1.

This results in a lower SIL and Performance Level!

**Information:**

The safety function STO1 does not require encoder evaluation.

## Danger!

If the safety function STO1 is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

### 4.6 Safe Brake Control, SBC

#### 4.6.1 Parameters

Parameter	Unit	Description	Default value
Safety Additional Parameters			
Delay time to start SBC (us)	[ $\mu$ s]	Delay time between the SBC request and activation of the safety function	0

Table 91: SBC safety function parameters

#### 4.6.2 Behavior

The SBC function is a safe (time-delayed) output whose purpose is to safely control a motor holding brake.

### Information:

To achieve a defined SIL level, the controlled holding brake must also have at least the same SIL level and errors in the wiring must be ruled out.




Figure 32: Safe Brake Control, SBC

Only the actuation of the motor holding brake output through the SafeMC module is safely evaluated with SIL 2.

The braking procedure is not monitored from a safety point of view by the SafeMC module.

### Information:

The functional safe state of the SBC function has been achieved when the safe motor holding brake output has been switched to 0 V.

The respective bit is set once the functional safe state has been achieved.

The purpose of the delay time T (Delay time to start SDI [ $\mu$ s]) is to compensate for the different runtimes of functional and safe applications.

### Information:

The safety function Safe Brake Control does not require encoder evaluation.

## Danger!

If the safety function SBC is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

## Information:

Functional errors will occur (e.g. 6029: Holding brake: Control signal on and output status off), if the holding is released by the standard application but the motor holding brake output is switched to 0 V by the SafeMC module.

## 4.7 Safe Operating Stop, SOS

### 4.7.1 Parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 92: SOS safety function parameters

### 4.7.2 Behavior

An enabled SOS safety function monitors the drive to ensure that it stops safely. The SafeMC module does not control pulse disabling.

The drive can remain active and must be kept at standstill by the standard application.

## Information:

The safety function SOS requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 33: Safe Operating Stop, SOS

To prevent the axis from drifting, both the speed and position are monitored with standstill tolerance limits. The position window is generated when the safety function is requested. If the request is withdrawn, then monitoring of the standstill tolerance window will also be terminated. The next time a request is made, the standstill tolerance position window is regenerated based on the current position.

## Information:

The functional safe state of the SOS safety function has been achieved when the drive is stopped and the standstill is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The standstill tolerances can be configured for each axis in SafeDESIGNER.

## Danger!

In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.

The dangerous movement must be determined by a risk analysis.

If the stop monitoring limits are violated, safe pulse disabling is activated and the drive switches to a Functional Fail Safe error state which must be acknowledged. When an error occurs, a synchronous axis loses its synchronicity.

## Danger!

If a standstill limit (position or speed) is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

## Danger!

If the safety function SOS is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The configured limits must be violated with the function enabled and the error response must be tested accordingly!

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## 4.8 Safe Stop 1, SS1

### 4.8.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 93: SS1 safety function parameters

### 4.8.2 Behavior

When the SS1 safety function is requested and after the ramp delay time, the deceleration process of the axis is monitored until standstill. After decelerating, safe pulse disabling is activated and switches off the torque and power to the drive.

## Danger!

Synchronous axes lose their synchronicity when SS1 is in its safe state.




Figure 34: Safe Stop 1, SS1

The deceleration itself is controlled by the standard application, which is not safety-oriented.

The purpose of the ramp delay time - parameter "*Delay time to start ramp monitoring ( $\mu\text{s}$ )*" - is to compensate for the different runtimes of functional and safe applications.

### Information:

The functional safe state of the SS1 function has been achieved when the pulse disabling outputs are switched to 0 V. The respective bit is set once the functional safe state has been achieved.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

Depending on the requirements for the safety function and its configuration, either only the deceleration time  $T$  (Ramp Monitoring Time for SS2) or also the deceleration ramp can be monitored.

If the monitoring limits are violated during deceleration, then an error state that must be confirmed is entered.

The parameter "*Ramp monitoring for SS1*" configures the behavior of the delay monitor.

### 4.8.3 SS1 - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SS1" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a stopping procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring ( $\mu$ s)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope. If the monitoring ramp reaches the configurable standstill speed limit "*Speed Tolerance (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SS1 ( $\mu$ s)*" has expired, then safe pulse disabling is activated and torque is switched off on the drive.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the standstill speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

If the active limit is violated during monitoring of the deceleration procedure, then the drive will immediately switch to the acknowledgeable error state Functional Fail Safe.

### Information:

If ramp monitoring is configured for the safety function SS1, then the speed must be safely evaluated. If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!

### Danger!

If safe pulse disabling is on (spin-out) and the safety function is in a functionally safe state, the maximum speed at the end of the deceleration ramp must be used to calculate the remaining distance. To determine the maximum possible speed, it must be assumed that in the event of error, the drive will accelerate to its maximum during the error response time starting from the standstill speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!

### Danger!

If the monitored ramp is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!

### Danger!

If the safety function SS1 with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine! The test should include at least one violation of the monitored ramp and the error response must be tested accordingly!

## 4.8.4 SS1 - Stopping procedure with time-monitoring

### "Ramp monitoring for SS1" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application.

After the delay time for the request, "*Delay time to start ramp monitoring ( $\mu$ s)*" and the monitoring time, "*Ramp Monitoring Time for SS1 ( $\mu$ s)*" have expired, safe pulse disabling is activated and torque is shutoff on the drive.

### Information:

With this configuration of the Safe Stop 1 safety function, only the time frame is monitored. No speed limit or position window is monitored. This is why the function can also be used in this configuration without safe encoder evaluation!

### Danger!

If safe pulse disabling is on (spin-out), the maximum speed after the time frame has expired must be used to calculate the remaining distance!

The drive can move at its physically maximum speed during this time window (plus the response time of the safe pulse disabling). If SMS is active, then the speed limit plus the error tolerance can be assumed as the maximum speed.

It must be ensured that the spin-out movement and remaining distance do not present any danger!

## Danger!

If the safety function SS1 with true time-monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The drive should be accelerated to its maximum during the monitored time frame and the error response tested accordingly!

### 4.9 Safe Stop 2, SS2

#### 4.9.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 94: SS2 safety function parameters

#### 4.9.2 Behavior

With the SS2, after the ramp delay time the deceleration process of the axis is monitored until standstill. The drive must then be kept at standstill by the standard application. This standstill is monitored, similar to SOS, by the SafeMC module according to the configured standstill tolerance window "Speed Tolerance [units/s]" and "Position Tolerance [units]".

The delay itself must be generated by the non-safety-oriented, standard application by halting the drive in response to the dangerous situation.

## Information:

The safety function Safe Stop 2 requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!






Figure 35: Safe Stop 2, SS2

## Danger!

If a standstill limit (position or speed) is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The "*S\_NotErrFUNC*" output on the function block is reset.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

The purpose of the ramp delay time - parameter "*Delay time to start ramp monitoring (μs)*" - is to compensate for the different runtimes of functional and safe applications.

## Information:

The functional safe state of the SS2 function has been achieved when the drive is stopped and the standstill is being monitored for safety. The respective bit is set once the functional safe state has been achieved.

As with SS1, it is possible to monitor either only the deceleration time or the deceleration ramp as well depending on the requirements of the safety function.

The parameter "*Ramp monitoring for SS2*" configures the behavior of the delay monitor.

#### 4.9.3 SS2 - Stopping procedure with ramp-based monitoring

##### "Ramp monitoring for SS2" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a stopping procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring (μs)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope. If the monitoring ramp reaches the configurable standstill speed limit "*Speed Tolerance (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SS2 (μs)*" has expired, then a position window is established and monitoring of the standstill tolerances is started.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the standstill speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

If the active limit or standstill window is violated during monitoring of the deceleration procedure or standstill, then the drive will immediately switch to the acknowledgeable error state Functional Fail Safe.

### **Danger!**

**When the monitored ramp or standstill tolerance window is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

### **Danger!**

**In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.**

**The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.**

**The dangerous movement must be determined by a risk analysis.**

### **Danger!**

**If the safety function SS2 with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!**

**The test should contain at least one violation of the monitored ramp and standstill tolerance window. The error response must be tested accordingly!**

#### 4.9.4 SS2 - Stopping procedure with time-monitoring

##### "Ramp monitoring for SS2" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application.

After the delay time for the request, "*Delay time to start ramp monitoring (μs)*" and the monitoring time, "*Ramp Monitoring Time for SS2 (μs)*" have expired, the standstill tolerance window will be monitored safely.

### **Danger!**

**When the standstill tolerance window is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit.**

**It must be ensured that the spin-out movement and remaining distance do not present any danger!**

## Danger!

In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.

The dangerous movement must be determined by a risk analysis.

## Danger!

If the safety function SS2 with time-monitored stopping procedure is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of the standstill tolerance window. The error response must be tested accordingly!

## 4.10 Safely Limited Speed, SLS

### 4.10.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	0
Safe Speed-limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	0
Safe Speed-limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	0
Safe Speed-limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Ramp Monitoring Time for SLS4 (us)	[μs]	Deceleration monitoring time for SLS4	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 95: SLS safety function parameters

### 4.10.2 Behavior

The safety function SLS monitors a specified speed limit - parameter "*Safe Speedlimit 1, 2, 3, 4 for SLS (units/s)*". It is also possible to monitor deceleration until the limit is reached if needed by the application.

Four different speed limits can be monitored on the SafeMC module. All limits can also be monitored in parallel. If a request is made to monitor multiple speed limits at the same time, then the lowest limit value will always be monitored. To make this possible, the function block includes four different inputs "S\_RequestSLSx" (x = 1-4).

The standard (non safety-oriented) application must use a closed-loop control appropriate for the level of danger to decelerate the movement and then maintain the respective speed limit.

## Information:

The safety function SLS requires safe evaluation of the speed. If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!




Figure 36: Safely Limited Speed, SLS

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## Danger!

If a speed limit is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

Torque and power to the drive are switched off, causing the drive to spin out!

An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

The purpose of the ramp delay time  $T$  (Delay time to start ramp monitoring) is to compensate for the different runtimes of functional and safe applications.

If the delay time (Ramp monitoring time for SLSX) is set to 0, then the speed limit will be monitored right after the request is made for the safety function.

## Information:

The functional safe state of the SLS function has been achieved if the drive has not exceeded a defined speed limit and this limit is being monitored for safety. The respective bit is set once the functional safe state has been achieved.

As with SS1 and SS2, the deceleration ramp monitoring can be adjusted according to the requirements, so that either only the deceleration time or both the deceleration time and the deceleration ramp are monitored.

The parameter "Ramp monitoring for SLS" configures the behavior of the delay monitor.

#### 4.10.3 SLS - Stopping procedure with ramp-based monitoring

##### "Ramp monitoring for SLS" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a deceleration procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring ( $\mu$ s)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope.

If the monitoring ramp reaches the respective speed limit "*Safe Speedlimit 1, 2, 3, 4 for SLS (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SLS1, 2, 3, 4 ( $\mu$ s)*" has expired, then the status of the safety function will be set and the enabled speed limit monitored.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the monitored speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

### **Danger!**

**When the monitored ramp or the enabled safe speed is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

### **Danger!**

**In the event of an error when monitoring the safe reduced speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.**

**Within this amount of time, the drive could accelerate to its maximum before spinning out.**

**The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger. The dangerous movement must be determined by a risk analysis.**

### **Danger!**

**If the safety function SLS with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!**

**The test should contain at least one violation of the monitored ramp and of each speed limit being used. The error response must be tested accordingly!**

#### 4.10.4 SLS - Stopping procedure with time-monitoring

##### "Ramp monitoring for SLS" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application. After the delay time for the request, "*Delay time to start ramp monitoring ( $\mu$ s)*" and the monitoring time, "*Ramp Monitoring Time for SLS1, 2, 3, 4 ( $\mu$ s)*" have expired, the speed limit will be monitored safely.

### **Danger!**

**When the speed limit is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit.**

**It must be ensured that the spin-out movement and remaining distance do not present any danger!**

**Danger!**

In the event of an error when monitoring the safe reduced speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SLS without ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of each speed limit being used.

The error response must be tested accordingly!

**4.11 Safe Maximum Speed, SMS****4.11.1 Parameters**

Parameter	Unit	Description	Default value
General settings			
Safe Maximum Speed	Used / Not used	SMS safety function activated or deactivated	Used
Speed Limits			
Maximum speed limit for SMS	[units/s]	Speed limit of the maximum speed	0

Table 96: SMS safety function parameters

**4.11.2 Behavior**

The difference between SMS and SLS is that SMS cannot be actively requested. It is either activated (parameter "Safe Maximum Speed" = Used) or deactivated (parameter "Safe Maximum Speed" = Not used) in the configuration.

When activated, the current speed is constantly monitored according to a defined limit (parameter "Safe Maximum Speed (units/s)").

**Information:**

The safety function SMS requires safe evaluation of the speed.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!

**Danger!**

When the monitored speed limit is exceeded, the remaining distance must be calculated based on the error response time.

It must be ensured that the spin-out movement and remaining distance do not present any danger!

**Danger!**

In the event of an error when monitoring the safe maximum speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out. The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SMS is used in the safe application, then it must be tested when commissioning the machine!

The configured limit must be exceeded! The error response must be tested accordingly!

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### 4.12 Safely Limited Increment, SLI

#### 4.12.1 Parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Safely Limited Increments			
Safe increments	[units]	Maximum moveable increments when SLI is active	0
SLI OFF Delay	[μs]	Switch off delay of SLI	0

Table 97: SLI safety function parameters

#### 4.12.2 Behavior

With the SLI safety function, the movement is monitored for a defined number of increments (parameter "Safe Increments (units)").

### Information:

The safety function SLI requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 37: Safely Limited Increment, SLI

**Information:**

The safety function SLI is only effective when used in combination with at least one other safety function. This could be one of the safety functions such as SOS, SS2, or SLS.

**Information:**

The functional safe state of the SLI function has been achieved if the drive has not exceeded a defined increment size and this limit is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The safe axis must be at a standstill when this function is enabled. To do this, the speed is monitored for adhering to the speed standstill tolerance (parameter "*Speed Tolerance (units /s)*").

A position window is then generated that is monitored from a safety point of view. This position window depends on the configured safe increment size (parameter "*Safe Increments (units)*"). The standard application must guarantee that this position window is not exceeded.

After deactivating the safety function, monitoring remains active for the configured amount of time (parameter "*SLI Off Delay (μs)*"). This prevents continuous movement caused by constant jogging.

**Danger!**

If a speed limit for requesting the function or if the position window is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous.

The "*S\_NotErrFUNC*" output on the function block is reset.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**Danger!**

In the event of an error when monitoring the safe increments, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out.

The remaining distance must be taken into consideration when configuring the permissible increments and must not cause any hazards.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SLI is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of the standstill speed limit when enabled and the permissible increments. The error response must be tested accordingly!

**4.13 Safe Direction, SDI****4.13.1 Parameters**

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[μs]	Delay time between the SDI request and activation of the safety function	0

Table 98: SDI safety function parameters

**4.13.2 Behavior**

The SDI safety function monitors the defined direction of movement.



Either the positive or the negative direction can be monitored. This is done using the two inputs “*S\_RequestSDIpos*” and “*S\_RequestSDIneg*” that are available on the function block.

### Information:

The safety function SDI requires safe evaluation of the position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!




Figure 38: Safe Direction, SDI - Positive direction of rotation allowed




Figure 39: Safe Direction, SDI - Negative direction of rotation allowed

**Information:**

The safe direction function can be enabled in parallel with other safety functions. For example, SLS or SLI can be limited to a certain direction.

**Information:**

The functional safe state of the SDI function has been achieved if the drive has not violated a defined direction of movement and this direction of movement is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The purpose of the delay time "*Delay time to start SDI ( $\mu$ s)*" is to compensate for the different runtimes of functional and safe applications.

When monitoring the direction of movement, the standstill position tolerance (parameter "*Position Tolerance (units)*") must not be exceeded in the forbidden direction of movement. When moving in the permitted direction of movement, the position window moves along like a slave pointer.

**Danger!**

If the safe direction of movement is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out!

An error will cause a synchronous axis to no longer be synchronous.

The "*S\_NotErrFUNC*" output on the function block is reset.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**Danger!**

In the event of an error when monitoring the safe direction of rotation, a dynamic forward movement in the dangerous direction can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out. The resulting remaining distance must be accounted for when configuring the permissible tolerance limits and must not present any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SDI is used in the safe application, then the ability to enable/disable each of the directions of movement that are being used must be tested when commissioning the machine!

The test should contain at least one violation of each safe direction of movement that is being used.

The error response must be tested accordingly!

**4.14 Safe Homing****Information:**

The safety function Safe Homing is only available in Safety Release R 1.4 or higher!

**4.14.1 Parameters**

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time ( $\mu$ s)	[ $\mu$ s]	Monitoring time for the homing procedure	0

Table 99: Parameters for the "safe homing" safety function

Parameter	Unit	Description	Default value
Mode	Direct/ Reference Switch/ Home Offset/ Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive/ Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive
Trigger direction	Positive/ Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used/ Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0

Table 99: Parameters for the "safe homing" safety function

#### 4.14.2 Behavior

The Safe Homing function provides a way to establish a reference between the encoder position and the machine position.

Depending on the homing mode, it may be necessary for the drive to perform a homing procedure. A homing procedure requires the control functions between the electronic controller and the drive motor to be active. Other safety functions might have to be selected in order to prevent a hazardous state during the homing procedure.

The following homing modes are supported:

- Direct
- Reference switch
- Home Offset / Home Offset with Correction (*only available for ACOPOSmulti with SafeMC EnDat 2.2!*)

#### Information:

**Safe homing requires safe evaluation of the position.**

**If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Fail Safe" state after the function block is activated! The "Fail Safe" state can only be exited by powering off and then on again!**

A positive edge on the control bit *S\_RequestHoming* will start safe homing and simultaneously reset the status bit *S\_SafePositionValid*.

As soon as the homing procedure is completed, the status bit *S\_SafePositionValid* will be set and the control bit *S\_RequestHoming* must be reset.

The homing procedure must be completed within the "*Homing monitoring time (μs)*" or else the SafeMC module will change to the functional fail-safe state.

The homing procedure will be aborted if the *S\_RequestHoming* control bit is reset before the procedure is completed.




Figure 40: Safe Homing

### Information:

The safe homing function is a pre-requisite for the safety functions SLP and SMP and for using the safe position. The status `S_SafePositionValid` will remain set to `SAFEFALSE` until safe homing has been performed!

### Danger!

If an error occurs during homing procedure, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

The function block output `S_NotErrFUNC` is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

### Danger!

If the safe position is used in SafeDESIGNER, then the Position Valid output of the SafeMC\_Position function block must also always be evaluated.

This will be reset immediately only with referenced axes `SAFETRUE`, and the first time an encoder error occurs (`SAFEFALSE`).

This enables the safety application to detect any encoder error, even if only brief.

If a machine reference is not required for usage, then the axis can be referenced using the Direct mode.

## 4.14.3 Direct mode

### 4.14.3.1 Parameters

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Correction	Selection of homing mode <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	Direct
Reference pulse	Used / Not Used	Selection of whether or not to use a reference pulse for homing	Not used
<b>General settings</b>			
Safe Maximum Position	Used / Not used	Activates the SMP safety function by configuration	Not used
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
<b>Safety Standstill and Direction Tolerances</b>			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0

Table 100: Parameters for the "safe homing" safety function - Direct mode

#### 4.14.3.2 Behavior

Direct mode is used if the current position of the axis is known and has only to be applied to the SafeMC module. The following scenario is an example of how this mode can be used:

- The ACOPOSMulti SafeMC module is first homed for the standard application.
- The axis is then moved to a defined position by the ACOPOSMulti SafeMC module.
- The user acknowledges that the correct position has been reached by pressing a safe button → This triggers a safe homing procedure internally in Direct mode.

When referencing in Direct mode, the actual position of the axis is set to the value specified in the parameter "*Home position or home offset*" immediately after the homing command (positive edge on the input S\_RequestHoming).

The input S\_ReferenceSwitch will not be evaluated.

#### Information:

**The axis must be at standstill when the homing request is made.**

The values configured under "Safety Standstill and Direction Tolerances" are monitored to this regard. If the standstill tolerances are violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. The function block output S\_NotErrFUNC is reset and the drive becomes torque-free and force-free, causing it to spin out!

#### Information:

**A reference pulse is not permitted to be used in Direct mode!**

If a reference pulse is enabled ("*Reference pulse*" = Used), then the system will enter Fail Safe state when checking the configuration during startup.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

#### Information:

If Safe Maximum Position has been enabled in the configuration (Parameter "*Safe Maximum Position*" = Used), then the value configured on the parameter "*Home position or home offset*" must be within the permissible SMP window (parameters "*Safe Lower Position Limit for SMP (units)*" and "*Safe Upper Position Limit for SMP (units)*").

If this is not the case, then the system will enter Fail Safe state when checking the configuration during startup.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

#### Danger!

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!**

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

#### 4.14.4 Reference Switch mode

##### 4.14.4.1 Parameters

Parameter	Unit	Description	Default value
Homing			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time (µs)	[µs]	Monitoring time for the homing procedure	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive / Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive

Table 101: Parameters for the "safe homing" safety function - Reference Switch mode

Parameter	Unit	Description	Default value
Trigger direction	Positive / Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used / Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 101: Parameters for the "safe homing" safety function - Reference Switch mode

#### 4.14.4.2 Behavior

The mode "Reference Switch" correlates with the referencing modes "Switch Gate", "Abs Switch" and "Limit Switch" on the ACOPOSmulti.

##### Information:

**If the reference switch input "S\_ReferenceSwitch" is not wired on the function block, then the SafeMC module will change to Fail Safe state.**

**The "Fail Safe" state can only be exited by powering off/on and changing the safe application!**

Depending on the configuration, the ACOPOSmulti will pass over the reference switch / limit switch several times.

##### Danger!

**The reference switch / limit switch is part of the safety function and must therefore be accounted for in the risk analysis.**

**Use a debounced position switch suitable for safety applications!**

**The machine manufacturer is responsible for implementing a suitable switch!**

After the homing command (= positive edge on the input *S\_RequestHoming*) the SafeMC module uses the home switch edge that matches the "Edge of reference switch" and "Trigger direction" settings as long as it is passed below the "Max Trigger Speed".

The home switch edge will be ignored if the reference switch is passed over at a speed higher than the "Max Trigger Speed".

Configuration	Reference switch evaluation
Edge of reference switch = Negative Trigger direction = Negative	
Edge of reference switch = Positive Trigger direction = Negative	
Edge of reference switch = Negative Trigger direction = Positive	
Edge of reference switch = Positive Trigger direction = Positive	

Table 102: Selecting the home switch edge

##### Information:


**After the homing command is made, the homing procedure must be completed within the configured time "Homing Monitoring Time ( $\mu$ s)". Otherwise, the module will change to the acknowledgeable error state "Functional Fail Safe".**

**The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!**

**An error will cause a synchronous axis to no longer be synchronous.**


## Danger!

The standstill "Position Tolerance" must be smaller than or equal to half the pulse width of the reference switch being used!



## Danger!

The filter ( $T_{on}$ ,  $T_{off}$ ) required when reading the reference switch edges in SafeDESIGNER must be determined according to the control behavior during standstill.



Error in the referenced absolute position due to the delay caused by the filter times must be taken into consideration!

### 4.14.4.2.1 ACOPOSMulti with SafeMC SinCos

The reference position is assumed immediately after successful evaluation of the reference edge.

### 4.14.4.2.2 ACOPOSMulti with SafeMC EnDat 2.2

#### Reference pulse = Not Used

If the reference pulse is disabled, then the reference position will be assumed immediately when the home switch edge is successfully processed.

#### Reference pulse = Used

This mode is recommended when the positions of ACOPOSMulti and the SafeMC module must match exactly. Processing of the reference pulse compensates for the speed-dependent position difference by processing the two values at different times.

## Information:

If "Reference pulse" is set to "Used", then a rotary EnDat 2.2 Functional Safety encoder must be used. The reference pulse is generated at every single turn overflow.

When "Reference pulse" = Used, the reference position will not be entered under the first valid reference pulse after the home switch edge has been reached.

After the valid home switch edge has been processed, the processing of the reference pulse will be suppressed for the distance configured in the parameter "Blocking distance (% encoder reference system)". The next reference pulse is only processed once this distance has been passed, at which point the home position is applied.

A valid homing procedure requires that the direction of movement does not change between when the home switch edge is passed and the valid reference pulse and that the speed limit "Max Trigger Speed" is not exceeded.

**Information:**

If the direction of movement changes while searching for the reference pulse, then the reference switch must be passed over again.

**Information:**

If the speed limit "*Max Trigger Speed*" is exceeded during the reference pulse search, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

#### 4.14.5 Home Offset / Home Offset with Correction mode (only for ACOPOSMulti with SafeMC EnDat 2.2)

**Information:**

The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!

##### 4.14.5.1 Parameter - Home Offset / Home Offset with Correction mode

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Mode	Direct/ Reference Switch/ Home Offset/ Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	Direct
<b>General settings</b>			
Safe Maximum Position	Used/Unused	Activates the SMP safety function by configuration	Unused
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0

Table 103: Parameters for the safety function "safe homing" - Modes: Home Offset / Home Offset with Correction

##### 4.14.5.2 Behavior - Home Offset / Home Offset with Correction mode

If an absolute encoder is being used, then the machine reference can be established via an offset to the encoder position.

A homing procedure is not necessary.

The homing command *Home Offset* uses this offset directly, while *Home Offset with Correction* mode accounts for any encoder overrun that might occur in the permissible range of movement.

The offset is configured in SafeDESIGNER with the *Home position or Home offset* parameter.

The input *S\_ReferenceSwitch* will not be evaluated.



## Danger!

This homing mode can only be used for absolute encoders (single-turn encoder / multi-turn encoder / linear encoder). Using another encoder for this mode will cause the SafeMC module to change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

## Information:

If the security functions SMP and/or SLP are used, then their position window must be smaller than the safety-related encoder counting range.

If one of the two position windows is configured larger than the encoder counting range, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

For more information, see the section Safe encoder counting range (only applies to the user documentation MAACPMSAFEMC-ENG (ACOPOSmulti with SafeMC EnDat 2.2)).

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### Home Offset

This mode is well suited for absolute encoders which provide unique position values over the entire movement range. Using the homing offset, the encoder position over the entire movement range can be represented as the correct machine position.




Figure 41: Home Offset referencing method

The Home Offset can be determined by carrying out a calibration move (e.g. Homing with Reference Switch).

### Home Offset with Correction

In this homing mode, after setting the Home Offset a check is made to see if the machine position is within the movement range defined by the SMP position limits. If this is not the case, the Home Offset in the safety-related encoder counting range is corrected:

## Information:

The SMP safety function must be activated when using this mode. If SMP is deactivated, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

Counting range correction is needed when using absolute encoders if the encoder provides a unique position value over the entire movement range but an encoder overflow occurs within the movement range. Here, the Home Offset depends on if the machine was calibrated at a position to the right or the left of the overflow point.




Figure 42: Referencing method - Home Offset with Correction

To the right of the overflow point, Home Offset 1 which is valid for the left side would lead to an incorrect position value. To the left of the overflow point, Home Offset 2 which is valid for the right side would lead to an incorrect position value. This can be compensated for with counting range correction.

### Information:

Counting range correction only functions if the encoder range is larger than or equal to the movement range! Keep in mind that only the safety-related part of the encoder counting range is used.

## 4.15 Safely Limited Position, SLP

### 4.15.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
Safety Position Limits			
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SLP (us)	[μs]	Delay time between request of SLP and start of monitoring	0

Table 104: SLP safety function parameters

### 4.15.2 Behavior

The purpose of the SLP safety function is to monitor a specified position window.

The "Safe Lower Position Limit for SLP" and "Safe Upper Position Limit for SLP" parameters can be used to configure the limits of the monitoring range.

The SLP safety function is requested when the input *S\_RequestSLP* is set to SAFEFALSE.

Monitoring of the position window will begin after the amount of time configured in "Delay time to start SLP" has expired.

The "*S\_SafetyActiveSLP*" status bit will be set to SAFETRUE if no errors occur while monitoring is active.




Figure 43: Safety Limited Position, SLP

## Information:

The axis must be homed successfully before using the Safety Limited Position function.

If a homing procedure is not completed successfully or if the "S\_SafePositionValid" status changes, then the request for the SLP safety function causes the module to change to the acknowledgeable *functional fail-safe* error state.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous.

The "S\_NotErrFUNC" output on the function block is reset.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

To minimize the distance remaining when the position window is exceeded, a position-dependent speed limit is monitored in addition to the position.

## Danger!

In the worst case, the monitored position window can be passed while the axis is spinning out. This must be taken into account when defining the limits!

When the position limit is approached, the monitored speed limit is calculated in such a way that the drive will come to a full stop before the positioning limit is reached using the configured deceleration ramp parameter.

The permitted speed in the direction of the upper position limit is

$$v_{LIM,POS} = \sqrt{2(LIM_{SLP,POS} - s) * a}$$

and in the direction of the lower position limit is

$$v_{LIM,NEG} = \sqrt{2(s - LIM_{SLP,NEG}) * a}$$

The position-dependent speed limit is illustrated in the following figure.




Figure 44: Position-dependent speed window

## Danger!

If the position window or the position-dependent speed limit is violated while the SLP safety function is activated or if the *S\_SafePositionValid* status is lost, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

## Danger!

If the safety function SLP is used in the safe application, then the activation and deactivation of this function must be tested when commissioning the machine!

The test should contain at least one violation of each position limit. The error response must be tested accordingly!

## 4.16 Safe Maximum Position, SMP

### 4.16.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Safe Maximum Position	Used / Not used	Activates the SMP safety function by configuration	Not used
Safety Position Limits			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 105: SMP safety function parameters

### 4.16.2 Behavior

The difference between SMP and SLP is that SMP cannot be actively requested. It is either enabled or disabled by the configuration.

When enabled, the current position is constantly monitored against a defined position window.

The "Safe Lower Position Limit for SMP" and "Safe Upper Position Limit for SMP" parameters can be used to configure the lower and upper position limits of the monitoring range.

The SMP safety function only works with homed axes since it requires a safe absolute position.

If SMP is configured, a 15-minute timeout begins once pulse disabling is activated, within which the homing procedure must take place.

Once homing is complete and if there were no errors during monitoring, the `S_SafetyActiveSMP` status bit is set to SAFETRUE.

### Information:

The axis must be homed successfully before using the function Safe Maximum Position.

If a homing procedure is not successful within 15 min after pulse disabling is activated or the `S_SafePositionValid` status is lost on an axis that has already been homed or if the position window or the position-dependent speed limit is violated, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output `S_NotErrFUNC` is reset and the drive becomes torque-free and force-free, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous.

As with the SLP safety function, the Safe Maximum Position function also monitors a position-dependent speed limit in addition to the position in order to minimize the remaining distance if the position window is exceeded.

For more information, please refer to the description of the safety function "Safely Limited Position, SLP".

### Danger!

In the worst case, the monitored position window can be passed while the axis is spinning out. This must be taken into account when defining the limits!

If the position window has been exceeded, then movement is only possible in the direction of the position window after the Functional Fail Safe state has been acknowledged.

An attempt to move beyond the standstill tolerance in the unsafe direction (i.e. away from the position window) will cause the module to enter the acknowledgeable error state "Functional Fail Safe".

### Danger!

If the safety function SMP is used in the safe application, then it must be tested when commissioning the machine! The test should contain at least one violation of each position limit. The error response must be tested accordingly!

### Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## 5 Status LEDs

see "Status indicators" on page 19

## 6 SafeMC - Register description

### 6.1 Parameters in the I/O configuration of the SafeMC module

#### Group: Function model

Parameter	Unit	Description	Default value
Function model	---	This parameter is reserved for future function expansions	Default

Table 106: SafeMC parameter I/O configuration: Function model

**Group: General**

Parameter	Unit	Description	Default value						
Module supervised	on/off	System behavior when a module is missing.	Off						
		<table><tr><th>Parameter value</th><th>Description</th></tr><tr><td>On</td><td>Missing module causes service mode to be activated</td></tr><tr><td>Off</td><td>Missing module is ignored</td></tr></table>		Parameter value	Description	On	Missing module causes service mode to be activated	Off	Missing module is ignored
		Parameter value		Description					
		On		Missing module causes service mode to be activated					
Off	Missing module is ignored								
On	Missing module causes service mode to be activated								
Off	Missing module is ignored								
SafeLOGIC ID	---	For applications with multiple SafeLOGIC controllers, this parameter specifies the module's association to a particular SafeLOGIC controller: <ul style="list-style-type: none"><li>Permissible values: 1 - 1024</li></ul>	Assigned automatically						
SafeMODULE ID	---	This parameter is reserved for future function expansions	Assigned automatically						

Table 107: SafeMC parameter I/O configuration: General

**Group: Extended**

Parameter	Unit	Description	Default value
Turn-off delay in $\mu$ s	[ $\mu$ s]	This parameter defines the delay before the SafeMC module should turn off if POWERLINK communication is lost	0

Table 108: SafeMC parameter I/O configuration: Extended

**6.2 SafeDESIGNER parameters****6.2.1 Safety Release 1.3****Group: Basic**

Parameter	Unit	Description	Default value								
Min_required_FW_Rev	Basic Release/ Test Version	This parameter is reserved for future functional expansions.	Basic release								
Optional	No/ Yes/ Startup	This parameter can be used to configure the module as "optional". Optional modules do not have to be present, i.e. SafeLOGIC will not indicate that these modules are not present. However, this parameter does not influence the module's signal or status data.	No								
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>No</td><td>This module is absolutely necessary for the application. The module has to go to Operational mode after start-up and safe communication to the SafeLOGIC device must be properly established (SafeModulOk = SAFETRUE). Processing of the safe application on the SafeLOGIC controller is delayed after startup until this state is achieved for all modules with "Optional = No". After startup, module problems are indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is also made in the logbook.</td></tr><tr><td>Yes</td><td>This module is not necessary for the application. The module is not taken into consideration during start-up, which means the safe application is started regardless of whether the modules with "Optional = Yes" are in Operational mode or if safe communication is properly established between these modules and the SafeLOGIC device. After startup, module problems are NOT indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is NOT made in the logbook.</td></tr><tr><td>Startup</td><td>This module is optional; the system determines how the module will proceed during startup. If, during start-up, it's determined that the module is physically present (regardless of if it's in Operational mode or not), then the module behaves as if "Optional = No" is set. If, during start-up, it's determined that the module is not physically present, the module behaves as if "Optional = Yes" is set.</td></tr></table>		Value	Description	No	This module is absolutely necessary for the application. The module has to go to Operational mode after start-up and safe communication to the SafeLOGIC device must be properly established (SafeModulOk = SAFETRUE). Processing of the safe application on the SafeLOGIC controller is delayed after startup until this state is achieved for all modules with "Optional = No". After startup, module problems are indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is also made in the logbook.	Yes	This module is not necessary for the application. The module is not taken into consideration during start-up, which means the safe application is started regardless of whether the modules with "Optional = Yes" are in Operational mode or if safe communication is properly established between these modules and the SafeLOGIC device. After startup, module problems are NOT indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is NOT made in the logbook.	Startup	This module is optional; the system determines how the module will proceed during startup. If, during start-up, it's determined that the module is physically present (regardless of if it's in Operational mode or not), then the module behaves as if "Optional = No" is set. If, during start-up, it's determined that the module is not physically present, the module behaves as if "Optional = Yes" is set.
		Value		Description							
		No		This module is absolutely necessary for the application. The module has to go to Operational mode after start-up and safe communication to the SafeLOGIC device must be properly established (SafeModulOk = SAFETRUE). Processing of the safe application on the SafeLOGIC controller is delayed after startup until this state is achieved for all modules with "Optional = No". After startup, module problems are indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is also made in the logbook.							
		Yes		This module is not necessary for the application. The module is not taken into consideration during start-up, which means the safe application is started regardless of whether the modules with "Optional = Yes" are in Operational mode or if safe communication is properly established between these modules and the SafeLOGIC device. After startup, module problems are NOT indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is NOT made in the logbook.							
Startup	This module is optional; the system determines how the module will proceed during startup. If, during start-up, it's determined that the module is physically present (regardless of if it's in Operational mode or not), then the module behaves as if "Optional = No" is set. If, during start-up, it's determined that the module is not physically present, the module behaves as if "Optional = Yes" is set.										
External_UDID	No/ Yes-ATTENTION	This parameter enables the option on the module for the expected UDID to be specified externally by the CPU.	No								
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Yes-ATTENTION</td><td>The UDID is determined by the CPU. SafeLOGIC must be restarted when the UDID is changed.</td></tr><tr><td>No</td><td>The UDID is specified by a teach-in procedure during start-up.</td></tr></table>		Value	Description	Yes-ATTENTION	The UDID is determined by the CPU. SafeLOGIC must be restarted when the UDID is changed.	No	The UDID is specified by a teach-in procedure during start-up.		
Value	Description										
Yes-ATTENTION	The UDID is determined by the CPU. SafeLOGIC must be restarted when the UDID is changed.										
No	The UDID is specified by a teach-in procedure during start-up.										

Table 109: SafeMC parameter group: Basic

## Danger!

If the "External\_UDID = Yes-CAUTION" function is used, incorrect specifications from the CPU can lead to safety-critical situations.

Perform an FMEA (Failure Mode and Effects Analysis) in order to detect and handle this situation properly using additional safety measures.

### Group: Safety\_Response\_Time

Parameters	Units	Description	Default value						
Manual_Configuration	Yes / No	<div><div>This parameter makes it possible to manually configure the safe response time for the module.</div><div>Generally, the parameters for safe response time are configured the same for all stations involved in the application. This is why these parameters are configured for the SafeLOGIC controller in the SafeDESIGNER. For application situations in which individual safety functions require optimum response time behavior, the parameters for safe response time can be configured individually on the respective module.</div><table><tr><th>Value</th><th>Description</th></tr><tr><td>Yes</td><td>The parameters for calculating the safe reaction time are taken from the module's "Safety_Response_Time" group.</td></tr><tr><td>No</td><td>The parameters for calculating the safe response time are taken from the "Safety_Response_Time" group on the SafeLOGIC controller.</td></tr></table></div>	Value	Description	Yes	The parameters for calculating the safe reaction time are taken from the module's "Safety_Response_Time" group.	No	The parameters for calculating the safe response time are taken from the "Safety_Response_Time" group on the SafeLOGIC controller.	No
Value	Description								
Yes	The parameters for calculating the safe reaction time are taken from the module's "Safety_Response_Time" group.								
No	The parameters for calculating the safe response time are taken from the "Safety_Response_Time" group on the SafeLOGIC controller.								
Synchronous_Network_Only	Yes / No	<div><div>This parameter determines the synchronization properties of the underlying network.</div><table><tr><th>Value</th><th>Description</th></tr><tr><td>Yes</td><td>In order to calculate the safe response time, networks must be synchronous and their cycle times must either be the same or an integer ratio of the cycle times.</td></tr><tr><td>No</td><td>No requirement for synchronization of the networks.</td></tr></table></div>	Value	Description	Yes	In order to calculate the safe response time, networks must be synchronous and their cycle times must either be the same or an integer ratio of the cycle times.	No	No requirement for synchronization of the networks.	Yes
Value	Description								
Yes	In order to calculate the safe response time, networks must be synchronous and their cycle times must either be the same or an integer ratio of the cycle times.								
No	No requirement for synchronization of the networks.								
Max_X2X_CycleTime_us	[µs]	<div><div>This parameter corresponds with the maximum duration of communication between the SafeMC module and the POWERLINK interface.</div><div><ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul></div></div>	1600						
Max_Powerlink_CycleTime_us	[µs]	<div><div>This parameter specifies the maximum POWERLINK cycle time used to calculate the safe response time.</div><div><ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul></div></div>	5000						
Max_CPU_CrossLinkTask_CycleTime_us	[µs]	<div><div>This parameter specifies the maximum cycle time for the copy task on the CPU used to calculate the safe response time. A value of 0 indicates that a copy task is not included for the response time.</div><div><ul style="list-style-type: none"><li>Permissible values: 0 - 30000 µs</li></ul></div></div>	5000						
Min_X2X_CycleTime_us	[µs]	<div><div>This parameter corresponds with the minimum duration of communication between the SafeMC module and the POWERLINK interface.</div><div><ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul></div></div>	600						
Min_Powerlink_CycleTime_us	[µs]	<div><div>This parameter specifies the minimum POWERLINK cycle time used to calculate the safe response time.</div><div><ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul></div></div>	200						
Min_CPU_CrossLinkTask_CycleTime_us	[µs]	<div><div>This parameter specifies the minimum cycle time for the copy task on the CPU used to calculate the safe response time. A value of 0 indicates that configurations without a copy task are also included for the response time.</div><div><ul style="list-style-type: none"><li>Permissible values: 0 - 30000 µs</li></ul></div></div>	0						
Worst_Case_Response_Time_us	[µs]	<div><div>This parameter specifies the limit value for monitoring the safe response time.</div><div><ul style="list-style-type: none"><li>Permissible values: 3000 - 50000 µs</li></ul></div></div>	50000						

Table 110: SafeMC parameter group: Safety\_Response\_Time

### Group: Encoder Unit System

Parameters	Units	Description	Default value
Number of encoder revolutions	---	<p>Unit scale: x-revolutions</p> <p>Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration).</p> <p>To do this, the relationship between a whole number multiple of this unit (units per x-revolutions) and a certain number of encoder revolutions (x-revolutions) has to be previously defined.</p>	1
Units per number of encoder revolutions	[units]	<p>Unit scale: Units per x revolutions</p> <p>Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration).</p> <p>To do this, the relationship between a whole number multiple of this unit (units per x-revolutions) and a certain number of encoder revolutions (x-revolutions) has to be previously defined.</p>	1000

Table 111: SafeMC parameter group: Encoder Unit System

Parameters	Units	Description	Default value	
Counting direction	Default/ Inverse	Counting direction of the position or speed		Standard
		Value	Description	
		Standard	Encoder counting direction is equal to the counting direction of the unit system	
		Inverse	Encoder counting direction is negative to the counting direction of the unit system	
Maximum speed to normalize the speed range	[units/s]	Maximum speed to which the displayed speed should be normalized The safe speed signal is a signed 2 byte value. A speed $v_{phys}$ that is higher than the value range must be scaled before it can be displayed. $v_{scaled} = (v_{phys} * 32767) / \text{MaxSpeedToNormalizeTheSpeedRange}$	32767	

Table 111: SafeMC parameter group: Encoder Unit System

## Information:

The physical drive speed cannot exceed the value set on the parameter *Maximum speed to normalize the speed range [units/s]*, or else the SafeMC module will change to the error state!

## Danger!

False configuration of the unit system can cause dangerous situations.  
 When validating the application, the monitored speed limits must be intentionally violated and their physical values tested! The same must also be done for the monitored direction of rotation!

### Group: Safety deceleration ramp

Parameter	Unit	Description	Default value
Deceleration Ramp [units/s²]	[units/s²]	Slope of the deceleration ramp to be monitored	1073676289

Table 112: SafeMC parameter group: Safety deceleration ramp

### Group: General settings

Parameters	Units	Description	Default value						
Safe Maximum Speed	Used/ Unused	Activates the SMS safety function by configuration.	Used						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Used</td><td>SMS is activated</td></tr><tr><td>Unused</td><td>SMS is deactivated</td></tr></table>		Value	Description	Used	SMS is activated	Unused	SMS is deactivated
		Value		Description					
		Used		SMS is activated					
Unused	SMS is deactivated								
Automatic Reset at Startup	Used/ Unused	Activates automatic reset of the function block at startup	Unused						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Used</td><td>After starting up, the module automatically changes to the state, "Operational" (start reset). The Reset input does not have to be actuated!</td></tr><tr><td>Unused</td><td>After startup, the module gets stuck in an Init state, until a positive edge is detected on the Reset input.</td></tr></table>		Value	Description	Used	After starting up, the module automatically changes to the state, "Operational" (start reset). The Reset input does not have to be actuated!	Unused	After startup, the module gets stuck in an Init state, until a positive edge is detected on the Reset input.
		Value		Description					
		Used		After starting up, the module automatically changes to the state, "Operational" (start reset). The Reset input does not have to be actuated!					
Unused	After startup, the module gets stuck in an Init state, until a positive edge is detected on the Reset input.								
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>HighSide</td><td>The high side IGBTs are actuated with the function STO1.</td></tr><tr><td>LowSide</td><td>The low side IGBTs are actuated with the function STO1.</td></tr></table>		Value	Description	HighSide	The high side IGBTs are actuated with the function STO1.	LowSide	The low side IGBTs are actuated with the function STO1.
		Value		Description					
		HighSide		The high side IGBTs are actuated with the function STO1.					
LowSide	The low side IGBTs are actuated with the function STO1.								
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>When changing to the safe state of the SS1 function, a deceleration ramp is also monitored, in addition to the configurable time</td></tr><tr><td>Deactivated</td><td>When changing to the safe state of the SS1 function, only a configurable time is monitored</td></tr></table>		Value	Description	Activated	When changing to the safe state of the SS1 function, a deceleration ramp is also monitored, in addition to the configurable time	Deactivated	When changing to the safe state of the SS1 function, only a configurable time is monitored
		Value		Description					
		Activated		When changing to the safe state of the SS1 function, a deceleration ramp is also monitored, in addition to the configurable time					
Deactivated	When changing to the safe state of the SS1 function, only a configurable time is monitored								
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is activated	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>When changing to the safe state of the SS2 function, a deceleration ramp is also monitored, in addition to the configurable time</td></tr><tr><td>Deactivated</td><td>When changing to the safe state of the SS2 function, only a configurable time is monitored</td></tr></table>		Value	Description	Activated	When changing to the safe state of the SS2 function, a deceleration ramp is also monitored, in addition to the configurable time	Deactivated	When changing to the safe state of the SS2 function, only a configurable time is monitored
		Value		Description					
		Activated		When changing to the safe state of the SS2 function, a deceleration ramp is also monitored, in addition to the configurable time					
Deactivated	When changing to the safe state of the SS2 function, only a configurable time is monitored								
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is activated	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>When changing to the safe state of the SLS function, a deceleration ramp is also monitored, in addition to the configurable time</td></tr><tr><td>Deactivated</td><td>When changing to the safe state of the SLS function, only a configurable time is monitored</td></tr></table>		Value	Description	Activated	When changing to the safe state of the SLS function, a deceleration ramp is also monitored, in addition to the configurable time	Deactivated	When changing to the safe state of the SLS function, only a configurable time is monitored
		Value		Description					
		Activated		When changing to the safe state of the SLS function, a deceleration ramp is also monitored, in addition to the configurable time					
Deactivated	When changing to the safe state of the SLS function, only a configurable time is monitored								

Table 113: SafeMC parameter group: General settings



Parameters	Units	Description	Default value	
Early Limit Monitoring	Activated/ Deactivated	Deceleration ramp monitoring is terminated prematurely if the value drops below the lower limit	Deactivated	
		"Early Limit Monitoring": If the current speed during the deceleration process falls below the end speed limit of the activated safety function for a defined amount of time, then the safe state of the respective function will be activated prematurely.		
		Value		Description
		Activated		"Early Limit Monitoring" is active!
		Deactivated		"Early Limit Monitoring" is not active!

Table 113: SafeMC parameter group: General settings

## Danger!

The parameter "Automatic Reset at Startup" activates/deactivates the restart inhibit during startup or when a network failure occurs.

If the parameter "Automatic Reset at Startup" is set to "Used", then the module automatically changes to "Operational" state (i.e. pulse disabling and the motor holding brake are enabled)!

Configuring an automatic restart can result in critical situations in relation to safety. The user must implement additional measures to ensure correct, safety-related functionality.

### Group: Encoder Monitoring

Parameter	Unit	Description	Default value						
Encoder Position monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the position lag error generated on the SafeMC module.	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>Monitoring active</td></tr><tr><td>Deactivated</td><td>Monitoring not active</td></tr></table>		Value	Description	Activated	Monitoring active	Deactivated	Monitoring not active
		Value		Description					
		Activated		Monitoring active					
Deactivated	Monitoring not active								
Encoder Speed monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the speed error generated on the SafeMC module.	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>Monitoring active</td></tr><tr><td>Deactivated</td><td>Monitoring not active</td></tr></table>		Value	Description	Activated	Monitoring active	Deactivated	Monitoring not active
		Value		Description					
		Activated		Monitoring active					
Deactivated	Monitoring not active								
Set position alive testing	Activated / Deactivated	Activates/deactivates the monitor that detects whether the set position generated on the ACOPOSmulti is frozen.	Deactivated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>Monitoring active</td></tr><tr><td>Deactivated</td><td>Monitoring not active</td></tr></table>		Value	Description	Activated	Monitoring active	Deactivated	Monitoring not active
		Value		Description					
		Activated		Monitoring active					
Deactivated	Monitoring not active								

Table 114: SafeMC parameter group: Encoder Monitoring

## Danger!

To achieve safety level SIL 2 for the safety functions that require safe encoder evaluation, any mechanical errors on the connection between the motor shaft and encoder must be identified and prevented! Simply using the function group "Encoder Monitoring" together with the parameters from the group "Encoder Monitoring Tolerances" is not sufficient for achieving SIL 2.

## Information:

The function group "Encoder Monitoring" together with the parameters from the group "Encoder Monitoring Tolerances" is not considered to be suitable for safety purposes because signals from the non-safety-related part of the inverter module are evaluated here. However, it is still recommended to enable this function to help detect potential errors early-on!

### Group: Behavior of Functional Fail Safe

Parameter	Unit	Description		Default value
Behavior of Functional Fail Safe	STO / STO1 and STO with time delay	In the Functional Fail Safe state, STO and SBC is activated immediately or STO1 and then STO after a delay		STO
		Value	Description	
		STO	In the Functional Fail Safe state, STO and SBC is activated immediately.	
		STO1 and STO with time delay	In the Functional Fail Safe state, STO1 is activated first and then STO and SBC after a delay.	
Delay for STO in Functional Fail Safe [µs]	[µs]	Delay time between STO1 and STO (and SBC) in the Functional Fail Safe state		0
Delay time until the brake engages [µs]	[µs]	<b>Delay time before the brake engages</b> The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.		0

Table 115: SafeMC parameter group: Safety deceleration ramp

**Group: Safety Speed Limits**

Parameter	Unit	Description	Default value
Maximum Speed for SMS (units/s)	[units/s]	Speed limit of the maximum speed (SMS)	0
Safe Speedlimit 1 for SLS (units/s)	[units/s]	Speed Limit 1 for SLS (SLS1)	0
Safe Speedlimit 2 for SLS (units/s)	[units/s]	Speed Limit 2 for SLS (SLS2)	0
Safe Speedlimit 3 for SLS (units/s)	[units/s]	Speed Limit 3 for SLS (SLS3)	0
Safe Speedlimit 4 for SLS (units/s)	[units/s]	Speed Limit 4 for SLS (SLS4)	0

Table 116: SafeMC parameter group: Safety Speed Limits

**Danger!**

The speed limit being monitored must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous speed cannot be exceeded in the event of error.

The dangerous speed must be determined by a risk analysis.

**Information:**

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} \leq \text{NormSpeedMax}$$

This is required for setting priority of the safety functions on the SafeMC module.

If this rule is not adhered to, then the SafeMC module immediately changes to the Fail Safe state after startup. The application in SafeDESIGNER must be set accordingly!

**Group: Safety Standstill and Direction Tolerances**

Parameter	Unit	Description	Default value
Speed Tolerance (units /s)	[units/s]	Speed tolerance for standstill monitoring (SOS)	0
Position Tolerance (units)	[units]	Position tolerance for standstill and direction monitoring	0

Table 117: SafeMC parameter group: Safety Standstill and Direction Tolerances

**Danger!**

The speed limit and position limit being monitored must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous movement cannot occur in the event of error.

The dangerous movement must be determined by a risk analysis.

**Group: Safely Limited Increment**

Parameter	Unit	Description	Default value
Safe Increments (units)	[units]	Maximum moveable increments when SLI is active	0
SLI Off Delay (μs)	[μs]	Switch off delay of SLI	0

Table 118: SafeMC parameter group: Safely Limited Increment

**Danger!**

The maximum increment range must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous movement cannot occur in the event of error.

The dangerous movement must be determined by a risk analysis.

**Group: Safety Ramp Monitoring Times**

Parameter	Unit	Description	Default value
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0

Table 119: SafeMC parameter group: Safety Ramp Monitoring Times

Parameter	Unit	Description	Default value
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Ramp Monitoring Time for SLS4 (us)	[μs]	Deceleration monitoring time for SLS4	0

Table 119: SafeMC parameter group: Safety Ramp Monitoring Times

**Group: Safety Additional Parameters**

Parameters	Units	Description	Default value
Delay time to start ramp monitoring	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Delay time to start SDI	[μs]	Delay time between request of SDI and activation of the safety function	0
Delay time to start SBC	[μs]	Delay time between request of SBC and activation of the safety function	0
Early Limit Monitoring time	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 120: SafeMC parameter group: Safety Additional Parameters

**Danger!**

The delay parameters cause a delay before the safety function is started. This delay must be accounted for when determining the increments and performing the risk analysis!

**Group: Encoder Monitoring Tolerances**

Parameter	Unit	Description	Default value
Encoder Monitoring Position Tolerance (units)	[units]	Position lag error tolerance for shaft breakage monitoring	0
Encoder Monitoring Speed Tolerance (units/s)	[units/s]	Speed error tolerance for encoder monitoring	0

Table 121: SafeMC parameter group: Encoder Monitoring Tolerances

**Danger!**

To achieve safety level SIL 2 for the safety functions that require safe encoder evaluation, any mechanical errors on the connection between the motor shaft and encoder must be identified and prevented! Simply using the function group "Encoder Monitoring" together with the parameters from the group "Encoder Monitoring Tolerances" is not sufficient for achieving SIL 2.

**Information:**

The function group "Encoder Monitoring" together with the parameters from the group "Encoder Monitoring Tolerances" is not considered to be suitable for safety purposes because signals from the non-safety-related part of the inverter module are evaluated here. However, it is still recommended to enable this function to help detect potential errors early-on!

## 6.2.2 Safety Release 1.4

### Group: Basic

Parameter	Unit	Description	Default value								
Min_required_FW_Rev	Basic Release/ Test Version	This parameter is reserved for future functional expansions.	Basic release								
Optional	No/ Yes/ Startup	This parameter can be used to configure the module as "optional". Optional modules do not have to be present, i.e. SafeLOGIC will not indicate that these modules are not present. However, this parameter does not influence the module's signal or status data.	No								
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>No</td><td>This module is absolutely necessary for the application. The module has to go to Operational mode after start-up and safe communication to the SafeLOGIC device must be properly established (SafeModulOk = SAFETRUE). Processing of the safe application on the SafeLOGIC controller is delayed after startup until this state is achieved for all modules with "Optional = No". After startup, module problems are indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is also made in the logbook.</td></tr><tr><td>Yes</td><td>This module is not necessary for the application. The module is not taken into consideration during start-up, which means the safe application is started regardless of whether the modules with "Optional = Yes" are in Operational mode or if safe communication is properly established between these modules and the SafeLOGIC device. After startup, module problems are NOT indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is NOT made in the logbook.</td></tr><tr><td>Startup</td><td>This module is optional; the system determines how the module will proceed during startup. If, during start-up, it's determined that the module is physically present (regardless of if it's in Operational mode or not), then the module behaves as if "Optional = No" is set. If, during start-up, it's determined that the module is not physically present, the module behaves as if "Optional = Yes" is set.</td></tr></table>		Value	Description	No	This module is absolutely necessary for the application. The module has to go to Operational mode after start-up and safe communication to the SafeLOGIC device must be properly established (SafeModulOk = SAFETRUE). Processing of the safe application on the SafeLOGIC controller is delayed after startup until this state is achieved for all modules with "Optional = No". After startup, module problems are indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is also made in the logbook.	Yes	This module is not necessary for the application. The module is not taken into consideration during start-up, which means the safe application is started regardless of whether the modules with "Optional = Yes" are in Operational mode or if safe communication is properly established between these modules and the SafeLOGIC device. After startup, module problems are NOT indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is NOT made in the logbook.	Startup	This module is optional; the system determines how the module will proceed during startup. If, during start-up, it's determined that the module is physically present (regardless of if it's in Operational mode or not), then the module behaves as if "Optional = No" is set. If, during start-up, it's determined that the module is not physically present, the module behaves as if "Optional = Yes" is set.
		Value		Description							
		No		This module is absolutely necessary for the application. The module has to go to Operational mode after start-up and safe communication to the SafeLOGIC device must be properly established (SafeModulOk = SAFETRUE). Processing of the safe application on the SafeLOGIC controller is delayed after startup until this state is achieved for all modules with "Optional = No". After startup, module problems are indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is also made in the logbook.							
		Yes		This module is not necessary for the application. The module is not taken into consideration during start-up, which means the safe application is started regardless of whether the modules with "Optional = Yes" are in Operational mode or if safe communication is properly established between these modules and the SafeLOGIC device. After startup, module problems are NOT indicated by a quickly blinking MXCHG LED on the SafeLOGIC controller. An entry is NOT made in the logbook.							
Startup	This module is optional; the system determines how the module will proceed during startup. If, during start-up, it's determined that the module is physically present (regardless of if it's in Operational mode or not), then the module behaves as if "Optional = No" is set. If, during start-up, it's determined that the module is not physically present, the module behaves as if "Optional = Yes" is set.										
External_UDID	No/ Yes-ATTENTION	This parameter enables the option on the module for the expected UDID to be specified externally by the CPU.	No								
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Yes-ATTENTION</td><td>The UDID is determined by the CPU. SafeLOGIC must be restarted when the UDID is changed.</td></tr><tr><td>No</td><td>The UDID is specified by a teach-in procedure during start-up.</td></tr></table>		Value	Description	Yes-ATTENTION	The UDID is determined by the CPU. SafeLOGIC must be restarted when the UDID is changed.	No	The UDID is specified by a teach-in procedure during start-up.		
		Value		Description							
		Yes-ATTENTION		The UDID is determined by the CPU. SafeLOGIC must be restarted when the UDID is changed.							
No	The UDID is specified by a teach-in procedure during start-up.										

Table 122: SafeMC parameter group: Basic

### Danger!

If the "External\_UDID = Yes-CAUTION" function is used, incorrect specifications from the CPU can lead to safety-critical situations.

Perform an FMEA (Failure Mode and Effects Analysis) in order to detect and handle this situation properly using additional safety measures.

### Group: Safety\_Response\_Time

Parameters	Units	Description	Default value						
Manual_Configuration	Yes / No	This parameter makes it possible to manually configure the safe response time for the module. Generally, the parameters for safe response time are configured the same for all stations involved in the application. This is why these parameters are configured for the SafeLOGIC controller in the SafeDESIGNER. For application situations in which individual safety functions require optimum response time behavior, the parameters for safe response time can be configured individually on the respective module.	No						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Yes</td><td>The parameters for calculating the safe reaction time are taken from the module's "Safety_Response_Time" group.</td></tr><tr><td>No</td><td>The parameters for calculating the safe response time are taken from the "Safety_Response_Time" group on the SafeLOGIC controller.</td></tr></table>		Value	Description	Yes	The parameters for calculating the safe reaction time are taken from the module's "Safety_Response_Time" group.	No	The parameters for calculating the safe response time are taken from the "Safety_Response_Time" group on the SafeLOGIC controller.
		Value		Description					
		Yes		The parameters for calculating the safe reaction time are taken from the module's "Safety_Response_Time" group.					
No	The parameters for calculating the safe response time are taken from the "Safety_Response_Time" group on the SafeLOGIC controller.								

Table 123: SafeMC parameter group: Safety\_Response\_Time

Parameters	Units	Description	Default value						
Synchronous_Network_Only	Yes / No	<div>This parameter determines the synchronization properties of the underlying network.</div> <table><tr><th>Value</th><th>Description</th></tr><tr><td>Yes</td><td>In order to calculate the safe response time, networks must be synchronous and their cycle times must either be the same or an integer ratio of the cycle times.</td></tr><tr><td>No</td><td>No requirement for synchronization of the networks.</td></tr></table>	Value	Description	Yes	In order to calculate the safe response time, networks must be synchronous and their cycle times must either be the same or an integer ratio of the cycle times.	No	No requirement for synchronization of the networks.	Yes
Value	Description								
Yes	In order to calculate the safe response time, networks must be synchronous and their cycle times must either be the same or an integer ratio of the cycle times.								
No	No requirement for synchronization of the networks.								
Max_X2X_CycleTime_us	[µs]	<div>This parameter corresponds with the maximum duration of communication between the SafeMC module and the POWERLINK interface.</div> <ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul>	1600						
Max_Powerlink_CycleTime_us	[µs]	<div>This parameter specifies the maximum POWERLINK cycle time used to calculate the safe response time.</div> <ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul>	5000						
Max_CPU_CrossLinkTask_CycleTime_us	[µs]	<div>This parameter specifies the maximum cycle time for the copy task on the CPU used to calculate the safe response time. A value of 0 indicates that a copy task is not included for the response time.</div> <ul style="list-style-type: none"><li>Permissible values: 0 - 30000 µs</li></ul>	5000						
Min_X2X_CycleTime_us	[µs]	<div>This parameter corresponds with the minimum duration of communication between the SafeMC module and the POWERLINK interface.</div> <ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul>	600						
Min_Powerlink_CycleTime_us	[µs]	<div>This parameter specifies the minimum POWERLINK cycle time used to calculate the safe response time.</div> <ul style="list-style-type: none"><li>Permissible values: 200 - 30000 µs</li></ul>	200						
Min_CPU_CrossLinkTask_CycleTime_us	[µs]	<div>This parameter specifies the minimum cycle time for the copy task on the CPU used to calculate the safe response time. A value of 0 indicates that configurations without a copy task are also included for the response time.</div> <ul style="list-style-type: none"><li>Permissible values: 0 - 30000 µs</li></ul>	0						
Worst_Case_Response_Time_us	[µs]	<div>This parameter specifies the limit value for monitoring the safe response time.</div> <ul style="list-style-type: none"><li>Permissible values: 3000 - 50000 µs</li></ul>	50000						

Table 123: SafeMC parameter group: Safety\_Response\_Time

**Group: Encoder Unit System**

Parameters	Units	Description	Default value						
Count of physical reference system	---	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: x-reference lengths (Reference length = Length of the physical reference system) Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1						
Units per count of physical reference system [units]	[units]	Rotary encoder unit-scale: Units per x revolutions Linear encoder unit scale: Units per x reference lengths Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1000						
Counting direction	Default/ Inverse	Counting direction of the position or speed <table><tr><th>Value</th><th>Description</th></tr><tr><td>Standard</td><td>Encoder counting direction is equal to the counting direction of the unit system</td></tr><tr><td>Inverse</td><td>Encoder counting direction is negative to the counting direction of the unit system</td></tr></table>	Value	Description	Standard	Encoder counting direction is equal to the counting direction of the unit system	Inverse	Encoder counting direction is negative to the counting direction of the unit system	Standard
Value	Description								
Standard	Encoder counting direction is equal to the counting direction of the unit system								
Inverse	Encoder counting direction is negative to the counting direction of the unit system								
Length of physical reference system for linear encoder (nm)	[nm]	For linear measurement systems, the length of a physical reference system will be defined here. This value is not used for rotary encoders, where the reference system is a single rotation.	1000000000						
Maximum speed to normalize the speed range (units/s)	[units/s]	Maximum speed to which the displayed speed should be normalized The safe speed signal is a signed 2 byte value. A speed $v_{phys}$ that is higher than the value range must be scaled before it can be displayed. $v_{scaled} = (v_{phys} * 32767) / \text{MaxSpeedToNormalizeTheSpeedRange}$	32767						
Maximum acceleration (rad/s <sup>2</sup> or mm/s <sup>2</sup> )	[rad/s <sup>2</sup> ] or [mm/s <sup>2</sup> ]	Maximum permissible encoder acceleration	100000						

Table 124: SafeMC parameter group: Encoder Unit System

**Information:**

The physical drive speed cannot exceed the value set on the parameter *Maximum speed to normalize the speed range [units/s]*, or else the SafeMC module will change to the error state!

## Danger!

The frictional connection between the cone-shaped shaft of the rotor and EnDat measurement device is dimensioned for maximum rotor acceleration in accordance with the Heidenhain installation instructions. This acceleration value must not be exceeded in the worst case. The maximum acceleration is monitored on the SafeMC module and can be configured using the parameter "*Maximum acceleration*".

## Danger!

False configuration of the unit system can cause dangerous situations.

When validating the application, the monitored speed limits must be intentionally violated and their physical values tested! The same must also be done for the monitored direction of rotation!

### Group: Homing

Parameter	Unit	Description	Default value
Home Position or Home Offset (units)	[units]	Reference position or homing offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time (µs)	[µs]	Monitoring time for the homing procedure	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Correction	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive / Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive
Trigger direction	Positive / Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used / Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0

Table 125: SafeMC parameter group: Homing

### Group: Safety deceleration ramp

Parameter	Unit	Description	Default value
Deceleration Ramp [units/s²]	[units/s²]	Slope of the deceleration ramp to be monitored	1073676289

Table 126: SafeMC parameter group: Safety deceleration ramp

### Group: General settings

Parameter	Unit	Description		Default value
Safe Maximum Speed	Used/ Unused	Activates the SMS safety function by configuration.		Used
		Value	Description	
		Used	SMS is activated	
		Unused	SMS is deactivated	
Automatic Reset at Startup	Used/ Unused	Activates automatic reset of the function block at startup		Unused
		Value	Description	
		Used	After starting up, the module automatically changes to the state, "Operational" (start reset). The Reset input does not have to be actuated!	
		Unused	After startup, the module gets stuck in an Init state, until a positive edge is detected on the Reset input.	
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function		HighSide
		Value	Description	
		HighSide	The high side IGBTs are actuated with the function STO1.	
		LowSide	The low side IGBTs are actuated with the function STO1.	

Table 127: SafeMC parameter group: General settings

Parameter	Unit	Description	Default value						
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>When changing to the safe state of the SS1 function, a deceleration ramp is also monitored, in addition to the configurable time</td></tr><tr><td>Deactivated</td><td>When changing to the safe state of the SS1 function, only a configurable time is monitored</td></tr></table>		Value	Description	Activated	When changing to the safe state of the SS1 function, a deceleration ramp is also monitored, in addition to the configurable time	Deactivated	When changing to the safe state of the SS1 function, only a configurable time is monitored
		Value		Description					
		Activated		When changing to the safe state of the SS1 function, a deceleration ramp is also monitored, in addition to the configurable time					
Deactivated	When changing to the safe state of the SS1 function, only a configurable time is monitored								
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is requested	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>When changing to the safe state of the SS2 function, a deceleration ramp is also monitored, in addition to the configurable time</td></tr><tr><td>Deactivated</td><td>When changing to the safe state of the SS2 function, only a configurable time is monitored</td></tr></table>		Value	Description	Activated	When changing to the safe state of the SS2 function, a deceleration ramp is also monitored, in addition to the configurable time	Deactivated	When changing to the safe state of the SS2 function, only a configurable time is monitored
		Value		Description					
		Activated		When changing to the safe state of the SS2 function, a deceleration ramp is also monitored, in addition to the configurable time					
Deactivated	When changing to the safe state of the SS2 function, only a configurable time is monitored								
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>When changing to the safe state of the SLS function, a deceleration ramp is also monitored, in addition to the configurable time</td></tr><tr><td>Deactivated</td><td>When changing to the safe state of the SLS function, only a configurable time is monitored</td></tr></table>		Value	Description	Activated	When changing to the safe state of the SLS function, a deceleration ramp is also monitored, in addition to the configurable time	Deactivated	When changing to the safe state of the SLS function, only a configurable time is monitored
		Value		Description					
		Activated		When changing to the safe state of the SLS function, a deceleration ramp is also monitored, in addition to the configurable time					
Deactivated	When changing to the safe state of the SLS function, only a configurable time is monitored								
Early Limit Monitoring	Activated/ Deactivated	Deceleration ramp monitoring is terminated prematurely if the value drops below the lower limit "Early Limit Monitoring": If the current speed during the deceleration process falls below the end speed limit of the activated safety function for a defined amount of time, then the safe state of the respective function will be activated prematurely.	Deactivated						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Activated</td><td>"Early Limit Monitoring" is active!</td></tr><tr><td>Deactivated</td><td>"Early Limit Monitoring" is not active!</td></tr></table>		Value	Description	Activated	"Early Limit Monitoring" is active!	Deactivated	"Early Limit Monitoring" is not active!
		Value		Description					
		Activated		"Early Limit Monitoring" is active!					
Deactivated	"Early Limit Monitoring" is not active!								
Safe Maximum Position	Used/ Unused	Activates the SMP safety function by configuration	Unused						
		<table><tr><th>Value</th><th>Description</th></tr><tr><td>Used</td><td>SMP is activated</td></tr><tr><td>Unused</td><td>SMP is deactivated</td></tr></table>		Value	Description	Used	SMP is activated	Unused	SMP is deactivated
		Value		Description					
		Used		SMP is activated					
Unused	SMP is deactivated								

Table 127: SafeMC parameter group: General settings

**Danger!**

The parameter "Automatic Reset at Startup" activates/deactivates the restart inhibit during startup or when a network failure occurs.

If the parameter "Automatic Reset at Startup" is set to "Used", then the module automatically changes to "Operational" state (i.e. pulse disabling and the motor holding brake are enabled)!

Configuring an automatic restart can result in critical situations in relation to safety. Implement additional measures to ensure proper safety-related functionality.

**Group: Encoder Monitoring**

Parameter	Unit	Description		Default value
Encoder Position monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the position lag error generated on the SafeMC module.		Activated
		Value	Description	
		Activated	Monitoring active	
		Deactivated	Monitoring not active	
Encoder Speed monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the speed error generated on the SafeMC module.		Activated
		Value	Description	
		Activated	Monitoring active	
		Deactivated	Monitoring not active	
Set position alive testing	Activated / Deactivated	Activates/deactivates the monitor that detects whether the set position generated on the ACOPOSmulti is frozen.		Deactivated
		Value	Description	
		Activated	Monitoring active	
		Deactivated	Monitoring not active	

Table 128: SafeMC parameter group: Encoder Monitoring

**Group: Behavior of Functional Fail Safe**

Parameter	Unit	Description	Default value	
Behavior of Functional Fail Safe	STO / STO1 and STO with time delay	In the Functional Fail Safe state, STO and SBC is activated immediately or STO1 and then STO after a delay		STO
		Value	Description	
		STO	In the Functional Fail Safe state, STO and SBC is activated immediately.	
		STO1 and STO with time delay	In the Functional Fail Safe state, STO1 is activated first and then STO and SBC after a delay.	
Delay for STO in Functional Fail Safe [μs]	[μs]	Delay time between STO1 and STO (and SBC) in the Functional Fail Safe state	0	
Delay time until the brake engages [μs]	[μs]	<b>Delay time before the brake engages</b> The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.	0	

Table 129: SafeMC parameter group: Safety deceleration ramp

**Group: Safety Speed Limits**

Parameter	Unit	Description	Default value
Maximum Speed for SMS (units/s)	[units/s]	Speed limit of the maximum speed (SMS)	0
Safe Speedlimit 1 for SLS (units/s)	[units/s]	Speed Limit 1 for SLS (SLS1)	0
Safe Speedlimit 2 for SLS (units/s)	[units/s]	Speed Limit 2 for SLS (SLS2)	0
Safe Speedlimit 3 for SLS (units/s)	[units/s]	Speed Limit 3 for SLS (SLS3)	0
Safe Speedlimit 4 for SLS (units/s)	[units/s]	Speed Limit 4 for SLS (SLS4)	0

Table 130: SafeMC parameter group: Safety Speed Limits

**Danger!**

The speed limit being monitored must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous speed cannot be exceeded in the event of error.

The dangerous speed must be determined by a risk analysis.

**Information:**

The following application rule must be observed:

$$LIM_{SOS} \leq LIM_{SLS4} \leq LIM_{SLS3} \leq LIM_{SLS2} \leq LIM_{SLS1} \leq LIM_{SMS} \leq NormSpeedMax$$

This is required for setting priority of the safety functions on the SafeMC module.

If this rule is not adhered to, then the SafeMC module immediately changes to the Fail Safe state after startup. The application in SafeDESIGNER must be set accordingly!

**Group: Safety Position Limits**

Parameter	Unit	Description	Default value
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0

Table 131: SafeMC parameter group: Safety Position Limits

**Danger!**

The position limits being monitored must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous movement cannot occur in the event of error.

The dangerous movement must be determined by a risk analysis.



## Information:

The following application rule must be observed:

$$\text{LIM}_{\text{SMP,NEG}} \leq \text{LIM}_{\text{SLP,NEG}} \leq \text{LIM}_{\text{SLP,POS}} \leq \text{LIM}_{\text{SMP,POS}}$$

If this rule is not adhered to, then the SafeMC module immediately changes to the Fail Safe state after startup. The application in SafeDESIGNER must be set accordingly!

### Group: Safety Standstill and Direction Tolerances

Parameter	Unit	Description	Default value
Speed Tolerance (units /s)	[units/s]	Speed tolerance for standstill monitoring (SOS)	0
Position Tolerance (units)	[units]	Position tolerance for standstill and direction monitoring	0

Table 132: SafeMC parameter group: Safety Standstill and Direction Tolerances

## Danger!

The speed limit and position limit being monitored must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous movement cannot occur in the event of error.

The dangerous movement must be determined by a risk analysis.

### Group: Safely Limited Increment

Parameter	Unit	Description	Default value
Safe Increments (units)	[units]	Maximum moveable increments when SLI is active	0
SLI Off Delay (μs)	[μs]	Switch off delay of SLI	0

Table 133: SafeMC parameter group: Safely Limited Increment

## Danger!

The maximum increment range must be set in such a manner that, with consideration for the error response time and the resulting movement in the worst case scenario, a dangerous movement cannot occur in the event of error.

The dangerous movement must be determined by a risk analysis.

### Group: Safety Ramp Monitoring Times

Parameter	Unit	Description	Default value
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Ramp Monitoring Time for SLS4 (us)	[μs]	Deceleration monitoring time for SLS4	0

Table 134: SafeMC parameter group: Safety Ramp Monitoring Times

### Group: Safety Additional Parameters

Parameter	Unit	Description	Default value
Delay time to start ramp monitoring (μs)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Delay time to start SDI (μs)	[μs]	Delay time between the SDI request and activation of the safety function	0
Delay time to start SBC (μs)	[μs]	Delay time between the SBC request and activation of the safety function	0
Delay time to start SLP (μs)	[μs]	Delay time between request of SLP and start of monitoring	0
Early Limit Monitoring time (μs)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 135: SafeMC parameter group: Safety Additional Parameters

## Danger!

The delay parameters cause a delay before the safety function is started. This delay must be accounted for when determining the increments and performing the risk analysis!

### Group: Encoder Monitoring Tolerances

Parameter	Unit	Description	Default value
Encoder Monitoring Position Tolerance (units)	[units]	Position lag error tolerance for shaft breakage monitoring	0
Encoder Monitoring Speed Tolerance (units/s)	[units/s]	Speed error tolerance for encoder monitoring	0

Table 136: SafeMC parameter group: Encoder Monitoring Tolerances

## 6.3 Channel list

Channel Name	Starting safety lease	in re-	Access via Automation Studio	Access via SafeDESIGN-ER	Data type	Description
ModulOK	R 13		Read	---	BOOL	Indicates if the module is OK
SerialNumber	R 13		Read <sup>1)</sup>	---	UDINT	Module serial number
ModuleID	R 13		Read <sup>1)</sup>	---	UINT	Module code
HardwareVariant	R 13		Read <sup>1)</sup>	---	UINT	Hardware variants
FirmwareVersion	R 13		Read <sup>2)</sup>	---	UINT	Module firmware version
UDID_low	R 13		(Read) <sup>2)</sup>	---	UDINT	UDID, lower 4 bytes
UDID_high	R 13		(Read) <sup>2)</sup>	---	UINT	UDID, upper 2 bytes
SafetyFWversion1	R 13		(Read) <sup>2)</sup>	---	UINT	Firmware version of safety processor 1
SafetyFWversion2	R 13		(Read) <sup>2)</sup>	---	UINT	Firmware version of safety processor 2
Diag1_Temp	R 13		(Read) <sup>2)</sup>	---	UINT	Module temperature in °C
SafeModuleOK	R 13		---	Read	SAFEBOOL	Indicates if the safe communication channel is OK
SafetyActiveSTO	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	STO safety function status (TRUE = safe state)
SafetyActiveSBC	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SBC safety function status (TRUE = safe state)
SafetyActiveSOS	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SOS safety function status (TRUE = safe state)
SafetyActiveSS1	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SS1 safety function status (TRUE = safe state)
SafetyActiveSS2	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SS2 safety function status (TRUE = safe state)
SafetyActiveSLS1	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SLS1 safety function status (TRUE = safe state)
SafetyActiveSLS2	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SLS2 safety function status (TRUE = safe state)
SafetyActiveSLS3	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SLS3 safety function status (TRUE = safe state)
SafetyActiveSLS4	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SLS4 safety function status (TRUE = safe state)
SafetyActiveSTO1	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	STO1 safety function status (TRUE = safe state)
SafetyActiveSDIpos	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SDIpos safety function status (TRUE = safe state)
SafetyActiveSLI	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SLI safety function status (TRUE = safe state)
SafetyActiveSDIneg	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SDIneg safety function status (TRUE = safe state)
SafetyActiveSLP	R 14		Read	(Read) <sup>3)</sup>	SAFEBOOL	SLP safety function status (TRUE = safe state)
SafetyActiveSMP	R 14		Read	(Read) <sup>3)</sup>	SAFEBOOL	SMP safety function status (TRUE = safe state)
SafePositionValid	R 14		Read	(Read) <sup>3)</sup>	SAFEBOOL	Status of the safe position (TRUE = valid position referencing and no errors found)
StatusSetPosAlive	R 13		Read	---	SAFEBOOL	Status of set position "Alive Testing" (TRUE = valid)
AllReqFuncAct	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	Status of the requested safety functions (TRUE = all requested safety functions are active)
SafetyActiveSDC	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	Status of the delay monitor (TRUE = delay monitoring is active)
Operational	R 13		Read	---	SAFEBOOL	Status of the function block (TRUE = function block is in the state "Operational", "Safe", or "Wait for Confirmation")
NotErrENC	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	Status of the safe encoder (FALSE = pending encoder error)
NotErrFUNC	R 13		Read	(Read) <sup>3)</sup>	SAFEBOOL	SafeMC module status (FALSE = SafeMC module is in the error state Functional Fail Safe)

Table 137: SafeMC channel list

Channel Name	Starting safety lease	in re-	Access via Automation Studio	Access via SafeDESIGN-ER	Data type	Description
ScaledSpeed	R 13		Read	(Read) <sup>3)</sup>	SAFEINT	Safe scaled speed
SafePos	R 14		Read	(Read) <sup>3)</sup>	SAFEDINT	Safe position
RequestSTO	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function STO
RequestSBC	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SBC
RequestSOS	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SOS
RequestSS1	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SS1
RequestSS2	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SS2
RequestSLS1	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SLS1
RequestSLS2	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SLS2
RequestSLS3	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SLS3
RequestSLS4	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SLS4
RequestSTO1	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function STO1
RequestSDIpos	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SDIpos
RequestSLI	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SLI
RequestSDIneg	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SDIneg
RequestSLP	R 14		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Select/deselect the safety function SLP
RequestHoming	R 14		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Request safe homing
ReferenceSwitch	R 14		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Safe input for using a reference switch
Activate	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Enabling the function block
Reset	R 13		(Read) <sup>4)</sup>	(Write) <sup>5)</sup>	SAFEBOOL	Reset input for confirming the "Functional Fail Safe" state.

Table 137: SafeMC channel list

- 1) Channel only visible if the parameter "Module Information" was set to "on"
- 2) This data is accessed in Automation Studio using the ASIOACC library.
- 3) This data is accessed indirectly via the outputs of the function blocks SF\_SafeMC\_BR, SF\_SafeMC\_BR\_V2, SF\_SafeMC\_Speed\_BR or SF\_SafeMC\_Position\_BR
- 4) This data can be accessed via NC Action or Trace.
- 5) This data is accessed indirectly via the inputs of the function block SF\_SafeMC\_BR or SF\_SafeMC\_BR\_V2.

## 7 Programming the safety application

The concept of integrated safety technology in the ACOPOSmulti with SafeMC is based on the function controller remaining fully in the inverter module (as before) and the SafeMC module monitoring configurable limits.

The only exception is that the SafeMC module activates safe pulse disabling and the safe motor holding brake.

The standard application must react accordingly to the request for a safety function.

To ensure proper interaction between the standard and the safe application (and thereby ensuring maximum availability of the system), the different timing of the two applications must be accounted for.




Figure 45: Inverter module timing - SafeMC module

The differing runtimes of the standard and the safe application can be accounted for using the "Delay times for requesting a safety function".

Parameter	Unit	Description	Default value
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Delay time to start SDI (us)	[μs]	Delay time between the SDI request and activation of the safety function	0
Delay time to start SBC (us)	[μs]	Delay time between the SBC request and activation of the safety function	0
Delay time to start SLP (us) <sup>1)</sup>	[μs]	Delay time between request of SLP and start of monitoring	0
Delay time to start SBT (us) <sup>2)</sup>	[μs]	Delay time between the SBT request and activation of the safety function	0

Table 138: Delay times for requesting a safety function

1) Only available in Safety Release 1.4 or higher!

2) Only available in Safety Release 1.7 or higher, only for ACOPOSmulti with SafeMC SinCos!

## 7.1 SafeMC Help Tool

The SafeMC Help Tool assists in the development of SafeMC projects. This program can be used to make calculations that are required frequently.

### 7.1.1 Status and Control Bits tab




Figure 46: SafeMC Help Tool - Status and Control Bits tab

#### "Status Information" section

##### Information:

Status information can be determined by running a trace on the cyclic data (ParID 4).

Showing status bits for the status information that has been determined

1. Specify whether the value that has been determined for the status information is decimal or hexadecimal
2. Enter the value that has been determined in the *Input value* field  
→ The check boxes now show the status bits for the determined status information.

Determining the input value for a combination of status bits

1. Specify whether the input value should be displayed as a decimal or hexadecimal value
2. Set the desired combination of status bits by selecting the check boxes  
→ The input value that corresponds with the combination of status bits is displayed.

#### "Control Information" section

### Information:

**Control information can be determined by running a trace on the cyclic data (ParID 5).**

#### Showing status bits for the control information that has been determined

1. Specify whether the value that has been determined for the control information is decimal or hexadecimal
2. Enter the value that has been determined in the *Input value* field  
→ The check boxes now display the control bits for the control information that has been determined.

#### Determining the input value for a combination of control bits

1. Specify whether the input value should be displayed as a decimal or hexadecimal value
2. Set the desired combination of control bits by selecting the check boxes  
→ The input value that corresponds with the combination of control bits is shown.

## 7.1.2 Velocity tab




Figure 47: SafeMC Help Tool - Velocity tab

### Scaled Speed section

In the *Scaled Speed* section, a scaled speed can be converted to a physical speed [units/s] and vice versa based on the value "Maximum speed to normalize the speed range [units/s]".

The parameter names marked in yellow correspond to the parameters in SafeDESIGNER.

#### Converting scaled → physical speed

1. Enter value for "Maximum speed to normalize the speed range [units/s]"
2. Enter value for scaled speed [units/s]  
→ The respective value for the physical speed [units/s] is shown.

#### Converting physical → scaled speed

1. Enter value for "Maximum speed to normalize the speed range [units/s]"
2. Enter value for physical speed [units/s]  
→ The respective value for the scaled speed [units/s] is shown.

### "Deceleration Ramp" section

In the *Deceleration Ramp* section, three parameters are used to calculate a fourth parameter in order to define a deceleration ramp. You can choose which parameter should be determined.

#### Procedure

1. Choose the parameter to determine:
  - Actual speed limit [units/s]
  - Delay [units/s]
  - Speed limit after the delay [units/s]
  - Delay time [s]

2. Enter values for the three remaining parameters in the respective fields  
→ The calculated value for the fourth parameter is shown.

### 7.1.3 Delay Time tab

This tab can be used to calculate the delay time for the SafeMC module (e.g.: Delay time to start ramp monitoring), see "Inverter module timing - SafeMC module" on page 199. The delay time is the difference between the times  $T_{\text{Request, Safety}}$  and  $T_{\text{Request, WorstCase}}$ .




Figure 48: SafeMC Help Tool - Delay Time tab

#### Delay Time section

##### Procedure

1. Enter value for POWERLINK cycle time [ $\mu\text{s}$ ]
2. Enter value for task cycle time [ $\mu\text{s}$ ]
3. Enter value for remaining time [ $\mu\text{s}$ ]  
→ The value calculated for the delay time [ $\mu\text{s}$ ] is shown.



### 7.1.4 SMP/SLP Speed Limits tab




Figure 49: SafeMC Help Tool - SMP/SLP Speed Limits tab

#### SMP/SLP Speed Limits section

In the *SMP/SLP Speed Limits* section, the parameters "Deceleration ramp [units/s<sup>2</sup>]" and "Actual speed limit [units/s]" are used to determine the negative and positive speed limit and display them in a diagram.

The "Safe Lower Position Limit for SMP/SLP [units]" and the "Safe Upper Position Limit for SMP/SLP [units]" values can be preset. When a value between these limits is entered, the corresponding values for the negative and positive speed limit [units/s] are determined and displayed.

The parameter names marked in yellow correspond to the parameters in SafeDESIGNER.

#### Calculating the negative and positive speed limits

1. Enter the value for "Deceleration ramp [units/s<sup>2</sup>]"
2. Enter the value for "Actual speed limit [units/s]"
3. Preset the values for "Safe Lower Position Limit for SMP/SLP [units]" and the "Safe Upper Position Limit for SMP/SLP [units]"
4. Enter a value between the limits or move the arrow with the left mouse button  
This value is shown in the diagram as a red vertical line. The red line can be scrolled or shifted using the arrow pointer.  
→ The corresponding values for the negative and positive speed limit [units/s] are shown in the fields and in the diagram.

## Diagram

In the diagram, the speed limit [units/s] is shown in relation to the safe position [units].

### Displaying and using the diagram




Figure 50: Displaying the diagram with the selection menu

### Move the mouse pointer into the diagram

→ A cross-hair pointer is displayed

Holding the left mouse button and marking a section zooms in the diagram.

Scrolling with the mouse also zooms in the diagram.

### Right-click with the mouse in an area of the diagram

→ A selection menu is displayed

Select a menu item with the left mouse button

**Copy to the clipboard**

**Save image as...**

**Show point values**

**Undo zoom**

**Undo all zoom/pan actions**

**Set scale to standard value**

Image is copied to the clipboard

Saves the image

Moving the cross-hair pointer over the line in the diagram shows the values of the individual points.

Resets the last zoom

Resets all zoom/pan actions

Sets scaling to the default values

### 7.1.5 Safe Brake Test SBT tab

The screenshot shows the 'SafeMC Help Tool' window with the 'Safe Brake Test SBT' tab selected. The window is divided into several sections:

- Hardware:**
  - ACOPOSMulti with SafeMC SinCos: 8BVI0014HxSA (selected from a dropdown)
  - Rated current (RMS): 1,6 A
  - Motor: Torque constant  $K_T$  [Nm/A]: 1,6
  - Maximum current measurement error  $I_{err}$ : 108,6 mA
- Test parameters:**
  - Test torque  $T$  [Nm]: 4
  - ☒ External Load  $T_{ext}$  [Nm]: 2
- Result:**
  - Minimum test current  $I_{set}$ : 1,3836 A
  - Copy result text to clipboard button
- Input parameters (text area):**

```
=====
ACOPOSMulti with SafeMC SinCos Module: 8BVI0014HxSA
Torque constant of the motor  $K_T$ : 1,6 Nm/A
Maximum measurement error  $T_{err}$ : 0,17376 Nm
Desired test torque  $T$ : 4 Nm
External load  $T_{ext}$ : 2 Nm

Test torque  $T_{test}$  without tolerances
=====
 $T_{test} = T - T_{ext}$ : 2 Nm

Equivalent stator current  $I_{test}$ 
=====
 $I_{test} = T_{test}/K_T$ : 1,25 A

Test current  $I_{set}$  with considered tolerances
=====
 $I_{set} = I_{test} * 1,02 + I_{err}$ : 1,3836 A
```

Figure 51: SafeMC Help Tool - Safe Brake Test SBT

The SafeMC Help Tool provides assistance on ACOPOSMulti SafeMC SinCos inverter modules for calculating the minimum required testing torque when accounting for drive parameters, *external load*  $T_{ext}$  and measurement errors.

The calculation is made according to the user documentation ACOPOSMulti with SafeMC SinCos / Safety technology / Integrated safety functions / Safe Brake Test, SBT.

#### Hardware section

The hardware section is where the ACOPOSMulti SafeMC SinCos inverter module being used can be set up. This is necessary because the *maximum measurement error for current measurement*  $I_{err}$  depends on the performance class.

Additionally, the motor's torque constant  $K_T$  must also be defined (available on the motor data sheet). The SafeMC Help Tool indicates the *maximum measurement error for current measurement*  $I_{err}$  on the ACOPOSMulti SafeMC SinCos inverter module being used.

#### Test Parameters section

This section is where the parameters for the *Safe Brake Test SBT* are defined. You can also specify whether or not to account for an *External load*  $T_{ext}$ . The values entered depend on the performance class defined. If an invalid value is entered, then the respective limit value will appear in its place.

**Result section**

The result of the calculation is configurable *Minimum test current*  $I_{\text{set}}$ , taking any *External load*  $T_{\text{ext}}$  and measurement error into account.

If an invalid value is entered, then the respective limit value will be output in the *Hardware* section and a result will not be calculated.

The result text can be copied directly to the clipboard.

**Information:**

**The SafeMC Help Tool is not designed according to safety criteria and simply provides support for the calculation of the values to be set. The calculation and the results must be checked!**


### 7.1.6 Options tab

#### Language section

Select English or German

#### About button

Clicking on "About" displays information about the manufacturer.



## 7.2 Application in SafeDESIGNER

The safety application is implemented in SafeDESIGNER.

The SafeMC modules are controlled using the function blocks **SF\_SafeMC\_BR** and **SF\_SafeMC\_Speed\_BR** and starting with Safety Release 1.4 also the function blocks **SF\_SafeMC\_BR\_V2** and **SF\_SafeMC\_Position\_BR**.

Starting with Safety Release 1.7, the function block **SF\_SafeMC\_SBT\_BR** is also available for the safe inverter module ACOPOSMulti with SafeMC SinCos.

The section 5 "PLCopen Safety" on page 220 contains detailed descriptions of how the function blocks and their underlying safety functions and safe parameters are used.

### **Danger!**

**The safety application should only be created by qualified personnel.  
The respective processes specified in the standards must be followed!**

Furthermore, the specifications in the section [SafeDESIGNER](#) of the Integrated Safety User's Manual MASAFE-TY1-ENG must also be taken into account.

### **Danger!**

**All of the safety functions that are used must be tested.  
A function is considered to be used if the respective input variable is connected or the safety function has been configured!**

### 7.3 Access the data on the SafeMC module in Automation Studio

There are three ways to access the safety-related data from a safe axis in Automation Studio.

#### 7.3.1 I/O mapping

The states of individual safety functions can be accessed via the I/O mapping window for the respective SafeMC module. This information is provided in the form of status bits.

To connect PVs to the status bits, the "I/O mapping" window must be opened. As can be seen in the following figure, the PV can then be selected in the "PV or channel name" column.




Figure 52: PV mapping

### 7.3.2 ACOPOSmulti parameter IDs

The following parameter IDs are available to make the SafeMC data available to the non safety-related part of the ACOPOSmulti.

ParID	Data type	NC constant (Define)	Description
4	UDINT	SAFEMC_STATUS	Status bits
5	UDINT	SAFEMC_CONTROL	Control bits
6	INT	SAFEMC_SPEED_ACT	Actual speed [scaled units/s]
7	INT	SAFEMC_SPEED_LIM	Speed limit value [scaled units/s], currently monitored speed limit
309	DINT	SAFEMC_POS_ACT	Safe position [units]

Table 139: ACOPOSmulti parameter IDs for SafeMC

Using these Par IDs, you can now use all the familiar features of ACOPOSmulti (e.g. ACOPOSmulti trace, read parameters via service channel, SPT-FBK connections, etc.).

The ACOPOSmulti trace can be used, for example, to optimize how the functional application handles approaching speed limit values. This also provides an easy way of checking whether the values configured for "Delay times for requesting a safety function" are correct or sufficient.




Figure 53: ACOPOSmulti Trace: Example - SafeMC data




Figure 54: ACOPOSMulti Trace: Speed reserve

The parameter IDs "4 status bits" and "5 control bits" are bit-coded, whereby only the lower three bytes are relevant. The following tables indicate the bit assignments:

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
STO	SBC	SOS	SS1	SS2	SLS1	SLS2	SLS3
Bit 8	Bit 9	Bit 10	Bit 11	Bit 12	Bit 13	Bit 14	Bit 15
SLS4	STO1	SDlpos	SLI	SDIneg	SLP <sup>1)</sup>	SMP <sup>1)</sup>	SafePosition Valid <sup>1)</sup>
Bit 16	Bit 17	Bit 18	Bit 19	Bit 20	Bit 21	Bit 22	Bit 23
Reserved	Set position Alive Testing	Safety Function Requested	All requested safety functions active	SDC	Operational	NOT ERR Encoder	NOT ERR Functional
Bit 24	Bit 25	Bit 26	Bit 27	Bit 28	Bit 29	Bit 30	Bit 31
SBT active <sup>2)</sup>	SBT status <sup>2)</sup>	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved

Table 140: Status bits

- 1) Only available in Safety Release 1.4 or higher!
- 2) Only available in Safety Release 1.7 or higher, only for ACOPOSMulti with SafeMC SinCos!

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
STO	SBC	SOS	SS1	SS2	SLS1	SLS2	SLS3
Bit 8	Bit 9	Bit 10	Bit 11	Bit 12	Bit 13	Bit 14	Bit 15
SLS4	STO1	SDlpos	SLI	SDIneg	SLP <sup>1)</sup>	Homing <sup>1)</sup>	Reference switch <sup>1)</sup>
Bit 16	Bit 17	Bit 18	Bit 19	Bit 20	Bit 21	Bit 22	Bit 23
SBT <sup>2)</sup>	Reserved	Reserved	Reserved	Reserved	Reserved	Activate	Reset

Table 141: Control bits

- 1) Only available in Safety Release 1.4 or higher!
- 2) Only available in Safety Release 1.7 or higher, only for ACOPOSMulti with SafeMC SinCos!

### 7.3.3 Library SafeMC

If the ACOPOSMulti modules are used with SafeMC, then in certain cases the SafeMC data that belongs to an ACOPOS axis must be able to be read in an application:


- **Safe OUT:** Data from the SafeLOGIC (SL) to the ACOPOSMulti module
- **Safe IN:** Data from the ACOPOSMulti module to the SafeLOGIC (SL)



For the **Safe IN** data it would be possible to define PVs in the I/O configuration to which the data would be copied cyclically. However, this data must be explicitly assigned to specific ACOPOS axes by the user.

Automation Studio does not contain any mechanism for read access to the **Safe OUT** data.

The function **SafeMC\_action()** in SafeMC makes it possible to access the SafeMC data of an ACOPOS axis, as described below. The SafeMC function blocks call the global function **SafeMC\_action()**. **SafeMC\_action()** uses the specified axis object to call a function **SafeMC\_action<sub>NCMAN</sub>()**, which is contained in the object's NC-Manager:



### Information:

The function **SafeMC\_action()** only contains a call frame. The actual functionality is contained in the corresponding NC manager function.

Therefore, the constants and data types for the functionalities implemented for the function **SafeMC\_action()** are not contained in the SafeMC library, but rather...

- the constants in the NCGLOBAL library
- the data types in the ACP10MAN library

#### 7.3.3.1 Function SafeMC\_action(): Execute SafeMC action

status = SafeMC_action(nc_object, action, par_ptr, par_size)		
<b>Input parameters:</b>		
nc_object	UDINT	NC object
Action	UDINT	Action to be executed
par_ptr	UDINT	Address of the parameter data
par_size	UDINT	Size of the parameter data in bytes
<b>Output parameters:</b>		
Status	UINT	ncOK or error code

Table 142: SafeMC\_action()

**Error codes** (also used for the FBs SafeMC\_ReadSafeOtData and SafeMC\_ReadSafeInData):

10720	Invalid function pointer: <ul style="list-style-type: none"> <li>• Error during NC software initialization (see Logger)</li> <li>• The NC Manager version on the PLC does not yet contain the SafeMC_action() function</li> </ul>
10721	Invalid NC object (parameter "nc_object")
10723	The action (parameter "action") is not defined or not allowed for this NC object
10724	Invalid NC object type
10726	This action is not allowed because the corresponding initializations are not yet complete.
10729	The parameter "par_ptr" is zero
10731	Invalid NC object data (is a PV being used as NC object, for which an INIT value is defined in the variable declaration?)
10732	The parameter "par_size" is not valid for this action
10733	Network status not valid for this action
10734	Invalid network type (the NC object does not belong to a module on the POWERLINK network)
10735	Invalid length of corresponding network data

Moreover, the following error codes are output for some actions, which suggests an initialization error in the SafeMC data:

10712	NC object not enabled (channel number too high or no PDO data defined)
20918	The "data_len" provided by plAction(plACTION_GET_DP_INFO) is too large
20953	The "direction_id" provided by plAction(plACTION_GET_DP_INFO) is invalid

All other error codes are provided by the POWERLINK library. Only the following is mentioned:

20923	Data point not available (not entered in the PDO Mapping)
-------	---

### 7.3.3.2 Access to the SafeMC data with the function SafeMC\_action()

#### 7.3.3.2.1 READ\_SAFEOUT\_DATA: Read SafeOUT data

##### Parameter:

```
ACP10SAFEOUTDAT_typ safeout_data;
```

##### Function call:

```
SafeMC_action(ax_obj, SafeMC_action_READ_SAFEOUT_DATA,
&safeout_data, sizeof(safeout_data));
```

##### Condition(s):

```
p_ax_dat->network.init == ncTRUE
```

##### Data structure ACP10SAFEOUTDAT\_typ (also used for the FB SafeMC\_ReadSafeOutData):

RequestSTO	USINT	STO control bit
RequestSBC	USINT	SBC control bit
RequestSOS	USINT	SOS control bit
RequestSS1	USINT	SS1 control bit
RequestSS2	USINT	SS2 control bit
RequestSLS1	USINT	SLS1 control bit
RequestSLS2	USINT	SLS2 control bit
RequestSLS3	USINT	SLS3 control bit
RequestSLS4	USINT	SLS4 control bit
RequestSTO1	USINT	STO1 control bit
RequestSDIpos	USINT	SDI control bit (positive direction)
RequestSLI	USINT	SLI control bit
RequestSDIneg	USINT	SDI control bit (negative direction)
RequestSLP <sup>1)</sup>	USINT	SLP control bit <sup>1)</sup>
RequestHoming <sup>1)</sup>	USINT	Homing control bit <sup>1)</sup>
RequestSwitch <sup>1)</sup>	USINT	Reference switch <sup>1)</sup>
RequestSBT <sup>2)</sup>	USINT	SBT Control Bit <sup>2)</sup>
reserved_ctrl_b17	USINT	Reserved
reserved_ctrl_b18	USINT	Reserved
reserved_ctrl_b19	USINT	Reserved
reserved_ctrl_b20	USINT	Reserved
reserved_ctrl_b21	USINT	Reserved
Activate	USINT	SafeMC module activation
Reset	USINT	Reset bit

1) Available for Safety Release 1.4 starting with V 2.250.

2) Available for Safety Release 1.7, starting with V 2.340, only for ACOPOSmulti with SafeMC SinCos!

#### 7.3.3.2.2 READ\_SAFEIN\_DATA: Read SafeIN data

##### Parameter:

```
ACP10SAFEINDAT_typ safein_data;
```

##### Function call:

```
SafeMC_action(ax_obj, SafeMC_action_READ_SAFEIN_DATA,
&safein_data, sizeof(safein_data));
```

##### Condition(s):

```
p_ax_dat->network.init == ncTRUE
```

##### Data structure ACP10SAFEINDAT\_typ (also used for the FB SafeMC\_ReadSafeInData):

SafetyActiveSTO	USINT	STO status bit
SafetyActiveSBC	USINT	SBC status bit
SafetyActiveSOS	USINT	SOS status bit
SafetyActiveSS1	USINT	SS1 status bit
SafetyActiveSS2	USINT	SS2 status bit
SafetyActiveSLS1	USINT	SLS1 status bit
SafetyActiveSLS2	USINT	SLS2 status bit
SafetyActiveSLS3	USINT	SLS3 status bit
SafetyActiveSLS4	USINT	SLS4 status bit
SafetyActiveSTO1	USINT	STO1 status bit
SafetyActiveSDIpos	USINT	SDI status bit (positive direction)
SafetyActiveSLI	USINT	SLI status bit

SafetyActiveSDIneg	USINT	SDI status bit (negative direction)
SafetyActiveSLP <sup>1)</sup>	USINT	SLP status bit <sup>1)</sup>
SafetyActiveSMP <sup>1)</sup>	USINT	SMP status bit <sup>1)</sup>
SafePositionValid <sup>1)</sup>	USINT	Safe position successfully homed and is valid <sup>1)</sup>
<i>reserved_stat_b16</i>	<i>USINT</i>	<i>Reserved</i>
StatusSetPosAlive	USINT	Set position has been tested
StatusSFR	USINT	At least one safety function has been requested
AllReqFuncAct	USINT	All requested safety functions are active
SafetyActiveSDC	USINT	Delay monitoring is active
Operational	USINT	Function block is operational
NotErrENC	USINT	Encoder error status bit
NotErrFUNC	USINT	Functional fail safe status bit
SafetyActiveSBT <sup>2)</sup>	USINT	SBT is active <sup>2)</sup>
SafetyStatusSBT <sup>2)</sup>	USINT	SBT Status Bit <sup>2)</sup>
<i>reserved_stat_b26</i>	<i>USINT</i>	<i>Reserved</i>
<i>reserved_stat_b27</i>	<i>USINT</i>	<i>Reserved</i>
<i>reserved_stat_b28</i>	<i>USINT</i>	<i>Reserved</i>
<i>reserved_stat_b29</i>	<i>USINT</i>	<i>Reserved</i>
<i>reserved_stat_b30</i>	<i>USINT</i>	<i>Reserved</i>
<i>reserved_stat_b31</i>	<i>USINT</i>	<i>Reserved</i>
ScaledSpeed	INT	Scaled safe speed
SafePosition <sup>1)</sup>	DINT	Safe position <sup>1)</sup>

1) Available for Safety Release 1.4 starting with V 2.250.

2) Available for Safety Release 1.7, starting with V 2.340, only for ACOPOSMulti with SafeMC SinCos!

### 7.3.3.2.3 Example: Access to the SafeOUT and SafeIN data

```
#include <bur/plctypes.h>
#include <SafeMC.h>

_LOCAL UINT          status_ncaccess;
_LOCAL UINT          status_safeout;
_LOCAL UINT          status_safein;

_LOCAL UDINT         ax_obj;
_LOCAL ACP10AXIS_typ *p_ax_dat;

_LOCAL ACP10SAFEOUTDAT_typ safeout_data;
_LOCAL ACP10SAFEINDAT_typ  safein_data;


void _INIT SafeMC_accessINIT( void )
{
    status_ncaccess = ncaccess(ncACP10MAN,"AxisObj1",(void *)&ax_obj);
    p_ax_dat = (ACP10AXIS_typ*)ax_obj;
}

void _CYCLIC SafeMC_accessCYCLIC( void )
{
    if ( status_ncaccess != ncOK )
    {
        return;
    }
    if ( p_ax_dat->network.init == ncTRUE )
    {
        status_safeout = SafeMC_action(ax_obj, SafeMC_action_READ_SAFEOUT_DATA,
                                       &safeout_data,sizeof(safeout_data));
        status_safein  = SafeMC_action(ax_obj, SafeMC_action_READ_SAFEIN_DATA,
                                       &safein_data,sizeof(safein_data));
    }
}
```

### 7.3.3.3 Access to the SafeMC data with SafeMC function blocks

#### 7.3.3.3.1 SafeMC\_ReadSafeOutData function block: Read SafeOUT data

##### Function block




##### Parameter

I/O	Parameter	Data type	Description
IN	Axis	UDINT	Axis reference (NC object)
IN	Enable	BOOL	If "Enable" is set, then the data will be read
OUT	Valid	BOOL	Data in output data structure is valid
OUT	Busy	BOOL	Function block not yet completed
OUT	Error	BOOL	Indicates a function block error
OUT	ErrorID	UINT	FB error code (see 7.3.3.1 "function SafeMC_action(): Execute SafeMC action / Error codes" on page 213)
OUT	SafeOutData	ACP10SAFEOUTDAT_typ	Output data structure

Data structure ACP10SAFEOUTDAT\_typ, see 7.3.3.2.1 "READ\_SAFEOUT\_DATA: Read SafeOUT data / data structure" on page 214

#### 7.3.3.3.2 SafeMC\_ReadSafeInData function block: Read SafeIN data

##### Function block



##### Parameter

I/O	Parameter	Data type	Description
IN	Axis	UDINT	Axis reference (NC object)
IN	Enable	BOOL	If "Enable" is set, then the data will be read
OUT	Valid	BOOL	Data in output data structure is valid
OUT	Busy	BOOL	Function block not yet completed
OUT	Error	BOOL	Indicates a function block error
OUT	ErrorID	UINT	FB error code (see 7.3.3.1 "function SafeMC_action(): Execute SafeMC action / Error codes" on page 213)
OUT	SafeInData	ACP10SAFEINDAT_typ	Output data structure

Data structure ACP10SAFEINDAT\_typ, see 7.3.3.2.2 "READ\_SAFEIN\_DATA: Read SafeIN data / data structure" on page 214

#### 7.3.3.3.3 Example: Access to the SafeOUT and SafeIN data

```

#include <bur/plctypes.h>
#include <SafeMC.h>

_LOCAL UINT          status_ncaccess;

_LOCAL UDINT         ax_obj;
_LOCAL ACP10AXIS_typ *p_ax_dat;
  
```

```

_LOCAL SafeMC_ReadSafeOutData_typ SafeMC_ReadSafeOutData_0;
_LOCAL SafeMC_ReadSafeInData_typ SafeMC_ReadSafeInData_0;

void _INIT SafeMC_accessINIT( void )
{
    status_ncaccess = ncaccess(ncACP10MAN,"AxisObj1",(void *)&ax_obj);
    p_ax_dat = (ACP10AXIS_typ*)ax_obj;

    SafeMC_ReadSafeOutData_0.Axis = ax_obj;
    SafeMC_ReadSafeInData_0.Axis = ax_obj;
}

void _CYCLIC SafeMC_accessCYCLIC( void )
{
    if ( status_ncaccess != ncOK )
    {
        return;
    }
    SafeMC_ReadSafeOutData_0.Enable = p_ax_dat->network.init;
    SafeMC_ReadSafeOutData(&SafeMC_ReadSafeOutData_0);
    SafeMC_ReadSafeInData_0.Enable = p_ax_dat->network.init;
    SafeMC_ReadSafeInData(&SafeMC_ReadSafeInData_0);
}

```

## 7.4 Validate the safety functions

### Danger!

The user is responsible for performing safeguard function tests.  
For this reason, it is important for the user to have the safety equipment validated!

### Information:

The applicable standards specify certain processes that must be followed when developing safety-related applications. You are solely responsible for establishing and adhering to these processes.

### Danger!

Safety applications should only be created by qualified personnel. Acceptance of the final product, in particular the validation and verification must also be performed by qualified personnel.

When commissioning the machine, the complete safety application must be tested as well as validated and verified in accordance with the SRS (Safety Requirements Specification).

When performing the comprehensive safety function test, all of the specified limits and timing values must be tested in accordance with the SRS. All of the monitored limits must be violated and the respective error responses must then be evaluated.

Each of the safety functions being used must be fully tested in regard to their respective limit values.

The physical units of the monitored limits must be tested! A function is considered as being used if the respective function block input is used in the safe application.

The following tests are mandatory in all cases:

Safety function	Select / deselect the safety function	Check the safe outputs	Violation of the deceleration ramp	Violation of the monitored speed limits	Violation of the monitored path
STO	✓	✓	---	---	---
STO1	✓	✓	---	---	---
SBC	✓	✓	---	---	---
SOS	✓	---	---	✓	✓
SS1	✓	✓	✓	---	---
SS2	✓	---	✓	✓	---
SLS1	✓	---	✓	✓	---
SLS2	✓	---	✓	✓	---
SLS3	✓	---	✓	✓	---
SLS4	✓	---	✓	✓	---
SMS	---	---	---	✓	---
SDIpos	✓	---	---	---	✓
SDIneg	✓	---	---	---	✓

Table 143: Test matrix for the safety functions

Safety function	Select / deselect the safety function	Check the safe outputs	Violation of the deceleration ramp	Violation of the monitored speed limits	Violation of the monitored path
SLI	✓	---	---	---	✓
SLP	✓	---	✓ <sup>1)</sup>	✓ <sup>1)</sup>	✓
SMP	---	---	✓ <sup>1)</sup>	✓ <sup>1)</sup>	✓
SBT <sup>2)</sup>	✓	Test torque or external load torque above max. / below min. limits			✓

Table 143: Test matrix for the safety functions

- 1) Speed limit is calculated dynamically according to the current position  
 2) Only available in Safety Release 1.7 or higher, only for ACOPOSmulti with SafeMC SinCos!

**Danger!**

**Check the parameter settings for the unit system! An incorrectly configured unit system can cause dangerous situations because the monitored limits may not correspond with the physical limits under certain circumstances!**

**7.5 Maintenance scenarios****7.5.1 Commissioning**

When commissioning the machine, the safety functions must always undergo thorough testing, as described in 7.4 "Validate the safety functions" on page 217.

**Danger!**

**All of the safety functions that are used must be tested.**  
**A function is considered to be used if the respective input variable is connected or the safety function has been configured!**

**7.5.2 Replacing ACOPOSmulti with SafeMC safe inverter modules**

The SafeLOGIC controller recognizes, on its own, when safe modules have been replaced. Following a module replacement, the complete system (SafeLOGIC, openSAFETY) automatically ensures that the module is operated again with the correct parameters and that incompatible modules are rejected.

Replacing a safe inverter module, such as ACOPOSmulti with SafeMC, can present the following potential errors, which must be detected and prevented through testing:

- Wiring errors in the motor connection
- Wiring errors in the motor holding brake connection
- Wrong encoder connected

**Danger!**

**All of the safety functions that are used on the exchanged module must be tested!**  
**Be sure to validate the entire safety function!**

**7.5.3 Replacing a safe encoder / motor**

A safe EnDat 2.2 FS encoder that is replaced on a safe inverter module with SafeMC EnDat 2.2 will be detected as a replacement on the SafeLOGIC controller and must be acknowledged as such.

SafeLOGIC does not detect if an encoder / motor is replaced on the safe inverter module with SafeMC SinCos!

After the replacement, the safety functions configured on the affected axis must be tested.

**Danger!**

**All of the safety functions that are used on the exchanged module must be tested!**  
**Be sure to validate the entire safety function!**

**7.5.4 Firmware update / Acknowledging a firmware exchange**

Changes to safety-related parts of the firmware are distributed by B&R as firmware updates.

Upgrades to safety-related firmware can only be performed by qualified personnel.

A firmware upgrade is indicated on the SafeLOGIC controller and must be acknowledged accordingly.

**Danger!**

**A firmware modification must always be concluded with full functional testing.**

**7.5.5 Decommissioning a system**

SafeMC modules have a mission time of maximum 20 years.

This means that all SafeMC modules must be taken out of service one week (at the latest) before the expiration of this 20 year time span (starting from B&R's delivery date).

**Danger!**

**Operating ACOPOSmulti SafeMC modules beyond the specified mission time is not permitted!**

**The user must ensure that all ACOPOSmulti SafeMC modules are removed from operation i.e. replaced by new ACOPOSmulti SafeMC modules, before their mission time expires.**

## Chapter 5 • PLCopen Safety

Special function blocks compliant with PLCopen Safety have been implemented to ensure the effective use of the SafeMC module. These function blocks have revolutionized the development of safety applications. Because they are certified, they reduce time and costs throughout all phases of a safety application's life cycle. From the specification and implementation to testing and checking functions, the procedure used is more like virtual wiring than programming.

Unlike "real wiring", downloading the program to the SafeLOGIC guarantees that an identical copy will be stored. This completely eliminates wiring errors during series production. Naturally, all options for a safe programmable controller are available to handle even more complex problems that can't be solved with "real wiring".

### 1 Definition of terms




Figure 55: Function block label

When calling the function block, the actual parameters supply the formal parameters with the current values of the variables or constants.

Actual parameters do not need to share the same name as the corresponding formal parameters, but must be the same type. A difference in the data type of formal and actual parameters is reported as an error following compilation.

A function block's name is created from the function (e.g. SF\_Antivalent, SF = safety function). The representation for version Vx\_yz used in the document is universal. Please take the actual version from the function block in use.



## 2 SF\_SafeMC\_BR




Figure 56: Function block SF\_SafeMC\_BR

## 2.1 Formal parameters of the function block

In the following, the term "variable" refers to both a variable as well as a graphic connection.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
<b>Activate</b>	BOOL	Variable / Constant	Status	FALSE	Activates the function block (= TRUE)
<b>S_RequestSTO</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	STO safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSTO1</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	STO1 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSBC</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SBC safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSOS</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SOS safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSS1</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SS1 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSS2</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SS2 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS1</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS1 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS2</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS2 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS3</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS3 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS4</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS4 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLI</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLI safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSDIpos</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SDIpos safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSDIneg</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SDIneg safety function request: SAFEFALSE: Safety function requested
<b>Reset</b>	BOOL	Variable	Edge	FALSE	Resets error messages and the SafeMC module once the cause of the error has been removed.
<b>S_AxisID</b>	SAFEINT	Constant	Status	-1	Assigns an axis to the function block

Table 144: SF\_SafeMC\_BR: Overview of input parameters

1) Evaluation of the input parameter signals in the function block. The signals must be controlled accordingly by the user.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
<b>Ready</b>	BOOL	Variable	Status	FALSE	Indication that the function block is enabled
<b>S_SafetyActiveSTO</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function STO is active (= SAFETRUE)
<b>S_SafetyActiveSTO1</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function STO1 is active (= SAFETRUE)
<b>S_SafetyActiveSBC</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SBC is active (= SAFETRUE)
<b>S_SafetyActiveSOS</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SOS is active, no violation of a monitored limit (= SAFETRUE)
<b>S_SafetyActiveSS1</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SS1 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSS2</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SS2 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS1</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS1 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS2</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS2 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS3</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS3 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS4</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS4 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLI</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLI is active, no violation of a monitored limit (= SAFETRUE)
<b>S_SafetyActiveSDIpos</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SDIpos is active (= SAFETRUE)

Table 145: SF\_SafeMC\_BR: Overview of output parameters

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
<b>S_SafetyActiveSDIneg</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SDIneg is active (= SAFETRUE)
<b>S_AllReqFuncActive</b>	SAFEBOOL	Variable	Status	SAFEFALSE	All requested safety functions have achieved their safe state. (= SAFETRUE)
<b>S_SafetyActiveSDC</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Deceleration monitor is active (= SAFETRUE)
<b>S_NotErrFUNC</b>	SAFEBOOL	Variable	Status	SAFEFALSE	SafeMC is not in the Functional Fail Safe state (= SAFETRUE)
<b>Error</b>	BOOL	Variable	Status	FALSE	Function block error message
<b>DiagCode</b>	WORD	Variable	Status	16#0000	Function block diagnostic message
<b>AxisStatus</b>	DWORD	Variable	Status	32#00000000	Status information from axis

Table 145: SF\_SafeMC\_BR: Overview of output parameters

1) Output of the output parameter signals. The signals must be evaluated and/or further processed accordingly by the user.

Type	Description	Size in bits	Format option
<b>BOOL</b>	Bit	1	Bool
<b>WORD</b>	Word	16	Binary number, hexadecimal number, unsigned decimal number
<b>SAFEBOOL</b>	Bit	1	Boolean (signal source: safe device)
<b>SAFEINT</b>	Integer	16	Binary number, hexadecimal number, unsigned decimal number (signal source: safe device)

Table 146: SF\_SafeMC\_BR: Formats of data types used

It is possible to link a safe signal with a non-safe input parameter. To do so, you need to use a function block for type conversion.

## 2.2 SafeMC module parameters

Parameter	Unit	Description	Safety function
<b>Encoder Unit System</b>			
Number of encoder revolutions	-	Unit scale: x-revolutions Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions) and a certain number of encoder revolutions (x-revolutions) has to be previously defined.	Unit system
Units per number of encoder revolutions	units	Unit scale: Units per x revolutions Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions) and a certain number of encoder revolutions (x-revolutions) has to be previously defined.	Unit system
Counting direction	Standard / Inverse	Counting direction of the position or speed Default...Encoder counter direction is equal to the counting direction of the unit system Inverse...Encoder counting direction is negative to the counting direction of the unit system	Unit system
Maximum speed to normalize the speed range	units	Maximum speed to which the displayed speed should be normalized	Unit system
<b>Safety deceleration ramp</b>			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	SS1, SS2, SLS
<b>General settings</b>			
Safe Maximum Speed	Used / Unused	Activates the SMS safety function by configuration	SMS
Automatic Reset at Startup (StartReset)	Used / Unused	Activates automatic reset of the function block at startup	Configuration
Channel selection for One Channel STO (STO1)	HighSide / LowSide	Selection of HighSide or LowSide IGBT in the function One Channel STO	STO1 / configuration Functional Fail Safe
Ramp monitoring for SS1	Activated / Deactivated	Activates the ramp monitoring (in addition to the time) when the SS1 safety function is requested	SS1
Ramp monitoring for SS2	Activated / Deactivated	Activates the ramp monitoring (in addition to the time) when the SS2 safety function is requested	SS2
Ramp monitoring for SLS	Activated / Deactivated	Activates the ramp monitoring (in addition to the time) when the SLS safety function is requested	SLS
Early Limit Monitoring	Activated / Deactivated	Monitoring of the deceleration ramp is prematurely terminated if the target limit is reached or exceeded.	SS1, SS2, SLS
<b>Encoder Monitoring</b>			
Encoder Position Monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the position lag error generated on the SafeMC module.	Monitoring Encoder shaft breakage
Encoder Speed Monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the speed error generated on the SafeMC module.	Monitoring Encoder shaft breakage
Set position alive testing	Activated / Deactivated	Activates/deactivates the monitor that detects whether the set position generated on the ACOPOSmulti is frozen.	Monitoring Encoder shaft breakage
<b>Behavior of Functional Fail Safe</b>			
SBC in Functional Fail Safe	Activated / Deactivated	The brake output is switched to 0 V when in the Functional Fail Safe state.	Configuration
Behavior of Functional Fail Safe	STO / STO1 and STO with time delay	In the Functional Fail Safe state, STO (SBC) is activated immediately or STO1 and then STO (SBC) after a delay.	Configuration
Delay time for STO in Functional Fail Safe	[μs]	Delay time between STO1 and STO (and SBC) in the Functional Fail Safe state	Configuration
Delay time until the brake engages	[μs]	Delay time before the brake engages The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.	Configuration
<b>Speed Limits</b>			
Maximum speed limit for SMS	[units/s]	Speed limit of the maximum speed	SMS
Safe Speed Limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	SLS
Safe Speed Limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	SLS
Safe Speed Limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	SLS
Safe Speed Limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	SLS
<b>Safety Standstill and Direction Tolerances</b>			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	SOS, SS2, SLI
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	SOS, SS2, SDI
<b>Safely Limited Increments</b>			
Safe increments	[units]	Maximum moveable increments when SLI is active	SLI
SLI OFF Delay	[μs]	Switch off delay of SLI	SLI
<b>Safety Ramp Monitoring Times</b>			
Ramp Monitoring Time for SS1	[μs]	Deceleration monitoring time for SS1	SS1
Ramp Monitoring Time for SS2	[μs]	Deceleration monitoring time for SS2	SS2
Ramp Monitoring Time for SLS1	[μs]	Deceleration monitoring time for SLS1	SLS1

Table 147: SF\_SafeMC\_BR: Module parameter

Parameter	Unit	Description	Safety function
Ramp Monitoring Time for SLS2	[µs]	Deceleration monitoring time for SLS2	SLS2
Ramp Monitoring Time for SLS3	[µs]	Deceleration monitoring time for SLS3	SLS3
Ramp Monitoring Time for SLS4	[µs]	Deceleration monitoring time for SLS4	SLS4
Safety Additional Parameters			
Delay time to start ramp Monitoring	[µs]	Delay time between request of ramp monitoring and start of monitoring	SS1, SS2, SLS
Delay time to start SDI	[µs]	Delay time between the SDI request and activation of the safety function	SDI
Delay time to start SBC	[µs]	Delay time between the SBC request and activation of the safety function	SBC
Early Limit Monitoring time	[µs]	Time during which the speed must be equal to or below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	SS1, SS2, SLS
Encoder Monitoring Tolerances			
Encoder Monitoring Position Tolerance	[units]	Position lag error tolerance for shaft breakage monitoring	Monitoring Encoder shaft breakage
Encoder Monitoring Speed Tolerance	[units/s]	Speed error tolerance for encoder monitoring	Monitoring Encoder shaft breakage

Table 147: SF\_SafeMC\_BR: Module parameter

In a safety application, it is possible for multiple safety functions to be requested at the same time. In order to prevent this from turning into an unsafe situation, the individual safety functions are prioritized on the SafeMC module.

If several functions are active, then the lowest speed limit is always the value being monitored.

### Information:

The following application rules must be followed in order to enable prioritization of the safety functions:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

If the application guideline rule is violated, then the SafeMC module changes to the Fail Safe state.

## 2.3 Integrated safety functions

### Information:

If a safety function is not used in the application, then the respective input variables must remain open.

The following functions are supported by the SafeMC module:

Safety function	Starting safety lease	in re-	EN ISO 13849-1	EN 61508/EN 62061	Safe encoder evaluation required
Safe Torque Off (STO)	R 1.3		Pl e	SIL 3	No
Safe Torque Off One Channel (STO1)	R 1.3		Pl d	SIL 2	No
Safe Operation Stop (SOS)	R 1.3		Pl d	SIL 2	Yes
Safe Stop 1 (SS1 )	R 1.3		PL e (time-monitored) Pl d	SIL 3 (time-monitored) SIL 2	No (time-monitored) Yes
Safe Stop 2 (SS2)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Speed (SLS)	R 1.3		Pl d	SIL 2	Yes
Safe Maximum Speed (SMS)	R 1.3		Pl d	SIL 2	Yes
Safe Direction (SDI)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Increment (SLI)	R 1.3		Pl d	SIL 2	Yes
Safe Brake Control (SBC)	R 1.3		Pl d	SIL 2	No
Safely Limited Position (SLP)	R 1.4		Pl d	SIL 2	Yes
Safe Maximum Position (SMP)	R 1.4		Pl d	SIL 2	Yes
Safe Homing	R 1.4		Pl d	SIL 2	Yes

Table 148: Safety functions and corresponding safety levels

### Information about using the integrated safety functions

At least the activate input and the S\_AxisID must be connected. Otherwise, the SafeMC module will not be operated by the SafeLOGIC. As a result, the pulse disabling and the motor holding brake output will be permanently set to 0 V, which means that the controller cannot be turned on.

### Danger!

All of the safety functions that are used must be tested.

A function is considered to be used if the respective input variable is connected or the safety function has been configured!

#### 2.3.1 Fail-safe state

##### 2.3.1.1 Parameters

None

##### 2.3.1.2 Behavior

If an error in the hardware or firmware occurs, then the safe inverter module changes to a non-acknowledgeable error state – the fail-safe state. The log book entry in Automation Studio provides more detailed information about the pending error. This log book can also be evaluated in the standard application.

If there is a hardware defect, then the entire inverter module must be replaced.

### Information:

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

However, the error can also have been caused by a configuration mistake. If this is the case, then the safe configuration must be checked and reloaded to the SafeLOGIC controller. This must then be followed by a PowerOff/PowerOn cycle to get the module back to the "Operational" state.

### Danger!

Safe pulse disabling is always active in the fail-safe state (i.e. the motor is no longer supplied with power or generating torque). The motor holding brake output is always switched to 0 V in this state!

**Danger!**

Constantly lit LEDs "SE" indicate a fail safe state that cannot be acknowledged. The cause of this could be a defective module or faulty configuration.

Check the entries in the logbook! If you are able to rule out a faulty configuration, then the module is defective and must be replaced immediately.

It is the user's responsibility to ensure that all necessary repair measures or corrections in the configuration are initiated after an error occurs since subsequent errors can result in dangerous situations!

**Danger!**

The motor holding brake is engaged in Fail Safe state. The motor holding brake will suffer mechanical wear if the motor is in motion just before the safe state is triggered. This must be considered when selecting and dimensioning the motor holding brake (E-stop capability).

**2.3.2 Functional fail-safe state****2.3.2.1 Parameters**

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide
Behavior of Functional Fail Safe			
Behavior of Functional Fail Safe	STO/ STO1 and STO with time delay	In the Functional Fail Safe state, STO (SBC) is activated immediately or STO1 and then STO (SBC) after a delay	STO
Delay time for STO in Functional Fail Safe	[µs]	Delay time between STO1 and STO (and SBC) in the Functional Fail Safe state	0
Delay time until the brake engages	[µs]	Delay time before the brake engages The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.	0

Table 149: Functional Fail Safe state configuration parameters

**2.3.2.2 Behavior**

If a monitored limit is exceeded or an encoder error occurs during operation – and as long as the safe encoder is required for the safety functions being used – then the SafeMC module changes to an acknowledgeable error state – the functional fail-safe state.

Information about any errors that occur can be found in the logbook entry in Automation Studio. This log book can also be evaluated in the standard application.

**Danger!**

The motor holding brake is engaged in Functional Fail Safe state. The motor holding brake will suffer mechanical wear if the motor is in motion just before the safe state is triggered. This must be considered when selecting and dimensioning the motor holding brake (E-stop capability).

**Danger!**

The error response time described in the manual affects the remnant movement in the event of error! This must be accounted for when planning the safety equipment (e.g. distances, monitored limits, etc.)

**"Behavior of Functional Fail Safe" = "STO"**

Pulse disabling is requested (low and high side) immediately after the error is detected and the safe motor holding brake output is set to 0V.




Figure 57: Functional Fail Safe - Configuration of STO

**"Behavior of Functional Fail Safe" = "STO1 and STO with time delay"**

Either the low or high side of the pulse disabling is switched to 0V immediately after the error is detected. The safe motor holding brake output is set to 0 V after the configured time "Delay time for STO in Functional Fail Safe" (T (Delay Time for STO in FFS)) has expired.

The second channel of the pulse disabling is also switched to 0 V after the configured time "Delay time until the brake engages" (T (Delay Time until the brake engages)) has expired.






Figure 58: Functional Fail Safe - Configuration of STO1 and STO with time delay

This makes it possible for the drive to be decelerated via the short circuit braking integrated in the ACOPOSmulti for the amount of time in which just one pulse disabling channel is active.

In this case, the time value T (Delay Time until the brake engages) is used to incorporate this brake engage time. This means that the second pulse disabling channel will only be switched to 0V after the motor holding brake has actually engaged.

## Danger!

The short circuit braking in the ACOPOSmulti is not suitable for safety purposes and can therefore only be used to protect the machine. If loss of power on the motor could result in dangerous situations (e.g. with hanging loads), then a mechanical safeguard must also be installed.

### 2.3.3 Safe Position, Safe Speed

#### 2.3.3.1 Parameters

Parameter	Unit	Description	Default value
Encoder Unit System			
Encoder type	Rotatory encoder / Linear encoder / Encoder not used	Determines the type of encoder being used: <ul style="list-style-type: none"> <li>Rotary encoder</li> <li>Linear encoder</li> <li>Encoder not used</li> </ul> The parameter is only available for ACOPOSmulti with SafeMC SinCos!	Rotary encoder
Number of signal periods	-	Number of encoder signal periods per rotation (rotary encoder) or per length of the physical reference system (linear encoder) The parameter is only available for ACOPOSmulti with SafeMC SinCos!	1
Count of physical reference system	-	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: y-reference lengths (Reference length = Length of the physical reference system) <p>Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.</p>	1

Table 150: Unit system parameters

Parameter	Unit	Description	Default value
Units per count of physical reference system	[units]	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: y-reference lengths  Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1000
Counting direction	Standard / Inverse	Counting direction of the position or speed Standard: Encoder counting direction is equal to the counting direction of the unit system Inverse: Encoder counting direction is negative to the counting direction of the unit system	Standard
Length of physical reference system for linear encoder (nm)	[nm]	For linear measurement systems, the length of a physical reference system will be defined here. This value is not used for rotary encoders, where the reference system is a single rotation.	1000000000
Maximum speed to normalize the speed range (units/s)	[units/s]	Maximum speed to which the displayed speed should be normalized	32767
Maximum acceleration (rad/s <sup>2</sup> or mm/s <sup>2</sup> )	[rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	Maximum permissible encoder acceleration	100000

Table 150: Unit system parameters

### 2.3.3.2 Behavior

The parameters (see 4.3.1 "Table: "Unit system parameters"" on page 154) can be used to configure the safe unit system.

The safe speed and the safe position are transferred in the safety frame. The process data is only allowed to be used together with the respective status bit. If the respective status bit is FALSE, then the corresponding data is invalid.

Function blocks are available for linking the process data with a specific axis and using in the safe application!

#### Safe position

The safe position is transferred in [units] according to the configured unit system. Once homing is complete, the "SafePosition Valid" status bit is set.

#### **Danger!**

If the position signal is not validated, then an invalid position could be used in the safe application. This can result in hazardous situations!

#### **Danger!**

Safe encoder evaluation can only detect an error in the transfer or position

- if a distance is traversed that is greater than the angular deviation of the safe position specified in the product information provided by the manufacturer of the measuring device (*applies to ACOPOSmulti with SafeMC EnDat 2.2*).
- if a distance is traversed that is greater than  $\pm 1/2$  signal period of the SinCos measurement device (*applies to ACOPOSmulti with SafeMC SinCos*).

The resulting maximum error in the safe position also depends on the length of the physical reference system (rotations, length of the scale, etc.).

This error affects the minimum distance required for the protection (e.g. of fingers) against crushing and must be accounted for when dimensioning the safety function.

#### **Danger!**

A frictionally engaged connection with fault exclusion requires no extra mechanical offset for the safe position.

If the fault exclusion is only achieved by implementing a mechanical stop with backlash, then this maximum possible offset must be calculated into the safe position. This is done by adding the values for the measuring instrument and for the mechanical link.

## Safe Speed

The safe speed is scaled to 2 bytes due to the limited Safety Frame bandwidth available. The scaled speed  $v_{scaled}$  is calculated as follows:

$$v_{scaled} = \frac{v_{physical} \cdot 32767}{\text{Maximum speed to normalize the speed range}} \left[ \frac{\text{scaled units}}{s} \right]$$

$v_{physical}$  (physical velocity) corresponds to the actual physical size and is calculated in the configured unit system in [units/s].

This means the scaled speed equals the physical speed for the default configuration of the parameter "Maximum speed to normalize the speed range" = 32767!

The maximum speed must never exceed the value configured for "Maximum speed to normalize the speed range" or else the module will switch to "Functional Fail Safe" state.

### Information:

The speed limits of the safety functions are configured in the physical speed [units/s]. The safety functions internally monitor the scaled speeds [scaled units / s] whereby scaling errors can occur.

### Example

The following configuration causes the speed tolerance for standstill monitoring to be scaled internally to 0 [scaled units / s].

Configuration:

"Maximum speed to normalize the speed range (units/s)" = 3276700

"Speed Tolerance (unit/s)" = 20

$$\text{Scaled Speed Tolerance} = \frac{\text{Speed Tolerance} \cdot \text{INT16MAX}}{\text{Maximum Speed to normalize the speed range}} = \frac{20 \cdot 32767}{3276700} = 0$$

If Safe Operating Stop is enabled, then a speed tolerance of 0 is monitored internally [scaled units / s]. This can result in a undesired speed violation during standstill.

### Information:

The configured unit system has significant influence on the maximum physical speed achieved.

If the unit system configuration is changed make sure to consider how this affects the parameter "Maximum speed to normalize the speed range".

### Danger!

If the module changes to the acknowledgeable error state "Functional Fail Safe", then the drive loses power and torque, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

### Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### Danger!

If the speed signal is not validated, then an invalid speed value could be used in the safe application. This can result in hazardous situations!

## Danger!

Safe encoder evaluation can only detect an error in the transfer or position

- if a distance is traversed that is greater than the angular deviation of the safe position specified in the product information provided by the manufacturer of the measuring device (*applies to ACOPOSmulti with SafeMC EnDat 2.2*).
- if a distance is traversed that is greater than  $\pm 1/2$  signal period of the SinCos measurement device (*applies to ACOPOSmulti with SafeMC SinCos*).

The resulting maximum error in the safe position also depends on the length of the physical reference system (rotations, length of the scale, etc.).

The error influences the error response time and must be accounted for when dimensioning the safety function.

### 2.3.4 STO - Safe Torque Off

#### 2.3.4.1 Parameters

None

#### 2.3.4.2 Behavior

STO is the fundamental safety function of the ACOPOSmulti with SafeMC, since it represents the "fail-safe" principle.

A request from the STO safety function activates safe pulse disabling and switches off the torque and power to the drive. Activation of safe pulse disabling is performed actively by the SafeMC module.

## Danger!

A STO request causes synchronized axes to no longer be synchronous.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!




Figure 59: STO - Safe Torque Off

**Information:**

The functional safe state of the STO function has been achieved when the pulse disabling outputs are switched to 0 V. The respective bit is set once the functional safe state has been achieved.

**Danger!**

The drive will spin out if it is in motion at the time of the STO request. The resulting remnant movement and time depends on the properties of the machine and must always be considered when dimensioning the safety equipment.

The maximum possible (worst case) movement must be assumed.

The maximum possible speed is determined by the current operating mode. If there is no active safety function, the maximum speed that is physically possible for the motor must be assumed.

**Danger!**

If the SMS or SLS function is active, the assumed maximum speed can be reduced to the currently active configured speed limit plus the maximum possible acceleration during the error response time.

**Information:**

The resulting remnant movement and time determines the intervals between the safety features that must be maintained and therefore the size of the machine as well.

**Information:**

The safety function Safe Torque Off does not require encoder evaluation.

**Danger!**

If the safety function STO is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

## 2.3.5 Single-channel Safe Torque Off, STO1

### 2.3.5.1 Parameters

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide

Table 151: STO1 safety function parameters

### 2.3.5.2 Behavior

The STO1 safety function works in the same way as STO. The sole difference is that either only the HighSide or only the LowSide IGBTs are switched off depending on the configuration.

**Information:**

The functional safe state of the STO1 safety function has been achieved when the configured pulse disabling output is switched to 0 V.

The respective bit is set once the functional safe state has been achieved.

**Information:**

The two-channel aspect is lost because either only the low side or only the high side of the pulse disabling is activated with the safety function STO1.

This results in a lower SIL and Performance Level!

**Information:**

The safety function STO1 does not require encoder evaluation.

## Danger!

If the safety function STO1 is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

### 2.3.6 Safe Brake Control, SBC

#### 2.3.6.1 Parameters

Parameter	Unit	Description	Default value
Safety Additional Parameters			
Delay time to start SBC (us)	[μs]	Delay time between the SBC request and activation of the safety function	0

Table 152: SBC safety function parameters

#### 2.3.6.2 Behavior

The SBC function is a safe (time-delayed) output whose purpose is to safely control a motor holding brake.

### Information:

To achieve a defined SIL level, the controlled holding brake must also have at least the same SIL level and errors in the wiring must be ruled out.




Figure 60: Safe Brake Control, SBC

Only the actuation of the motor holding brake output through the SafeMC module is safely evaluated with SIL 2.

The braking procedure is not monitored from a safety point of view by the SafeMC module.

### Information:

The functional safe state of the SBC function has been achieved when the safe motor holding brake output has been switched to 0 V.

The respective bit is set once the functional safe state has been achieved.

The purpose of the delay time T (Delay time to start SDI [μs]) is to compensate for the different runtimes of functional and safe applications.

### Information:

The safety function Safe Brake Control does not require encoder evaluation.

## Danger!

If the safety function SBC is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

## Information:

Functional errors will occur (e.g. 6029: Holding brake: Control signal on and output status off), if the holding is released by the standard application but the motor holding brake output is switched to 0 V by the SafeMC module.

### 2.3.7 Safe Operating Stop, SOS

#### 2.3.7.1 Parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 153: SOS safety function parameters

#### 2.3.7.2 Behavior

An enabled SOS safety function monitors the drive to ensure that it stops safely. The SafeMC module does not control pulse disabling.

The drive can remain active and must be kept at standstill by the standard application.

## Information:

The safety function SOS requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 61: Safe Operating Stop, SOS

To prevent the axis from drifting, both the speed and position are monitored with standstill tolerance limits. The position window is generated when the safety function is requested. If the request is withdrawn, then monitoring of the standstill tolerance window will also be terminated. The next time a request is made, the standstill tolerance position window is regenerated based on the current position.

## Information:

The functional safe state of the SOS safety function has been achieved when the drive is stopped and the standstill is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The standstill tolerances can be configured for each axis in SafeDESIGNER.

## Danger!

In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.

The dangerous movement must be determined by a risk analysis.

If the stop monitoring limits are violated, safe pulse disabling is activated and the drive switches to a Functional Fail Safe error state which must be acknowledged. When an error occurs, a synchronous axis loses its synchronicity.

## Danger!

If a standstill limit (position or speed) is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The "*S\_NotErrFUNC*" output on the function block is reset.

## Danger!

If the safety function SOS is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The configured limits must be violated with the function enabled and the error response must be tested accordingly!

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### 2.3.8 Safe Stop 1, SS1

#### 2.3.8.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 154: SS1 safety function parameters

#### 2.3.8.2 Behavior

When the SS1 safety function is requested and after the ramp delay time, the deceleration process of the axis is monitored until standstill. After decelerating, safe pulse disabling is activated and switches off the torque and power to the drive.



## Danger!

Synchronous axes lose their synchronicity when SS1 is in its safe state.




Figure 62: Safe Stop 1, SS1

The deceleration itself is controlled by the standard application, which is not safety-oriented.

The purpose of the ramp delay time - parameter "*Delay time to start ramp monitoring ( $\mu\text{s}$ )*" - is to compensate for the different runtimes of functional and safe applications.

### Information:

The functional safe state of the SS1 function has been achieved when the pulse disabling outputs are switched to 0 V. The respective bit is set once the functional safe state has been achieved.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

Depending on the requirements for the safety function and its configuration, either only the deceleration time  $T$  (Ramp Monitoring Time for SS2) or also the deceleration ramp can be monitored.

If the monitoring limits are violated during deceleration, then an error state that must be confirmed is entered.

The parameter "*Ramp monitoring for SS1*" configures the behavior of the delay monitor.

### 2.3.8.3 SS1 - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SS1" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a stopping procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring ( $\mu$ s)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope. If the monitoring ramp reaches the configurable standstill speed limit "*Speed Tolerance (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SS1 ( $\mu$ s)*" has expired, then safe pulse disabling is activated and torque is switched off on the drive.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the standstill speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

If the active limit is violated during monitoring of the deceleration procedure, then the drive will immediately switch to the acknowledgeable error state Functional Fail Safe.

### Information:

**If ramp monitoring is configured for the safety function SS1, then the speed must be safely evaluated. If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!**

### Danger!

**If safe pulse disabling is on (spin-out) and the safety function is in a functionally safe state, the maximum speed at the end of the deceleration ramp must be used to calculate the remaining distance. To determine the maximum possible speed, it must be assumed that in the event of error, the drive will accelerate to its maximum during the error response time starting from the standstill speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

### Danger!

**If the monitored ramp is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

### Danger!

**If the safety function SS1 with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine! The test should include at least one violation of the monitored ramp and the error response must be tested accordingly!**

#### 2.3.8.4 SS1 - Stopping procedure with time-monitoring

##### "Ramp monitoring for SS1" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application.

After the delay time for the request, "*Delay time to start ramp monitoring ( $\mu$ s)*" and the monitoring time, "*Ramp Monitoring Time for SS1 ( $\mu$ s)*" have expired, safe pulse disabling is activated and torque is shutoff on the drive.

### Information:

**With this configuration of the Safe Stop 1 safety function, only the time frame is monitored. No speed limit or position window is monitored. This is why the function can also be used in this configuration without safe encoder evaluation!**

## Danger!

If safe pulse disabling is on (spin-out), the maximum speed after the time frame has expired must be used to calculate the remaining distance!

The drive can move at its physically maximum speed during this time window (plus the response time of the safe pulse disabling). If SMS is active, then the speed limit plus the error tolerance can be assumed as the maximum speed.

It must be ensured that the spin-out movement and remaining distance do not present any danger!

## Danger!

If the safety function SS1 with true time-monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The drive should be accelerated to its maximum during the monitored time frame and the error response tested accordingly!

### 2.3.9 Safe Stop 2, SS2

#### 2.3.9.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 155: SS2 safety function parameters

#### 2.3.9.2 Behavior

With the SS2, after the ramp delay time the deceleration process of the axis is monitored until standstill. The drive must then be kept at standstill by the standard application. This standstill is monitored, similar to SOS, by the SafeMC module according to the configured standstill tolerance window "Speed Tolerance [units/s]" and "Position Tolerance [units]".

The delay itself must be generated by the non-safety-oriented, standard application by halting the drive in response to the dangerous situation.

## Information:

The safety function Safe Stop 2 requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 63: Safe Stop 2, SS2

## Danger!

If a standstill limit (position or speed) is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The "*S\_NotErrFUNC*" output on the function block is reset.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

The purpose of the ramp delay time - parameter "*Delay time to start ramp monitoring (μs)*" - is to compensate for the different runtimes of functional and safe applications.

## Information:

The functional safe state of the SS2 function has been achieved when the drive is stopped and the standstill is being monitored for safety. The respective bit is set once the functional safe state has been achieved.

As with SS1, it is possible to monitor either only the deceleration time or the deceleration ramp as well depending on the requirements of the safety function.

The parameter "*Ramp monitoring for SS2*" configures the behavior of the delay monitor.

### 2.3.9.3 SS2 - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SS2" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a stopping procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring (μs)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope. If the monitoring ramp reaches the configurable standstill speed limit "*Speed Tolerance (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SS2 (μs)*" has expired, then a position window is established and monitoring of the standstill tolerances is started.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the standstill speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

If the active limit or standstill window is violated during monitoring of the deceleration procedure or standstill, then the drive will immediately switch to the acknowledgeable error state Functional Fail Safe.

#### **Danger!**

**When the monitored ramp or standstill tolerance window is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

#### **Danger!**

**In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.**

**The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.**

**The dangerous movement must be determined by a risk analysis.**

#### **Danger!**

**If the safety function SS2 with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!**

**The test should contain at least one violation of the monitored ramp and standstill tolerance window. The error response must be tested accordingly!**

### 2.3.9.4 SS2 - Stopping procedure with time-monitoring

#### "Ramp monitoring for SS2" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application.

After the delay time for the request, "*Delay time to start ramp monitoring (μs)*" and the monitoring time, "*Ramp Monitoring Time for SS2 (μs)*" have expired, the standstill tolerance window will be monitored safely.

#### **Danger!**

**When the standstill tolerance window is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit.**

**It must be ensured that the spin-out movement and remaining distance do not present any danger!**

## Danger!

In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.

The dangerous movement must be determined by a risk analysis.

## Danger!

If the safety function SS2 with time-monitored stopping procedure is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of the standstill tolerance window. The error response must be tested accordingly!

### 2.3.10 Safely Limited Speed, SLS

#### 2.3.10.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	0
Safe Speed-limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	0
Safe Speed-limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	0
Safe Speed-limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Ramp Monitoring Time for SLS4 (us)	[μs]	Deceleration monitoring time for SLS4	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 156: SLS safety function parameters

#### 2.3.10.2 Behavior

The safety function SLS monitors a specified speed limit - parameter "*Safe Speedlimit 1, 2, 3, 4 for SLS (units/s)*". It is also possible to monitor deceleration until the limit is reached if needed by the application.

Four different speed limits can be monitored on the SafeMC module. All limits can also be monitored in parallel. If a request is made to monitor multiple speed limits at the same time, then the lowest limit value will always be monitored. To make this possible, the function block includes four different inputs "S\_RequestSLSx" (x = 1-4).

The standard (non safety-oriented) application must use a closed-loop control appropriate for the level of danger to decelerate the movement and then maintain the respective speed limit.

## Information:

The safety function SLS requires safe evaluation of the speed. If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!




Figure 64: Safely Limited Speed, SLS

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## Danger!

If a speed limit is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

Torque and power to the drive are switched off, causing the drive to spin out!

An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

The purpose of the ramp delay time T (Delay time to start ramp monitoring) is to compensate for the different runtimes of functional and safe applications.

If the delay time (Ramp monitoring time for SLSX) is set to 0, then the speed limit will be monitored right after the request is made for the safety function.

## Information:

The functional safe state of the SLS function has been achieved if the drive has not exceeded a defined speed limit and this limit is being monitored for safety. The respective bit is set once the functional safe state has been achieved.

As with SS1 and SS2, the deceleration ramp monitoring can be adjusted according to the requirements, so that either only the deceleration time or both the deceleration time and the deceleration ramp are monitored.

The parameter "Ramp monitoring for SLS" configures the behavior of the delay monitor.

### 2.3.10.3 SLS - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SLS" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a deceleration procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring (μs)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope.

If the monitoring ramp reaches the respective speed limit "*Safe Speedlimit 1, 2, 3, 4 for SLS (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SLS1, 2, 3, 4 (μs)*" has expired, then the status of the safety function will be set and the enabled speed limit monitored.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the monitored speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

#### **Danger!**

**When the monitored ramp or the enabled safe speed is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

#### **Danger!**

**In the event of an error when monitoring the safe reduced speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.**

**Within this amount of time, the drive could accelerate to its maximum before spinning out.**

**The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger. The dangerous movement must be determined by a risk analysis.**

#### **Danger!**

**If the safety function SLS with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!**

**The test should contain at least one violation of the monitored ramp and of each speed limit being used. The error response must be tested accordingly!**

### 2.3.10.4 SLS - Stopping procedure with time-monitoring

#### "Ramp monitoring for SLS" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application. After the delay time for the request, "*Delay time to start ramp monitoring (μs)*" and the monitoring time, "*Ramp Monitoring Time for SLS1, 2, 3, 4 (μs)*" have expired, the speed limit will be monitored safely.

#### **Danger!**

**When the speed limit is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit.**

**It must be ensured that the spin-out movement and remaining distance do not present any danger!**



## Danger!

In the event of an error when monitoring the safe reduced speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger.

The dangerous movement must be determined by a risk analysis.

## Danger!

If the safety function SLS without ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of each speed limit being used.

The error response must be tested accordingly!

### 2.3.11 Safe Maximum Speed, SMS

#### 2.3.11.1 Parameters

Parameter	Unit	Description	Default value
General settings			
Safe Maximum Speed	Used / Not used	SMS safety function activated or deactivated	Used
Speed Limits			
Maximum speed limit for SMS	[units/s]	Speed limit of the maximum speed	0

Table 157: SMS safety function parameters

#### 2.3.11.2 Behavior

The difference between SMS and SLS is that SMS cannot be actively requested. It is either activated (parameter "Safe Maximum Speed" = Used) or deactivated (parameter "Safe Maximum Speed" = Not used) in the configuration.

When activated, the current speed is constantly monitored according to a defined limit (parameter "Safe Maximum Speed (units/s)").

## Information:

The safety function SMS requires safe evaluation of the speed.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!

## Danger!

When the monitored speed limit is exceeded, the remaining distance must be calculated based on the error response time.

It must be ensured that the spin-out movement and remaining distance do not present any danger!

## Danger!

In the event of an error when monitoring the safe maximum speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out. The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger.

The dangerous movement must be determined by a risk analysis.

## Danger!

If the safety function SMS is used in the safe application, then it must be tested when commissioning the machine!

The configured limit must be exceeded! The error response must be tested accordingly!

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### 2.3.12 Safely Limited Increment, SLI

#### 2.3.12.1 Parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Safely Limited Increments			
Safe increments	[units]	Maximum moveable increments when SLI is active	0
SLI OFF Delay	[μs]	Switch off delay of SLI	0

Table 158: SLI safety function parameters

#### 2.3.12.2 Behavior

With the SLI safety function, the movement is monitored for a defined number of increments (parameter "Safe Increments (units)").

### Information:

The safety function SLI requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 65: Safely Limited Increment, SLI

**Information:**

The safety function SLI is only effective when used in combination with at least one other safety function. This could be one of the safety functions such as SOS, SS2, or SLS.

**Information:**

The functional safe state of the SLI function has been achieved if the drive has not exceeded a defined increment size and this limit is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The safe axis must be at a standstill when this function is enabled. To do this, the speed is monitored for adhering to the speed standstill tolerance (parameter "*Speed Tolerance (units /s)*").

A position window is then generated that is monitored from a safety point of view. This position window depends on the configured safe increment size (parameter "*Safe Increments (units)*"). The standard application must guarantee that this position window is not exceeded.

After deactivating the safety function, monitoring remains active for the configured amount of time (parameter "*SLI Off Delay ( $\mu$ s)*"). This prevents continuous movement caused by constant jogging.

**Danger!**

If a speed limit for requesting the function or if the position window is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous.

The "*S\_NotErrFUNC*" output on the function block is reset.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**Danger!**

In the event of an error when monitoring the safe increments, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out.

The remaining distance must be taken into consideration when configuring the permissible increments and must not cause any hazards.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SLI is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of the standstill speed limit when enabled and the permissible increments. The error response must be tested accordingly!

**2.3.13 Safe Direction, SDI****2.3.13.1 Parameters**

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[ $\mu$ s]	Delay time between the SDI request and activation of the safety function	0

Table 159: SDI safety function parameters

**2.3.13.2 Behavior**

The SDI safety function monitors the defined direction of movement.

Either the positive or the negative direction can be monitored. This is done using the two inputs “*S\_RequestSDIpos*” and “*S\_RequestSDIneg*” that are available on the function block.

### Information:

The safety function SDI requires safe evaluation of the position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!




Figure 66: Safe Direction, SDI - Positive direction of rotation allowed




Figure 67: Safe Direction, SDI - Negative direction of rotation allowed

**Information:**

The safe direction function can be enabled in parallel with other safety functions. For example, SLS or SLI can be limited to a certain direction.

**Information:**

The functional safe state of the SDI function has been achieved if the drive has not violated a defined direction of movement and this direction of movement is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The purpose of the delay time "*Delay time to start SDI (μs)*" is to compensate for the different runtimes of functional and safe applications.

When monitoring the direction of movement, the standstill position tolerance (parameter "*Position Tolerance (units)*") must not be exceeded in the forbidden direction of movement. When moving in the permitted direction of movement, the position window moves along like a slave pointer.

**Danger!**

If the safe direction of movement is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out!

An error will cause a synchronous axis to no longer be synchronous.

The "*S\_NotErrFUNC*" output on the function block is reset.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**Danger!**

In the event of an error when monitoring the safe direction of rotation, a dynamic forward movement in the dangerous direction can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out. The resulting remaining distance must be accounted for when configuring the permissible tolerance limits and must not present any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SDI is used in the safe application, then the ability to enable/disable each of the directions of movement that are being used must be tested when commissioning the machine!

The test should contain at least one violation of each safe direction of movement that is being used. The error response must be tested accordingly!

**2.3.14 Safe Homing****Information:**

The safety function Safe Homing is only available in Safety Release R 1.4 or higher!

**2.3.14.1 Parameters**

Parameter	Unit	Description	Default value
Homing			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time (μs)	[μs]	Monitoring time for the homing procedure	0

Table 160: Parameters for the "safe homing" safety function

Parameter	Unit	Description	Default value
Mode	Direct/ Reference Switch/ Home Offset/ Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive/ Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive
Trigger direction	Positive/ Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used/ Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0

Table 160: Parameters for the "safe homing" safety function

### 2.3.14.2 Behavior

The Safe Homing function provides a way to establish a reference between the encoder position and the machine position.

Depending on the homing mode, it may be necessary for the drive to perform a homing procedure. A homing procedure requires the control functions between the electronic controller and the drive motor to be active. Other safety functions might have to be selected in order to prevent a hazardous state during the homing procedure.

The following homing modes are supported:

- Direct
- Reference switch
- Home Offset / Home Offset with Correction (*only available for ACOPOSmulti with SafeMC EnDat 2.2!*)

#### Information:

**Safe homing requires safe evaluation of the position.**

**If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Fail Safe" state after the function block is activated! The "Fail Safe" state can only be exited by powering off and then on again!**

A positive edge on the control bit *S\_RequestHoming* will start safe homing and simultaneously reset the status bit *S\_SafePositionValid*.

As soon as the homing procedure is completed, the status bit *S\_SafePositionValid* will be set and the control bit *S\_RequestHoming* must be reset.

The homing procedure must be completed within the "*Homing monitoring time (μs)*" or else the SafeMC module will change to the functional fail-safe state.

The homing procedure will be aborted if the *S\_RequestHoming* control bit is reset before the procedure is completed.




Figure 68: Safe Homing

### Information:

The safe homing function is a pre-requisite for the safety functions SLP and SMP and for using the safe position. The status `S_SafePositionValid` will remain set to `SAFEFALSE` until safe homing has been performed!

### Danger!

If an error occurs during homing procedure, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

The function block output `S_NotErrFUNC` is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

### Danger!

If the safe position is used in SafeDESIGNER, then the Position Valid output of the `SafeMC_Position` function block must also always be evaluated.

This will be reset immediately only with referenced axes `SAFETRUE`, and the first time an encoder error occurs (`SAFEFALSE`).

This enables the safety application to detect any encoder error, even if only brief.

If a machine reference is not required for usage, then the axis can be referenced using the Direct mode.

## 2.3.14.3 Direct mode

### 2.3.14.3.1 Parameters

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Correction	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Reference pulse	Used / Not Used	Selection of whether or not to use a reference pulse for homing	Not used
<b>General settings</b>			
Safe Maximum Position	Used / Not used	Activates the SMP safety function by configuration	Not used
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
<b>Safety Standstill and Direction Tolerances</b>			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0

Table 161: Parameters for the "safe homing" safety function - Direct mode

### 2.3.14.3.2 Behavior

Direct mode is used if the current position of the axis is known and has only to be applied to the SafeMC module.

The following scenario is an example of how this mode can be used:

- The ACOPOSMulti SafeMC module is first homed for the standard application.
- The axis is then moved to a defined position by the ACOPOSMulti SafeMC module.
- The user acknowledges that the correct position has been reached by pressing a safe button → This triggers a safe homing procedure internally in Direct mode.

When referencing in Direct mode, the actual position of the axis is set to the value specified in the parameter "*Home position or home offset*" immediately after the homing command (positive edge on the input S\_RequestHoming).

The input S\_ReferenceSwitch will not be evaluated.

#### Information:

**The axis must be at standstill when the homing request is made.**

**The values configured under "Safety Standstill and Direction Tolerances" are monitored to this regard. If the standstill tolerances are violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!**

#### Information:

**A reference pulse is not permitted to be used in Direct mode!**

**If a reference pulse is enabled ("*Reference pulse*" = Used), then the system will enter Fail Safe state when checking the configuration during startup.**

**The Fail Safe state can only be exited by powering off/on and changing the safe application!**

#### Information:

**If Safe Maximum Position has been enabled in the configuration (Parameter "*Safe Maximum Position*" = Used), then the value configured on the parameter "*Home position or home offset*" must be within the permissible SMP window (parameters "*Safe Lower Position Limit for SMP (units)*" and "*Safe Upper Position Limit for SMP (units)*").**

**If this is not the case, then the system will enter Fail Safe state when checking the configuration during startup.**

**The Fail Safe state can only be exited by powering off/on and changing the safe application!**

#### Danger!

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!**

**If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!**

### 2.3.14.4 Reference Switch mode

#### 2.3.14.4.1 Parameters

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time (µs)	[µs]	Monitoring time for the homing procedure	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive / Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive

Table 162: Parameters for the "safe homing" safety function - Reference Switch mode



Parameter	Unit	Description	Default value
Trigger direction	Positive / Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used / Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 162: Parameters for the "safe homing" safety function - Reference Switch mode

### 2.3.14.4.2 Behavior

The mode "Reference Switch" correlates with the referencing modes "Switch Gate", "Abs Switch" and "Limit Switch" on the ACOPOSmulti.

#### Information:

If the reference switch input "**S\_ReferenceSwitch**" is not wired on the function block, then the SafeMC module will change to Fail Safe state.

The "Fail Safe" state can only be exited by powering off/on and changing the safe application!

Depending on the configuration, the ACOPOSmulti will pass over the reference switch / limit switch several times.

#### Danger!

The reference switch / limit switch is part of the safety function and must therefore be accounted for in the risk analysis.

Use a debounced position switch suitable for safety applications!

The machine manufacturer is responsible for implementing a suitable switch!

After the homing command (= positive edge on the input **S\_RequestHoming**) the SafeMC module uses the home switch edge that matches the "*Edge of reference switch*" and "*Trigger direction*" settings as long as it is passed below the "*Max Trigger Speed*".

The home switch edge will be ignored if the reference switch is passed over at a speed higher than the "*Max Trigger Speed*".

Configuration	Reference switch evaluation
Edge of reference switch = Negative Trigger direction = Negative	
Edge of reference switch = Positive Trigger direction = Negative	
Edge of reference switch = Negative Trigger direction = Positive	
Edge of reference switch = Positive Trigger direction = Positive	

Table 163: Selecting the home switch edge

#### Information:


After the homing command is made, the homing procedure must be completed within the configured time "*Homing Monitoring Time (μs)*". Otherwise, the module will change to the acknowledgeable error state "Functional Fail Safe".

The function block output **S\_NotErrFUNC** is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.


## Danger!

The standstill "Position Tolerance" must be smaller than or equal to half the pulse width of the reference switch being used!



## Danger!

The filter ( $T_{on}$ ,  $T_{off}$ ) required when reading the reference switch edges in SafeDESIGNER must be determined according to the control behavior during standstill.



Error in the referenced absolute position due to the delay caused by the filter times must be taken into consideration!

### ACOPOSMulti with SafeMC SinCos

The reference position is assumed immediately after successful evaluation of the reference edge.

### ACOPOSMulti with SafeMC EnDat 2.2

#### Reference pulse = Not Used

If the reference pulse is disabled, then the reference position will be assumed immediately when the home switch edge is successfully processed.

#### Reference pulse = Used

This mode is recommended when the positions of ACOPOSMulti and the SafeMC module must match exactly. Processing of the reference pulse compensates for the speed-dependent position difference by processing the two values at different times.

## Information:

If "Reference pulse" is set to "Used", then a rotary EnDat 2.2 Functional Safety encoder must be used. The reference pulse is generated at every single turn overflow.

When "Reference pulse" = Used, the reference position will not be entered under the first valid reference pulse after the home switch edge has been reached.

After the valid home switch edge has been processed, the processing of the reference pulse will be suppressed for the distance configured in the parameter "Blocking distance (% encoder reference system)". The next reference pulse is only processed once this distance has been passed, at which point the home position is applied.

A valid homing procedure requires that the direction of movement does not change between when the home switch edge is passed and the valid reference pulse and that the speed limit "Max Trigger Speed" is not exceeded.

**Information:**

If the direction of movement changes while searching for the reference pulse, then the reference switch must be passed over again.

**Information:**

If the speed limit "*Max Trigger Speed*" is exceeded during the reference pulse search, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**2.3.14.5 Home Offset / Home Offset with Correction mode (only for ACOPOSmulti with SafeMC EnDat 2.2)****Information:**

The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!

**2.3.14.5.1 Parameter - Home Offset / Home Offset with Correction mode**

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Mode	Direct/ Reference Switch/ <i>Home Offset/ Home Offset with Cor- rection</i>	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
<b>General settings</b>			
Safe Maximum Position	Used/Unused	Activates the SMP safety function by configuration	Unused
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0

Table 164: Parameters for the safety function "safe homing" - Modes: Home Offset / Home Offset with Correction

**2.3.14.5.2 Behavior - Home Offset / Home Offset with Correction mode**

If an absolute encoder is being used, then the machine reference can be established via an offset to the encoder position.

A homing procedure is not necessary.

The homing command *Home Offset* uses this offset directly, while *Home Offset with Correction* mode accounts for any encoder overrun that might occur in the permissible range of movement.

The offset is configured in SafeDESIGNER with the *Home position* or *Home offset* parameter.

The input *S\_ReferenceSwitch* will not be evaluated.

## Danger!

This homing mode can only be used for absolute encoders (single-turn encoder / multi-turn encoder / linear encoder). Using another encoder for this mode will cause the SafeMC module to change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

## Information:

If the security functions SMP and/or SLP are used, then their position window must be smaller than the safety-related encoder counting range.

If one of the two position windows is configured larger than the encoder counting range, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

For more information, see the section Safe encoder counting range (only applies to the user documentation MAACPMSAFEMC-ENG (ACOPOSmulti with SafeMC EnDat 2.2)).

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### Home Offset

This mode is well suited for absolute encoders which provide unique position values over the entire movement range. Using the homing offset, the encoder position over the entire movement range can be represented as the correct machine position.




Figure 69: Home Offset referencing method

The Home Offset can be determined by carrying out a calibration move (e.g. Homing with Reference Switch).

### Home Offset with Correction

In this homing mode, after setting the Home Offset a check is made to see if the machine position is within the movement range defined by the SMP position limits. If this is not the case, the Home Offset in the safety-related encoder counting range is corrected:

## Information:

The SMP safety function must be activated when using this mode. If SMP is deactivated, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

Counting range correction is needed when using absolute encoders if the encoder provides a unique position value over the entire movement range but an encoder overflow occurs within the movement range. Here, the Home Offset depends on if the machine was calibrated at a position to the right or the left of the overflow point.




Figure 70: Referencing method - Home Offset with Correction

To the right of the overflow point, Home Offset 1 which is valid for the left side would lead to an incorrect position value. To the left of the overflow point, Home Offset 2 which is valid for the right side would lead to an incorrect position value. This can be compensated for with counting range correction.

### Information:

Counting range correction only functions if the encoder range is larger than or equal to the movement range! Keep in mind that only the safety-related part of the encoder counting range is used.

## 2.3.15 Safely Limited Position, SLP

### 2.3.15.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
Safety Position Limits			
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SLP (us)	[μs]	Delay time between request of SLP and start of monitoring	0

Table 165: SLP safety function parameters

### 2.3.15.2 Behavior

The purpose of the SLP safety function is to monitor a specified position window.

The "Safe Lower Position Limit for SLP" and "Safe Upper Position Limit for SLP" parameters can be used to configure the limits of the monitoring range.

The SLP safety function is requested when the input *S\_RequestSLP* is set to SAFEFALSE.

Monitoring of the position window will begin after the amount of time configured in "Delay time to start SLP" has expired.

The "*S\_SafetyActiveSLP*" status bit will be set to SAFETRUE if no errors occur while monitoring is active.




Figure 71: Safety Limited Position, SLP

### Information:

The axis must be homed successfully before using the Safety Limited Position function.

If a homing procedure is not completed successfully or if the "S\_SafePositionValid" status changes, then the request for the SLP safety function causes the module to change to the acknowledgeable *functional fail-safe* error state.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous.

The "S\_NotErrFUNC" output on the function block is reset.

### Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

To minimize the distance remaining when the position window is exceeded, a position-dependent speed limit is monitored in addition to the position.

### Danger!

In the worst case, the monitored position window can be passed while the axis is spinning out. This must be taken into account when defining the limits!

When the position limit is approached, the monitored speed limit is calculated in such a way that the drive will come to a full stop before the positioning limit is reached using the configured deceleration ramp parameter.

The permitted speed in the direction of the upper position limit is

$$v_{LIM,POS} = \sqrt{2(LIM_{SLP,POS} - s) * a}$$

and in the direction of the lower position limit is

$$v_{LIM,NEG} = \sqrt{2(s - LIM_{SLP,NEG}) * a}$$

The position-dependent speed limit is illustrated in the following figure.




Figure 72: Position-dependent speed window

## Danger!

If the position window or the position-dependent speed limit is violated while the SLP safety function is activated or if the *S\_SafePositionValid* status is lost, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

## Danger!

If the safety function SLP is used in the safe application, then the activation and deactivation of this function must be tested when commissioning the machine!

The test should contain at least one violation of each position limit. The error response must be tested accordingly!

### 2.3.16 Safe Maximum Position, SMP

#### 2.3.16.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Safe Maximum Position	Used / Not used	Activates the SMP safety function by configuration	Not used
Safety Position Limits			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 166: SMP safety function parameters

#### 2.3.16.2 Behavior

The difference between SMP and SLP is that SMP cannot be actively requested. It is either enabled or disabled by the configuration.

When enabled, the current position is constantly monitored against a defined position window.

The "*Safe Lower Position Limit for SMP*" and "*Safe Upper Position Limit for SMP*" parameters can be used to configure the lower and upper position limits of the monitoring range.

The SMP safety function only works with homed axes since it requires a safe absolute position.

If SMP is configured, a 15-minute timeout begins once pulse disabling is activated, within which the homing procedure must take place.

Once homing is complete and if there were no errors during monitoring, the *S\_SafetyActiveSMP* status bit is set to SAFETRUE.

### Information:

**The axis must be homed successfully before using the function Safe Maximum Position.**

**If a homing procedure is not successful within 15 min after pulse disabling is activated or the *S\_SafePositionValid* status is lost on an axis that has already been homed or if the position window or the position-dependent speed limit is violated, then the module changes to the acknowledgeable error state "Functional Fail Safe".**

**The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous.**

As with the SLP safety function, the Safe Maximum Position function also monitors a position-dependent speed limit in addition to the position in order to minimize the remaining distance if the position window is exceeded.

For more information, please refer to the description of the safety function "Safely Limited Position, SLP".

### Danger!

**In the worst case, the monitored position window can be passed while the axis is spinning out. This must be taken into account when defining the limits!**

**If the position window has been exceeded, then movement is only possible in the direction of the position window after the Functional Fail Safe state has been acknowledged.**

**An attempt to move beyond the standstill tolerance in the unsafe direction (i.e. away from the position window) will cause the module to enter the acknowledgeable error state "Functional Fail Safe".**

### Danger!

**If the safety function SMP is used in the safe application, then it must be tested when commissioning the machine! The test should contain at least one violation of each position limit. The error response must be tested accordingly!**

### Danger!

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!**

**If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!**



## 2.4 Error prevention

### Danger!

#### Validation

**Each of the safety functions that are used must be validated separately. In addition, the entire safety application, including interactions between individual functions, must also be tested.**

### 2.4.1 Exceeding monitored limits

The SafeMC module monitors limits that can be configured. The drive itself, however, is controlled by the functional application on the standard PLC.

The following points must be considered in order to prevent the violation of a monitored limit:

- Movement of the drive must be adapted to the requested safety function and initiated on time.
- The monitored limits must match the calculated limits and the movement limitations. Make sure that the different configurations of the unit system match in the safe application and in the functional application!

### Danger!

**Any violation of a monitored limit will cause the module to change to the error state "Functional Fail Safe", which must be confirmed.**

**The function block output `S_NotErrFUNC` is reset and the drive becomes torque-free and force-free, causing it to spin out!**

**Depending on the configuration, the motor holding brake will also be switched to 0 V.**

**An error will cause a synchronous axis to no longer be synchronous.**

**Check the Safety Logger in Automation Studio for detailed information about monitoring!**

### 2.4.2 Plausibility errors

Plausibility errors (limit values, data types, variables/constants) that occur when the function block is used are detected and reported by the function block or compiler.

This is not always possible in the event of connection errors, however.

The function block cannot check whether:

- Actual parameter values or constants within the valid range are in fact incorrect for the safety function being executed. A static TRUE signal on the Reset input is detected by the function block and indicated as an error, however.
- Actual parameters have been connected incorrectly.
- I/O formal parameters were not connected inadvertently.

For this reason:

### Danger!

**You are responsible for the connection of the safety function (sub-application).**

**Check the connections when validating the sub-application.**

### 2.4.3 Sporadically changing/toggling signal levels or impermissible signals

Sporadically changing or toggling signal levels on

- Edge-controlled formal input parameters cause the function block to interpret the signal as an edge, which results in an unintended action being triggered in the function block if error prevention measures are not in place.
- Without implementing error prevention, state-driven input formal parameters cause this signal to unexpectedly trigger a corresponding action.

Impermissible signals on input formal parameters can lead to an unexpected initial movement, non-execution of a requested action or an error message.

Possible causes of these signals:

- Programming error in the application program (user error)
- Cross fault, short circuit or cable break (user error, wiring error)
- Error in the standard controller

To prevent this, the following measures can be taken depending on the safety function:

- Use of safe device signals
- Implementing additional measures for preventing a hazard if using a signal from a standard controller (e.g. executing an additional function start after a safety function has been triggered or an error has been corrected)
- Line control in the safe control system
- Suitable cabling when using non-safe signals from the standard controller
- Verifying the source code in the application program and final validation of the safety functionality

The measures listed above can also be taken in combination to safely prevent errors.

It is important to note that a signal change detected on a status-controlled formal parameter will be output as a diagnostic code.

#### 2.4.4 Simultaneous edge change

To reduce the chances of an unexpected startup, make sure that the formal parameter Reset is only connected to the signal of a manual reset. This signal is based on your risk analysis.

#### 2.4.5 Machine/system startup without performing functional testing of safety equipment

Faulty safety equipment can only be detected following functional testing. Functional testing is not supported by this function block. If additional measures are not implemented, faulty safety equipment can result in errors.

### **Danger!**

**The user is responsible for performing safeguard function tests.**

**For this reason, it is important for the user to have the safety equipment validated!**

Possible causes of faulty safety equipment:

- Faulty devices (hardware error)
- Cross fault, short circuit, and cable break (user error, wiring error)

## 2.5 Input parameters

### 2.5.1 General information about the "S\_Request" inputs

The "S\_Request" inputs are used to request the respective safety functions.

If a safety function should not be used in the safe application, then the respective input should not be connected.

#### **Information:**

If a safety function should not be used in the application, then the respective input variables should remain open.

#### **Danger!**

The safety functions that are used must be tested.

A function is considered to be used if the respective input variable is connected!

#### **Information:**

At least the activate input and the S\_AxisID must be connected. Otherwise, the SafeMC module will not be operated by the SafeLOGIC. As a result, the pulse disabling and the motor holding brake output will be permanently set to 0 V, which means that the controller cannot be turned on.

## 2.5.2 Activate

### General function

- Function block activation

### Data type

- BOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to enable the function block.

- If you are activating or deactivating safe devices, link Activate to a variable that indicates the status (de-activated or activated) of the corresponding safe devices. This ensures that the function block does not output a triggered safety function as diagnostic information when a device is disabled.
- In addition, Activate can be connected to a constant (TRUE) in order to activate the function block.

### TRUE

The function block is enabled.

### FALSE

The function block is disabled.

All binary output parameters are set to FALSE.

Sets the DiagCode diagnostic parameter to WORD#16#0000.

If you want to control function block diagnostics as needed in your diagnostic concept whenever error messages from safe devices and/or deactivated safe devices occur, connect Activate to a signal that indicates the status of the safe devices that utilize the safety function supported by the function block. Create this signal only for safe devices whose I/O signals are connected to the function block via actual parameters. This prevents triggered safety functions from being reported by deactivated safe devices. This measure is only used to control diagnostics in the event of disabled safe devices.

### 2.5.3 S\_RequestSTO

#### General function

- Selects/deselects the safety function “Safe Torque Off”, STO

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function STO.

#### TRUE

Safety function is deselected; the safe pulse disabling is not active!

#### FALSE

Safety function is selected; the safe pulse disabling is active! Torque and power are switched off on the drive.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

- None

## 2.5.4 S\_RequestSTO1

### General function

- Selects / deselects the safety function "Safe Torque Off, One Channel", STO1

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function STO1.

#### TRUE

Safety function is deselected; the safe pulse disabling is not active!

#### FALSE

Safety function is selected; depending on the configuration, the HighSide or LowSide of the safe pulse disabling is active! Torque and power are switched off on the drive.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide

Table 167: STO1 safety function parameters

### 2.5.5 S\_RequestSBC

#### General function

- Selects/deselects the safety function “Safe Brake Control”, SBC

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SBC.

#### TRUE

Safety function is deselected. The motor holding brake is active and can be used by the standard application.

#### FALSE

Safety function is selected. The motor holding brake is switched to 0 V!

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Additional Parameters			
Delay time to start SBC (us)	[µs]	Delay time between the SBC request and activation of the safety function	0

Table 168: SBC safety function parameters

## 2.5.6 S\_RequestSOS

### General function

- Selects/deselects the safety function “Safe Operating Stop”, SOS

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SOS.

#### TRUE

Safety function is deselected. Standstill tolerances are not being monitored.

#### FALSE

Safety function is selected. Standstill tolerances are being monitored.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 169: SOS safety function parameters

### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!



## 2.5.7 S\_RequestSS1

### General function

- Selects/deselects the safety function "Safe Stop 1", SS1

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SS1.

#### TRUE

Safety function is deselected; Safe Stop 1 is not active!

#### FALSE

Safety function is selected. Safe pulse disabling is activated after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 170: SS1 safety function parameters

### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

### Information:

**In order to use the function without safe encoder evaluation, "Ramp monitoring for SS1" and "Early Limit Monitoring" must both be disabled.**

**Information:**

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

## 2.5.8 S\_RequestSS2

### General function

- Selects/deselects the safety function “Safe Stop 2”, SS2

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SS2.

#### TRUE

Safety function is deselected; Safe Stop 2 is not active!

#### FALSE

Safety function is selected. Standstill monitoring is activated after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 171: SS2 safety function parameters

### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

### Information:

**If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.**

**The following application rule must be observed:**

$$LIM_{SOS} \leq LIM_{SLS4} \leq LIM_{SLS3} \leq LIM_{SLS2} \leq LIM_{SLS1} \leq LIM_{SMS} < NormSpeed$$

**Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!**

## 2.5.9 S\_RequestSLS1

### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 1

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SLS1.

#### TRUE

Safety function is deselected; SLS1 is not active!

#### FALSE

Safety function is selected. Speed Limit 1 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 172: SLS1 safety function parameters

### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

## 2.5.10 S\_RequestSLS2

### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 2

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SLS2.

#### TRUE

Safety function is deselected; SLS2 is not active!

#### FALSE

Safety function is selected. Speed Limit 2 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 173: SLS2 safety function parameters

### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

## 2.5.11 S\_RequestSLS3

### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 3

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SLS3.

#### TRUE

Safety function is deselected; SLS3 is not active!

#### FALSE

Safety function is selected. Speed Limit 3 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 174: SLS3 safety function parameters

### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

## 2.5.12 S\_RequestSLS4

### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 4

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SLS4.

#### TRUE

Safety function is deselected; SLS4 is not active!

#### FALSE

Safety function is selected. Speed Limit 4 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS4 (us)	[μs]	Deceleration monitoring time for SLS4	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 175: SLS4 safety function parameters

### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 2.5.13 S\_RequestSLI

#### General function

- Selects / deselects the safety function "Safely Limited Increment", SLI

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLI.

#### TRUE

Safety function is deselected; SLI is not active!

#### FALSE

Safety function is selected. A safe range of increments is monitored.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Safely Limited Increments			
Safe increments	[units]	Maximum moveable increments when SLI is active	0
SLI OFF Delay	[µs]	Switch off delay of SLI	0

Table 176: SLI safety function parameters

#### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**



## 2.5.14 S\_RequestSDIpos

### General function

- Selects / deselects the safety function "Safe Direction", movement is allowed in the positive direction

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SDI, movement is allowed in the positive direction of movement.

#### TRUE

Safety function is deselected; SDI is not active!

#### FALSE

The direction of movement is monitored after the delay time has expired. Movement is allowed in the positive direction.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[µs]	Delay time between the SDI request and activation of the safety function	0

Table 177: SDI safety function parameters

### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

## 2.5.15 S\_RequestSDIneg

### General function

- Selects / deselects the safety function "Safe Direction", movement is allowed in the negative direction

### Data type

- SAFEBOOL

### Connection

- Constant or variable

### Description of function

This input parameter is used to select or deselect the safety function SDI, movement is allowed in the negative direction of movement.

#### TRUE

Safety function is deselected; SDI is not active!

#### FALSE

The direction of movement is monitored after the delay time has expired. Movement is allowed in the negative direction.

#### Not connected

The safety function is disabled.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[µs]	Delay time between the SDI request and activation of the safety function	0

Table 178: SDI safety function parameters

### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

## 2.5.16 Reset

### General function

- Reset input for acknowledging the "Functional Fail Safe" state or for putting the SafeMC module in to Operational state after startup

### Data type

- BOOL

### Connection

- Variable

### Description of function

Reset input for confirming the "Functional Fail Safe" state.

A positive switching edge triggers the reset function.

Depending on the configuration of the parameter "Automatic Reset at Startup", a positive switching edge might be needed to get the SafeMC module from the "Init" state to the "Operational" state after starting up.

### Relevant configuration parameters

Parameter	Unit	Description	Default value
General settings			
Automatic Reset at Startup (StartReset)	Used / Unused	Activates automatic reset of the function block at startup	Unused

Table 179: Parameter Reset

### 2.5.17 S\_AxisID

#### General function

- This input parameter assigns a real axis to the function block.

#### Data type

- SAFEINT

#### Connection

- Constant

#### Description of function

The corresponding axis can be connected to the input in SafeDESIGNER using drag-and-drop.

#### Information:

There can only be one combination of AxisID and SF\_SafeMC\_BR or SF\_SafeMC\_BR\_V2 function block in the safety application. Otherwise, the safety application cannot be compiled.

## 2.6 Output parameters

The output parameters provide information about the state of the SafeMC module and the individual safety functions.

### 2.6.1 Ready

#### General function

- Message: Function block activated/deactivated.

#### Data type

- BOOL

#### Connection

- Variable

#### Description of function

This output parameter indicates whether or not the function block is active.

#### TRUE

The function block is active (Activate = TRUE) and the output parameters indicate the current state of the safety function.

#### FALSE

The function block is deactivated (Activate = FALSE), with the function block outputs set to FALSE.

## 2.6.2 S\_SafetyActiveSTO

### General function

- Status information about the safety function "Safe Torque Off", STO

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function STO.

#### TRUE

Safety function STO is active and currently in its safe state.

#### FALSE

Safety function STO is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 2.6.3 S\_SafetyActiveSTO1

#### General function

- Status information for the safety function "Safe Torque Off, One Channel", STO1

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function STO1.

#### TRUE

Safety function STO1 is active and currently in its safe state.

#### FALSE

Safety function STO1 is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.4 S\_SafetyActiveSBC

### General function

- Status information for the safety function "Safe Brake Control", SBC

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SBC.

#### TRUE

Safety function SBC is active and currently in its safe state.

#### FALSE

Safety function SBC is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.



## 2.6.5 S\_SafetyActiveSOS

### General function

- Status information for the safety function "Safe Operating Stop", SOS.

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SOS.

#### TRUE

Safety function SOS is active and currently in its safe state.

#### FALSE

Safety function SOS is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.6 S\_SafetyActiveSS1

### General function

- Status information for the safety function "Safe Stop 1", SS1.

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SS1.

#### TRUE

Safety function SS1 is active and currently in its safe state.

#### FALSE

Safety function SS1 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.7 S\_SafetyActiveSS2

### General function

- Status information for the safety function "Safe Stop 2", SS2.

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SS2.

#### TRUE

Safety function SS2 is active and currently in its safe state.

#### FALSE

Safety function SS2 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.8 S\_SafetyActiveSLS1

### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 1

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SLS1.

#### TRUE

Safety function SLS1 is active and currently in its safe state.

#### FALSE

Safety function SLS1 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.9 S\_SafetyActiveSLS2

### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 2

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SLS2.

#### TRUE

Safety function SLS2 is active and currently in its safe state.

#### FALSE

Safety function SLS2 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.10 S\_SafetyActiveSLS3

### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 3

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SLS3.

#### TRUE

Safety function SLS3 is active and currently in its safe state.

#### FALSE

Safety function SLS3 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.11 S\_SafetyActiveSLS4

### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 4

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SLS4.

#### TRUE

Safety function SLS4 is active and currently in its safe state.

#### FALSE

Safety function SLS4 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.12 S\_SafetyActiveSLI

### General function

- Status information the safety function "Safely Limited Increment"

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SLI.

#### TRUE

Safety function SLI is active and currently in its safe state.

#### FALSE

Safety function SLI is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.



### 2.6.13 S\_SafetyActiveSDIpos

#### General function

- Status information for the safety function "Safe Direction", movement is allowed in the positive direction

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SDIpos.

#### TRUE

Safety function SDIpos is active and currently in its safe state.

#### FALSE

Safety function SDIpos is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.14 S\_SafetyActiveSDIneg

### General function

- Status information for the safety function "Safe Direction", movement is allowed in the negative direction

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

Indicates the functional safe state of the safety function SDIneg.

#### TRUE

Safety function SDIneg is active and currently in its safe state.

#### FALSE

Safety function SDIneg is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

## 2.6.15 S\_SafetyActiveSDC

### General function

- Information about the status of the ramp monitor

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

This output parameter indicates the status of ramp monitoring.

#### TRUE

Ramp monitoring is active.

#### FALSE

Ramp monitoring is not active, the module is currently in an error state or the function block has not been activated.

### **Danger!**

**This signal should only be used for status information.**

## 2.6.16 S\_AllReqFuncActive

### General function

- Information about the status of the requested safety functions

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

This output parameter specifies the status of the requested safety functions.

#### TRUE

All requested safety functions are currently in their functional safe state.

#### FALSE

One or more safety functions have not yet achieved their safe state, the module is in an error state or the function block has not yet been activated.

## 2.6.17 S\_NotErrFUNC

### General function

- Information about the error state of the SafeMC module

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

This output parameter specifies the error status of the SafeMC module.

#### TRUE

No error was found on the SafeMC module.

#### FALSE

An error was detected on the SafeMC module (e.g. a monitored limit was exceeded) or the function block has not yet been activated.

In the event of an error, additional information about the error can be found in Automation Studio's Safety Logger. If the error is a functional error, then it can be confirmed by changing the signal on the Reset input from FALSE to TRUE (positive edge)!

### **Danger!**

**This signal should only be used for status information. This only applies in relation to the requested safety functions.**

**S\_NotErrFUNC does not represent the functional safe state of the SafeMC module!**

### **Danger!**

**It is the user's responsibility to ensure that all necessary repair measures are initiated after an error occurs since subsequent errors can result in dangerous situations!**

## 2.6.18 Error

### General function

- Function block error message

### Data type

- BOOL

### Connection

- Variable

### Description of function

This formal parameter indicates a pending function block error message.

#### TRUE

The enabled function block has detected an error. DiagCode indicates the error code.

#### FALSE

The function block is not enabled or the enabled function block has not detected any errors. DiagCode indicates the status.

### **Danger!**

**It is the user's responsibility to ensure that all necessary repair measures are initiated after an error occurs since subsequent errors can result in dangerous situations!**

In order to exit an error state (Error= TRUE), the signal on the Reset input must change from FALSE to TRUE (positive edge).

## 2.6.19 DiagCode

### General function

- Function block diagnostic message

### Data type

- WORD

### Connection

- Variable

### Description of function

Block-specific diagnostic and status messages are output and automatically made available to the higher-level diagnostic tools via this output parameter.

Higher-level diagnostic tools cannot acknowledge diagnostic messages from the function block, however. This is done exclusively in the **safe** application program.

The function block indicates the presence of an error message on the DiagCode output via the output parameter "Error".

### Diagnostic code

The diagnostic code is specified using the WORD data type. The values and meanings of these diagnostics codes are listed below.

In the event of status messages (0xxx<sub>hex</sub>, 8xxx<sub>hex</sub>), the function block sets "Error" to FALSE.

In the event of error messages (Cxxx<sub>hex</sub>), the function block sets "Error" to TRUE.

## 2.6.20 Diagnostic codes

Code (hex)	State	Description	Possible remedy
0000	Idle	The function block is not enabled.	Activate the function block by setting Activate to TRUE.
8001	Init	The function block has been activated and the SafeMC module is in the Init state. The SafeMC module startup inhibit is active.	Configure the parameter "Startreset" accordingly or change to a positive edge on the Reset input.
8002	Operational	The SafeMC module is in the "Operational" state. No safety function is selected. The speed limit SMS is monitored according to the configuration.	No action required.
8003	Wait for Confirmation	The SafeMC module is in the internal "Operational" state. At least one safety function has been requested and at least one safety function has not yet achieved its functional safe state. None of the limits currently being monitored have been violated.	No action required.
8000	Safe State	All requested safety functions have achieved their functional safe state. None of the limits currently being monitored have been violated.	No action required.
C000	Functional Fail Safe	An error has occurred.	Check the Safety Logger in Automation Studio. This will provide you with detailed information about the currently pending error. Depending on the type of error, check the standard and safe applications. If a functional error occurs, check the module configuration or replace the faulty module!

Table 180: SF\_SafeMC\_BR(\_V2): Diagnostic codes



## 2.6.21 AxisStatus

### General function

- Diagnostics message from the function block, representation of the axis status bits in a DWORD

### Data type

- DWORD

### Connection

- Variable

### Description of function

The AxisStatus output returns bit-coded information about the status of the individual safety functions.

This information is equal to a summary of the S\_xxx outputs in a DWORD.

The individual bits have the following meaning:

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
Status STO	Status SBC	Status SOS	Status SS1	Status SS2	Status SLS1	Status SLS2	Status SLS3
Bit 8	Bit 9	Bit 10	Bit 11	Bit 12	Bit 13	Bit 14	Bit 15
Status SLS4	Status STO1	Status SDI pos	Status SLI	Status SDI neg	-	-	-
Bit 16	Bit 17	Bit 18	Bit 19	Bit 20	Bit 21	Bit 22	Bit 23
-	Status Set Position Alive Test	Status SFR	Status "All requested safety functions active"	Status SDC	Status Operational	Status Not Encoder Error	Status Not Functional Error

Table 181: SF\_SafeMC\_BR: SafeMC module status bits

## 2.7 State machine

The state machine shown is implemented on the SafeMC module.




Figure 73: SF\_SafeMC\_BR(\_V2): State machine

The individual statuses are reflected on the DiagCode output parameter. In this sense, the function block provides a representation of the SafeMC module's state machine.

## 2.8 Signal sequence diagram of the function block

A general signal sequence diagram of the function block cannot be specified because it depends on which safety functions are selected or deselected.

The signal curve diagrams of the individual safety functions are shown in the section "System features / SafeMC module oder SafeMC module with SinCos interface / Safety functions"!

### 3 SF\_SafeMC\_BR\_V2




Figure 74: Function block SF\_SafeMC\_BR\_V2

#### Information:

The SF\_SafeMC\_BR\_V2\_00 function block cannot be used without Safety Release 1.4.

If safety release 1.3 is being used, then SafeDESIGNER returns an error when compiling the safety application!

### 3.1 Formal parameters of the function block

In the following, the term "variable" refers to both a variable as well as a graphic connection.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
<b>Activate</b>	BOOL	Variable / Constant	Status	FALSE	Activates the function block (= TRUE)
<b>S_RequestSTO</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	STO safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSTO1</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	STO1 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSBC</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SBC safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSOS</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SOS safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSS1</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SS1 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSS2</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SS2 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS1</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS1 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS2</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS2 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS3</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS3 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLS4</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLS4 safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLI</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLI safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSDIpos</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SDIpos safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSDIneg</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SDIneg safety function request: SAFEFALSE: Safety function requested
<b>S_RequestSLP</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	SLP safety function request: SAFEFALSE: Safety function requested
<b>S_RequestHoming</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	Request for safe homing Request is made at positive edge!
<b>S_ReferenceSwitch</b>	SAFEBOOL	Variable / Constant	Status	SAFEFALSE	Safe input for a reference switch
<b>Reset</b>	BOOL	Variable	Edge	FALSE	Resets error messages and the SafeMC module once the cause of the error has been removed.
<b>S_AxisID</b>	SAFEINT	Constant	Status	-1	Assigns an axis to the function block

Table 182: SF\_SafeMC\_BR\_V2: Overview of input parameters

1) Evaluation of the input parameter signals in the function block. The signals must be controlled accordingly by the user.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
<b>Ready</b>	BOOL	Variable	Status	FALSE	Indication that the function block is enabled
<b>S_SafetyActiveSTO</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function STO is active (= SAFETRUE)
<b>S_SafetyActiveSTO1</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function STO1 is active (= SAFETRUE)
<b>S_SafetyActiveSBC</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SBC is active (= SAFETRUE)
<b>S_SafetyActiveSOS</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SOS is active, no violation of a monitored limit (= SAFETRUE)
<b>S_SafetyActiveSS1</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SS1 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSS2</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SS2 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS1</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS1 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS2</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS2 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLS3</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS3 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)

Table 183: SF\_SafeMC\_BR\_V2: Overview of output parameters

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
<b>S_SafetyActiveSLS4</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLS4 is active, deceleration monitor is finished, no violation of a monitored limit detected (= SAFETRUE)
<b>S_SafetyActiveSLI</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLI is active, no violation of a monitored limit (= SAFETRUE)
<b>S_SafetyActiveSDIpos</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SDIpos is active (= SAFETRUE)
<b>S_SafetyActiveSDIneg</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SDIneg is active (= SAFETRUE)
<b>S_SafetyActiveSLP</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SLP is active (= SAFETRUE)
<b>S_SafetyActiveSMP</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Safety function SMP is active (= SAFETRUE)
<b>S_SafePositionValid</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Specifies whether the safe position is valid (=SAFETRUE, homing procedure has completed successfully and there are no encoder errors)
<b>S_AllReqFuncActive</b>	SAFEBOOL	Variable	Status	SAFEFALSE	All requested safety functions have achieved their safe state. (= SAFETRUE)
<b>S_SafetyActiveSDC</b>	SAFEBOOL	Variable	Status	SAFEFALSE	Deceleration monitor is active (= SAFETRUE)
<b>S_NotErrFUNC</b>	SAFEBOOL	Variable	Status	SAFEFALSE	SafeMC is not in the Functional Fail Safe state (= SAFETRUE)
<b>Error</b>	BOOL	Variable	Status	FALSE	Function block error message
<b>DiagCode</b>	WORD	Variable	Status	16#0000	Function block diagnostic message
<b>AxisStatus</b>	DWORD	Variable	Status	32#00000000	Status information from axis

Table 183: SF\_SafeMC\_BR\_V2: Overview of output parameters

1) Output of the output parameter signals. The signals must be evaluated and/or further processed accordingly by the user.

Type	Description	Size in bits	Format option
<b>BOOL</b>	Bit	1	Bool
<b>WORD</b>	Word	16	Binary number, hexadecimal number, unsigned decimal number
<b>SAFEBOOL</b>	Bit	1	Boolean (signal source: safe device)
<b>SAFEINT</b>	Integer	16	Binary number, hexadecimal number, unsigned decimal number (signal source: safe device)

Table 184: SF\_SafeMC\_BR\_V2: Formats of data types used

It is possible to link a safe signal with a non-safe input parameter. To do so, you need to use a function block for type conversion.

### 3.2 SafeMC module parameters

Parameter	Unit	Description	Safety function
<b>Encoder Unit System</b>			
Count of physical reference system	-	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: x-reference lengths (Reference length = Length of the physical reference system) Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	Unit system
Units per count of physical reference system [units]	units	Rotary encoder unit-scale: Units per x revolutions Linear encoder unit scale: Units per x reference lengths Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	Unit system
Counting direction	Standard / Inverse	Counting direction of the position or speed Default...Encoder counter direction is equal to the counting direction of the unit system Inverse...Encoder counting direction is negative to the counting direction of the unit system	Unit system
Length of physical reference system for linear encoder (nm)	nm	For linear measurement systems, the length of a physical reference system will be defined here. This value is not used for rotary encoders, where the reference system is a single rotation.	Unit system
Maximum speed to normalize the speed range (units)	units	Maximum speed to which the displayed speed should be normalized	Unit system
Maximum acceleration (rad/s <sup>2</sup> or mm/s <sup>2</sup> )	rad/s <sup>2</sup> or mm/s <sup>2</sup>	Maximum permissible encoder acceleration	Unit system
<b>Homing</b>			
Home Position or home Offset (units)	units	Home position or home offset	Homing
Max. trigger speed (units/s)	units/s	Maximum permissible speed for evaluating the reference switch / reference pulse.	Homing
Homing Monitoring Time (μs)	μs	Monitoring time for the homing procedure	Homing
Mode	Direct / Reference Switch / Home Offset / Home Offset with Correction	Selection of homing mode	Homing
Edge of reference switch	Positive / Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Homing
Trigger direction	Positive / Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Homing
Reference pulse	Used / Not used	Selection of whether or not to use a reference pulse for homing	Homing
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.	Homing
<b>Safety deceleration ramp</b>			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	SS1, SS2, SLS
<b>General settings</b>			
Safe Maximum Speed	Used / Unused	Activates the SMS safety function by configuration	SMS
Automatic Reset at Startup (StartReset)	Used / Unused	Activates automatic reset of the function block at startup	Configuration
Channel selection for One Channel STO (STO1)	HighSide / LowSide	Selection of HighSide or LowSide IGBT in the function One Channel STO	STO1 / configuration Functional Fail Safe
Ramp monitoring for SS1	Activated / Deactivated	Activates the ramp monitoring (in addition to the time) when the SS1 safety function is requested	SS1
Ramp monitoring for SS2	Activated / Deactivated	Activates the ramp monitoring (in addition to the time) when the SS2 safety function is requested	SS2
Ramp monitoring for SLS	Activated / Deactivated	Activates the ramp monitoring (in addition to the time) when the SLS safety function is requested	SLS
Early Limit Monitoring	Activated / Deactivated	Monitoring of the deceleration ramp is prematurely terminated if the target limit is reached or exceeded.	SS1, SS2, SLS
Safe Maximum Position	Used / Unused	Activates the SMP safety function by configuration	SMP
<b>Encoder Monitoring</b>			
Encoder Position Monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the position lag error generated on the SafeMC module.	Monitoring Encoder shaft breakage
Encoder Speed Monitoring	Activated / Deactivated	Activates/deactivates the monitoring of the speed error generated on the SafeMC module.	Monitoring Encoder shaft breakage

Table 185: SF\_SafeMC\_BR\_V2: Module parameter

Parameter	Unit	Description	Safety function
Set position alive testing	Activated / Deactivated	Activates/deactivates the monitor that detects whether the set position generated on the ACOPOSmulti is frozen.	Monitoring Encoder shaft breakage
<b>Behavior of Functional Fail Safe</b>			
Behavior of Functional Fail Safe	STO/ STO1 and STO with time delay	In the Functional Fail Safe state, STO (SBC) is activated immediately or STO1 and then STO (SBC) after a delay.	Configuration
Delay time for STO in Functional Fail Safe	[µs]	Delay between STO1 and STO (and SBC) in the state Functional Fail Safe	Configuration
Delay time until the brake engages	[µs]	Delay time before the brake engages The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.	Configuration
<b>Speed Limits</b>			
Maximum speed limit for SMS	[units/s]	Speed limit of the maximum speed	SMS
Safe Speed Limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	SLS
Safe Speed Limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	SLS
Safe Speed Limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	SLS
Safe Speed Limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	SLS
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	SMP
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	SMP
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	SLP
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	SLP
<b>Safety Standstill and Direction Tolerances</b>			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	SOS, SS2, SLI, SMP, SLP
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	SOS, SS2, SDI, SMP, SLP
<b>Safely Limited Increments</b>			
Safe increments	[units]	Maximum moveable increments when SLI is active	SLI
SLI OFF Delay	[µs]	Switch off delay of SLI	SLI
<b>Safety Ramp Monitoring Times</b>			
Ramp Monitoring Time for SS1	[µs]	Deceleration monitoring time for SS1	SS1
Ramp Monitoring Time for SS2	[µs]	Deceleration monitoring time for SS2	SS2
Ramp Monitoring Time for SLS1	[µs]	Deceleration monitoring time for SLS1	SLS1
Ramp Monitoring Time for SLS2	[µs]	Deceleration monitoring time for SLS2	SLS2
Ramp Monitoring Time for SLS3	[µs]	Deceleration monitoring time for SLS3	SLS3
Ramp Monitoring Time for SLS4	[µs]	Deceleration monitoring time for SLS4	SLS4
<b>Safety Additional Parameters</b>			
Delay time to start ramp monitoring (us)	[µs]	Delay time between request of ramp monitoring and start of monitoring	SS1, SS2, SLS
Delay time to start SDI (us)	[µs]	Delay time between the SDI request and activation of the safety function	SDI
Delay time to start SBC (us)	[µs]	Delay time between the SBC request and activation of the safety function	SBC
Delay time to start SLP (us)	[µs]	Delay time between request of SLP and start of monitoring	SLP
Early Limit Monitoring time (us)	[µs]	Time during which the speed limit must be equal to or below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	SS1, SS2, SLS
<b>Encoder Monitoring Tolerances</b>			
Encoder Monitoring Position Tolerance	[units]	Position lag error tolerance for shaft breakage monitoring	Monitoring Encoder shaft breakage
Encoder Monitoring Speed Tolerance	[units/s]	Speed error tolerance for encoder monitoring	Monitoring Encoder shaft breakage

Table 185: SF\_SafeMC\_BR\_V2: Module parameter

In a safety application, it is possible for multiple safety functions to be requested at the same time. In order to prevent this from turning into an unsafe situation, the individual safety functions are prioritized on the SafeMC module.

If several functions are active, then the lowest speed limit is always the value being monitored.

**Information:**

The following application rules must be followed in order to enable prioritization of the safety functions:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

or

$$\text{LIM}_{\text{SMP,NEG}} \leq \text{LIM}_{\text{SLP,NEG}} \leq \text{LIM}_{\text{SLP,POS}} \leq \text{LIM}_{\text{SMP,POS}}$$

If the application guideline is violated, then the SafeMC module changes to the Fail Safe state.



### 3.3 Integrated safety functions

#### Information:

If a safety function is not used in the application, then the respective input variables must remain open.

The following functions are supported by the SafeMC module:

Safety function	Starting safety lease	in re-	EN ISO 13849-1	EN 61508/EN 62061	Safe encoder evaluation required
Safe Torque Off (STO)	R 1.3		Pl e	SIL 3	No
Safe Torque Off One Channel (STO1)	R 1.3		Pl d	SIL 2	No
Safe Operation Stop (SOS)	R 1.3		Pl d	SIL 2	Yes
Safe Stop 1 (SS1 )	R 1.3		PL e (time-monitored) Pl d	SIL 3 (time-monitored) SIL 2	No (time-monitored) Yes
Safe Stop 2 (SS2)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Speed (SLS)	R 1.3		Pl d	SIL 2	Yes
Safe Maximum Speed (SMS)	R 1.3		Pl d	SIL 2	Yes
Safe Direction (SDI)	R 1.3		Pl d	SIL 2	Yes
Safely Limited Increment (SLI)	R 1.3		Pl d	SIL 2	Yes
Safe Brake Control (SBC)	R 1.3		Pl d	SIL 2	No
Safely Limited Position (SLP)	R 1.4		Pl d	SIL 2	Yes
Safe Maximum Position (SMP)	R 1.4		Pl d	SIL 2	Yes
Safe Homing	R 1.4		Pl d	SIL 2	Yes

Table 186: Safety functions and corresponding safety levels

#### Information about using the integrated safety functions

At least the activate input and the S\_AxisID must be connected. Otherwise, the SafeMC module will not be operated by the SafeLOGIC. As a result, the pulse disabling and the motor holding brake output will be permanently set to 0 V, which means that the controller cannot be turned on.

#### Danger!

All of the safety functions that are used must be tested.

A function is considered to be used if the respective input variable is connected or the safety function has been configured!

#### 3.3.1 Fail-safe state

##### 3.3.1.1 Parameters

None

##### 3.3.1.2 Behavior

If an error in the hardware or firmware occurs, then the safe inverter module changes to a non-acknowledgeable error state – the fail-safe state. The log book entry in Automation Studio provides more detailed information about the pending error. This log book can also be evaluated in the standard application.

If there is a hardware defect, then the entire inverter module must be replaced.

#### Information:

The SafeMC modules cannot be replaced! SafeMC modules and the corresponding inverter module form a single unit. In the event of an error, the entire inverter module must be replaced.

However, the error can also have been caused by a configuration mistake. If this is the case, then the safe configuration must be checked and reloaded to the SafeLOGIC controller. This must then be followed by a PowerOff/PowerOn cycle to get the module back to the "Operational" state.

#### Danger!

Safe pulse disabling is always active in the fail-safe state (i.e. the motor is no longer supplied with power or generating torque). The motor holding brake output is always switched to 0 V in this state!

**Danger!**

Constantly lit LEDs "SE" indicate a fail safe state that cannot be acknowledged. The cause of this could be a defective module or faulty configuration.

Check the entries in the logbook! If you are able to rule out a faulty configuration, then the module is defective and must be replaced immediately.

It is the user's responsibility to ensure that all necessary repair measures or corrections in the configuration are initiated after an error occurs since subsequent errors can result in dangerous situations!

**Danger!**

The motor holding brake is engaged in Fail Safe state. The motor holding brake will suffer mechanical wear if the motor is in motion just before the safe state is triggered. This must be considered when selecting and dimensioning the motor holding brake (E-stop capability).

**3.3.2 Functional fail-safe state****3.3.2.1 Parameters**

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide
Behavior of Functional Fail Safe			
Behavior of Functional Fail Safe	STO/ STO1 and STO with time delay	In the Functional Fail Safe state, STO (SBC) is activated immediately or STO1 and then STO (SBC) after a delay	STO
Delay time for STO in Functional Fail Safe	[µs]	Delay time between STO1 and STO (and SBC) in the Functional Fail Safe state	0
Delay time until the brake engages	[µs]	Delay time before the brake engages The second enable channel is activated after this delay time if STO1 and delayed STO and SBC are configured for Functional Fail Safe.	0

Table 187: Functional Fail Safe state configuration parameters

**3.3.2.2 Behavior**

If a monitored limit is exceeded or an encoder error occurs during operation – and as long as the safe encoder is required for the safety functions being used – then the SafeMC module changes to an acknowledgeable error state – the functional fail-safe state.

Information about any errors that occur can be found in the logbook entry in Automation Studio. This log book can also be evaluated in the standard application.

**Danger!**

The motor holding brake is engaged in Functional Fail Safe state. The motor holding brake will suffer mechanical wear if the motor is in motion just before the safe state is triggered. This must be considered when selecting and dimensioning the motor holding brake (E-stop capability).

**Danger!**

The error response time described in the manual affects the remnant movement in the event of error! This must be accounted for when planning the safety equipment (e.g. distances, monitored limits, etc.)

**"Behavior of Functional Fail Safe" = "STO"**

Pulse disabling is requested (low and high side) immediately after the error is detected and the safe motor holding brake output is set to 0V.




Figure 75: Functional Fail Safe - Configuration of STO

**"Behavior of Functional Fail Safe" = "STO1 and STO with time delay"**

Either the low or high side of the pulse disabling is switched to 0V immediately after the error is detected. The safe motor holding brake output is set to 0 V after the configured time "Delay time for STO in Functional Fail Safe" (T (Delay Time for STO in FFS)) has expired.

The second channel of the pulse disabling is also switched to 0 V after the configured time "Delay time until the brake engages" (T (Delay Time until the brake engages)) has expired.




Figure 76: Functional Fail Safe - Configuration of STO1 and STO with time delay

This makes it possible for the drive to be decelerated via the short circuit braking integrated in the ACOPOSmulti for the amount of time in which just one pulse disabling channel is active.

In this case, the time value T (Delay Time until the brake engages) is used to incorporate this brake engage time. This means that the second pulse disabling channel will only be switched to 0V after the motor holding brake has actually engaged.

## Danger!

The short circuit braking in the ACOPOSmulti is not suitable for safety purposes and can therefore only be used to protect the machine. If loss of power on the motor could result in dangerous situations (e.g. with hanging loads), then a mechanical safeguard must also be installed.

### 3.3.3 Safe Position, Safe Speed

#### 3.3.3.1 Parameters

Parameter	Unit	Description	Default value
Encoder Unit System			
Encoder type	Rotatory encoder / Linear encoder / Encoder not used	Determines the type of encoder being used: <ul style="list-style-type: none"> <li>Rotary encoder</li> <li>Linear encoder</li> <li>Encoder not used</li> </ul> <i>The parameter is only available for ACOPOSmulti with SafeMC SinCos!</i>	Rotary encoder
Number of signal periods	-	Number of encoder signal periods per rotation (rotary encoder) or per length of the physical reference system (linear encoder) <i>The parameter is only available for ACOPOSmulti with SafeMC SinCos!</i>	1
Count of physical reference system	-	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: y-reference lengths (Reference length = Length of the physical reference system)  Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1

Table 188: Unit system parameters

Parameter	Unit	Description	Default value
Units per count of physical reference system	[units]	Rotary encoder unit scale: x-revolutions Linear encoder unit scale: y-reference lengths  Any unit (mm, 1/100 mm, 1/20 inch, degree of angle, etc.) can be used for positions (and data which can result such as speed and acceleration). Therefore, the relationship between an integer multiple of this unit (units per x-revolutions / units per x-reference lengths) and a certain number of x-revolutions / x-reference lengths has to be previously defined.	1000
Counting direction	Standard / Inverse	Counting direction of the position or speed Standard: Encoder counting direction is equal to the counting direction of the unit system Inverse: Encoder counting direction is negative to the counting direction of the unit system	Standard
Length of physical reference system for linear encoder (nm)	[nm]	For linear measurement systems, the length of a physical reference system will be defined here. This value is not used for rotary encoders, where the reference system is a single rotation.	1000000000
Maximum speed to normalize the speed range (units/s)	[units/s]	Maximum speed to which the displayed speed should be normalized	32767
Maximum acceleration (rad/s <sup>2</sup> or mm/s <sup>2</sup> )	[rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	Maximum permissible encoder acceleration	100000

Table 188: Unit system parameters

### 3.3.3.2 Behavior

The parameters (see 4.3.1 "Table: "Unit system parameters"" on page 154) can be used to configure the safe unit system.

The safe speed and the safe position are transferred in the safety frame. The process data is only allowed to be used together with the respective status bit. If the respective status bit is FALSE, then the corresponding data is invalid.

Function blocks are available for linking the process data with a specific axis and using in the safe application!

#### Safe position

The safe position is transferred in [units] according to the configured unit system. Once homing is complete, the "SafePosition Valid" status bit is set.

#### **Danger!**

If the position signal is not validated, then an invalid position could be used in the safe application. This can result in hazardous situations!

#### **Danger!**

Safe encoder evaluation can only detect an error in the transfer or position

- if a distance is traversed that is greater than the angular deviation of the safe position specified in the product information provided by the manufacturer of the measuring device (*applies to ACOPOSmulti with SafeMC EnDat 2.2*).
- if a distance is traversed that is greater than  $\pm 1/2$  signal period of the SinCos measurement device (*applies to ACOPOSmulti with SafeMC SinCos*).

The resulting maximum error in the safe position also depends on the length of the physical reference system (rotations, length of the scale, etc.).

This error affects the minimum distance required for the protection (e.g. of fingers) against crushing and must be accounted for when dimensioning the safety function.

#### **Danger!**

A frictionally engaged connection with fault exclusion requires no extra mechanical offset for the safe position.

If the fault exclusion is only achieved by implementing a mechanical stop with backlash, then this maximum possible offset must be calculated into the safe position. This is done by adding the values for the measuring instrument and for the mechanical link.

## Safe Speed

The safe speed is scaled to 2 bytes due to the limited Safety Frame bandwidth available. The scaled speed  $v_{scaled}$  is calculated as follows:

$$v_{scaled} = \frac{v_{physical} \cdot 32767}{\text{Maximum speed to normalize the speed range}} \left[ \frac{\text{scaled units}}{s} \right]$$

$v_{physical}$  (physical velocity) corresponds to the actual physical size and is calculated in the configured unit system in [units/s].

This means the scaled speed equals the physical speed for the default configuration of the parameter "Maximum speed to normalize the speed range" = 32767!

The maximum speed must never exceed the value configured for "Maximum speed to normalize the speed range" or else the module will switch to "Functional Fail Safe" state.

### Information:

The speed limits of the safety functions are configured in the physical speed [units/s]. The safety functions internally monitor the scaled speeds [scaled units / s] whereby scaling errors can occur.

### Example

The following configuration causes the speed tolerance for standstill monitoring to be scaled internally to 0 [scaled units / s].

Configuration:

"Maximum speed to normalize the speed range (units/s)" = 3276700

"Speed Tolerance (unit/s)" = 20

$$\text{Scaled Speed Tolerance} = \frac{\text{Speed Tolerance} \cdot \text{INT16MAX}}{\text{Maximum Speed to normalize the speed range}} = \frac{20 \cdot 32767}{3276700} = 0$$

If Safe Operating Stop is enabled, then a speed tolerance of 0 is monitored internally [scaled units / s]. This can result in a undesired speed violation during standstill.

### Information:

The configured unit system has significant influence on the maximum physical speed achieved.

If the unit system configuration is changed make sure to consider how this affects the parameter "Maximum speed to normalize the speed range".

### Danger!

If the module changes to the acknowledgeable error state "Functional Fail Safe", then the drive loses power and torque, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

### Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### Danger!

If the speed signal is not validated, then an invalid speed value could be used in the safe application. This can result in hazardous situations!

## Danger!

Safe encoder evaluation can only detect an error in the transfer or position

- if a distance is traversed that is greater than the angular deviation of the safe position specified in the product information provided by the manufacturer of the measuring device (*applies to ACOPOSmulti with SafeMC EnDat 2.2*).
- if a distance is traversed that is greater than  $\pm\frac{1}{2}$  signal period of the SinCos measurement device (*applies to ACOPOSmulti with SafeMC SinCos*).

The resulting maximum error in the safe position also depends on the length of the physical reference system (rotations, length of the scale, etc.).

The error influences the error response time and must be accounted for when dimensioning the safety function.

### 3.3.4 STO - Safe Torque Off

#### 3.3.4.1 Parameters

None

#### 3.3.4.2 Behavior

STO is the fundamental safety function of the ACOPOSmulti with SafeMC, since it represents the "fail-safe" principle.

A request from the STO safety function activates safe pulse disabling and switches off the torque and power to the drive. Activation of safe pulse disabling is performed actively by the SafeMC module.

## Danger!

A STO request causes synchronized axes to no longer be synchronous.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!




Figure 77: STO - Safe Torque Off

**Information:**

The functional safe state of the STO function has been achieved when the pulse disabling outputs are switched to 0 V. The respective bit is set once the functional safe state has been achieved.

**Danger!**

The drive will spin out if it is in motion at the time of the STO request. The resulting remnant movement and time depends on the properties of the machine and must always be considered when dimensioning the safety equipment.

The maximum possible (worst case) movement must be assumed.

The maximum possible speed is determined by the current operating mode. If there is no active safety function, the maximum speed that is physically possible for the motor must be assumed.

**Danger!**

If the SMS or SLS function is active, the assumed maximum speed can be reduced to the currently active configured speed limit plus the maximum possible acceleration during the error response time.

**Information:**

The resulting remnant movement and time determines the intervals between the safety features that must be maintained and therefore the size of the machine as well.

**Information:**

The safety function Safe Torque Off does not require encoder evaluation.

**Danger!**

If the safety function STO is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

### 3.3.5 Single-channel Safe Torque Off, STO1

#### 3.3.5.1 Parameters

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide

Table 189: STO1 safety function parameters

#### 3.3.5.2 Behavior

The STO1 safety function works in the same way as STO. The sole difference is that either only the HighSide or only the LowSide IGBTs are switched off depending on the configuration.

**Information:**

The functional safe state of the STO1 safety function has been achieved when the configured pulse disabling output is switched to 0 V.

The respective bit is set once the functional safe state has been achieved.

**Information:**

The two-channel aspect is lost because either only the low side or only the high side of the pulse disabling is activated with the safety function STO1.

This results in a lower SIL and Performance Level!

**Information:**

The safety function STO1 does not require encoder evaluation.



## Danger!

If the safety function STO1 is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

### 3.3.6 Safe Brake Control, SBC

#### 3.3.6.1 Parameters

Parameter	Unit	Description	Default value
Safety Additional Parameters			
Delay time to start SBC (us)	[μs]	Delay time between the SBC request and activation of the safety function	0

Table 190: SBC safety function parameters

#### 3.3.6.2 Behavior

The SBC function is a safe (time-delayed) output whose purpose is to safely control a motor holding brake.

### Information:

To achieve a defined SIL level, the controlled holding brake must also have at least the same SIL level and errors in the wiring must be ruled out.




Figure 78: Safe Brake Control, SBC

Only the actuation of the motor holding brake output through the SafeMC module is safely evaluated with SIL 2.

The braking procedure is not monitored from a safety point of view by the SafeMC module.

### Information:

The functional safe state of the SBC function has been achieved when the safe motor holding brake output has been switched to 0 V.

The respective bit is set once the functional safe state has been achieved.

The purpose of the delay time T (Delay time to start SDI [μs]) is to compensate for the different runtimes of functional and safe applications.

### Information:

The safety function Safe Brake Control does not require encoder evaluation.

## Danger!

If the safety function SBC is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

## Information:

Functional errors will occur (e.g. 6029: Holding brake: Control signal on and output status off), if the holding is released by the standard application but the motor holding brake output is switched to 0 V by the SafeMC module.

### 3.3.7 Safe Operating Stop, SOS

#### 3.3.7.1 Parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 191: SOS safety function parameters

#### 3.3.7.2 Behavior

An enabled SOS safety function monitors the drive to ensure that it stops safely. The SafeMC module does not control pulse disabling.

The drive can remain active and must be kept at standstill by the standard application.

## Information:

The safety function SOS requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 79: Safe Operating Stop, SOS

To prevent the axis from drifting, both the speed and position are monitored with standstill tolerance limits. The position window is generated when the safety function is requested. If the request is withdrawn, then monitoring of the standstill tolerance window will also be terminated. The next time a request is made, the standstill tolerance position window is regenerated based on the current position.

## Information:

The functional safe state of the SOS safety function has been achieved when the drive is stopped and the standstill is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The standstill tolerances can be configured for each axis in SafeDESIGNER.

## Danger!

In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.

The dangerous movement must be determined by a risk analysis.

If the stop monitoring limits are violated, safe pulse disabling is activated and the drive switches to a Functional Fail Safe error state which must be acknowledged. When an error occurs, a synchronous axis loses its synchronicity.

## Danger!

If a standstill limit (position or speed) is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The "*S\_NotErrFUNC*" output on the function block is reset.

## Danger!

If the safety function SOS is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The configured limits must be violated with the function enabled and the error response must be tested accordingly!

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### 3.3.8 Safe Stop 1, SS1

#### 3.3.8.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 192: SS1 safety function parameters

#### 3.3.8.2 Behavior

When the SS1 safety function is requested and after the ramp delay time, the deceleration process of the axis is monitored until standstill. After decelerating, safe pulse disabling is activated and switches off the torque and power to the drive.

## Danger!

Synchronous axes lose their synchronicity when SS1 is in its safe state.




Figure 80: Safe Stop 1, SS1

The deceleration itself is controlled by the standard application, which is not safety-oriented.

The purpose of the ramp delay time - parameter "*Delay time to start ramp monitoring ( $\mu s$ )*" - is to compensate for the different runtimes of functional and safe applications.

### Information:

The functional safe state of the SS1 function has been achieved when the pulse disabling outputs are switched to 0 V. The respective bit is set once the functional safe state has been achieved.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

Depending on the requirements for the safety function and its configuration, either only the deceleration time  $T$  (Ramp Monitoring Time for SS2) or also the deceleration ramp can be monitored.

If the monitoring limits are violated during deceleration, then an error state that must be confirmed is entered.

The parameter "*Ramp monitoring for SS1*" configures the behavior of the delay monitor.

### 3.3.8.3 SS1 - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SS1" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a stopping procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring ( $\mu$ s)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope. If the monitoring ramp reaches the configurable standstill speed limit "*Speed Tolerance (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SS1 ( $\mu$ s)*" has expired, then safe pulse disabling is activated and torque is switched off on the drive.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the standstill speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

If the active limit is violated during monitoring of the deceleration procedure, then the drive will immediately switch to the acknowledgeable error state Functional Fail Safe.

### Information:

**If ramp monitoring is configured for the safety function SS1, then the speed must be safely evaluated. If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!**

### Danger!

**If safe pulse disabling is on (spin-out) and the safety function is in a functionally safe state, the maximum speed at the end of the deceleration ramp must be used to calculate the remaining distance. To determine the maximum possible speed, it must be assumed that in the event of error, the drive will accelerate to its maximum during the error response time starting from the standstill speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

### Danger!

**If the monitored ramp is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

### Danger!

**If the safety function SS1 with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine! The test should include at least one violation of the monitored ramp and the error response must be tested accordingly!**

#### 3.3.8.4 SS1 - Stopping procedure with time-monitoring

##### "Ramp monitoring for SS1" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application.

After the delay time for the request, "*Delay time to start ramp monitoring ( $\mu$ s)*" and the monitoring time, "*Ramp Monitoring Time for SS1 ( $\mu$ s)*" have expired, safe pulse disabling is activated and torque is shutoff on the drive.

### Information:

**With this configuration of the Safe Stop 1 safety function, only the time frame is monitored. No speed limit or position window is monitored. This is why the function can also be used in this configuration without safe encoder evaluation!**

## Danger!

If safe pulse disabling is on (spin-out), the maximum speed after the time frame has expired must be used to calculate the remaining distance!

The drive can move at its physically maximum speed during this time window (plus the response time of the safe pulse disabling). If SMS is active, then the speed limit plus the error tolerance can be assumed as the maximum speed.

It must be ensured that the spin-out movement and remaining distance do not present any danger!

## Danger!

If the safety function SS1 with true time-monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The drive should be accelerated to its maximum during the monitored time frame and the error response tested accordingly!

### 3.3.9 Safe Stop 2, SS2

#### 3.3.9.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 193: SS2 safety function parameters

#### 3.3.9.2 Behavior

With the SS2, after the ramp delay time the deceleration process of the axis is monitored until standstill. The drive must then be kept at standstill by the standard application. This standstill is monitored, similar to SOS, by the SafeMC module according to the configured standstill tolerance window "Speed Tolerance [units/s]" and "Position Tolerance [units]".

The delay itself must be generated by the non-safety-oriented, standard application by halting the drive in response to the dangerous situation.

## Information:

The safety function Safe Stop 2 requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 81: Safe Stop 2, SS2

## Danger!

If a standstill limit (position or speed) is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The "*S\_NotErrFUNC*" output on the function block is reset.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

The purpose of the ramp delay time - parameter "*Delay time to start ramp monitoring ( $\mu s$ )*" - is to compensate for the different runtimes of functional and safe applications.

## Information:

The functional safe state of the SS2 function has been achieved when the drive is stopped and the standstill is being monitored for safety. The respective bit is set once the functional safe state has been achieved.

As with SS1, it is possible to monitor either only the deceleration time or the deceleration ramp as well depending on the requirements of the safety function.

The parameter "*Ramp monitoring for SS2*" configures the behavior of the delay monitor.

### 3.3.9.3 SS2 - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SS2" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a stopping procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring (μs)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope. If the monitoring ramp reaches the configurable standstill speed limit "*Speed Tolerance (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SS2 (μs)*" has expired, then a position window is established and monitoring of the standstill tolerances is started.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the standstill speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

If the active limit or standstill window is violated during monitoring of the deceleration procedure or standstill, then the drive will immediately switch to the acknowledgeable error state Functional Fail Safe.

#### **Danger!**

**When the monitored ramp or standstill tolerance window is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

#### **Danger!**

**In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.**

**The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.**

**The dangerous movement must be determined by a risk analysis.**

#### **Danger!**

**If the safety function SS2 with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!**

**The test should contain at least one violation of the monitored ramp and standstill tolerance window. The error response must be tested accordingly!**

### 3.3.9.4 SS2 - Stopping procedure with time-monitoring

#### "Ramp monitoring for SS2" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application.

After the delay time for the request, "*Delay time to start ramp monitoring (μs)*" and the monitoring time, "*Ramp Monitoring Time for SS2 (μs)*" have expired, the standstill tolerance window will be monitored safely.

#### **Danger!**

**When the standstill tolerance window is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit.**

**It must be ensured that the spin-out movement and remaining distance do not present any danger!**



## Danger!

In the event of an error, forward movement can occur during the error response time when monitoring the standstill tolerance window. Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed and position limits being monitored must be set in a manner so that the calculated forward movement does not cause any danger.

The dangerous movement must be determined by a risk analysis.

## Danger!

If the safety function SS2 with time-monitored stopping procedure is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of the standstill tolerance window. The error response must be tested accordingly!

### 3.3.10 Safely Limited Speed, SLS

#### 3.3.10.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	0
Safe Speed-limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	0
Safe Speed-limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	0
Safe Speed-limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Ramp Monitoring Time for SLS4 (us)	[μs]	Deceleration monitoring time for SLS4	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 194: SLS safety function parameters

#### 3.3.10.2 Behavior

The safety function SLS monitors a specified speed limit - parameter "*Safe Speedlimit 1, 2, 3, 4 for SLS (units/s)*". It is also possible to monitor deceleration until the limit is reached if needed by the application.

Four different speed limits can be monitored on the SafeMC module. All limits can also be monitored in parallel. If a request is made to monitor multiple speed limits at the same time, then the lowest limit value will always be monitored. To make this possible, the function block includes four different inputs "S\_RequestSLSx" (x = 1-4).

The standard (non safety-oriented) application must use a closed-loop control appropriate for the level of danger to decelerate the movement and then maintain the respective speed limit.

## Information:

The safety function SLS requires safe evaluation of the speed. If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!




Figure 82: Safely Limited Speed, SLS

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## Danger!

If a speed limit is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

Torque and power to the drive are switched off, causing the drive to spin out!

An error will cause a synchronous axis to no longer be synchronous. The "S\_NotErrFUNC" output on the function block is reset.

The purpose of the ramp delay time T (Delay time to start ramp monitoring) is to compensate for the different runtimes of functional and safe applications.

If the delay time (Ramp monitoring time for SLSX) is set to 0, then the speed limit will be monitored right after the request is made for the safety function.

## Information:

The functional safe state of the SLS function has been achieved if the drive has not exceeded a defined speed limit and this limit is being monitored for safety. The respective bit is set once the functional safe state has been achieved.

As with SS1 and SS2, the deceleration ramp monitoring can be adjusted according to the requirements, so that either only the deceleration time or both the deceleration time and the deceleration ramp are monitored.

The parameter "Ramp monitoring for SLS" configures the behavior of the delay monitor.

### 3.3.10.3 SLS - Stopping procedure with ramp-based monitoring

#### "Ramp monitoring for SLS" = Activated

With this configuration, the configurable deceleration ramp is monitored in addition to time monitoring. In the event of an error, this provides the advantage that a lower maximum speed can be assumed when entering the safe state. During deceleration ramp monitoring, a deceleration procedure must be adjusted to the dangerous situation by the standard application.

The slope of the monitoring ramp can be set using the parameter, "*Deceleration Ramp*".

A timer is started when the safety function is requested. Monitoring of the deceleration ramp begins after the delay time for the request "*Delay time to start ramp monitoring (μs)*". The monitored ramp always begins at the currently monitored limit and is calculated using the configured slope.

If the monitoring ramp reaches the respective speed limit "*Safe Speedlimit 1, 2, 3, 4 for SLS (units/s)*" or if the monitoring time "*Ramp Monitoring Time for SLS1, 2, 3, 4 (μs)*" has expired, then the status of the safety function will be set and the enabled speed limit monitored.

Early activation of the safety state can be configured using the parameter "*Early Limit Monitoring*" = Activated. If the setting above has been made, then the safe state of the safety function will be started when the current speed falls below the monitored speed limit for at least the amount of time defined by "*Early Limit Monitoring timer*" during deceleration ramp monitoring.

#### **Danger!**

**When the monitored ramp or the enabled safe speed is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit. It must be ensured that the spin-out movement and remaining distance do not present any danger!**

#### **Danger!**

**In the event of an error when monitoring the safe reduced speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.**

**Within this amount of time, the drive could accelerate to its maximum before spinning out.**

**The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger. The dangerous movement must be determined by a risk analysis.**

#### **Danger!**

**If the safety function SLS with ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!**

**The test should contain at least one violation of the monitored ramp and of each speed limit being used. The error response must be tested accordingly!**

### 3.3.10.4 SLS - Stopping procedure with time-monitoring

#### "Ramp monitoring for SLS" = Deactivated

This configuration provides true time-monitoring of the delay.

A timer is started when the safety function is requested. Within this time frame, the drive must implement a stopping procedure that is appropriate for the respective dangerous situation using the standard application. After the delay time for the request, "*Delay time to start ramp monitoring (μs)*" and the monitoring time, "*Ramp Monitoring Time for SLS1, 2, 3, 4 (μs)*" have expired, the speed limit will be monitored safely.

#### **Danger!**

**When the speed limit is exceeded, the remaining distance must be calculated based on the error response time, starting with the currently monitored speed limit.**

**It must be ensured that the spin-out movement and remaining distance do not present any danger!**

**Danger!**

In the event of an error when monitoring the safe reduced speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out.

The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SLS without ramp monitoring is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of each speed limit being used.

The error response must be tested accordingly!

**3.3.11 Safe Maximum Speed, SMS****3.3.11.1 Parameters**

Parameter	Unit	Description	Default value
General settings			
Safe Maximum Speed	Used / Not used	SMS safety function activated or deactivated	Used
Speed Limits			
Maximum speed limit for SMS	[units/s]	Speed limit of the maximum speed	0

Table 195: SMS safety function parameters

**3.3.11.2 Behavior**

The difference between SMS and SLS is that SMS cannot be actively requested. It is either activated (parameter "Safe Maximum Speed" = Used) or deactivated (parameter "Safe Maximum Speed" = Not used) in the configuration.

When activated, the current speed is constantly monitored according to a defined limit (parameter "Safe Maximum Speed (units/s)").

**Information:**

The safety function SMS requires safe evaluation of the speed.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!

**Danger!**

When the monitored speed limit is exceeded, the remaining distance must be calculated based on the error response time.

It must be ensured that the spin-out movement and remaining distance do not present any danger!

**Danger!**

In the event of an error when monitoring the safe maximum speed, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out. The speed limit being monitored must be set in a manner so that the calculated forward movement will not cause any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SMS is used in the safe application, then it must be tested when commissioning the machine!

The configured limit must be exceeded! The error response must be tested accordingly!

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### 3.3.12 Safely Limited Increment, SLI

#### 3.3.12.1 Parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Safely Limited Increments			
Safe increments	[units]	Maximum moveable increments when SLI is active	0
SLI OFF Delay	[µs]	Switch off delay of SLI	0

Table 196: SLI safety function parameters

#### 3.3.12.2 Behavior

With the SLI safety function, the movement is monitored for a defined number of increments (parameter "Safe Increments (units)").

### Information:

The safety function SLI requires safe evaluation of the speed and position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Functional Fail Safe" state after the function block is activated!




Figure 83: Safely Limited Increment, SLI

**Information:**

The safety function SLI is only effective when used in combination with at least one other safety function. This could be one of the safety functions such as SOS, SS2, or SLS.

**Information:**

The functional safe state of the SLI function has been achieved if the drive has not exceeded a defined increment size and this limit is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The safe axis must be at a standstill when this function is enabled. To do this, the speed is monitored for adhering to the speed standstill tolerance (parameter "*Speed Tolerance (units /s)*").

A position window is then generated that is monitored from a safety point of view. This position window depends on the configured safe increment size (parameter "*Safe Increments (units)*"). The standard application must guarantee that this position window is not exceeded.

After deactivating the safety function, monitoring remains active for the configured amount of time (parameter "*SLI Off Delay (μs)*"). This prevents continuous movement caused by constant jogging.

**Danger!**

If a speed limit for requesting the function or if the position window is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous.

The "*S\_NotErrFUNC*" output on the function block is reset.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**Danger!**

In the event of an error when monitoring the safe increments, a dynamic forward movement that goes beyond the monitored limit can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out.

The remaining distance must be taken into consideration when configuring the permissible increments and must not cause any hazards.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SLI is used in the safe application, then the ability to enable/disable it must be tested when commissioning the machine!

The test should contain at least one violation of the standstill speed limit when enabled and the permissible increments. The error response must be tested accordingly!

**3.3.13 Safe Direction, SDI****3.3.13.1 Parameters**

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[μs]	Delay time between the SDI request and activation of the safety function	0

Table 197: SDI safety function parameters

**3.3.13.2 Behavior**

The SDI safety function monitors the defined direction of movement.

Either the positive or the negative direction can be monitored. This is done using the two inputs “*S\_RequestSDIpos*” and “*S\_RequestSDIneg*” that are available on the function block.

### Information:

The safety function SDI requires safe evaluation of the position.

If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the Functional Fail Safe state after the function block is activated!




Figure 84: Safe Direction, SDI - Positive direction of rotation allowed




Figure 85: Safe Direction, SDI - Negative direction of rotation allowed

**Information:**

The safe direction function can be enabled in parallel with other safety functions. For example, SLS or SLI can be limited to a certain direction.

**Information:**

The functional safe state of the SDI function has been achieved if the drive has not violated a defined direction of movement and this direction of movement is being monitored for safety.

The respective bit is set once the functional safe state has been achieved.

The purpose of the delay time "*Delay time to start SDI ( $\mu$ s)*" is to compensate for the different runtimes of functional and safe applications.

When monitoring the direction of movement, the standstill position tolerance (parameter "*Position Tolerance (units)*") must not be exceeded in the forbidden direction of movement. When moving in the permitted direction of movement, the position window moves along like a slave pointer.

**Danger!**

If the safe direction of movement is violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. Torque and power to the drive are switched off, causing the drive to spin out!

An error will cause a synchronous axis to no longer be synchronous.

The "*S\_NotErrFUNC*" output on the function block is reset.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**Danger!**

In the event of an error when monitoring the safe direction of rotation, a dynamic forward movement in the dangerous direction can occur during the error response time.

Within this amount of time, the drive could accelerate to its maximum before spinning out. The resulting remaining distance must be accounted for when configuring the permissible tolerance limits and must not present any danger.

The dangerous movement must be determined by a risk analysis.

**Danger!**

If the safety function SDI is used in the safe application, then the ability to enable/disable each of the directions of movement that are being used must be tested when commissioning the machine!

The test should contain at least one violation of each safe direction of movement that is being used.

The error response must be tested accordingly!

**3.3.14 Safe Homing****Information:**

The safety function Safe Homing is only available in Safety Release R 1.4 or higher!

**3.3.14.1 Parameters**

Parameter	Unit	Description	Default value
Homing			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time ( $\mu$ s)	[ $\mu$ s]	Monitoring time for the homing procedure	0

Table 198: Parameters for the "safe homing" safety function



Parameter	Unit	Description	Default value
Mode	Direct/ Reference Switch/ Home Offset/ Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive/ Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive
Trigger direction	Positive/ Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used/ Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0

Table 198: Parameters for the "safe homing" safety function

### 3.3.14.2 Behavior

The Safe Homing function provides a way to establish a reference between the encoder position and the machine position.

Depending on the homing mode, it may be necessary for the drive to perform a homing procedure. A homing procedure requires the control functions between the electronic controller and the drive motor to be active. Other safety functions might have to be selected in order to prevent a hazardous state during the homing procedure.

The following homing modes are supported:

- Direct
- Reference switch
- Home Offset / Home Offset with Correction (*only available for ACOPOSmulti with SafeMC EnDat 2.2!*)

#### Information:

**Safe homing requires safe evaluation of the position.**

**If the function is programmed in the safe application and if an error is detected in the safe encoder evaluation, then the SafeMC module immediately changes to the "Fail Safe" state after the function block is activated! The "Fail Safe" state can only be exited by powering off and then on again!**

A positive edge on the control bit *S\_RequestHoming* will start safe homing and simultaneously reset the status bit *S\_SafePositionValid*.

As soon as the homing procedure is completed, the status bit *S\_SafePositionValid* will be set and the control bit *S\_RequestHoming* must be reset.

The homing procedure must be completed within the "*Homing monitoring time (μs)*" or else the SafeMC module will change to the functional fail-safe state.

The homing procedure will be aborted if the *S\_RequestHoming* control bit is reset before the procedure is completed.




Figure 86: Safe Homing

### Information:

The safe homing function is a pre-requisite for the safety functions SLP and SMP and for using the safe position. The status `S_SafePositionValid` will remain set to `SAFEFALSE` until safe homing has been performed!

### Danger!

If an error occurs during homing procedure, then the module changes to the error state "Functional Fail Safe", which must be confirmed.

The function block output `S_NotErrFUNC` is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

### Danger!

If the safe position is used in SafeDESIGNER, then the Position Valid output of the `SafeMC_Position` function block must also always be evaluated.

This will be reset immediately only with referenced axes `SAFETRUE`, and the first time an encoder error occurs (`SAFEFALSE`).

This enables the safety application to detect any encoder error, even if only brief.

If a machine reference is not required for usage, then the axis can be referenced using the Direct mode.

### 3.3.14.3 Direct mode

#### 3.3.14.3.1 Parameters

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Correction	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Reference pulse	Used / Not Used	Selection of whether or not to use a reference pulse for homing	Not used
<b>General settings</b>			
Safe Maximum Position	Used / Not used	Activates the SMP safety function by configuration	Not used
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
<b>Safety Standstill and Direction Tolerances</b>			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0

Table 199: Parameters for the "safe homing" safety function - Direct mode

### 3.3.14.3.2 Behavior

Direct mode is used if the current position of the axis is known and has only to be applied to the SafeMC module.

The following scenario is an example of how this mode can be used:

- The ACOPOSmulti SafeMC module is first homed for the standard application.
- The axis is then moved to a defined position by the ACOPOSmulti SafeMC module.
- The user acknowledges that the correct position has been reached by pressing a safe button → This triggers a safe homing procedure internally in Direct mode.

When referencing in Direct mode, the actual position of the axis is set to the value specified in the parameter "*Home position or home offset*" immediately after the homing command (positive edge on the input S\_RequestHoming).

The input S\_ReferenceSwitch will not be evaluated.

#### Information:

**The axis must be at standstill when the homing request is made.**

**The values configured under "Safety Standstill and Direction Tolerances" are monitored to this regard. If the standstill tolerances are violated, then the module changes to the error state "Functional Fail Safe", which must be confirmed. The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!**

#### Information:

**A reference pulse is not permitted to be used in Direct mode!**

**If a reference pulse is enabled ("*Reference pulse*" = Used), then the system will enter Fail Safe state when checking the configuration during startup.**

**The Fail Safe state can only be exited by powering off/on and changing the safe application!**

#### Information:

**If Safe Maximum Position has been enabled in the configuration (Parameter "*Safe Maximum Position*" = Used), then the value configured on the parameter "*Home position or home offset*" must be within the permissible SMP window (parameters "*Safe Lower Position Limit for SMP (units)*" and "*Safe Upper Position Limit for SMP (units)*").**

**If this is not the case, then the system will enter Fail Safe state when checking the configuration during startup.**

**The Fail Safe state can only be exited by powering off/on and changing the safe application!**

#### Danger!

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!**

**If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!**

### 3.3.14.4 Reference Switch mode

#### 3.3.14.4.1 Parameters

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time (µs)	[µs]	Monitoring time for the homing procedure	0
Mode	Direct / Reference Switch / Home Offset / Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive / Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive

Table 200: Parameters for the "safe homing" safety function - Reference Switch mode

Parameter	Unit	Description	Default value
Trigger direction	Positive / Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used / Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 200: Parameters for the "safe homing" safety function - Reference Switch mode

### 3.3.14.4.2 Behavior

The mode "Reference Switch" correlates with the referencing modes "Switch Gate", "Abs Switch" and "Limit Switch" on the ACOPOSMulti.

#### Information:

If the reference switch input "**S\_ReferenceSwitch**" is not wired on the function block, then the SafeMC module will change to Fail Safe state.

The "Fail Safe" state can only be exited by powering off/on and changing the safe application!

Depending on the configuration, the ACOPOSMulti will pass over the reference switch / limit switch several times.

#### Danger!

The reference switch / limit switch is part of the safety function and must therefore be accounted for in the risk analysis.

Use a debounced position switch suitable for safety applications!

The machine manufacturer is responsible for implementing a suitable switch!

After the homing command (= positive edge on the input **S\_RequestHoming**) the SafeMC module uses the home switch edge that matches the "*Edge of reference switch*" and "*Trigger direction*" settings as long as it is passed below the "*Max Trigger Speed*".

The home switch edge will be ignored if the reference switch is passed over at a speed higher than the "*Max Trigger Speed*".

Configuration	Reference switch evaluation
Edge of reference switch = Negative Trigger direction = Negative	
Edge of reference switch = Positive Trigger direction = Negative	
Edge of reference switch = Negative Trigger direction = Positive	
Edge of reference switch = Positive Trigger direction = Positive	

Table 201: Selecting the home switch edge

#### Information:


After the homing command is made, the homing procedure must be completed within the configured time "*Homing Monitoring Time (μs)*". Otherwise, the module will change to the acknowledgeable error state "Functional Fail Safe".

The function block output **S\_NotErrFUNC** is reset and the drive becomes torque-free and force-free, causing it to spin out!


An error will cause a synchronous axis to no longer be synchronous.

**Danger!**

The standstill "Position Tolerance" must be smaller than or equal to half the pulse width of the reference switch being used!

**Danger!**

The filter ( $T_{on}$ ,  $T_{off}$ ) required when reading the reference switch edges in SafeDESIGNER must be determined according to the control behavior during standstill.



Error in the referenced absolute position due to the delay caused by the filter times must be taken into consideration!

**ACOPOSMulti with SafeMC SinCos**

The reference position is assumed immediately after successful evaluation of the reference edge.

**ACOPOSMulti with SafeMC EnDat 2.2****Reference pulse = Not Used**

If the reference pulse is disabled, then the reference position will be assumed immediately when the home switch edge is successfully processed.

**Reference pulse = Used**

This mode is recommended when the positions of ACOPOSMulti and the SafeMC module must match exactly. Processing of the reference pulse compensates for the speed-dependent position difference by processing the two values at different times.

**Information:**

If "Reference pulse" is set to "Used", then a rotary EnDat 2.2 Functional Safety encoder must be used. The reference pulse is generated at every single turn overflow.

When "Reference pulse" = Used, the reference position will not be entered under the first valid reference pulse after the home switch edge has been reached.

After the valid home switch edge has been processed, the processing of the reference pulse will be suppressed for the distance configured in the parameter "Blocking distance (% encoder reference system)". The next reference pulse is only processed once this distance has been passed, at which point the home position is applied.

A valid homing procedure requires that the direction of movement does not change between when the home switch edge is passed and the valid reference pulse and that the speed limit "Max Trigger Speed" is not exceeded.

**Information:**

If the direction of movement changes while searching for the reference pulse, then the reference switch must be passed over again.

**Information:**

If the speed limit "*Max Trigger Speed*" is exceeded during the reference pulse search, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

**Danger!**

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

**3.3.14.5 Home Offset / Home Offset with Correction mode (only for ACOPOSMulti with SafeMC EnDat 2.2)****Information:**

The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!

**3.3.14.5.1 Parameter - Home Offset / Home Offset with Correction mode**

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Mode	Direct/ Reference Switch/ <i>Home Offset/ Home Offset with Cor- rection</i>	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSMulti with SafeMC EnDat 2.2!</i>	Direct
<b>General settings</b>			
Safe Maximum Position	Used/Unused	Activates the SMP safety function by configuration	Unused
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0

Table 202: Parameters for the safety function "safe homing" - Modes: Home Offset / Home Offset with Correction

**3.3.14.5.2 Behavior - Home Offset / Home Offset with Correction mode**

If an absolute encoder is being used, then the machine reference can be established via an offset to the encoder position.

A homing procedure is not necessary.

The homing command *Home Offset* uses this offset directly, while *Home Offset with Correction* mode accounts for any encoder overrun that might occur in the permissible range of movement.

The offset is configured in SafeDESIGNER with the *Home position* or *Home offset* parameter.

The input *S\_ReferenceSwitch* will not be evaluated.

## Danger!

This homing mode can only be used for absolute encoders (single-turn encoder / multi-turn encoder / linear encoder). Using another encoder for this mode will cause the SafeMC module to change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

## Information:

If the security functions SMP and/or SLP are used, then their position window must be smaller than the safety-related encoder counting range.

If one of the two position windows is configured larger than the encoder counting range, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

For more information, see the section Safe encoder counting range (only applies to the user documentation MAACPMSAFEMC-ENG (ACOPOSmulti with SafeMC EnDat 2.2)).

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

### Home Offset

This mode is well suited for absolute encoders which provide unique position values over the entire movement range. Using the homing offset, the encoder position over the entire movement range can be represented as the correct machine position.




Figure 87: Home Offset referencing method

The Home Offset can be determined by carrying out a calibration move (e.g. Homing with Reference Switch).

### Home Offset with Correction

In this homing mode, after setting the Home Offset a check is made to see if the machine position is within the movement range defined by the SMP position limits. If this is not the case, the Home Offset in the safety-related encoder counting range is corrected:

## Information:

The SMP safety function must be activated when using this mode. If SMP is deactivated, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

Counting range correction is needed when using absolute encoders if the encoder provides a unique position value over the entire movement range but an encoder overflow occurs within the movement range. Here, the Home Offset depends on if the machine was calibrated at a position to the right or the left of the overflow point.




Figure 88: Referencing method - Home Offset with Correction

To the right of the overflow point, Home Offset 1 which is valid for the left side would lead to an incorrect position value. To the left of the overflow point, Home Offset 2 which is valid for the right side would lead to an incorrect position value. This can be compensated for with counting range correction.

### Information:

Counting range correction only functions if the encoder range is larger than or equal to the movement range! Keep in mind that only the safety-related part of the encoder counting range is used.

## 3.3.15 Safely Limited Position, SLP

### 3.3.15.1 Parameters

Parameter	Unit	Description	Default value
<b>Safety deceleration ramp</b>			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
<b>Safety Position Limits</b>			
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0
<b>Safety Standstill and Direction Tolerances</b>			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
<b>Safety Additional Parameters</b>			
Delay time to start SLP (us)	[μs]	Delay time between request of SLP and start of monitoring	0

Table 203: SLP safety function parameters

### 3.3.15.2 Behavior

The purpose of the SLP safety function is to monitor a specified position window.

The "Safe Lower Position Limit for SLP" and "Safe Upper Position Limit for SLP" parameters can be used to configure the limits of the monitoring range.

The SLP safety function is requested when the input *S\_RequestSLP* is set to SAFEFALSE.

Monitoring of the position window will begin after the amount of time configured in "Delay time to start SLP" has expired.

The "*S\_SafetyActiveSLP*" status bit will be set to SAFETRUE if no errors occur while monitoring is active.






Figure 89: Safety Limited Position, SLP

### Information:

The axis must be homed successfully before using the Safety Limited Position function.

If a homing procedure is not completed successfully or if the "S\_SafePositionValid" status changes, then the request for the SLP safety function causes the module to change to the acknowledgeable *functional fail-safe* error state.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous.

The "S\_NotErrFUNC" output on the function block is reset.

### Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!

If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

To minimize the distance remaining when the position window is exceeded, a position-dependent speed limit is monitored in addition to the position.

### Danger!

In the worst case, the monitored position window can be passed while the axis is spinning out. This must be taken into account when defining the limits!

When the position limit is approached, the monitored speed limit is calculated in such a way that the drive will come to a full stop before the positioning limit is reached using the configured deceleration ramp parameter.

The permitted speed in the direction of the upper position limit is

$$v_{LIM,POS} = \sqrt{2(LIM_{SLP,POS} - s) * a}$$

and in the direction of the lower position limit is

$$v_{LIM,NEG} = \sqrt{2(s - LIM_{SLP,NEG}) * a}$$

The position-dependent speed limit is illustrated in the following figure.




Figure 90: Position-dependent speed window

## Danger!

If the position window or the position-dependent speed limit is violated while the SLP safety function is activated or if the *S\_SafePositionValid* status is lost, then the module changes to the acknowledgeable error state "Functional Fail Safe".

The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

## Danger!

If the safety function SLP is used in the safe application, then the activation and deactivation of this function must be tested when commissioning the machine!

The test should contain at least one violation of each position limit. The error response must be tested accordingly!

### 3.3.16 Safe Maximum Position, SMP

#### 3.3.16.1 Parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Safe Maximum Position	Used / Not used	Activates the SMP safety function by configuration	Not used
Safety Position Limits			
Safe Lower Position Limit for SMP (units)	[units]	Lower position limit for the machine's full range of movement	0
Safe Upper Position Limit for SMP (units)	[units]	Upper position limit for the machine's full range of movement	0
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 204: SMP safety function parameters

#### 3.3.16.2 Behavior

The difference between SMP and SLP is that SMP cannot be actively requested. It is either enabled or disabled by the configuration.

When enabled, the current position is constantly monitored against a defined position window.

The "Safe Lower Position Limit for SMP" and "Safe Upper Position Limit for SMP" parameters can be used to configure the lower and upper position limits of the monitoring range.

The SMP safety function only works with homed axes since it requires a safe absolute position.

If SMP is configured, a 15-minute timeout begins once pulse disabling is activated, within which the homing procedure must take place.

Once homing is complete and if there were no errors during monitoring, the `S_SafetyActiveSMP` status bit is set to SAFETRUE.

### Information:

**The axis must be homed successfully before using the function Safe Maximum Position.**

**If a homing procedure is not successful within 15 min after pulse disabling is activated or the `S_SafePositionValid` status is lost on an axis that has already been homed or if the position window or the position-dependent speed limit is violated, then the module changes to the acknowledgeable error state "Functional Fail Safe".**

**The function block output `S_NotErrFUNC` is reset and the drive becomes torque-free and force-free, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous.**

As with the SLP safety function, the Safe Maximum Position function also monitors a position-dependent speed limit in addition to the position in order to minimize the remaining distance if the position window is exceeded.

For more information, please refer to the description of the safety function "Safely Limited Position, SLP".

### Danger!

**In the worst case, the monitored position window can be passed while the axis is spinning out. This must be taken into account when defining the limits!**

**If the position window has been exceeded, then movement is only possible in the direction of the position window after the Functional Fail Safe state has been acknowledged.**

**An attempt to move beyond the standstill tolerance in the unsafe direction (i.e. away from the position window) will cause the module to enter the acknowledgeable error state "Functional Fail Safe".**

### Danger!

**If the safety function SMP is used in the safe application, then it must be tested when commissioning the machine! The test should contain at least one violation of each position limit. The error response must be tested accordingly!**

### Danger!

**This can cause dangerous movement in situations involving external forces (e.g. hanging loads)!**

**If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!**

### 3.4 Safe encoder connection monitoring

#### 3.4.1 Encoder mounting with proof of fatigue strength

Proof of the fatigue strength of the encoder's mechanical mounting must be provided in order to prevent encoder slippage or shaft breakage.

This proof and the respective installation guidelines can be requested from the manufacturer of either the measuring device or the machine.

#### **Danger!**

To ensure safe operation up to and including the motor shaft, any errors on the connection between the motor shaft and encoder must be identified and prevented.

#### **Danger!**

The proof of fatigue strength of the encoder's mechanical mounting must be dimensioned to the maximum rotor acceleration. This acceleration value must not be exceeded in the worst case. The maximum acceleration is monitored on the SafeMC module and can be configured using the parameter "Maximum acceleration".

#### **Danger!**

Mechanical tolerances in the encoder mounting must be accounted for when calculating the remnant movement. This remnant movement must be accounted for in the safety functions.

#### 3.4.2 Encoder mounting without proof of fatigue strength - Safe lag error monitoring

In some applications, the proof of fatigue strength is not required for the encoder's mechanical mounting when safe "Encoder Monitoring" is enabled in the SafeMC module.

The following safety-related restrictions must be taken into consideration!

#### **Danger!**

Only safety functions for which a safe absolute position is not being monitored can be used (STO, SBC, SOS, SS1, SS2, SLS, SMS, SLI, SDI, SBT (only available for ACOPOSmulti with SafeMC SinCos), SafeSPEED).

#### **Danger!**

The application must meet the following requirements for safety-oriented monitoring of the encoder-motor connection:

- Encoder connection monitoring can only be used for encoders that are integrated in a position control.
- Encoder connection monitoring can only be used for drive systems with synchronous motors.
- The encoder must be protected against shearing in standstill (e.g. with encasement in the motor housing)!
- Monitoring for position lag errors, speed errors and set position change (Alive Testing) must be enabled in the safe application and sufficiently strict limits must be monitored!
- The safety functions SafePOSITION, SLP and/or SMP must not be used!
- Safe monitoring can only be guaranteed when closed loop control is enabled.

#### **Danger!**

- An electrical offset of  $<90^\circ$  will not be detected sufficiently.
- There is no way to monitor the encoder connection if the set value remains constant.
- An encoder connection error or an error in the encoder evaluation is always assumed as the cause for the lag error.
- The error reaction in the standard application to a position lag error or speed error is disabled by the SafeMC module (overridden). When lag errors occur, only the error responses STO or STO1 are possible with induction stop.

## Danger!

Note that a brief forward movement may occur in the event of an error. The maximum angle of rotation of the motor shaft  $\varphi$  during this forward movement depends on the motor being used.

For permanently excited synchronous motors,  $\varphi = 360^\circ/2p$  (for B&R standard motors,  $p=3$  so the angle is  $60^\circ$ ). For three-phase induction motors, there is a relatively small angle of rotation (between  $5^\circ$  and  $15^\circ$ ).

The maximum speed of the forward movement can be calculated as follows:

$$n_{Jolt} = \frac{1}{2\pi} \sqrt{\frac{6a_{max}}{p_z}} \left[ \frac{U}{s} \right]$$

with the maximum acceleration  $a_{max} = \frac{M_{max}}{J} \left[ \frac{rad}{s^2} \right]$  and the number of motor pole pairs  $p_z$

## Danger!


When viewing the worst-case scenario for a safety function, the highest value of the maximum speed of the forward movement  $n_{Jolt}$  and the speed must be used as maximum speed due to the maximum error response time  $n_{T_{worstcase}}$

$$n_{max} = \max(n_{Jolt}, n_{T_{worstcase}}) = \max\left(\frac{1}{2\pi} \sqrt{\frac{6a_{max}}{p_z}}, \frac{T_{worstcase}}{2\pi} \cdot a_{max}\right)$$

with the maximum error response time  $T_{worstcase} = 7.2[ms]$

The maximum speed  $n_{max}$  resulting from this must be considered together with the speed when the safety function  $n_{LIM}$  is violated in order to determine the maximum possible speed  $n_{worstcase}$  at the time of spin-out!

$$n_{worstcase} = n_{LIM} + n_{max}$$



## Information:

In order to check the plausibility of the set value after each power-on, the axis must be moved by at least twice the configured lag error limit before the first request of a safety function, which requires a safe encoder evaluation, or at least within 15min.

If this is not done, then the module changes to the error state "Functional Fail Safe", which must be confirmed. The function block output  $S\_NotErrFUNC$  is reset and the drive becomes torque-free and force-free, causing it to spin out!

An error will cause a synchronous axis to no longer be synchronous.

## Danger!

This can cause dangerous movement in situations involving external forces (e.g. hanging loads)! If this poses a safety risk, then the user must implement the necessary equipment to eliminate the risk (e.g. mechanical brakes)! This equipment must correspond to the required safety level!

## Information:

A 24h timeout begins after successfully checking the plausibility of the set value.

The timeout is reset any time the set position changes by more than twice the position lag error tolerance.

If the set position does not change during 24h of continuous controller operation, then the module changes to the acknowledgeable error state "Functional Fail Safe". The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out! An error will cause a synchronous axis to no longer be synchronous.

The following parameters are relevant for safe monitoring of the encoder / motor shaft connection (Encoder Monitoring):

Parameter	Unit	Description	Default value
Encoder Unit System			
Maximum acceleration [rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	[rad/s <sup>2</sup> or mm/s <sup>2</sup> ]	Maximum permissible encoder acceleration	100000
Encoder Monitoring			
Encoder Position Monitoring	Activated/ Deactivated	Activates/deactivates the monitoring of the position lag error generated on the SafeMC module.	Activated
Encoder Speed Monitoring	Activated/ Deactivated	Activates/deactivates the monitoring of the speed error generated on the SafeMC module.	Activated
Set position alive testing	Activated/ Deactivated	Activates/deactivates the monitor that detects whether the set position generated on the ACOPOSmulti is frozen.	Activated
Encoder Monitoring Tolerances			
Encoder Monitoring Position Tolerance	[units]	Position lag error tolerance for shaft breakage monitoring	0
Encoder Monitoring Speed Tolerance	[units/s]	Speed error tolerance for encoder monitoring	0

Table 205: Encoder Monitoring safety function parameters

## Danger!

The machine manufacturer is responsible for deciding whether or not the application is suited for safe encoder connection monitoring if there is no mechanical mechanism for detecting encoder shaft breakage.

The machine manufacturer is responsible for ensuring that the safe encoder monitoring has been configured correctly!

## Danger!

Encoder connection monitoring can only be used in a safety-related capacity if the aforementioned requirements for the application have been fulfilled!

### 3.4.2.1 Activation of monitoring

The following parameters must be set to "Activated" in SafeDESIGNER in order to enable safe encoder connection monitoring:

- *Encoder Position Monitoring* = Activated
- *Encoder Speed Monitoring* = Activated
- *Set position alive testing* = Activated

## Danger!

In order to ensure safety-related monitoring of the encoder/motor connection, all three parameters "*Encoder Position Monitoring*", "*Encoder Speed Monitoring*" and "*Set position alive testing*" must be set to "Activated"!

If this is not the case, then the monitoring system cannot be used for safety purposes and a mechanical solution for detecting errors must be implemented!

### 3.4.2.2 Configuration rule for position lag error limit

The position lag error limit must be set large enough to ensure availability. This can be done by first measuring the position lag error under the highest influence of disturbance variables and at maximum acceleration and then setting the position lag error limit accordingly higher.

#### **Danger!**

**The position lag error limit cannot be higher than half of one pole length!**

**When the safety function is enabled, the size of the position lag error limit value  $ds_{lim}$  affects how long it will take to look for errors and therefore also the error response time and estimation of the remaining distance.**

**This must be accounted for by the machine manufacturer in the risk analysis!**

#### **Information:**

**Due to rounding errors, a reserve of 1 unit should be accounted for with the parameter "Encoder Monitoring Position Tolerance".**

### 3.4.2.3 Configuration rule for speed error limit

The speed error limit must be set large enough to ensure availability.

This can be done by first measuring the speed error under the highest influence of disturbance variables and set values (e.g. at maximum acceleration) and then setting the speed error limit accordingly higher.

#### **Danger!**

**When the safety function is enabled, the size of the speed error limit value  $ds_{lim}$  affects how long it will take to look for errors and therefore also the error response time and estimation of the remaining distance.**

**This must be accounted for by the machine manufacturer in the risk analysis!**

#### **Information:**

**Due to rounding errors, a reserve of 1 unit/s should be accounted for with the parameter "Encoder Monitoring Speed Tolerance".**

## 3.5 Error prevention

### **Danger!**

#### **Validation**

**Each of the safety functions that are used must be validated separately.**

**In addition, the entire safety application, including interactions between individual functions, must also be tested.**

### 3.5.1 Exceeding monitored limits

The SafeMC module monitors limits that can be configured. The drive itself, however, is controlled by the functional application on the standard PLC.

The following points must be considered in order to prevent the violation of a monitored limit:

- Movement of the drive must be adapted to the requested safety function and initiated on time.
- The monitored limits must match the calculated limits and the movement limitations. Make sure that the different configurations of the unit system match in the safe application and in the functional application!

## **Danger!**

**Any violation of a monitored limit will cause the module to change to the error state "Functional Fail Safe", which must be confirmed.**

**The function block output *S\_NotErrFUNC* is reset and the drive becomes torque-free and force-free, causing it to spin out!**

**Depending on the configuration, the motor holding brake will also be switched to 0 V.**

**An error will cause a synchronous axis to no longer be synchronous.**

**Check the Safety Logger in Automation Studio for detailed information about monitoring!**

### **3.5.2 Plausibility errors**

Plausibility errors (limit values, data types, variables/constants) that occur when the function block is used are detected and reported by the function block or compiler.

This is not always possible in the event of connection errors, however.

The function block cannot check whether:

- Actual parameter values or constants within the valid range are in fact incorrect for the safety function being executed. A static TRUE signal on the Reset input is detected by the function block and indicated as an error, however.
- Actual parameters have been connected incorrectly.
- I/O formal parameters were not connected inadvertently.

For this reason:

## **Danger!**

**You are responsible for the connection of the safety function (sub-application).**

**Check the connections when validating the sub-application.**

### **3.5.3 Sporadically changing/toggling signal levels or impermissible signals**

Sporadically changing or toggling signal levels on

- Edge-controlled formal input parameters cause the function block to interpret the signal as an edge, which results in an unintended action being triggered in the function block if error prevention measures are not in place.
- Without implementing error prevention, state-driven input formal parameters cause this signal to unexpectedly trigger a corresponding action.

Impermissible signals on input formal parameters can lead to an unexpected initial movement, non-execution of a requested action or an error message.

Possible causes of these signals:

- Programming error in the application program (user error)
- Cross fault, short circuit or cable break (user error, wiring error)
- Error in the standard controller

To prevent this, the following measures can be taken depending on the safety function:

- Use of safe device signals
- Implementing additional measures for preventing a hazard if using a signal from a standard controller (e.g. executing an additional function start after a safety function has been triggered or an error has been corrected)
- Line control in the safe control system
- Suitable cabling when using non-safe signals from the standard controller
- Verifying the source code in the application program and final validation of the safety functionality

The measures listed above can also be taken in combination to safely prevent errors.



It is important to note that a signal change detected on a status-controlled formal parameter will be output as a diagnostic code.

### 3.5.4 Simultaneous edge change

To reduce the chances of an unexpected startup, make sure that the formal parameter Reset is only connected to the signal of a manual reset. This signal is based on your risk analysis.

### 3.5.5 Machine/system startup without performing functional testing of safety equipment

Faulty safety equipment can only be detected following functional testing. Functional testing is not supported by this function block. If additional measures are not implemented, faulty safety equipment can result in errors.

## **Danger!**

**The user is responsible for performing safeguard function tests.**

**For this reason, it is important for the user to have the safety equipment validated!**

Possible causes of faulty safety equipment:

- Faulty devices (hardware error)
- Cross fault, short circuit, and cable break (user error, wiring error)

### 3.6 Input parameters

#### **Information:**

Detailed information about the individual safety functions can be found in the section "Integrated safety functions"!

#### 3.6.1 General information about the "S\_Request" inputs

The "S\_Request" inputs are used to request the respective safety functions.

If a safety function should not be used in the safe application, then the respective input should not be connected.

#### **Information:**

If a safety function should not be used in the application, then the respective input variables should remain open.

#### **Danger!**

The safety functions that are used must be tested.

A function is considered to be used if the respective input variable is connected!

#### **Information:**

At least the activate input and the S\_AxisID must be connected. Otherwise, the SafeMC module will not be operated by the SafeLOGIC. As a result, the pulse disabling and the motor holding brake output will be permanently set to 0 V, which means that the controller cannot be turned on.

### 3.6.2 Activate

#### General function

- Function block activation

#### Data type

- BOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to enable the function block.

- If you are activating or deactivating safe devices, link Activate to a variable that indicates the status (de-activated or activated) of the corresponding safe devices. This ensures that the function block does not output a triggered safety function as diagnostic information when a device is disabled.
- In addition, Activate can be connected to a constant (TRUE) in order to activate the function block.

#### TRUE

The function block is enabled.

#### FALSE

The function block is disabled.

All binary output parameters are set to FALSE.

Sets the DiagCode diagnostic parameter to WORD#16#0000.

If you want to control function block diagnostics as needed in your diagnostic concept whenever error messages from safe devices and/or deactivated safe devices occur, connect Activate to a signal that indicates the status of the safe devices that utilize the safety function supported by the function block. Create this signal only for safe devices whose I/O signals are connected to the function block via actual parameters. This prevents triggered safety functions from being reported by deactivated safe devices. This measure is only used to control diagnostics in the event of disabled safe devices.

### 3.6.3 S\_RequestSTO

#### General function

- Selects/deselects the safety function “Safe Torque Off”, STO

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function STO.

#### TRUE

Safety function is deselected; the safe pulse disabling is not active!

#### FALSE

Safety function is selected; the safe pulse disabling is active! Torque and power are switched off on the drive.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

- None

### 3.6.4 S\_RequestSTO1

#### General function

- Selects / deselects the safety function "Safe Torque Off, One Channel", STO1

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function STO1.

#### TRUE

Safety function is deselected; the safe pulse disabling is not active!

#### FALSE

Safety function is selected; depending on the configuration, the HighSide or LowSide of the safe pulse disabling is active! Torque and power are switched off on the drive.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
General settings			
Channel selection for One Channel STO (STO1)	HighSide/ LowSide	Selection of HighSide or LowSide IGBT in the One Channel STO function	HighSide

Table 206: STO1 safety function parameters

### 3.6.5 S\_RequestSBC

#### General function

- Selects/deselects the safety function “Safe Brake Control”, SBC

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SBC.

#### TRUE

Safety function is deselected. The motor holding brake is active and can be used by the standard application.

#### FALSE

Safety function is selected. The motor holding brake is switched to 0 V!

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Additional Parameters			
Delay time to start SBC (us)	[µs]	Delay time between the SBC request and activation of the safety function	0

Table 207: SBC safety function parameters

### 3.6.6 S\_RequestSOS

#### General function

- Selects/deselects the safety function “Safe Operating Stop”, SOS

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SOS.

#### TRUE

Safety function is deselected. Standstill tolerances are not being monitored.

#### FALSE

Safety function is selected. Standstill tolerances are being monitored.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0

Table 208: SOS safety function parameters

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

#### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 3.6.7 S\_RequestSS1

#### General function

- Selects/deselects the safety function “Safe Stop 1”, SS1

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SS1.

#### TRUE

Safety function is deselected; Safe Stop 1 is not active!

#### FALSE

Safety function is selected. Safe pulse disabling is activated after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS1	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS1 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS1 (us)	[μs]	Deceleration monitoring time for SS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 209: SS1 safety function parameters

#### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

#### Information:

**In order to use the function without safe encoder evaluation, "*Ramp monitoring for SS1*" and "*Early Limit Monitoring*" must both be disabled.**



## Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 3.6.8 S\_RequestSS2

#### General function

- Selects/deselects the safety function “Safe Stop 2”, SS2

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SS2.

#### TRUE

Safety function is deselected; Safe Stop 2 is not active!

#### FALSE

Safety function is selected. Standstill monitoring is activated after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SS2	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SS2 function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SS2 (us)	[μs]	Deceleration monitoring time for SS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 210: SS2 safety function parameters

#### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

#### Information:

**If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.**

**The following application rule must be observed:**

$$LIM_{SOS} \leq LIM_{SLS4} \leq LIM_{SLS3} \leq LIM_{SLS2} \leq LIM_{SLS1} \leq LIM_{SMS} < NormSpeed$$

**Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!**

### 3.6.9 S\_RequestSLS1

#### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 1

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLS1.

#### TRUE

Safety function is deselected; SLS1 is not active!

#### FALSE

Safety function is selected. Speed Limit 1 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 1 for SLS	[units/s]	Speed Limit 1 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS1 (us)	[μs]	Deceleration monitoring time for SLS1	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 211: SLS1 safety function parameters

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

#### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 3.6.10 S\_RequestSLS2

#### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 2

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLS2.

#### TRUE

Safety function is deselected; SLS2 is not active!

#### FALSE

Safety function is selected. Speed Limit 2 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 2 for SLS	[units/s]	Speed Limit 2 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS2 (us)	[μs]	Deceleration monitoring time for SLS2	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 212: SLS2 safety function parameters

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

#### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 3.6.11 S\_RequestSLS3

#### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 3

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLS3.

#### TRUE

Safety function is deselected; SLS3 is not active!

#### FALSE

Safety function is selected. Speed Limit 3 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 3 for SLS	[units/s]	Speed Limit 3 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS3 (us)	[μs]	Deceleration monitoring time for SLS3	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[μs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[μs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 213: SLS3 safety function parameters

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

#### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 3.6.12 S\_RequestSLS4

#### General function

- Selects / deselects the safety function "Safely Limited Speed", Speed Limit 4

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLS4.

#### TRUE

Safety function is deselected; SLS4 is not active!

#### FALSE

Safety function is selected. Speed Limit 4 is monitored after the end of ramp monitoring.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s²]	Slope of the deceleration ramp to be monitored	1073676289
General settings			
Ramp monitoring for SLS	Activated/ Deactivated	Activates ramp monitoring (in addition to the time) when the SLS function is requested	Activated
Early Limit Monitoring	Activated/ Deactivated	Prematurely terminates monitoring of the deceleration ramp if the value falls below the lower limit for a defined amount of time	Deactivated
Speed Limits			
Safe Speed-limit 4 for SLS	[units/s]	Speed Limit 4 for SLS	0
Safety Ramp Monitoring Times			
Ramp Monitoring Time for SLS4 (us)	[µs]	Deceleration monitoring time for SLS4	0
Safety Additional Parameters			
Delay time to start ramp monitoring (us)	[µs]	Delay time between request of ramp monitoring and start of monitoring	0
Early Limit Monitoring time (us)	[µs]	Time during which the speed must be below the target speed limit in order to prematurely end the deceleration ramp and to assume the safety function's end state	0

Table 214: SLS4 safety function parameters

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

#### Information:

If several safety functions are active at the same time, then the lowest speed limit is always the value being monitored.

The following application rule must be observed:

$$\text{LIM}_{\text{SOS}} \leq \text{LIM}_{\text{SLS4}} \leq \text{LIM}_{\text{SLS3}} \leq \text{LIM}_{\text{SLS2}} \leq \text{LIM}_{\text{SLS1}} \leq \text{LIM}_{\text{SMS}} < \text{NormSpeed}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

### 3.6.13 S\_RequestSLI

#### General function

- Selects / deselects the safety function "Safely Limited Increment", SLI

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLI.

#### TRUE

Safety function is deselected; SLI is not active!

#### FALSE

Safety function is selected. A safe range of increments is monitored.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Safely Limited Increments			
Safe increments	[units]	Maximum moveable increments when SLI is active	0
SLI OFF Delay	[µs]	Switch off delay of SLI	0

Table 215: SLI safety function parameters

#### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

### 3.6.14 S\_RequestSDIpos

#### General function

- Selects / deselects the safety function "Safe Direction", movement is allowed in the positive direction

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SDI, movement is allowed in the positive direction of movement.

#### TRUE

Safety function is deselected; SDI is not active!

#### FALSE

The direction of movement is monitored after the delay time has expired. Movement is allowed in the positive direction.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[µs]	Delay time between the SDI request and activation of the safety function	0

Table 216: SDI safety function parameters

#### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**



### 3.6.15 S\_RequestSDIneg

#### General function

- Selects / deselects the safety function "Safe Direction", movement is allowed in the negative direction

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SDI, movement is allowed in the negative direction of movement.

#### TRUE

Safety function is deselected; SDI is not active!

#### FALSE

The direction of movement is monitored after the delay time has expired. Movement is allowed in the negative direction.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety Standstill and Direction Tolerances			
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SDI (us)	[µs]	Delay time between the SDI request and activation of the safety function	0

Table 217: SDI safety function parameters

#### Information:

**The safety function requires safe evaluation of the position or speed.**

**If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!**

### 3.6.16 S\_RequestSLP

#### General function

- Selects / deselects the safety function "Safely Limited Position", SLP.

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used to select or deselect the safety function SLP.

#### TRUE

Safety function is deselected; SLP is not active!

#### FALSE

The configured position window will be safety-monitored after "*Delay time to start SLP (us)*".

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
Safety deceleration ramp			
Deceleration ramp	[units/s <sup>2</sup> ]	Slope of the deceleration ramp to be monitored	1073676289
Safety Position Limits			
Safe Lower Position Limit for SLP (units)	[units]	Lower position limit for the monitoring range	0
Safe Upper Position Limit for SLP (units)	[units]	Upper position limit for the monitoring range	0
Safety Standstill and Direction Tolerances			
Speed Tolerance	[units/s]	Speed tolerance for standstill monitoring	0
Position Tolerance	[units]	Position tolerance for standstill and direction monitoring	0
Safety Additional Parameters			
Delay time to start SLP (us)	[μs]	Delay time between request of SLP and start of monitoring	0

Table 218: SLP safety function parameters

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

#### Information:

The following application rule must be observed:

$$LIM_{SMP,NEG} \leq LIM_{SLP,NEG} \leq LIM_{SLP,POS} \leq LIM_{SMP,POS}$$

Failure to follow the application rule will cause the SafeMC module to enter the Fail Safe state. If this occurs, it can only be made operational again by changing the safe application followed by a Power OFF / Power ON!

## Information:

Safe homing of the axis must be completed prior to using this safety function.

If a homing procedure is not completed successfully or if the "S\_SafePositionValid" status changes, then the request for the SLP safety function causes the module to change to the acknowledgeable *functional fail-safe* error state.

Torque and power to the drive are switched off, causing the drive to spin out! An error will cause a synchronous axis to no longer be synchronous. The output of the *S\_NotErrFUNC* function block is reset.

### 3.6.17 S\_RequestHoming

#### General function

- Selects / deselects the safety function "safe homing"

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter is used for starting a safe homing procedure. A positive edge on the input starts the safety function.

#### Positive edge: Changes FALSE to TRUE

Starts safe homing.

#### Negative edge: Changes TRUE to FALSE

If still active, the homing procedure will be terminated by the negative edge. This state transition has no effect if the homing procedure has already been completed.

#### Not connected

The safety function is disabled.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
<b>Homing</b>			
Home Position or home Offset (units)	[units]	Home position or home offset	0
Max. trigger speed (units/s)	[units/s]	Maximum permissible speed for evaluating the reference switch / reference pulse.	0
Homing Monitoring Time (µs)	[µs]	Monitoring time for the homing procedure	0
Mode	Direct/ Reference Switch/ Home Offset/ Home Offset with Cor- rection	Selection of homing mode  <i>The modes "Home Offset" and "Home Offset with Correction" are only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Direct
Edge of reference switch	Positive/ Negative	Selection of switching edge for reference switch The switch edge for the reference switch input is positive if the logical state of the reference switch changes from SAFEFALSE to SAFETRUE in the positive direction of movement.	Positive
Trigger direction	Positive/ Negative	Selection of the trigger direction If the homing procedure requires a movement, then this parameter specifies the direction for evaluating the reference switch / reference pulse.	Positive
Reference pulse	Used/ Not used	Selection of whether or not to use a reference pulse for homing  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	Not used
Blocking distance (% encoder reference system)	%	Distance within which evaluation of the reference pulse will be suppressed. It is calculated starting at the configured reference switch edge and indicated as a % of the encoder reference system. A single rotation is used as the encoder reference system for rotary encoders.  <i>The parameter is only available for ACOPOSmulti with SafeMC EnDat 2.2!</i>	0

Table 219: Parameters for the "safe homing" safety function

#### Information:

The safety function requires safe evaluation of the position or speed.

If an error is detected in the evaluation, then the SafeMC module changes to the acknowledgeable state "Functional Fail Safe"!

**Information:**

The safe homing function is a pre-requisite for the safety functions SLP and SMP and for using the safe position.

The status *S\_SafePositionValid* will remain set to **SAFEFALSE** until safe homing has been performed!

### 3.6.18 S\_ReferenceSwitch

#### General function

- Reference switch input for the "safe homing" safety function

#### Data type

- SAFEBOOL

#### Connection

- Constant or variable

#### Description of function

This input parameter serves as reference switch input for the "safe homing" safety function and is only evaluated in the "Reference Switch" homing mode.

The status of a safe reference switch, which for example was scanned to the safe application via a safe input module (X20Sixxxx), should be linked to the input.

#### Not connected

The reference switch is not used!

#### Information:

If the homing mode "*Reference Switch*" is configured and the reference switch input "*S\_ReferenceSwitch*" is not wired on the function block, then the SafeMC module will change to Fail Safe state.

The Fail Safe state can only be exited by powering off/on and changing the safe application!

#### Information:

The input "*S\_ReferenceSwitch*" is only evaluated with the homing mode "*Reference Switch*".  
The input is ignored in other homing modes!

### 3.6.19 Reset

#### General function

- Reset input for acknowledging the "Functional Fail Safe" state or for putting the SafeMC module in to Operational state after startup

#### Data type

- BOOL

#### Connection

- Variable

#### Description of function

Reset input for confirming the "Functional Fail Safe" state.

A positive switching edge triggers the reset function.

Depending on the configuration of the parameter "Automatic Reset at Startup", a positive switching edge might be needed to get the SafeMC module from the "Init" state to the "Operational" state after starting up.

#### Relevant configuration parameters

Parameter	Unit	Description	Default value
General settings			
Automatic Reset at Startup (StartReset)	Used / Unused	Activates automatic reset of the function block at startup	Unused

Table 220: Parameter Reset

### 3.6.20 S\_AxisID

#### General function

- This input parameter assigns a real axis to the function block.

#### Data type

- SAFEINT

#### Connection

- Constant

#### Description of function

The corresponding axis can be connected to the input in SafeDESIGNER using drag-and-drop.

#### Information:

There can only be one combination of AxisID and SF\_SafeMC\_BR or SF\_SafeMC\_BR\_V2 function block in the safety application. Otherwise, the safety application cannot be compiled.



## 3.7 Output parameters

The output parameters provide information about the state of the SafeMC module and the individual safety functions.

### 3.7.1 Ready

#### General function

- Message: Function block activated/deactivated.

#### Data type

- BOOL

#### Connection

- Variable

#### Description of function

This output parameter indicates whether or not the function block is active.

#### TRUE

The function block is active (Activate = TRUE) and the output parameters indicate the current state of the safety function.

#### FALSE

The function block is deactivated (Activate = FALSE), with the function block outputs set to FALSE.

### 3.7.2 S\_SafetyActiveSTO

#### General function

- Status information about the safety function "Safe Torque Off", STO

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function STO.

#### TRUE

Safety function STO is active and currently in its safe state.

#### FALSE

Safety function STO is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.3 S\_SafetyActiveSTO1

#### General function

- Status information for the safety function "Safe Torque Off, One Channel", STO1

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function STO1.

#### TRUE

Safety function STO1 is active and currently in its safe state.

#### FALSE

Safety function STO1 is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.4 S\_SafetyActiveSBC

#### General function

- Status information for the safety function "Safe Brake Control", SBC

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SBC.

#### TRUE

Safety function SBC is active and currently in its safe state.

#### FALSE

Safety function SBC is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.5 S\_SafetyActiveSOS

#### General function

- Status information for the safety function "Safe Operating Stop", SOS.

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SOS.

#### TRUE

Safety function SOS is active and currently in its safe state.

#### FALSE

Safety function SOS is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.6 S\_SafetyActiveSS1

#### General function

- Status information for the safety function "Safe Stop 1", SS1.

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SS1.

#### TRUE

Safety function SS1 is active and currently in its safe state.

#### FALSE

Safety function SS1 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.7 S\_SafetyActiveSS2

#### General function

- Status information for the safety function "Safe Stop 2", SS2.

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SS2.

#### TRUE

Safety function SS2 is active and currently in its safe state.

#### FALSE

Safety function SS2 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.8 S\_SafetyActiveSLS1

#### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 1

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SLS1.

#### TRUE

Safety function SLS1 is active and currently in its safe state.

#### FALSE

Safety function SLS1 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.



### 3.7.9 S\_SafetyActiveSLS2

#### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 2

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SLS2.

#### TRUE

Safety function SLS2 is active and currently in its safe state.

#### FALSE

Safety function SLS2 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.10 S\_SafetyActiveSLS3

#### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 3

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SLS3.

#### TRUE

Safety function SLS3 is active and currently in its safe state.

#### FALSE

Safety function SLS3 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.11 S\_SafetyActiveSLS4

#### General function

- Status information the safety function "Safely Limited Speed" Speed Limit 4

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SLS4.

#### TRUE

Safety function SLS4 is active and currently in its safe state.

#### FALSE

Safety function SLS4 is not requested, has not yet achieved its safe state, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.12 S\_SafetyActiveSLI

#### General function

- Status information the safety function "Safely Limited Increment"

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SLI.

#### TRUE

Safety function SLI is active and currently in its safe state.

#### FALSE

Safety function SLI is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.13 S\_SafetyActiveSDIpos

#### General function

- Status information for the safety function "Safe Direction", movement is allowed in the positive direction

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SDIpos.

#### TRUE

Safety function SDIpos is active and currently in its safe state.

#### FALSE

Safety function SDIpos is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.14 S\_SafetyActiveSDIneg

#### General function

- Status information for the safety function "Safe Direction", movement is allowed in the negative direction

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SDIneg.

#### TRUE

Safety function SDIneg is active and currently in its safe state.

#### FALSE

Safety function SDIneg is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.15 S\_SafetyActiveSLP

#### General function

- Status information for the safety function "Safely Limited Position", SLP

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SLP.

#### TRUE

Safety function SLP is active and currently in its safe state.

#### FALSE

Safety function SLP is not requested, the function or the SafeMC module is currently in an error state or the function block has not been activated.

### 3.7.16 S\_SafetyActiveSMP

#### General function

- Status information for the safety function "Safe Maximum Position", SMP

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

Indicates the functional safe state of the safety function SMP.

#### TRUE

Safety function SMP is active and currently in its safe state.

#### FALSE

Monitoring of the SMP position limits is not active. Monitoring is not yet active because the module has not yet been homed, the function or the SafeMC module is currently in an error state or the function block has not been activated.



### 3.7.17 S\_SafePositionValid

#### General function

- Status information for the safety function "safe homing" and the safe position

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

This output parameter specifies whether or not safe homing of the axis has been completed and whether or not the position signal is valid.

#### TRUE

The axis has been safely homed and the safe position is valid.

#### FALSE

The axis has not yet been safely homed, the axis encoder signal contains errors, the SafeMC module is in an error state or the function block has not yet been activated.

The safe position is invalid!

#### **Danger!**

**This signal should only be used for status information.**

**S\_SafePositionValid does not represent the functional safe state of the SafeMC module!**

#### **Danger!**

**The value of the output parameter S\_SafePosition is only valid if the output parameter S\_SafePositionValid is SAFETRUE. Otherwise, it is invalid and can no longer be used.**

### 3.7.18 S\_SafetyActiveSDC

#### General function

- Information about the status of the ramp monitor

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

This output parameter indicates the status of ramp monitoring.

#### TRUE

Ramp monitoring is active.

#### FALSE

Ramp monitoring is not active, the module is currently in an error state or the function block has not been activated.

### **Danger!**

**This signal should only be used for status information.**

### 3.7.19 S\_AllReqFuncActive

#### General function

- Information about the status of the requested safety functions

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

This output parameter specifies the status of the requested safety functions.

#### TRUE

All requested safety functions are currently in their functional safe state.

#### FALSE

One or more safety functions have not yet achieved their safe state, the module is in an error state or the function block has not yet been activated.

### 3.7.20 S\_NotErrFUNC

#### General function

- Information about the error state of the SafeMC module

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

This output parameter specifies the error status of the SafeMC module.

#### TRUE

No error was found on the SafeMC module.

#### FALSE

An error was detected on the SafeMC module (e.g. a monitored limit was exceeded) or the function block has not yet been activated.

In the event of an error, additional information about the error can be found in Automation Studio's Safety Logger. If the error is a functional error, then it can be confirmed by changing the signal on the Reset input from FALSE to TRUE (positive edge)!

#### **Danger!**

**This signal should only be used for status information. This only applies in relation to the requested safety functions.**

**S\_NotErrFUNC does not represent the functional safe state of the SafeMC module!**

#### **Danger!**

**It is the user's responsibility to ensure that all necessary repair measures are initiated after an error occurs since subsequent errors can result in dangerous situations!**

### 3.7.21 Error

#### General function

- Function block error message

#### Data type

- BOOL

#### Connection

- Variable

#### Description of function

This formal parameter indicates a pending function block error message.

#### TRUE

The enabled function block has detected an error. DiagCode indicates the error code.

#### FALSE

The function block is not enabled or the enabled function block has not detected any errors. DiagCode indicates the status.

### **Danger!**

**It is the user's responsibility to ensure that all necessary repair measures are initiated after an error occurs since subsequent errors can result in dangerous situations!**

In order to exit an error state (Error= TRUE), the signal on the Reset input must change from FALSE to TRUE (positive edge).

### 3.7.22 DiagCode

#### General function

- Function block diagnostic message

#### Data type

- WORD

#### Connection

- Variable

#### Description of function

Block-specific diagnostic and status messages are output and automatically made available to the higher-level diagnostic tools via this output parameter.

Higher-level diagnostic tools cannot acknowledge diagnostic messages from the function block, however. This is done exclusively in the **safe** application program.

The function block indicates the presence of an error message on the DiagCode output via the output parameter "Error".

#### Diagnostic code

The diagnostic code is specified using the WORD data type. The values and meanings of these diagnostics codes are listed below.

In the event of status messages (0xxx<sub>hex</sub>, 8xxx<sub>hex</sub>), the function block sets "Error" to FALSE.

In the event of error messages (Cxxx<sub>hex</sub>), the function block sets "Error" to TRUE.

### 3.7.23 Diagnostic codes

Code (hex)	State	Description	Possible remedy
0000	Idle	The function block is not enabled.	Activate the function block by setting Activate to TRUE.
8001	Init	The function block has been activated and the SafeMC module is in the Init state. The SafeMC module startup inhibit is active.	Configure the parameter "Startreset" accordingly or change to a positive edge on the Reset input.
8002	Operational	The SafeMC module is in the "Operational" state. No safety function is selected. The speed limit SMS is monitored according to the configuration.	No action required.
8003	Wait for Confirmation	The SafeMC module is in the internal "Operational" state. At least one safety function has been requested and at least one safety function has not yet achieved its functional safe state. None of the limits currently being monitored have been violated.	No action required.
8000	Safe State	All requested safety functions have achieved their functional safe state. None of the limits currently being monitored have been violated.	No action required.
C000	Functional Fail Safe	An error has occurred.	Check the Safety Logger in Automation Studio. This will provide you with detailed information about the currently pending error. Depending on the type of error, check the standard and safe applications. If a functional error occurs, check the module configuration or replace the faulty module!

Table 221: SF\_SafeMC\_BR(\_V2): Diagnostic codes

### 3.7.24 AxisStatus

#### General function

- Diagnostics message from the function block, representation of the axis status bits in a DWORD

#### Data type

- DWORD

#### Connection

- Variable

#### Description of function

The AxisStatus output returns bit-coded information about the status of the individual safety functions.

This information is equal to a summary of the S\_xxx outputs in a DWORD.

The individual bits have the following meaning:

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
Status STO	Status SBC	Status SOS	Status SS1	Status SS2	Status SLS1	Status SLS2	Status SLS3
Bit 8	Bit 9	Bit 10	Bit 11	Bit 12	Bit 13	Bit 14	Bit 15
Status SLS4	Status STO1	Status SDI pos	Status SLI	Status SDI neg	Status SLP	Status SMP	Status PositionValid
Bit 16	Bit 17	Bit 18	Bit 19	Bit 20	Bit 21	Bit 22	Bit 23
-	Status Set Position Alive Test	Status SFR	Status "All requested safety functions active"	Status SDC	Status Operational	Status Not Encoder Error	Status Not Functional Er- ror

Table 222: SF\_SafeMC\_BR\_V2: SafeMC module status bits

### 3.8 State machine

The state machine shown is implemented on the SafeMC module.




Figure 91: SF\_SafeMC\_BR(\_V2): State machine

The individual statuses are reflected on the DiagCode output parameter. In this sense, the function block provides a representation of the SafeMC module's state machine.

### 3.9 Signal sequence diagram of the function block

A general signal sequence diagram of the function block cannot be specified because it depends on which safety functions are selected or deselected.

Signal sequence diagrams of individual safety functions can be found in Section "Integrated safety functions".



## 4 SF\_SafeMC\_Speed\_BR




Figure 92: Function block SF\_SafeMC\_Speed\_BR

### 4.1 Formal parameters of the function block

In the following, the term "variable" refers to both a variable as well as a graphic connection.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
S_AxisID	SAFEINT	Constant	Status	-1	Assigns an axis to the function block

Table 223: SF\_SafeMC\_Speed\_BR: Overview of input parameters

1) Evaluation of the input parameter signals in the function block. The signals must be controlled accordingly by the user.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
S_ScaledSpeed	SAFEINT	Variable	Value	-	Scaled safe speed
S_NotErrENC	SAFEBOOL	Variable	Status	SAFEFALSE	No encoder error has been detected (=SAFETRUE), the signal S_ScaledSpeed is valid

Table 224: SF\_SafeMC\_Speed\_BR: Overview of output parameters

1) Output of the output parameter signals. The signals must be evaluated and/or further processed accordingly by the user.

Type	Description	Size in bits	Format option
SAFEBOOL	Bit	1	Boolean (signal source: safe device)
SAFEINT	Integer	16	Binary number, hexadecimal number, unsigned decimal number (signal source: safe device)

Table 225: SF\_SafeMC\_Speed\_BR: Formats of data types used

### 4.2 Function

The primary purpose of the SF\_SafeMC\_Speed\_BR function block is to establish a connection between the safe speed of an axis and the associated encoder error status. An assignment is then made to a defined safe axis.

The SF\_SafeMC\_Speed\_BR function block can be used to process the current safe speed of an axis in the safe application.

#### **Danger!**

**Make sure that the correct AxisID is always used on the input!**  
**Each assignment must be validated separately.**

To ensure valid evaluation of the speed signal, the corresponding encoder error status bit must also always be checked.

The speed signal itself is only considered valid if this output parameter is set to TRUE.

#### **Danger!**

**If the speed signal is not validated, then an invalid speed value could be used in the safe application.**  
**This can result in hazardous situations!**

### 4.3 Error prevention

#### **Danger!**

##### **Validation**

**Each of the safety functions that are used must be validated separately.**  
**In addition, the entire safety application, including interactions between individual functions, must also be tested.**

### 4.3.1 Plausibility errors

Plausibility errors (limit values, data types, variables/constants) that occur when the function block is used are detected and reported by the function block or compiler.

This is not always possible in the event of connection errors, however.

The function block cannot check whether:

- Actual parameter values or constants within the valid range are in fact incorrect for the safety function being executed. A static TRUE signal on the Reset input is detected by the function block and indicated as an error, however.
- Actual parameters have been connected incorrectly.
- I/O formal parameters were not connected inadvertently.

For this reason:

#### **Danger!**

**The user is responsible for the connection of the safety function (sub-application).**

**The connection for validating the sub-application must be checked**

### 4.3.2 Validate the speed signal

In order for the speed signal to undergo a valid evaluation, the associated encoder error status bit must always be checked as well.

The speed signal itself is only considered valid if this output parameter is set to TRUE.

#### **Danger!**

**If the speed signal is not validated, then an invalid speed value could be used in the safe application. This can result in hazardous situations!**

### 4.3.3 Machine/system startup without performing functional testing of safety equipment

Faulty safety equipment can only be detected following functional testing. Functional testing is not supported by this function block. If additional measures are not implemented, faulty safety equipment can result in errors.

#### **Danger!**

**The user is responsible for performing safeguard function tests. This means that the safeguard must be validated!**

Possible causes of faulty safety equipment:

- Faulty devices (hardware error)
- Cross fault, short circuit, and cable break (user error, wiring error)

## 4.4 Input parameters

### 4.4.1 S\_AxisID

#### General function

- This input parameter assigns a real axis to the function block.

#### Data type

- SAFEINT

#### Connection

- Constant

#### Description of function

The corresponding axis can be connected to the input in SafeDESIGNER using drag-and-drop.

#### Information:

The combination of AxisID and function block SF\_SafeMC\_Speed\_BR can be used more than once in the safe application!

## 4.5 Output parameters

### 4.5.1 S\_ScaledSpeed

#### General function

- Indicates the current value of the scaled safe speed

#### Data type

- SAFEINT

#### Connection

- Variable

#### Description of function

This output parameter indicates the current value of the scaled safe speed for a real axis.

### **Danger!**

The value of the output parameter **S\_ScaledSpeed** is only valid if the output parameter **S\_NotErrENC** is **TRUE**. Otherwise, it is invalid and can no longer be used.

## 4.5.2 S\_NotErrENC

### General function

- Information about the error state of the safe encoder signal

### Data type

- SAFEBOOL

### Connection

- Variable

### Description of function

This output parameter indicates the error state of the signal for a defined safe encoder.

If an encoder error is detected or if the SafeMC module is in an error state, then the output is set to FALSE. This state is maintained until the error has been corrected.

#### TRUE

An error was not detected on the encoder signal. The value of the safe speed on the output parameter S\_ScaledSpeed is valid.

#### FALSE

The encoder signal from a defined safe axis is faulty or the axis itself is in an error state. Further information about the error can be found in the Safety Logger in Automation Studio.

### **Danger!**

**This signal should only be used for status information. This only applies in relation to the requested safety functions.**

**S\_NotErrENC does not represent the functional safe state of the SafeMC module!**

### **Danger!**

**The value of the output parameter S\_ScaledSpeed is only valid if the output parameter S\_NotErrENC is TRUE. Otherwise, it is invalid and can no longer be used.**

#### 4.6 Signal sequence diagram of the function block

A signal sequence diagram cannot be specified for this function block.

#### 4.7 Application example

The following application example illustrates one possible comparison of the scaled safe speed with a set defined value in the safe application.




Figure 93: SF\_SafeMC\_Speed\_BR: Evaluation of the scaled safe speed

## 5 SF\_SafeMC\_Position\_BR




Figure 94: Function block SF\_SafeMC\_Position\_BR

### Information:

The SF\_SafeMC\_Position\_BR\_V1\_01 function block cannot be used without Safety Release 1.4.

If safety release 1.3 is being used, then SafeDESIGNER returns an error when compiling the safety application!

### 5.1 Formal parameters of the function block

In the following, the term "variable" refers to both a variable as well as a graphic connection.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
S_AxisID	SAFEINT	Constant	Status	-1	Assigns an axis to the function block

Table 226: SF\_SafeMC\_Position\_BR: Overview of input parameters

1) Evaluation of the input parameter signals in the function block. The signals must be controlled accordingly by the user.

Name	Type	Connection	Signal type <sup>1)</sup>	Initial value	Description / General function
S_SafePosition	SAFEDINT	Variable	Value	-	Safe position in units
S_SafePositionValid	SAFEBOOL	Variable	Status	SAFEFALSE	Specifies whether the safe position is valid (=SAFETRUE, homing procedure has completed successfully and there are no encoder errors)

Table 227: SF\_SafeMC\_Position\_BR: Overview of output parameters

1) Output of the output parameter signals. The signals must be evaluated and/or further processed accordingly by the user.

Type	Description	Size in bits	Format option
SAFEBOOL	Bit	1	Boolean (signal source: safe device)
SAFEINT	Integer	16	Binary number, hexadecimal number, unsigned decimal number (signal source: safe device)
SAFEDINT	Long	32	Binary number, hexadecimal number, unsigned decimal number (signal source: safe device)

Table 228: SF\_SafeMC\_Position\_BR: Formats of data types used

### 5.2 Function

The primary purpose of the SF\_SafeMC\_Position\_BR function block is to establish a connection between the safe position of an axis and its associated status. An assignment is then made to a defined safe axis.

The SF\_SafeMC\_Position\_BR function block can be used to process the current safe position of an axis in the safe application.

### Danger!

**Make sure that the correct AxisID is always used on the input!**  
**Each assignment must be validated separately.**

To ensure valid evaluation of the position signal, the corresponding status bit S\_PositionValid must also always be checked.

The position itself is only considered homed and valid if this output parameter is set to SAFETRUE.

### Danger!

**If the position signal is not validated, then an invalid position could be used in the safe application.**  
**This can result in hazardous situations!**

## 5.3 Error prevention

### **Danger!**

#### **Validation**

**Each of the safety functions that are used must be validated separately.**

**In addition, the entire safety application, including interactions between individual functions, must also be tested.**

#### 5.3.1 Plausibility errors

Plausibility errors (limit values, data types, variables/constants) that occur when the function block is used are detected and reported by the function block or compiler.

This is not always possible in the event of connection errors, however.

The function block cannot check whether:

- Actual parameter values or constants within the valid range are in fact incorrect for the safety function being executed.
- Actual parameters have been connected incorrectly.
- I/O formal parameters were not connected inadvertently.

Therefore the following must be taken into account:

### **Danger!**

**The user is responsible for the connection of the safety function (sub-application).**

**The connection for validating the sub-application must be checked**

#### 5.3.2 Validate the position signal

To ensure valid evaluation of the position signal, the corresponding status bit S\_PositionValid must also always be checked.

The position itself is only considered homed and valid if this output parameter is set to SAFETRUE.

### **Danger!**

**If the position signal is not validated, then an invalid position could be used in the safe application. This can result in hazardous situations!**

#### 5.3.3 Machine/system startup without performing functional testing of safety equipment

Faulty safety equipment can only be detected following functional testing. Functional testing is not supported by this function block. If additional measures are not implemented, faulty safety equipment can result in errors.

### **Danger!**

**The user is responsible for performing safeguard function tests.**

**This means that the safeguard must be validated!**

Possible causes of faulty safety equipment:

- Faulty devices (hardware error)
- Cross fault, short circuit, and cable break (user error, wiring error)



## 5.4 Input parameters

### 5.4.1 S\_AxisID

#### General function

- This input parameter assigns a real axis to the function block.

#### Data type

- SAFEINT

#### Connection

- Constant

#### Description of function

The corresponding axis can be connected to the input in SafeDESIGNER using drag-and-drop.

#### **Information:**

The combination of AxisID and function block SF\_SafeMC\_Position\_BR can be used more than once in the safe application!

## 5.5 Output parameters

### 5.5.1 S\_SafePosition

#### General function

- Indicates the current safe position in units

#### Data type

- SAFEDINT

#### Connection

- Variable

#### Description of function

This output parameter indicates the current value of the safe position for a real axis in units.

### **Danger!**

The value of the output parameter **S\_SafePosition** is only valid if the output parameter **S\_SafePositionValid** is **SAFETRUE**. Otherwise, it is invalid and can no longer be used.

### 5.5.2 S\_SafePositionValid

#### General function

- Status information for the safety function "safe homing" and the safe position

#### Data type

- SAFEBOOL

#### Connection

- Variable

#### Description of function

This output parameter specifies whether or not safe homing of the axis has been completed and whether or not the position signal is valid.

#### TRUE

The axis has been safely homed and the safe position is valid.

#### FALSE

The axis has not yet been safely homed, the axis encoder signal contains errors, the SafeMC module is in an error state or the function block has not yet been activated.

The safe position is invalid!

#### **Danger!**

**This signal should only be used for status information.**

**S\_SafePositionValid does not represent the functional safe state of the SafeMC module!**

#### **Danger!**

**The value of the output parameter S\_SafePosition is only valid if the output parameter S\_SafePositionValid is SAFETRUE. Otherwise, it is invalid and can no longer be used.**

## 5.6 Signal sequence diagram of the function block

A signal sequence diagram cannot be specified for this function block.

## 5.7 Application example

The following application example illustrates one possible use of the Safe Position Monitor function on the SafeL-OGIC controller.




Figure 95: SF\_SafeMC\_Position\_BR: The Safe Position Monitor function

## Chapter 6 • SafeDESIGNER

---

See Integrated Safety User's Manual MASAFETY1-ENG, Chapter "SafeDESIGNER".

# Chapter 7 • Standards and certifications

## 1 Applicable European directives

- EMC directive 2004/108/EC
- Low-voltage directive 2006/95/EC
- Machinery directive 2006/42/EC<sup>1)</sup>

## 2 Applicable standards

Standard	Description
IEC/EN 61800-2	Adjustable speed electrical power drive systems <ul style="list-style-type: none"> <li>• Part 2: General requirements; Rating specifications for low voltage adjustable frequency AC power drive systems</li> </ul>
IEC/EN 61800-3	Adjustable speed electrical power drive systems <ul style="list-style-type: none"> <li>• Part 3: EMC requirements including specific test methods</li> </ul>
IEC 61800-5-1	Electrical drive systems with adjustable speed <ul style="list-style-type: none"> <li>• Part 5-1: Safety requirements - Electrical, thermal and power requirements (IEC 61800-5-1:2003)</li> </ul>
EN 61800-5-2	Adjustable speed electrical power drive systems <ul style="list-style-type: none"> <li>• Part 5-2: Safety requirements - Functional requirements</li> </ul>
IEC/EN 61131-2	Programmable logic controllers <ul style="list-style-type: none"> <li>• Part 2: Equipment requirements and tests</li> </ul>
EN 60204-1	Safety of machinery - Electrical equipment on machines <ul style="list-style-type: none"> <li>• Part 1: General requirements</li> </ul>
IEC 61508	Functional safety of electrical / electronic / programmable electronic safety-related systems
EN 50178-1	Electronic equipment for high voltage systems
EN 1037	Safety of machinery - Prevention of unexpected startup
EN ISO 13849-1	Safety of machinery - Safety-related parts of control systems <ul style="list-style-type: none"> <li>• Part 1: General design principles</li> </ul>
EN 62061	Safety of machinery - Functional safety of safety-related electrical, electronic and programmable electronic control systems
UL 508C	Power conversion equipment

Table 229: Applicable standards for ACOPOS servo drives

### 2.1 Limit values

The limit values specified from section Mechanical conditions during operation to section Additional environmental limit values are taken from the product standard EN 61800 (or IEC 61800) for servo drives in industrial environments (category C3<sup>2)</sup>). Stricter test procedures and limit values are used during the type tests for ACOPOSmulti servo drives. Additional information is available from B&R.

## 3 Environmental limits

### 3.1 Mechanical conditions in accordance with IEC 61800-2

#### Operation

IEC 60721-3-3, class 3M1	
	EN 61800-2
Vibration during operation 2 ≤ f < 9 Hz 9 ≤ f < 200 Hz	0.3 mm amplitude 1 m/s <sup>2</sup> acceleration

Table 230: Mechanical conditions during operation

<sup>1)</sup> This machinery directive only applies to logic units for safety functions that are initially being placed on the market by B&R for sale or use.

<sup>2)</sup> EN 61800-3 C3 (second environment)

## Transport

IEC 60721-3-2, class 2M1	
	EN 61800-2
Vibration during transport <sup>1) 2)</sup> 2 ≤ f < 9 Hz 9 ≤ f < 200 Hz 200 ≤ f < 500 Hz	3.5 mm amplitude 10 m/s <sup>2</sup> acceleration 15 m/s <sup>2</sup> acceleration
Drop height in free fall <sup>1)</sup> Weight <100 kg	0.25 m

Table 231: Mechanical conditions during transport

1) Only valid for components in original packaging

2) The values in section "Operation" apply to components that are not in their original packaging.

## 3.2 Climate conditions in accordance with IEC 61800-2

### Operation

IEC 60721-3-3, class 3K3	
	EN 61800-2
Ambient temperature during operation	5 to 40°C
Relative humidity during operation	5 to 85%, non-condensing

Table 232: Climate conditions during operation

### Storage

IEC 60721-3-1, class 1K4	
	EN 61800-2
Storage temperature	-25 to +55°C

Table 233: Climate conditions (temperature) during storage

IEC 60721-3-1, class 1K3	
	EN 61800-2
Relative humidity during storage	5 to 95%, non-condensing

Table 234: Climate conditions (humidity) during storage

### Transport

IEC 60721-3-2, class 2K3	
	EN 61800-2
Transport temperature	-25 to +70°C
Relative humidity during transport	Max. 95% at +40°C

Table 235: Climate conditions during transport

## 4 Requirements for immunity to disturbances (EMC)

- EN 61800-3 requirements apply.
- For all modules that have certified safety functions, stricter requirements apply for section 4.3 "High-frequency disturbances in accordance with EN 61800-3" in accordance with IFA (previously BGIA): EMC and functional safety for drive systems 2/2012.

### 4.1 Evaluation criteria (performance criteria)

Performance criteria (PC)	Description
A	The test object is not interfered with during testing.
B	The test object is only interfered with temporarily during testing.
C	The system does not reboot itself automatically (reset required).
FS	Functional safety - Behavior of test object in accordance with EN 61800-5-2, Item 6.2.5.3

Table 236: Evaluation criteria (performance criteria) for immunity to disturbances

### 4.2 Low-frequency disturbances in accordance with IEC 61800-3

The following limit values are applicable for industrial environments (category C3).

#### Power mains harmonics and commutation notches / voltage distortions

IEC 61000-2-4, class 3		
	EN 61800-3	Performance criteria
Harmonics	THD = 10%	A
Short harmonics (<15 s)	1.5x continuous level	B

Table 237: Limit values for power mains harmonics

IEC 60146-1-1, class 3		
	EN 61800-3	Performance criteria
Commutation notches	Depth = 40%, Total area = 250% x degree	A

Table 238: Limit values for commutation notches / voltage distortions

#### Voltage changes, fluctuations, dips and short-term interruptions

IEC 61000-2-4, class 3		
	EN 61800-3	Performance criteria
Voltage changes and fluctuations	±10%	A
Voltage changes and fluctuations (<1 min)	+10% to -15%	

Table 239: Limit values for voltage changes and fluctuations

IEC 61000-2-1		
	EN 61800-3	Performance criteria
Voltage dips and short-term interruptions	10% to 100%	C

Table 240: Limit values for voltage dips and short-term interruptions

#### Asymmetric voltage and frequency changes

IEC 61000-2-4, class 3		
	EN 61800-3	Performance criteria
Asymmetric voltages	3% negative component	A
Frequency change and change rate	±2%, 1%/s (±4 %, 2%/s if the power supply is isolated from general power mains)	

Table 241: Limit values for asymmetric voltages and frequency changes



### 4.3 High-frequency disturbances in accordance with IEC 61800-3

These immunity tests are applicable for industrial environments (category C3).

#### Electrostatic discharge

Tests in accordance with IEC 61000-4-2				
	EN 61800-3		Increased immunity to disturbances	
	Requirement	PC	Requirement <sup>1)</sup>	PC
Contact discharge to powder-coated and bare metal housing parts	4 kV	B	6 kV	FS
Discharge through the air to plastic housing parts	8 kV		15 kV	

Table 242: Limits for electrostatic discharge

- 1) The total number of discharges depends on the required Safety Integrity Level (SIL) and can be found in IFA (previously BGIA): EMC and Functional Safety for Drive Systems 2/2012.

#### Electromagnetic fields

Tests in accordance with IEC 61000-4-3				
	EN 61800-3		Increased immunity to disturbances	
	Requirement	PC	Requirement	PC
Housing, completely wired	80 MHz - 1 GHz, 10 V/m, 80% amplitude modulation at 1 kHz	A	80 MHz to 1 GHz ... 20 V/m, 1.4 to 2 GHz ... 10 V/m, 2 GHz to 2.7 GHz ... 3 V/m, 80% amplitude modulation at 1 kHz	FS

Table 243: Limits for electromagnetic fields

#### Burst

Tests in accordance with IEC 61000-4-4				
	EN 61800-3		Increased immunity to disturbances	
	Requirement	PC	Requirement <sup>1)</sup>	PC
Power connection	2 kV, 1 min, direct coupling	B	4 kV, direct coupling	FS
Connections for measurement and control functions in the process environment	2 kV, 1 min		4 kV	
Signal interfaces, other wires	1 kV, 1 min		2 kV	

Table 244: Limits for burst

- 1) How long the effects last depends on the required Safety Integrity Level (SIL) and can be found in IFA (previously BGIA): EMC and Functional Safety for Drive Systems 2/2012.

#### Surge

Tests in accordance with IEC 61000-4-5				
	EN 61800-3		Increased immunity to disturbances	
	Requirement	PC	Requirement <sup>1)</sup>	PC
Power connection	1 kV (2 Ω <sup>2)</sup> , DM, symmetrical 2 kV (12 Ω <sup>2)</sup> , CM, unsymmetrical	B	2 kV (2 Ω <sup>2)</sup> , DM, symmetrical 4 kV (12 Ω <sup>2)</sup> , CM, unsymmetrical	FS

Table 245: Limits for surge

- 1) The number of pulses depends on the required Safety Integrity Level (SIL) and can be found in IFA (previously BGIA): EMC and Functional Safety for Drive Systems 2/2012.  
2) The impedance from IEC 61000-4-5 has been added because it is not defined in IEC 61800-3.

#### High-frequency conducted disturbances

Tests in accordance with IEC 61000-4-6				
	EN 61800-3		Increased immunity to disturbances	
	Requirement	PC	Requirement	PC
Power connection	0.15 - 80 MHz, 10 V, 80% amplitude modulation at 1 kHz	A	0.15 - 80 MHz, 20 V, 80% amplitude modulation at 1 kHz	FS
Connections for measurement and control functions in the process environment				
Signal interfaces, other wires				

Table 246: Limits for high-frequency conducted disturbances

## 5 Requirements for emissions (EMC)

### 5.1 High-frequency emissions in accordance with IEC 61800-3

These emission tests are valid for industry (category C3).

**Disturbance voltages on the power connections**

Tests in accordance with IEC 55011			
Continuous current on motor	Frequency range [MHz]	Quasi-peak value	Average
$I \leq 100 \text{ A}$	$0.15 \leq f < 0.5$	100 dB ( $\mu\text{V}$ )	90 dB ( $\mu\text{V}$ )
	$0.5 \leq f < 5$	86 dB ( $\mu\text{V}$ )	76 dB ( $\mu\text{V}$ )
	$5 \leq f < 30$	90 dB ( $\mu\text{V}$ ) Decreases with the logarithm of the frequency to 70	80 dB ( $\mu\text{V}$ ) Decreases with the logarithm of the frequency to 60
$100 \text{ A} < I$	$0.15 \leq f < 0.5$	130 dB ( $\mu\text{V}$ )	120 dB ( $\mu\text{V}$ )
	$0.5 \leq f < 5$	125 dB ( $\mu\text{V}$ )	115 dB ( $\mu\text{V}$ )
	$5 \leq f < 30$	115 dB ( $\mu\text{V}$ )	105 dB ( $\mu\text{V}$ )

Table 247: Limits for disturbance voltages on the power connections

**Electromagnetic emissions**

Tests in accordance with IEC 55011	
Frequency range [MHz]	Quasi-peak value
$30 \leq f \leq 230$	40 dB ( $\mu\text{V}/\text{m}$ ), measured at distance of 30 m <sup>1)</sup>
$230 < f \leq 1000$	50 dB ( $\mu\text{V}/\text{m}$ ), measured at distance of 30 m <sup>1)</sup>

Table 248: Limit values for electro-magnetic emissions

1) Limit values are increased by 10 dB ( $\mu\text{V}/\text{m}$ ) when measured from a distance of 10 m.

**6 Additional environmental limit values in accordance with IEC 61800-2**

EN 61800-2	
Degree of pollution in accordance with IEC 61800-2, 4.1.2.1.	2 (non-conductive pollution)
Overvoltage category in accordance with IEC 60364-4-443:1999	III
EN 60529 protection	IP20
Reduction of the continuous current at installation altitudes over 500 m above sea level	10 % per 1000 m
Maximum installation altitude	4,000 m

Table 249: Additional environmental limit values

## 7 International certifications

B&R products and services comply with applicable standards. This includes international standards from organizations such as ISO, IEC and CENELEC, as well as national standards from organizations such as UL, CSA, FCC, VDE, ÖVE, etc. We are committed to ensuring the reliability of our products in an industrial environment.






Certifications	
USA and Canada 	All important B&R products are tested and listed by Underwriters Laboratories and checked quarterly by a UL inspector. This mark is valid for the USA and Canada and simplifies the certification of your machines and systems in these areas.
Europe 	This mark certifies that all harmonized EN standards for the applicable directives have been met.
Russian Federation 	GOST-R certification is available for the export of all ACOPOS servo drives to the Russian Federation.
 Functional Safety Type Approved 	All significant B&R servo drives have the FS - Functional Safety - mark from TÜV Rheinland.

Table 250: International certifications

## 8 Standards and definitions for safety technology

### Stop functions in accordance with IEC 60204-1:2006 (Electrical equipment of machines, Part 1: General requirements)

There are three categories of stop functions:

Category	Description
0	Stop by immediately switching off power to the machine drive elements (i.e. uncontrolled stop)
1	A controlled stop where power to the machine drive elements remains on until the stop procedure is completed. Power is only switched off after the stop is complete.
2	A controlled stop where power to the machine drive elements is not switched off

Table 251: Overview of stop function categories

The necessary stop functions must be determined based on a risk assessment of the machine. Stop functions in Category 0 and Category 1 must be able to function regardless of the operating mode. A Category 0 stop must have priority. Stop functions must have priority over assigned start functions. Resetting the stop function must never result in a dangerous state.

### Emergency stops in accordance with IEC 60204-1:2006 (Electrical equipment for machines, Part 1: General requirements)

The following requirements are valid for an emergency stop in addition to the requirements for stop functions:

- It must have priority over all other functions and operations in all operating modes.
- Power to machine drive elements that can cause a dangerous state must be switched off as quickly as possible without creating other dangers.
- Resetting is not permitted to cause a restart.

Emergency stops must be Category 0 or Category 1 stop functions. The stop function required must be determined based on a risk assessment for the machine.

For Category 0 emergency stop functions, only hard-wired electromechanical equipment can be used. In addition, this functionality is not permitted to depend on electronic switching logic (hardware or software) or the transfer of commands via a communication network or data connection. <sup>3)</sup>

When using a Category 1 emergency stop function, it must be guaranteed that the power to the machine drive elements is completely switched off. These elements must be switched off using electromechanical equipment. <sup>4)</sup>

### Performance Levels (PL) in accordance with EN ISO 13849-1 (Safety of machinery – Safety-related parts of control systems, Part 1: General principles for design)

The safety-related parts of control systems must meet one or more of the requirements for five defined Performance Levels. These Performance Levels define the required behavior of safety-related controller parts with regard to their resistance to errors.

Performance Level (in accordance with EN ISO 13849-1)	Safety integrity level - SIL (in accordance with IEC 61508-2)	Short description	System behavior
a	---	Safety-related components must be designed and built so that they can meet the expected operational requirements (no specific safety measures are implemented).	<b>Caution!</b> An error can cause the loss of safety functionality.
b	1	Safety-related components must be designed and built in such a way that only reliable components and safety principles are used (e.g. preventing short circuits by using sufficient distances, reducing the probability of errors by using oversized components, defining the failure route - bias current fail-safe, etc.).	<b>Caution!</b> An error can cause the loss of safety functionality.

Table 252: Overview of Performance Levels (PL)

<sup>3)</sup> In accordance with the national foreword of the valid German-language version of IEC 60204-1:2006, electronic equipment – and especially emergency stop systems – may be used regardless of the stop category, if e.g. it provides the same safety using the standards EN ISO 13849-1:2008 and/or IEC 61508 as required by EN 60204-1.


<sup>4)</sup> In accordance with the national foreword of the valid German-language version of IEC 60204-1:2006, electronic equipment – and especially emergency stop systems – may be used regardless of the stop category, if e.g. it provides the same safety using the standards EN ISO 13849-1:2008 and/or IEC 61508 as required by EN 60204-1.

Performance Level (in accordance with EN ISO 13849-1)	Safety integrity level - SIL (in ac- cordance with IEC 61508-2)	Short description	System behavior
c	1	Safety-related components must be designed in such a way that their safety functionality is checked at suitable intervals by the machine controller (e.g. automatic or manual check during startup).	<b>Caution!</b>  An error between checks can cause the loss of safety functionality. The loss of safety functionality will be detected during the check.
d	2	Safety-related components must be designed in such a way that individual errors do not cause the loss of safety functionality. Individual errors should – if possible – be detected the next time (or before) the safety function is required.	<b>Caution!</b>  Safety functionality remains active when an error occurs. Some but not all errors are detected. A buildup of errors can cause safety functionality to fail.
e	3	Safety-related components must be designed in such a way that individual errors do not cause the loss of safety functionality. Individual errors must be detected the next time (or before) the safety function is required. If this type of detection is not possible, a buildup of errors is not permitted to cause safety functionality to fail.	<b>Information:</b>  Safety functionality remains active when an error occurs. Errors are detected in time to prevent safety functionality from failing.

Table 252: Overview of Performance Levels (PL)

A suitable Performance Level must be selected separately for each drive system (or for each axis) based on a risk assessment. This risk assessment is a part of the total risk assessment for the machine.

The following risk graph (in accordance with EN ISO 13849-1, Appendix A) provides a simplified procedure for risk assessment:

Figure 96: Risk diagram for determining the PL<sub>r</sub> for each safety function in accordance with EN ISO 13849-1, Appendix A

### Legend:

- 1 Starting point for assessing the impact on risk reduction
- L Low impact on risk reduction
- H High impact on risk reduction
- PL<sub>r</sub> Necessary performance level
- SIL Safety Integrity Level in accordance with IEC 61508-2

### Risk parameters

- S Severity of injury
- S1 Slight (usually reversible) injury
- S2 Serious (usually irreversible) injury or death
- F Frequency and/or duration of the exposure to the hazard
- F1 Rare to often and/or short exposure to the hazard
- F2 Frequent to continuous and/or long exposure
- P Possibility to circumvent the danger or limit the damage
- P1 Possible under some conditions
- P2 Nearly impossible

The Performance Level to be used is determined by starting at the specified starting point and taking the risk parameters S, F and P into consideration.

**Restart inhibit in accordance with EN 1037/04.96 (Safety of Machinery – Prevention of Unexpected Startup)**

Keeping a machine in a state of rest when people are working in the danger zone is one of the most important requirements for safely operating machines.

Starting refers to the transition of a machine or its parts from a state of rest to a moving state. Any start is unexpected if it is caused by:

- A startup command sent because of a controller failure or because of external influences on the controller
- A startup command sent because of incorrect operation of a start element or another part of the machine
- Restoration of power supply after an interruption
- External/internal influences on parts of the machine

To prevent unexpected startup of machines or parts of machines, power should be removed and dissipated. If this is not practical (e.g. frequent brief interventions in danger zones), other measures must be taken:

- Measures to prevent random startup commands
- Measures to prevent random startup commands from causing unexpected startup
- Measures to automatically stop dangerous parts of the machine before a dangerous situation can be caused by unexpected startup

## Appendix A • EC declaration of conformity

---

This document was originally written in the German language. The German edition therefore represents the original instruction manual in accordance with the 2006/42/EC machinery directive. Documents in other languages are to be interpreted as translations of the original instruction manual.

**Product manufacturer:**

Bernecker + Rainer

Industrie-Elektronik Ges.m.b.H.

B&R Strasse 1

5142 Eggelsberg

AUSTRIA

The EC declarations of conformity for B&R products can be downloaded from the B&R website [www.br-automation.com](http://www.br-automation.com).

Figure 1:	Warning sticker on the ACOPOSmulti module.....	16
Figure 2:	Indicator groups for 8BVI inverter modules with SafeMC (single-axis modules).....	19
Figure 3:	Indicator groups for 8BVI inverter modules with SafeMC (two-axis modules).....	20
Figure 4:	Single-axis modules.....	22
Figure 5:	Dual-axis modules.....	22
Figure 6:	Overview of pin assignments.....	43
Figure 7:	Overview of pin assignments.....	59
Figure 8:	Overview of pin assignments.....	76
Figure 9:	Overview of pin assignments.....	90
Figure 10:	Overview of pin assignments.....	104
Figure 11:	X5A - Cable installation.....	107
Figure 12:	Pinout overview.....	113
Figure 13:	X5A - Cable installation.....	116
Figure 14:	Overview of ground/shield for ACOPOSmulti drive system (passive power supply).....	121
Figure 15:	Overview of ground/shield for ACOPOSmulti drive system (active power supply).....	122
Figure 16:	Connection between two 8BVE expansion modules.....	123
Figure 17:	Connection between several 8BVE expansion modules.....	123
Figure 18:	Ground connections and shield connections for 8BVI inverter modules with SafeMC.....	124
Figure 19:	Use of the shield set 8SCS005.0000-00.....	125
Figure 20:	Cable shielding in DSUB housing.....	125
Figure 21:	Grounding the POWERLINK cable shielding.....	125
Figure 22:	Integrated Safety Technology - Topology.....	129
Figure 23:	Total lag time.....	131
Figure 24:	Safe error response time.....	133
Figure 25:	Response time calculator.....	134
Figure 26:	Safe power transmission.....	139
Figure 27:	Control of safe pulse disabling.....	142
Figure 28:	Connection of safe motor holding brake output.....	143
Figure 29:	Functional Fail Safe - Configuration of STO.....	153
Figure 30:	Functional Fail Safe - Configuration of STO1 and STO with time delay.....	154
Figure 31:	STO - Safe Torque Off.....	157
Figure 32:	Safe Brake Control, SBC.....	159
Figure 33:	Safe Operating Stop, SOS.....	160
Figure 34:	Safe Stop 1, SS1.....	162
Figure 35:	Safe Stop 2, SS2.....	165
Figure 36:	Safely Limited Speed, SLS.....	168
Figure 37:	Safely Limited Increment, SLI.....	171
Figure 38:	Safe Direction, SDI - Positive direction of rotation allowed.....	173
Figure 39:	Safe Direction, SDI - Negative direction of rotation allowed.....	173
Figure 40:	Safe Homing.....	176
Figure 41:	Home Offset referencing method.....	181
Figure 42:	Referencing method - Home Offset with Correction.....	182
Figure 43:	Safely Limited Position, SLP.....	183
Figure 44:	Position-dependent speed window.....	184
Figure 45:	Inverter module timing - SafeMC module.....	199
Figure 46:	SafeMC Help Tool - Status and Control Bits tab.....	200
Figure 47:	SafeMC Help Tool - Velocity tab.....	202
Figure 48:	SafeMC Help Tool - Delay Time tab.....	204
Figure 49:	SafeMC Help Tool - SMP/SLP Speed Limits tab.....	205
Figure 50:	Displaying the diagram with the selection menu.....	206
Figure 51:	SafeMC Help Tool - Safe Brake Test SBT.....	207
Figure 52:	PV mapping.....	210
Figure 53:	ACOPOSmulti Trace: Example - SafeMC data.....	211
Figure 54:	ACOPOSmulti Trace: Speed reserve.....	212
Figure 55:	Function block label.....	220
Figure 56:	Function block SF_SafeMC_BR.....	221
Figure 57:	Functional Fail Safe - Configuration of STO.....	228



Figure 58:	Functional Fail Safe - Configuration of STO1 and STO with time delay.....	229
Figure 59:	STO - Safe Torque Off.....	232
Figure 60:	Safe Brake Control, SBC.....	234
Figure 61:	Safe Operating Stop, SOS.....	235
Figure 62:	Safe Stop 1, SS1.....	237
Figure 63:	Safe Stop 2, SS2.....	240
Figure 64:	Safely Limited Speed, SLS.....	243
Figure 65:	Safely Limited Increment, SLI.....	246
Figure 66:	Safe Direction, SDI - Positive direction of rotation allowed.....	248
Figure 67:	Safe Direction, SDI - Negative direction of rotation allowed.....	248
Figure 68:	Safe Homing.....	251
Figure 69:	Home Offset referencing method.....	256
Figure 70:	Referencing method - Home Offset with Correction.....	257
Figure 71:	Safely Limited Position, SLP.....	258
Figure 72:	Position-dependent speed window.....	259
Figure 73:	SF_SafeMC_BR(_V2): State machine.....	302
Figure 74:	Function block SF_SafeMC_BR_V2.....	303
Figure 75:	Functional Fail Safe - Configuration of STO.....	311
Figure 76:	Functional Fail Safe - Configuration of STO1 and STO with time delay.....	312
Figure 77:	STO - Safe Torque Off.....	315
Figure 78:	Safe Brake Control, SBC.....	317
Figure 79:	Safe Operating Stop, SOS.....	318
Figure 80:	Safe Stop 1, SS1.....	320
Figure 81:	Safe Stop 2, SS2.....	323
Figure 82:	Safely Limited Speed, SLS.....	326
Figure 83:	Safely Limited Increment, SLI.....	329
Figure 84:	Safe Direction, SDI - Positive direction of rotation allowed.....	331
Figure 85:	Safe Direction, SDI - Negative direction of rotation allowed.....	331
Figure 86:	Safe Homing.....	334
Figure 87:	Home Offset referencing method.....	339
Figure 88:	Referencing method - Home Offset with Correction.....	340
Figure 89:	Safely Limited Position, SLP.....	341
Figure 90:	Position-dependent speed window.....	342
Figure 91:	SF_SafeMC_BR(_V2): State machine.....	396
Figure 92:	Function block SF_SafeMC_Speed_BR.....	397
Figure 93:	SF_SafeMC_Speed_BR: Evaluation of the scaled safe speed.....	402
Figure 94:	Function block SF_SafeMC_Position_BR.....	403
Figure 95:	SF_SafeMC_Position_BR: The Safe Position Monitor function.....	408
Figure 96:	Risk diagram for determining the PL <sub>r</sub> for each safety function in accordance with EN ISO 13849-1, Appendix A.....	417

Table 1:	Manual history.....	11
Table 2:	Publications.....	12
Table 3:	Release information.....	13
Table 4:	Description of the safety notices used in this documentation.....	13
Table 5:	Environmentally friendly separation of materials.....	17
Table 6:	LED Status indicators - 8BVI inverter modules with SafeMC (single-axis modules).....	19
Table 7:	LED Status indicators - 8BVI inverter modules with SafeMC (two-axis modules).....	20
Table 8:	RDY, RUN, ERR (8BVI, 8BVP, 8BOP) - LED status indicators.....	21
Table 9:	POWERLINK - LED status indicators.....	21
Table 10:	LED Status indicators - Backup battery.....	21
Table 11:	SafeMC module - LED status indicators.....	22
Table 12:	Status changes when booting the operating system loader.....	23
Table 13:	Setting the POWERLINK station number.....	23
Table 14:	8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1 - Order data.....	25
Table 15:	8BVI0014HCSS.000-1, 8BVI0014HWSS.000-1 - Technical data.....	26
Table 16:	8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Order data.....	29
Table 17:	8BVI0028HCSS.000-1, 8BVI0028HWSS.000-1 - Technical data.....	30
Table 18:	8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1 - Order data.....	34
Table 19:	8BVI0055HCSS.000-1, 8BVI0055HWSS.000-1 - Technical data.....	35
Table 20:	8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Order data.....	38
Table 21:	8BVI0110HCSS.000-1, 8BVI0110HWSS.000-1 - Technical data.....	39
Table 22:	X2 connector - Pinout.....	43
Table 23:	X3A, X3B connectors - Pinout.....	44
Table 24:	X4A connector - Pinout.....	44
Table 25:	X5A connector - Pinout.....	45
Table 26:	8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Order data.....	46
Table 27:	8BVI0220HCSS.000-1, 8BVI0220HWSS.000-1 - Technical data.....	47
Table 28:	8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Order data.....	50
Table 29:	8BVI0330HCSS.000-1, 8BVI0330HWSS.000-1 - Technical data.....	51
Table 30:	8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1 - Order data.....	55
Table 31:	8BVI0440HCSS.000-1, 8BVI0440HWSS.000-1 - Technical data.....	56
Table 32:	X2 connector - Pinout.....	60
Table 33:	X3A, X3B connectors - Pinout.....	60
Table 34:	X4A connector - Pinout.....	60
Table 35:	X5A connector - Pinout.....	61
Table 36:	8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1 - Order data.....	63
Table 37:	8BVI0014HCDS.000-1, 8BVI0014HWDS.000-1 - Technical data.....	64
Table 38:	8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1 - Order data.....	67
Table 39:	8BVI0028HCDS.000-1, 8BVI0028HWDS.000-1 - Technical data.....	68
Table 40:	8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Order data.....	71
Table 41:	8BVI0055HCDS.000-1, 8BVI0055HWDS.000-1 - Technical data.....	72
Table 42:	X2 connector - Pinout.....	76
Table 43:	X3A, X3B connectors - Pinout.....	77
Table 44:	X4A connector - Pinout.....	77
Table 45:	Pin assignments X4B plug.....	78
Table 46:	X5A connector - Pinout.....	79
Table 47:	X5B connector - Pinout.....	79
Table 48:	8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1 - Order data.....	81
Table 49:	8BVI0110HCDS.000-1, 8BVI0110HWDS.000-1 - Technical data.....	82
Table 50:	8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Order data.....	85
Table 51:	8BVI0220HCDS.000-1, 8BVI0220HWDS.000-1 - Technical data.....	86
Table 52:	X2 connector - Pinout.....	90
Table 53:	X3A, X3B connectors - Pinout.....	91
Table 54:	X4A connector - Pinout.....	91
Table 55:	Pin assignments X4B plug.....	92
Table 56:	X5A connector - Pinout.....	93
Table 57:	X5B connector - Pinout.....	93

Table 58:	8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Order data.....	95
Table 59:	8BVI0660HCSS.000-1, 8BVI0660HWSS.000-1 - Technical data.....	96
Table 60:	8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Order data.....	99
Table 61:	8BVI0880HCSS.004-1, 8BVI0880HWSS.004-1 - Technical data.....	100
Table 62:	X2 connector - Pinout.....	104
Table 63:	X3A, X3B connectors - Pinout.....	105
Table 64:	X4A connector - Pinout.....	105
Table 65:	X5A connector - Pinout.....	107
Table 66:	PE connection (1-wire) - Cable installation.....	107
Table 67:	PE connection (3-wire) - Cable installation.....	107
Table 68:	8BVI1650HCSS.000-1 - Order data.....	109
Table 69:	8BVI1650HCSS.000-1 - Technical data.....	110
Table 70:	X2 connector - Pinout.....	114
Table 71:	X3A, X3B connectors - Pinout.....	114
Table 72:	X4A connector - Pinout.....	114
Table 73:	X5A connector - Pinout.....	116
Table 74:	PE connection (1-wire) - Cable installation.....	116
Table 75:	PE connection (3-wire) - Cable installation.....	116
Table 76:	Safety functions and corresponding safety levels.....	128
Table 77:	Fields in the "Response time calculator".....	134
Table 78:	Meaning of the min./max. CPU parameters.....	135
Table 79:	Output fields in the "Response time calculator".....	135
Table 80:	Parameters for the safe response time in SafeDESIGNER.....	135
Table 81:	Wiring error in safe motor holding brake output.....	143
Table 82:	Encoder Monitoring safety function parameters.....	147
Table 83:	Safety characteristics Safe Torque Off (STO), Safe Stop 1 (SS1) time-monitored.....	149
Table 84:	Safety characteristics Safe Torque Off, single-channel (STO1).....	149
Table 85:	Safety characteristics Safe Brake Control (SBC).....	149
Table 86:	Safety characteristics Safe Operating Stop (SOS), Safe Stop 1 (SS1), Safe Stop 2 (SS2), Safely Limited Speed (SLS), Safe Direction (SDI), Safely Limited Increments (SLI), Safe Maximum Speed (SMS), Safely Limited Position (SLP), Safe Maximum Position (SMP), Safe Homing.....	149
Table 87:	Safety functions and corresponding safety levels.....	151
Table 88:	Functional Fail Safe state configuration parameters.....	152
Table 89:	Unit system parameters.....	154
Table 90:	STO1 safety function parameters.....	158
Table 91:	SBC safety function parameters.....	159
Table 92:	SOS safety function parameters.....	160
Table 93:	SS1 safety function parameters.....	161
Table 94:	SS2 safety function parameters.....	164
Table 95:	SLS safety function parameters.....	167
Table 96:	SMS safety function parameters.....	170
Table 97:	SLI safety function parameters.....	171
Table 98:	SDI safety function parameters.....	172
Table 99:	Parameters for the "safe homing" safety function.....	174
Table 100:	Parameters for the "safe homing" safety function - Direct mode.....	176
Table 101:	Parameters for the "safe homing" safety function - Reference Switch mode.....	177
Table 102:	Selecting the home switch edge.....	178
Table 103:	Parameters for the safety function "safe homing" - Modes: Home Offset / Home Offset with Correction.....	180
Table 104:	SLP safety function parameters.....	182
Table 105:	SMP safety function parameters.....	184
Table 106:	SafeMC parameter I/O configuration: Function model.....	185
Table 107:	SafeMC parameter I/O configuration: General.....	185
Table 108:	SafeMC parameter I/O configuration: Extended.....	185
Table 109:	SafeMC parameter group: Basic.....	186
Table 110:	SafeMC parameter group: Safety_Response_Time.....	186
Table 111:	SafeMC parameter group: Encoder Unit System.....	186
Table 112:	SafeMC parameter group: Safety deceleration ramp.....	186

Table 113:	SafeMC parameter group: General settings.....	186
Table 114:	SafeMC parameter group: Encoder Monitoring.....	186
Table 115:	SafeMC parameter group: Safety deceleration ramp.....	186
Table 116:	SafeMC parameter group: Safety Speed Limits.....	186
Table 117:	SafeMC parameter group: Safety Standstill and Direction Tolerances.....	186
Table 118:	SafeMC parameter group: Safely Limited Increment.....	186
Table 119:	SafeMC parameter group: Safety Ramp Monitoring Times.....	186
Table 120:	SafeMC parameter group: Safety Additional Parameters.....	186
Table 121:	SafeMC parameter group: Encoder Monitoring Tolerances.....	186
Table 122:	SafeMC parameter group: Basic.....	192
Table 123:	SafeMC parameter group: Safety_Response_Time.....	192
Table 124:	SafeMC parameter group: Encoder Unit System.....	192
Table 125:	SafeMC parameter group: Homing.....	192
Table 126:	SafeMC parameter group: Safety deceleration ramp.....	192
Table 127:	SafeMC parameter group: General settings.....	192
Table 128:	SafeMC parameter group: Encoder Monitoring.....	192
Table 129:	SafeMC parameter group: Safety deceleration ramp.....	192
Table 130:	SafeMC parameter group: Safety Speed Limits.....	192
Table 131:	SafeMC parameter group: Safety Position Limits.....	192
Table 132:	SafeMC parameter group: Safety Standstill and Direction Tolerances.....	192
Table 133:	SafeMC parameter group: Safely Limited Increment.....	192
Table 134:	SafeMC parameter group: Safety Ramp Monitoring Times.....	192
Table 135:	SafeMC parameter group: Safety Additional Parameters.....	192
Table 136:	SafeMC parameter group: Encoder Monitoring Tolerances.....	192
Table 137:	SafeMC channel list.....	198
Table 138:	Delay times for requesting a safety function.....	200
Table 139:	ACOPOSMulti parameter IDs for SafeMC .....	211
Table 140:	Status bits.....	212
Table 141:	Control bits.....	212
Table 142:	SafeMC_action().....	213
Table 143:	Test matrix for the safety functions.....	217
Table 144:	SF_SafeMC_BR: Overview of input parameters.....	222
Table 145:	SF_SafeMC_BR: Overview of output parameters.....	222
Table 146:	SF_SafeMC_BR: Formats of data types used.....	223
Table 147:	SF_SafeMC_BR: Module parameter.....	224
Table 148:	Safety functions and corresponding safety levels.....	226
Table 149:	Functional Fail Safe state configuration parameters.....	227
Table 150:	Unit system parameters.....	229
Table 151:	STO1 safety function parameters.....	233
Table 152:	SBC safety function parameters.....	234
Table 153:	SOS safety function parameters.....	235
Table 154:	SS1 safety function parameters.....	236
Table 155:	SS2 safety function parameters.....	239
Table 156:	SLS safety function parameters.....	242
Table 157:	SMS safety function parameters.....	245
Table 158:	SLI safety function parameters.....	246
Table 159:	SDI safety function parameters.....	247
Table 160:	Parameters for the "safe homing" safety function.....	249
Table 161:	Parameters for the "safe homing" safety function - Direct mode.....	251
Table 162:	Parameters for the "safe homing" safety function - Reference Switch mode.....	252
Table 163:	Selecting the home switch edge.....	253
Table 164:	Parameters for the safety function "safe homing" - Modes: Home Offset / Home Offset with Correction.....	255
Table 165:	SLP safety function parameters.....	257
Table 166:	SMP safety function parameters.....	259
Table 167:	STO1 safety function parameters.....	266
Table 168:	SBC safety function parameters.....	267

Table 169:	SOS safety function parameters.....	268
Table 170:	SS1 safety function parameters.....	269
Table 171:	SS2 safety function parameters.....	271
Table 172:	SLS1 safety function parameters.....	272
Table 173:	SLS2 safety function parameters.....	273
Table 174:	SLS3 safety function parameters.....	274
Table 175:	SLS4 safety function parameters.....	275
Table 176:	SLI safety function parameters.....	276
Table 177:	SDI safety function parameters.....	277
Table 178:	SDI safety function parameters.....	278
Table 179:	Parameter Reset.....	279
Table 180:	SF_SafeMC_BR(_V2): Diagnostic codes.....	300
Table 181:	SF_SafeMC_BR: SafeMC module status bits .....	301
Table 182:	SF_SafeMC_BR_V2: Overview of input parameters.....	304
Table 183:	SF_SafeMC_BR_V2: Overview of output parameters.....	304
Table 184:	SF_SafeMC_BR_V2: Formats of data types used.....	305
Table 185:	SF_SafeMC_BR_V2: Module parameter.....	306
Table 186:	Safety functions and corresponding safety levels.....	309
Table 187:	Functional Fail Safe state configuration parameters.....	310
Table 188:	Unit system parameters.....	312
Table 189:	STO1 safety function parameters.....	316
Table 190:	SBC safety function parameters.....	317
Table 191:	SOS safety function parameters.....	318
Table 192:	SS1 safety function parameters.....	319
Table 193:	SS2 safety function parameters.....	322
Table 194:	SLS safety function parameters.....	325
Table 195:	SMS safety function parameters.....	328
Table 196:	SLI safety function parameters.....	329
Table 197:	SDI safety function parameters.....	330
Table 198:	Parameters for the "safe homing" safety function.....	332
Table 199:	Parameters for the "safe homing" safety function - Direct mode.....	334
Table 200:	Parameters for the "safe homing" safety function - Reference Switch mode.....	335
Table 201:	Selecting the home switch edge.....	336
Table 202:	Parameters for the safety function "safe homing" - Modes: Home Offset / Home Offset with Correction.....	338
Table 203:	SLP safety function parameters.....	340
Table 204:	SMP safety function parameters.....	342
Table 205:	Encoder Monitoring safety function parameters.....	346
Table 206:	STO1 safety function parameters.....	353
Table 207:	SBC safety function parameters.....	354
Table 208:	SOS safety function parameters.....	355
Table 209:	SS1 safety function parameters.....	356
Table 210:	SS2 safety function parameters.....	358
Table 211:	SLS1 safety function parameters.....	359
Table 212:	SLS2 safety function parameters.....	360
Table 213:	SLS3 safety function parameters.....	361
Table 214:	SLS4 safety function parameters.....	362
Table 215:	SLI safety function parameters.....	363
Table 216:	SDI safety function parameters.....	364
Table 217:	SDI safety function parameters.....	365
Table 218:	SLP safety function parameters.....	366
Table 219:	Parameters for the "safe homing" safety function.....	368
Table 220:	Parameter Reset.....	371
Table 221:	SF_SafeMC_BR(_V2): Diagnostic codes.....	394
Table 222:	SF_SafeMC_BR_V2: SafeMC module status bits .....	395
Table 223:	SF_SafeMC_Speed_BR: Overview of input parameters.....	397
Table 224:	SF_SafeMC_Speed_BR: Overview of output parameters.....	397

Table 225:	SF_SafeMC_Speed_BR: Formats of data types used.....	397
Table 226:	SF_SafeMC_Position_BR: Overview of input parameters.....	403
Table 227:	SF_SafeMC_Position_BR: Overview of output parameters.....	403
Table 228:	SF_SafeMC_Position_BR: Formats of data types used.....	403
Table 229:	Applicable standards for ACOPOS servo drives.....	410
Table 230:	Mechanical conditions during operation.....	410
Table 231:	Mechanical conditions during transport.....	411
Table 232:	Climate conditions during operation.....	411
Table 233:	Climate conditions (temperature) during storage.....	411
Table 234:	Climate conditions (humidity) during storage.....	411
Table 235:	Climate conditions during transport.....	411
Table 236:	Evaluation criteria (performance criteria) for immunity to disturbances.....	412
Table 237:	Limit values for power mains harmonics.....	412
Table 238:	Limit values for commutation notches / voltage distortions.....	412
Table 239:	Limit values for voltage changes and fluctuations.....	412
Table 240:	Limit values for voltage dips and short-term interruptions.....	412
Table 241:	Limit values for asymmetric voltages and frequency changes.....	412
Table 242:	Limits for electrostatic discharge.....	413
Table 243:	Limits for electromagnetic fields.....	413
Table 244:	Limits for burst.....	413
Table 245:	Limits for surge.....	413
Table 246:	Limits for high-frequency conducted disturbances.....	413
Table 247:	Limits for disturbance voltages on the power connections.....	414
Table 248:	Limit values for electro-magnetic emissions.....	414
Table 249:	Additional environmental limit values.....	414
Table 250:	International certifications.....	415
Table 251:	Overview of stop function categories.....	416
Table 252:	Overview of Performance Levels (PL).....	416

<b>3</b>	
3-phase industrial power mains.....	14
<b>A</b>	
Accident prevention regulations.....	13
<b>C</b>	
Calculating the safe response time.....	133
Certifications.....	415
<b>D</b>	
Directives.....	410
Disposal.....	17
<b>E</b>	
Emergency stops.....	416
Environmentally friendly disposal.....	17
Environmentally friendly separation of materials.....	17, 17
ESD.....	14
ESD protective measures.....	15
E-stop button.....	16
European directives.....	410
Evaluation criteria for immunity to disturbances.....	412, 412
<b>G</b>	
Ground (PE rail).....	15
Ground connections.....	15
Guidelines for ESD handling.....	14
<b>H</b>	
Hazards.....	13
<b>I</b>	
Internal monitoring.....	16
<b>M</b>	
Machine guidelines.....	14
<b>O</b>	
Operation.....	15
<b>P</b>	
Packaging.....	14
Performance criteria for immunity to disturbances.....	412, 412
Performance Levels (PL).....	416
Proper ESD handling.....	14
Protective equipment.....	15

**Q**

Qualified personnel.....	13
--------------------------	----

**R**

Restart inhibit.....	418
Risk assessment.....	417
Risk graph.....	417
Risk parameters.....	417

**S**

Safe response time.....	131
Safety Features.....	16
Safety integrity level - SIL.....	416
Safety-related parts of a control system.....	416
Starting of machines.....	418
Stop function categories.....	416
Stop functions.....	416
Storage.....	15

**T**

Third-party line filters.....	122
TN networks.....	14
Transport.....	15
TT networks.....	14

**W**

Warning label.....	16
--------------------	----



8BVI0014HCDS.000-1.....	63
8BVI0014HCSS.000-1.....	25
8BVI0014HWDS.000-1.....	63
8BVI0014HWSS.000-1.....	25
8BVI0028HCDS.000-1.....	67
8BVI0028HCSS.000-1.....	29
8BVI0028HWDS.000-1.....	67
8BVI0028HWSS.000-1.....	29
8BVI0055HCDS.000-1.....	71
8BVI0055HCSS.000-1.....	34
8BVI0055HWDS.000-1.....	71
8BVI0055HWSS.000-1.....	34
8BVI0110HCDS.000-1.....	81
8BVI0110HCSS.000-1.....	38
8BVI0110HWDS.000-1.....	81
8BVI0110HWSS.000-1.....	38
8BVI0220HCDS.000-1.....	85
8BVI0220HCSS.000-1.....	46
8BVI0220HWDS.000-1.....	85
8BVI0220HWSS.000-1.....	46
8BVI0330HCSS.000-1.....	50
8BVI0330HWSS.000-1.....	50
8BVI0440HCSS.000-1.....	55
8BVI0440HWSS.000-1.....	55
8BVI0660HCSS.000-1.....	95
8BVI0660HWSS.000-1.....	95
8BVI0880HCSS.004-1.....	99
8BVI0880HWSS.004-1.....	99
8BVI1650HCSS.000-1.....	109