1.7 RS485 BUS CONNECTOR

1.7.1 Order Data



1.7.2 General Information

The RS485 bus connector is used to connect a controller to remote I/O, in a PROFIBUS network or in a RS485 network. The termination resistor is integrated in the bus connector. The terminating resistor can be turned on or off.

General Accessories 609