Automation PC 810

User's Manual

Version: **1.34 (July 2011)**

Model number: **MAAPC800-ENG**

All information contained in this manual is current as of its creation/publication. We reserve the right to change the contents of this manual without warning. The information contained herein is believed to be accurate as of the date of publication; however, Bernecker + Rainer Industrie-Elektronik Ges.m.b.H. makes no warranty, expressed or implied, with regard to the products or documentation contained within this manual. In addition, Bernecker + Rainer Industrie-Elektronik Ges.m.b.H. shall not be liable in the event of incidental or consequential damages in connection with or resulting from the furnishing, performance, or use of these products. The software names, hardware names, and trademarks used in this document are registered by the respective companies.

Chapter 1: General information

Chapter 2: Technical data

Chapter 3: Commissioning

Chapter 4: Software

Chapter 5: Standards and certifications

Chapter 6: Accessories

Chapter 7: Maintenance / Servicing

Appendix A

Figure index

Table index

Model number index

Index

Chapter 1: General information 19

1. Manual history 19
2. Safety notices 24
   2.1 Intended use 24
   2.2 Protection against electrostatic discharges 24
      2.2.1 Packaging 24
      2.2.2 Guidelines for proper ESD handling 24
   2.3 Policy and procedures 25
   2.4 Transport and storage 25
   2.5 Installation 26
   2.6 Operation 26
      2.6.1 Protection against touching electrical parts 26
      2.6.2 Environmental conditions - dust, humidity, aggressive gases 26
      2.6.3 Programs, viruses, and dangerous programs 27
   2.7 Environmentally-friendly disposal 27
      2.7.1 Separation of materials 27
3. Organization of safety notices 28
4. Guidelines 28
5. Model numbers 29
   5.1 System units 29
   5.2 Bus units 29
   5.3 CPU boards 945GME COM Express 30
   5.4 Heat sink 30
   5.5 Main memory 31
   5.6 Drives 31
   5.7 Fan kits 32
   5.8 AP Link cards 32
   5.9 Add-on interfaces (IF option) 32
   5.10 Uninterruptible power supply 32
   5.11 Accessories 33
      5.11.1 Supply voltage connectors 33
      5.11.2 Batteries 33
      5.11.3 CompactFlash cards 33
      5.11.4 USB accessories 34
      5.11.5 Cables 34
      5.11.6 PCI cards 36
      5.11.7 Power supplies 36
      5.11.8 Replacement fan 36
      5.11.9 Miscellaneous 37
   5.12 Software 37
6. Typical topology 40
   6.1 APC810 for central control and visualization 40
   6.2 APC810 as a visualization device 41

Chapter 2: Technical data 43

1. Introduction 43

1.1 Features 44
1.2 System components / configuration 44
1.3 Configuration - Basic system 45
1.4 Configuration - Drives, software, accessories 46
2. Entire device 47
2.1 Overview of APC810 1 card slot variations 47
2.1.1 Interfaces 47
2.1.2 Technical data 49
2.1.3 Dimensions 51
2.2 Overview of APC810 2 card slot variations 52
2.2.1 Interfaces 52
2.2.2 Technical data 54
2.2.3 Dimensions 56
2.3 Overview of APC810 3 card slot variations 57
2.3.1 Interfaces 57
2.3.2 Technical data 59
2.3.3 Dimensions 61
2.4 Overview of APC810 5 card slot variations 62
2.4.1 Interfaces 62
2.4.2 Technical data 64
2.4.3 Dimensions 66
2.5 Ambient temperatures 67
2.5.1 Maximum ambient temperature without a fan kit 68
2.5.2 Maximum ambient temperature with a fan kit 71
2.5.3 Minimum ambient temperature 73
2.5.4 How is the the maximum ambient temperature determined? 73
2.5.5 Temperature monitoring 73
2.6 Humidity specifications 74
2.7 Power management 75
2.7.1 Block diagram - supply voltage 75
2.7.2 Power calculation with 5PC810.SX01-00 revision >= D0 76
2.7.3 Power calculation with 5PC810.SX01-00 revision < D0 77
2.7.4 Power calculation with 5PC810.SX02-00 revision>= D0 78
2.7.5 Power calculation with 5PC810.SX02-00 revision < D0 79
2.7.6 Power calculation with 5PC810.SX03-00 80
2.7.7 Power calculation with 5PC810.SX05-00 81
2.8 Serial number sticker 82
2.9 Block diagram 84
2.9.1 System unit 5PC810.SX01-00 + bus unit 5PC810.BX01-00 84
2.9.2 System unit 5PC810.SX01-00 + bus unit 5PC810.BX01-01 85
2.9.3 System unit 5PC810.SX02-00 + bus unit 5PC810.BX02-00 86
2.9.4 System unit 5PC810.SX02-00 + bus unit 5PC810.BX02-01 87
2.9.5 System unit 5PC810.SX03-00 + bus unit 5PC810.BX03-00 88
2.9.6 System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-00 89
2.9.7 System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-01 90
2.9.8 System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-02 91
2.10 Device interfaces 92

2.10.1 +24 VDC supply voltage 92
2.10.2 Serial interface COM1 94
2.10.3 Serial interface COM2 95
2.10.4 Monitor / Panel connection - SDL (Smart Display Link / DVI) 95
2.10.5 Ethernet 1 (ETH1) 96
2.10.6 Ethernet 2 (ETH2) 98
2.10.7 USB interfaces (USB1, 2, 3, 4, 5) 99
2.10.8 MIC, Line IN, Line OUT 101
2.10.9 Add-on interface slot 102
2.10.10 Add-on UPS slot 103
2.10.11 AP Link slot 103
2.10.12 Card slot (PCI / PCIe) 104
2.10.13 Status LEDs 105
2.10.14 CMOS profile switch 106
2.10.15 Power button 107
2.10.16 Reset button 107
2.10.17 Battery 108
2.10.18 Hardware security key 109
2.10.19 CompactFlash slot 1 110
2.10.20 CompactFlash slot 2 111
2.10.21 Slide-in slot 1 112
2.10.22 Slide-in slot 2 113
2.10.23 Slide-in compact slot 114
3. Individual components 115
3.1 System units 115
3.1.1 Technical data 115
3.2 Bus units 117
3.2.1 Technical data 118
3.3 CPU boards 945GME 119
3.3.1 Technical data 119
3.4 Heat sink 120
3.4.1 Technical data 120
3.5 Main memory 121
3.5.1 Technical data 121
3.6 Drives 122
3.6.1 Slide-in compact HDD 40GB EE25 - 5AC801.HDDI-00 122
3.6.2 Slide-in compact HDD 80GB EE25 - 5AC801.HDDI-01 125
3.6.3 Slide-in compact HDD 160 GB 24x7 ET - 5AC801.HDDI-02 128
3.6.4 Slide-in compact HDD 250GB - 5AC801.HDDI-03 131
3.6.5 Slide-in compact SSD - 5AC801.SSDI-00 134
3.6.6 Hard disk adapter (slide-in compact) - 5AC801.ADAS-00 138
3.6.7 Slide-in HDD EE25 - 5AC801.HDDS-00 139
3.6.8 Slide-in DVD-ROM - 5AC801.DVDS-00 142
3.6.9 Slide-in DVD-R/RW - 5AC801.DVRS-00 145
3.6.10 PCI SATA RAID controller - 5ACPCI.RAIC-01 148
3.6.11 Replacement PCI SATA RAID HDD 60GB - 5ACPCI.RAIC-02 152
3.6.12 PCI SATA RAID 2 x 160 GB 24x7 ET - 5ACPCI.RAIC-03 155

3.6.13 Replacement PCI SATA RAID HDD 160 GB - 5ACPCI.RAIC-04 159
3.6.14 PCI SATA RAID 2 x 250 GB - 5ACPCI.RAIC-05 162
3.6.15 Replacement SATA HDD 250 GB - 5MMHDD.0250-00 166
3.7 Fan kit 169
3.7.1 Fan kit 1 card slot - 5PC810.FA01-00 169
3.7.2 Fan kit 2 card slot - 5PC810.FA02-00 and 5PC810.FA02-01 171
3.7.3 Fan kit 3 card slot - 5PC810.FA03-00 172
3.7.4 Fan kit 5 card slot - 5PC810.FA05-00 173
3.8 AP Link cards 174
3.8.1 AP Link SDL transmitter 5AC801.SDL0-00 174
3.8.2 Ready relay 5AC801.RDYR-00 177
3.9 Add-on interfaces (IF option) 179
3.9.1 Add-on CAN interface - 5AC600.CANI-00 180
3.9.2 Add-on RS232/422/485 interface - 5AC600.485I-00 184

Chapter 3: Commissioning 189

1. Installation 189
1.1 Important mounting information 189
1.2 Drilling templates 190
1.3 Mounting orientation 192
1.3.1 Standard mounting - vertical 192
1.3.2 Optional mounting - horizontal 192
1.3.3 Spacing for air circulation. 193
2. Cable connections 194
3. Grounding concept 195
4. Connection examples 196
4.1 Selecting the display units 196
4.2 One Automation Panel 900 via DVI (onboard) 196
4.2.1 Basic system requirements 197
4.2.2 Link modules 198
4.2.3 Cables 198
4.2.4 Possible Automation Panel units, resolutions und segment lengths 198
4.2.5 BIOS settings 199
4.3 An Automation Panel 900 via SDL (onboard) 200
4.3.1 Basic system requirements 200
4.3.2 Link modules 201
4.3.3 Cables 201
4.3.4 BIOS settings 202
4.4 An Automation Panel 800 via SDL (onboard) 203
4.4.1 Basic system requirements 203
4.4.2 Cables 204
4.4.3 BIOS settings 204
4.5 An AP900 and an AP800 via SDL (onboard) 206
4.5.1 Basic system requirements 206
4.5.2 Link modules 207
4.5.3 Cables 207

4.5.4 BIOS settings 207
4.6 Four Automation Panel 900 units via SDL (onboard) 208
4.6.1 Basic system requirements 208
4.6.2 Link modules 209
4.6.3 Cables 209
4.6.4 BIOS settings 210
4.7 One Automation Panel 900 unit via SDL (AP Link) 212
4.7.1 Basic system requirements 212
4.7.2 Link modules 213
4.7.3 Cables 213
4.7.4 BIOS settings 214
4.8 Four Automation Panel 900 units via SDL (AP Link) 215
4.8.1 Basic system requirements 215
4.8.2 Link modules 216
4.8.3 Cables 216
4.8.4 BIOS settings 218
4.9 Two Automation Panel 900 units via SDL (onboard) and SDL (AP Link) 219
4.9.1 Basic system requirements 219
4.9.2 Link modules 220
4.9.3 Cables 220
4.9.4 BIOS settings 221
4.10 Eight Automation Panel 900 units via SDL (onboard) and SDL (AP Link) 222
4.10.1 Basic system requirements 223
4.10.2 Link modules 223
4.10.3 Cables 223
4.10.4 BIOS settings 225
4.11 Six AP900 and two AP800 devices via SDL (onboard) and SDL (AP Link) 226
4.11.1 Basic system requirements 227
4.11.2 Link modules 227
4.11.3 Cables 227
5. Connection of USB peripheral devices 229
5.1 Local on the APC810 229
5.2 Remote connection to Automation Panel 900 via DVI 230
5.3 Remote connection to Automation Panel 800/900 via SDL 231
6. Configuration of a SATA RAID array 232
6.1 Create RAID set 233
6.1.1 Create RAID set - Striped 234
6.1.2 Create RAID set - Mirrored 235
6.2 Delete RAID set 236
6.3 Rebuild mirrored set 237
6.4 Resolve conflicts 238
6.5 Low level format 239
7. Known problems / issues 240

Chapter 4: Software 243
1. BIOS options 243

1.1 General information 243
1.2 BIOS setup and boot procedure 243
1.2.1 BIOS setup keys 244
1.3 Main 246
1.4 Advanced 247
1.4.1 ACPI configuration 249
1.4.2 PCI Configuration 251
1.4.3 PCI express configuration 255
1.4.4 Graphics configuration 257
1.4.5 CPU configuration 261
1.4.6 Chipset configuration 262
1.4.7 I/O interface configuration 264
1.4.8 Clock Configuration 265
1.4.9 IDE Configuration 266
1.4.10 USB configuration 274
1.4.11 Keyboard/mouse configuration 276
1.4.12 Remote access configuration 277
1.4.13 CPU board monitor 279
1.4.14 Main Board/Panel Features 280
1.5 Boot 286
1.6 Security 288
1.6.1 Hard disk security user password 289
1.6.2 Hard disk security master password 290
1.7 Power 291
1.8 Exit 293
1.9 BIOS default settings 294
1.9.1 Main 295
1.9.2 Advanced 295
1.9.3 Boot 303
1.9.4 Security 304
1.9.5 Power 304
1.10 BIOS Error signals (beep codes) 306
1.10.1 BIOS 945GME 306
1.11 Distribution of resources 307
1.11.1 RAM address assignment 307
1.11.2 I/O address assignment 308
1.11.3 Interrupt assignments in PCI mode 309
1.11.4 Interrupt assignments in APIC mode 310
2. Upgrade information 314
2.1 BIOS upgrade 314
2.1.1 What information do I need? 314
2.1.2 BIOS upgrade for 945GME COM Express 317
2.2 Firmware upgrade 318
2.2.1 Procedure 318
2.2.2 Possible upgrade problems and software dependencies (for V1.00) 321
2.3 Creating an MS-DOS boot diskette in Windows XP 322
2.4 Creating a bootable USB flash drive for B&R upgrade files 324

2.4.1 Requirements 324
2.4.2 Procedure 324
2.4.3 Where do I get MS-DOS? 325
2.5 Creating a bootable CompactFlash card for B&R upgrade files 326
2.5.1 Requirements 326
2.5.2 Procedure 326
2.5.3 Where do I get MS-DOS? 327
2.6 Upgrade problems 327
3. Automation PC 810 with MS-DOS 328
3.1 Known problems 328
4. Automation PC 810 with Windows XP Professional 330
4.1 Installation 330
4.1.1 Installation on PCI SATA RAID controller - 5ACPCI.RAIC-03, 5ACPCI.RAIC-05 331
4.1.2 For 5PCI slot model 331
4.2 Drivers 332
5. Automation PC 810 with Windows 7 333
5.1 Installation 333
5.1.1 Installation on PCI SATA RAID controller - 5ACPCI.RAIC-03, 5ACPCI.RAIC-05 334
5.1.2 Special considerations for the 5PCI slot model 334
5.2 Drivers 335
5.3 Special considerations, limitations: 335
6. Automation PC 810 with Windows XP Embedded 336
6.1 General information 336
6.2 Features with FP2007 (Feature Pack 2007) 337
6.3 Installation 338
6.4 Drivers 338
6.4.1 Touch screen driver 338
7. Automation PC 810 with Windows Embedded Standard 2009 339
7.1 General information 339
7.2 Features with WES2009 (Windows Embedded Standard 2009) 340
7.3 Installation 341
7.4 Drivers 341
7.4.1 Touch screen driver 341
8. Automation PC 810 with Windows Embedded Standard 7 342
8.1 General Information 342
8.2 Features with WES7 (Windows Embedded Standard 7) 343
8.3 Installation 344
8.4 Drivers 344
8.4.1 Touch screen driver 344
9. Automation PC 810 with Windows CE 345
9.1 General information 345
9.2 Windows CE 6.0 features 346
9.3 Requirements 347
9.4 Installation 347
9.4.1 B&R Embedded OS Installer 347
10. Automation PC 810 with Automation Runtime 348
10.1 General information 348

10.2 Automation Runtime Windows (ARwin) 348
10.3 Automation Runtime Embedded (ARemb) 348
11. B&R Automation Device Interface (ADI) - Control Center 349
11.1 Functions 350
11.2 Installation 351
11.3 SDL equalizer setting 352
11.4 UPS configuration 353
11.4.1 Installing the UPS service for the B&R APC add-on UPS 354
11.4.2 Displaying UPS status values 354
11.4.3 Changing UPS battery settings 356
11.4.4 Updating UPS battery settings 357
11.4.5 Saving UPS battery settings 358
11.4.6 Configuring UPS system settings 358
11.4.7 Changing additional UPS settings 360
11.4.8 Procedure following power failure 362

Chapter 5: Standards and certifications 363
1. Applicable European directives 363
2. Overview of standards 363
3. Emission requirements 365
3.1 Network-related emissions 366
3.2 Emissions, electromagnetic emissions 367
4. Requirements for immunity to disturbances 368
4.1 Electrostatic discharge (ESD) 369
4.2 High-frequency electromagnetic fields (HF field) 369
4.3 High-speed transient electrical disturbances (burst) 369
4.4 Surges 370
4.5 Conducted disturbances 370
4.6 Magnetic fields with electrical frequencies 371
4.7 Voltage dips, fluctuations and short-term interruptions 371
4.8 Damped vibration 371
5. Mechanical conditions 372
5.1 Vibration operation 372
5.2 Vibration during transport (packaged) 373
5.3 Shock during operation 373
5.4 Shock during transport (packaged) 373
5.5 Toppling 373
5.6 Free fall (packaged) 374
6. Climate conditions 375
6.1 Worst case operation 375
6.2 Dry heat 375
6.3 Dry cold 375
6.4 Large temperature fluctuations 376
6.5 Temperature fluctuations in operation 376
6.6 Humid heat, cyclic 376
6.7 Humid heat, constant (storage) 376

7. Safety 377
7.1 Ground resistance 377
7.2 Insulation resistance 378
7.3 High voltage 378
7.4 Residual voltage 378
7.5 Leakage current 379
7.6 Overload 379
7.7 Defective component 379
7.8 Voltage range 379
8. Other tests 380
8.1 Protection 380
9. International certifications 381

Chapter 6: Accessories 383
1. Overview 383
2. TB103 3-pin supply voltage connector 387
2.1 General information 387
2.2 Order data 387
2.3 Technical data 387
3. Replacement CMOS batteries 389
3.1 Order data 389
3.2 Technical data 389
4. Replacement fan 390
5. DVI - monitor adapter 5AC900.1000-00 391
5.1 Order data 391
6. CompactFlash cards 5CFCRD.xxxx-04 392
6.1 General information 392
6.2 Order data 392
6.3 Technical data 393
6.3.1 Temperature humidity diagram 395
6.4 Dimensions 395
6.5 Benchmark 396
7. CompactFlash cards - 5CFCRD.xxxx-03 397
7.1 General information 397
7.2 Order data 397
7.3 Technical data 398
7.3.1 Temperature humidity diagram 400
7.4 Dimensions 400
8. USB Media Drive - 5MD900.USB2-01 401
8.1 Order data 401
8.2 Features 401
8.3 Technical data 402
8.4 Dimensions 404
8.5 Dimensions with front cover 405
8.5.1 Cutout installation 405
8.6 Contents of delivery 406

8.7 Interfaces ... 406
8.8 Installation ... 406
8.8.1 Mounting orientation ... 406
8.9 Front cover 5A5003.03 for the USB Media Drive ... 407
8.9.1 Technical data ... 407
8.9.2 Dimensions ... 407
8.9.3 Installation ... 408
8.9.4 Cutout installation ... 408
9. USB flash drive ... 409
9.1 General information ... 409
9.2 Order data ... 409
9.3 Technical data - 5MMUSB.2048-00 ... 410
9.3.1 Temperature humidity diagram ... 411
9.4 Technical data - 5MMUSB.2048-01 ... 412
9.4.1 Temperature humidity diagram ... 413
10. B&R Automation Runtime Dongle ... 414
10.1 General information ... 414
10.2 Order data ... 414
11. Uninterruptible power supply UPS ... 415
11.1 Order data ... 416
11.2 Features ... 416
11.3 Requirements ... 416
11.4 Individual components ... 417
11.4.1 Add-on UPS module 5AC600.UPSI-00 ... 417
11.4.2 Battery unit 5AC600.UPSB-00 ... 419
11.4.3 UPS connection cable ... 423
12. Power supplies ... 424
12.1 Order data and brief technical overview ... 424
12.1.1 Single-phase power supplies ... 424
12.1.2 Three-phase power supplies ... 425
13. PCI cards ... 426
13.1 PCI Ethernet card 10/100 1port - 5ACPCI.ETH1-01 ... 426
13.1.1 Order data ... 426
13.1.2 Technical data ... 427
13.1.3 Driver support ... 427
13.1.4 Dimensions ... 428
13.2 PCI Ethernet card 10/100 - 5ACPCI.ETH3-01 ... 429
13.2.1 Order data ... 429
13.2.2 Technical data ... 430
13.2.3 Driver support ... 430
13.2.4 Dimensions ... 431
14. Cables ... 432
14.1 DVI cable 5CADVI.0xxx-00 ... 432
14.1.1 Order data ... 432
14.1.2 Technical data ... 433
14.1.3 Flex radius specification ... 433
14.1.4 Dimensions ... 434

14.1.5 Contents of delivery 434
14.1.6 Cable specifications 435
14.2 SDL cable 5CASDL.0xxx-00 436
14.2.1 Order data 436
14.2.2 Technical data 437
14.2.3 Flex radius specification 437
14.2.4 Dimensions 438
14.2.5 Contents of delivery 438
14.2.6 Cable specifications 439
14.3 SDL cable with 45° plug 5CASDL.0xxx-01 440
14.3.1 Order data 440
14.3.2 Technical data 441
14.3.3 Flex radius specification 441
14.3.4 Dimensions 442
14.3.5 Contents of delivery 442
14.3.6 Cable specifications 443
14.4 SDL flex cable 5CASDL.0xxx-03 444
14.4.1 Order data 444
14.4.2 Technical data 445
14.4.3 Flex radius specification 446
14.4.4 Dimensions 446
14.4.5 Contents of delivery 447
14.4.6 Construction 447
14.4.7 Cable specifications 448
14.5 SDL flex cable with extender 5CASDL.0x00-13 449
14.5.1 Order data 449
14.5.2 Technical data 449
14.5.3 Flex radius specification 451
14.5.4 Dimensions 451
14.5.5 Contents of delivery 451
14.5.6 Cable specifications 452
14.6 RS232 cable 453
14.6.1 Order data 453
14.6.2 Technical data 453
14.6.3 Contents of delivery 453
14.6.4 Cable specifications 454
14.7 USB cable 455
14.7.1 Order data 455
14.7.2 Technical data 455
14.7.3 Contents of delivery 455
14.7.4 Cable specifications 456
14.8 APC810 internal supply cable 5CAMSC.0001-00 457
14.8.1 Order data 457
14.8.2 Technical data 457
15. HDD replacement tray 5AC801.FRAM-00 458
15.1 Order data 458
15.2 Dimensions 459

16. Ready relay 5AC801.RDYR-01 460
16.1 Order data 460
16.2 Pin assignments 460
16.3 Contents of delivery 461
17. HMI Drivers & Utilities DVD 5SWHMI.0000-00 462

Chapter 7: Maintenance / Servicing 467
1. Changing the battery 467
1.1 Procedure 468
2. Installing / exchanging a slide-in compact drive 470
3. Installing / exchanging a slide-in slot drive 471
3.1 Procedure 471
4. Installing the slide-in compact adapter 472
4.1 Procedure 472
5. Installing / exchanging the fan kit 474
6. Installing the UPS module 476
6.1 Installation without installed add-on interface module 476
6.1.1 APC810 1 card slot 476
6.1.2 APC810 2 and 3 card slot 478
6.1.3 APC810 5 card slot 481
6.2 Installation with installed add-on interface module 483
6.2.1 APC810 1 card slot 483
6.2.2 APC810 2 and 3 card slot 485
6.2.3 APC810 5 card slot 487
7. Mounting the side cover 489
7.1 APC810 with 1 card slot 489
7.2 APC810 with 2 and 3 card slot 489
7.3 APC810 with 5 card slot 490
8. AP Link installation 491
9. Exchanging a PCI SATA RAID hard disk in a RAID 1 system 492
9.1 Exchange procedure 492
10. Installing the HDD replacement disk tray 494
11. Installing the ready relay /2 in the add-on UPS slot 495

Appendix A: 497
1. Temperature sensor locations 497
2. Maintenance Controller Extended (MTCX) 498
2.1 Temperature monitoring - Fan control 499
3. Connection of an external device to the main board 500
4. B&R Key Editor information 501
5. B&R Automation Device Interface (ADI) development kit 503
6. B&R Automation Device Interface (ADI) .NET SDK 505
7. Glossary 507

Chapter 1 • General information

1. Manual history

Version	Date	Change
0.10 Preliminary	2007-11-20	- First version
0.20 Preliminary	2008-01-11	- Text changed in the brief system unit text - Text change made to 945GME (instead of 945GM) - 256 MB main memory removed. - 5AC801.ADAS-00 and 5AC801.HDDS-00 added. - Accessories added. - Ready relay 5AC801.RDYR-00, SATA RAID controller, fan kit, IF options, replacement fan filter added. - BIOS description added.
0.30 Preliminary	2008-01-31	- Mistake regarding the configuration corrected. - BIOS default profile added. - Name change from APC810 to APC800 and model number change - Technical data for the entire device updated. - Connection examples added. - Problems and properties of the first production lot added.
0.40 Preliminary	2008-04-11	- Problems and properties of the first production lot revised. - Section "Temperature sensor locations", on page 497 in chapter appendix A expanded. - "Ambient temperatures", on page 67 added. - System unit with 1 card slot added. - Content changes (especially in "Maintenance / Servicing" chapter). -BIOS description for Version 1.10 revised.
0.41 Preliminary	2008-05-09	- Graphic corrections to "Ambient temperatures with and without a fan kit". - Measurement values of the 1 and 2 card slot devices around the heat sink 5AC801.HS00-01 updated. - "Power management" section added. - Serial number sticker information updated - Section "Automation PC 810 with Windows XP Professional and Windows XP embedded" added. - "Automation Device Interface (ADI)" expanded. - 5 card slot variants added. - Drilling templates added for 5-card slot variants. - Section "Connection of USB peripheral devices", on page 229Connection of USB peripheral devices added. - Index expanded
0.42 Preliminary	2008-05-29	- Information for mounting orientation (vertical, horizontal) added in Chapter 3 "Commissioning". - Ambient temperature values with and without a fan kit regarding mounting orientation (vertical, horizontal) updated. Error correction (Fan kit model numbers) in Figure 4 "Configuration - Drives, software, accessories", on page 46. - Error correction (pin assignments) in Table 29 "Supply voltage connection + 24VDC", on page 92. - Slide-in slot 2 description revised. - Slide-in DVD burner 5AC801.DVDS-00 added. - Fan kit for the 5-card slot variant (5PC810.FA05-00) added.

Table 1: Manual history

Version	Date	Change
		- Real-time clock (RTC) specifications added.
1.00	2008-07-10	- Spelling and grammar errors corrected. - Block diagram of all system units according to the bus unit added (see section "Block diagram", on page 84.) - Description of the add-on interface module 5AC600.485I-00 updated.
1.10	2008-09-12	- Spelling and grammar errors corrected. - Values of the starting current changed (because of new power supply). - PCI Ethernet cards 5ACPCI.ETH1-01and 5ACPCI.ETH3-01 added. - Current requirements changed from 1..5A to 1..6A. - Manual adjusted to the maximum value of 130W. - New "Standards and certifications" chapter added. - Humidity specifications added, see section "Humidity specifications", on page 74. - User ID described in further detail. - Order number for Windows XP with SP3 5SWWXP.0600-ENG, 5SWWXP.0600-GER, 5SWWXP.0600-MUL added. - Minimum ambient temperature specifications added. - Internal supply cable 5CAMSC.0001-00 (for external devices on the PCI slot) added. - Configuration of a SATA RAID controller moved from "Software" to "Commissioning". - Error correction - 5PC810.FA05-00 (page 173). - BIOS settings changed (new BIOS version). - Information on creating an MS-DOS start diskette updated. - Information for creating a bootable USB flash drive added. - B&R Key Editor description expanded. - HMI Drivers & Utilities DVD updated. - Description edited for operating the add-on RS232/422/485 interface module as an RS485 interface. - ADI Control center expanded. - Glossary updated. - Update to disassembling the side cover for 5PC810.SX01-00 and 5PC810.SX05-00. - Update to assembling the UPS module (with and without add-on interface module). - Error correction to the 3-phase power supply 40A (0PS340.1) in the order numbers on page 29. - Update to 5 card slot system unit. - Several temperature humidity diagrams corrected. - Add-on interface slot added. - Description "Connection of an external device to the main board", on page 500 added. - Description "AP Link installation", on page 491 added. - Correction made to the power supply fuse from 10A to 15A on page 92. - Update to the CMOS profile switch position 2 on page 106. - Correction to the lifespan and the revolution speed of the fan kit 5PC810.FA01-00. - Temperature monitoring and fan control updated, see page 499.
1.20	2009-10-14	- Topology graphic updated. - Correction made to the maximum ambient temperature for the system unit 5AC800.B945-02 in the figure on page 68. - Description for "Power Supply" in Chapter 4 "Software" on page 283 changed. - HDD replacement tray added to accessories on page 458 and corresponding assembly in Chapter 7 "Maintenance / Servicing" on page 494. - Error corrected in figure index and table index. - Error corrected in the temperature humidity diagram for SATA RAID hard disk - 5ACPCI.RAIC-03 and SATA RAID hard disk - 5ACPCI.RAIC-04 . - ADI Development Kit changed. - Table for the maximum ambient temperature for the heat sink 5AC801.HS00-00 > Rev. D0 and 5AC801.HS00-01 > Rev. D0. - PCIE port (ETH2) and PCIE port (ETH1) BIOS description updated. - 9S0000.08-010, 9S0000.08-020, 9S0000.09-090 discontinued. - Information about firmware upgrade updated.

Table 1: Manual history (Forts.)

Version	Date	Change
		- CMOS profile 3 (5PC820.SX01-00) added - further information about the CMOS profile can be found in the APC820 user's manual. - Section 2.7 "Environmentally-friendly disposal" in chapter 1 "General information" added. - New 2-slot fan kit 5PC810.FA02-01 APC810 added. - PCI bus type added to bus units. - BIOS default settings for FDC/LPT/COM ports updated. - Contents of delivery for USB flash drives removed. - Image for Silicon Systems CompactFlash updated. - L2 cache of CPU board 5PC800.B945-00 corrected - has 2 MB L2 cache - B&R CompactFlash cards updated. - Technical data for Silicon Systems CFs revised. - Section 1.11 "Distribution of resources", on page 307 added - 4.1.1 "Installation on PCI SATA RAID controller - 5ACPCI.RAIC-03, 5ACPCI.RAIC-05", on page 331 added. - New "Slide-in compact SSD - 5AC801.SSDI-00", on page 134 added. - BIOS settings updated to version V1.14. - The tables "CPU board software versions" and "Automation Panel Link software versions" from the section 2.1 "BIOS upgrade" were removed. - Dimensions for the slide-in and slide-in compact devices changed - current dimensions are based on the device's total mechanics. - Mechanical properties for the products 5AC801.DVDS-00 and 5AC801.DVRS-00 updated. - Operating systems 5SWWXP.0500-GER, 5SWWXP.0500-ENG and 5SWWXP.0500-MUL updated. - Section 9.4 "Creating a bootable USB flash drive" removed. - In Chapter 4 "Software", the sections 1.12 "BIOS Upgrade", 1.13 "Firmware upgrade" and 1.14 "Creating an MS-DOS boot diskette in Windows XP" moved to section 2 "Upgrade information" and updated. - Section 2.4 "Creating a bootable USB flash drive for B&R upgrade files", on page 324 in chapter 4 "Software" added. - Section 2.5 "Creating a bootable CompactFlash card for B&R upgrade files", on page 326 in chapter 4 "Software" added. - Information regarding possible resolutions added to the technical data for the CPU boards. - Section 1.10 "BIOS Error signals (beep codes)" in chapter 4 "Software" added. - Windows XP Professional installation text changed. - Section 1 "Temperature sensor locations", on page 497 changed. - B&R Key Editor information updated. - Section 3 "Automation PC 810 with MS-DOS", on page 328 added - Chipset for technical data of the CPU board on page 119 corrected. - Table text for technical data of the hard disk adapter on page 138 corrected. - Information added on page 186. - Table 132 "Link modules for configuration: 6 AP900 and 2 AP800 devices via SDL and SDL (optional)", on page 227 corrected. - Hex area added in the table 188 "RAM address assignment", on page 307. - Replacement CMOS batteries 0AC201.9 replaced by 0AC201.91. - CPU board 5PC800.B945-05 added. - Section 2.6 "Humidity specifications", on page 74 updated.

Table 1: Manual history (Forts.)

Version	Date	Change
1.30	2010-09-16	- The system unit 5PC810.SX03-00, the bus unit 5PC810.BX03-00, the fan kit 5PC810.FA03-00 and the replacement fan 5AC801.FA03-00 added. - Section 7 "Automation PC 810 with Windows Embedded Standard 2009", on page 339 added - Section 11 "B&R Automation Device Interface (ADI) - Control Center", on page 349 updated. - Chapter 5 "Standards and certifications", on page 363 updated. - B&R 16 GB CompactFlash card (5CFCRD.016G-04) added. - Section 7 "Known problems / issues", on page 240 expanded by one item. - Section 14 "Cables", on page 432 in chapter 6 "Accessories" added. - B&R ID codes for system units added. - Section 9 "Automation PC 810 with Windows CE", on page 345 (5SWWCE.0826-ENG) added. - B&R USB flash drive added to the chapter 6 "Accessories" on page 412. - CPU boards 5PC800.B945-10, 5PC800.B945-11, 5PC800.B945-12, 5PC800.B945-13, 5PC800.B945-14 added. - Technical data "Remanent variables for AR (Automation Runtime) in Power Fail Mode" added for the APC810 system units. - Section 5 "Automation PC 810 with Windows 7", on page 333 added
		- Section 11 "Uninterruptible power supply UPS", on page 415 updated.
1.31	2010-10-15	- Ready relay 5AC801.RDYR-01 updated in the chapter 6 "Accessories". - Section 11 "Installing the ready relay /2 in the add-on UPS slot", on page 495 in chapter 7 "Maintenance / Servicing" added.
1.32	2010-11-02	- "Slide-in compact HDD 250GB - 5AC801.HDDI-03", on page 131 added. - "PCI SATA RAID 2 x 250 GB - 5ACPCI.RAIC-05", on page 162 added. - "Replacement SATA HDD 250 GB - 5MMHDD.0250-00", on page 166 added. - Figure "Configuration - Drives, software, accessories", on page 46 updated. - 5AC801.HDDI-03, 5ACPCI.RAIC-05 and 5MMHDD.0250-00 added to the images for the ambient temperatures (page 68 to 72) and in table "Overview of humidity specifications for individual components", on page 74.
1.33	2011-05-27	- Sections "Automation PC 810 with Windows Embedded Standard 7", on page 342, "B&R Automation Device Interface (ADI) .NET SDK", on page 505, "Automation PC 810 with Automation Runtime", on page 348, and "B&R Automation Runtime Dongle", on page 414 added. - BIOS version updated (1.14 -> 1.17). - Sections "B&R Automation Device Interface (ADI) - Control Center", on page 349, "B&R Key Editor information", on page 501, "HMI Drivers & Utilities DVD 5SWHMI.0000-00", on page 462, "B&R Automation Device Interface (ADI) development kit", on page 503 updated. - Bus unit 5PC810.BX05-02 added to figure "5 slot bus units", on page 118, table "Technical data - Bus units", on page 118, block diagram "System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-02", on page 91, figure "Configuration - Basic system", on page 45 and in figures to "Interrupt assignments in APIC mode", on page 310. - Chipset information of "CPU boards 945GME", on page 119 corrected. - Figure "Configuration - Drives, software, accessories", on page 46 updated.

Table 1: Manual history (Forts.)

Version	Date	Change
1.34	2011-07-19	- USB 5 added in headline ("USB interfaces (USB1, 2, 3, 4, 5)", on page 99). - 5AC801.HDDI-03 in table 51 "Slide-in compact slot", on page 114 added and short description of 5AC801.HDDI-02 corrected. - Tableentry „typ. recharge time at low battery“ in table 265 "Technical data - 5AC600.UPSB-00", on page 419 added. - Sections "B&R Automation Device Interface (ADI) - Control Center", on page 349, "B&R Automation Device Interface (ADI) development kit", on page 503 and "B&R Automation Device Interface (ADI) .NET SDK", on page 505 updated. - Informations about „special considerations for the 5PCI slot model“ and 5ACPCI.RAIC-05 in headline added at sections "Automation PC 810 with Windows XP Professional", on page 330 and "Automation PC 810 with Windows 7", on page 333. - Information about „Windows XP Mode“ in Section "Automation PC 810 with Windows Embedded Standard 7", on page 342 corrected. - Referring to external UPS 24VDC in Section "Uninterruptible power supply UPS", on page 415 updated.

Table 1: Manual history (Forts.)

2. Safety notices

2.1 Intended use

Programmable logic controllers (PLCs), operating and monitoring devices (industrial PCs, Power Panels, Mobile Panels, etc.), and B&R uninterruptible power supplies have been designed, developed, and manufactured for conventional use in industry. They were not designed, developed, and manufactured for any use involving serious risks or hazards that could lead to death, injury, serious physical damage, or loss of any kind without the implementation of exceptionally stringent safety precautions. In particular, such risks and hazards include the use of these devices to monitor nuclear reactions in nuclear power plants, as well as flight control systems, flight safety, the control of mass transit systems, medical life support systems and the control of weapons systems.

2.2 Protection against electrostatic discharges

Electrical components that are vulnerable to electrostatic discharge (ESD) must be handled accordingly.

2.2.1 Packaging

- Electrical components with housing
  … do not require special ESD packaging, but must be handled properly (see "Electrical components with housing").
- Electrical components without housing
  … must be protected by ESD-suitable packaging.

2.2.2 Guidelines for proper ESD handling

Electrical components with housing

- Do not touch the connector contacts on connected cables.
- Do not touch the contact tips on the circuit boards.

Electrical components without housing

The following is valid in addition to "Electrical components with housing"

- Any persons handling electrical components or devices that will be installed in the electrical components must be grounded.
- Components can only be touched on the small sides or on the front plate.
- Components should always be stored in a suitable medium (ESD packaging, conductive foam, etc.).
  Metallic surfaces are not suitable storage surfaces!

- Electrostatic discharges should be avoided on the components (e.g. through charged plastics).
- A minimum distance of 10 cm must be kept from monitors and TV sets.
- Measurement devices and equipment must be grounded.
- Measurement probes on potential-free measurement devices must be discharged on sufficiently grounded surfaces before taking measurements.

Individual components

- ESD protective measures for individual components are thoroughly integrated at B&R (conductive floors, footwear, arm bands, etc.).

The increased ESD protective measures for individual components are not necessary for our customers for handling B&R products.

2.3 Policy and procedures

Electronic devices are generally not failsafe. In the event of a failure on the programmable control system, operating or monitoring device, or uninterruptible power supply, the user is responsible for ensuring that other devices that may be connected, e.g. motors, are in a secure state.

Both when using programmable logic controllers and when using operating and monitoring devices as control systems in conjunction with a soft PLC (e.g. B&R Automation Runtime or comparable products) or a slot PLC (e.g. B&R LS251 or comparable products), the safety precautions applying to industrial control systems (e.g. the provision of safety devices such as emergency stop circuits, etc.) must be observed in accordance with applicable national and international regulations. The same applies for all other devices connected to the system, such as drives.

All tasks such as installation, commissioning, and maintenance are only permitted to be carried out by qualified personnel. Qualified personnel are persons familiar with transport, mounting, installation, commissioning, and operation of the product who also have the respective qualifications (e.g. IEC 60364). National accident prevention guidelines must be followed.
The safety guidelines, connection descriptions (type plate and documentation), and limit values listed in the technical data are to be read carefully before installation and commissioning and must be observed.

2.4 Transport and storage

During transport and storage, devices must be protected from excessive stress (mechanical load, temperature, humidity, aggressive atmospheres, etc.).

2.5 Installation

- Installation must take place according to the documentation, using suitable equipment and tools.
- Devices must be installed without voltage applied and by qualified personnel.
- General safety regulations and nationally applicable accident prevention guidelines must be observed.
- Electrical installation must be carried out according to the relevant guidelines (e.g. line cross section, fuse, protective ground connection).

2.6 Operation

2.6.1 Protection against touching electrical parts

To operate programmable logic controllers, operating and monitoring devices or uninterruptible power supplies, certain components must carry dangerous voltage levels of over 42 VDC. A life-threatening electrical shock could occur if you come into contact with these parts. This could result in death, severe injury or material damage.

Before turning on the programmable logic controller, the operating and monitoring devices and the uninterruptible power supply, ensure that the housing is properly grounded (PE rail). The ground connection must be established when testing the operating and monitoring devices or the uninterruptible power supply, even when operating them for only a short time.

Before turning the device on, make sure that all parts with voltage applied are securely covered. During operation, all covers must remain closed.

2.6.2 Environmental conditions - dust, humidity, aggressive gases

Use of operating and monitoring devices (e.g. industrial PCs, power panels, mobile panels, etc.) and uninterruptible power supplies in very dusty environments should be avoided. Dust collection on the devices influences their function and, especially in systems with active cooling (fans), sufficient cooling cannot be guaranteed.

The presence of aggressive gases in the environment can also lead to malfunctions. When combined with high temperature and humidity, aggressive gases - e.g. with sulfur, nitrogen and chlorine components - start chemical processes that can damage electronic components very quickly. Signs of the presence of aggressive gases are blackened copper surfaces and cable ends on existing installations.

For operation in dusty or humid conditions, correctly installed (cutout installation) operating and monitoring devices like Automation Panel or Power Panel are protected on the front side. The rear side of all devices must be protected from dust and humidity and must be cleaned at suitable intervals.

2.6.3 Programs, viruses, and dangerous programs

The system is subject to potential danger each time data is exchanged or software is installed from a data medium (e.g. diskette, CD-ROM, USB flash drive, etc.), a network connection, or the Internet. The user is responsible for assessing these dangers, implementing preventative measures such as virus protection programs, firewalls, etc. and obtaining software from reliable sources.

2.7 Environmentally-friendly disposal

All B&R programmable controllers, operating and monitoring devices, and uninterruptible power supplies are designed to inflict as little harm on the environment as possible.

2.7.1 Separation of materials

It is necessary to separate different materials so the device can undergo an environmentally-friendly recycling process.

Component	Disposal
Programmable logic controllers Operating and monitoring devices Uninterruptible power supply Cables	Electronics recycling
Cardboard box / paper packaging	Paper / cardboard recycling
Plastic packaging	Plastic recycling

Table 2: Environmentally-friendly separation of materials

Disposal must comply with the respective legal regulations.

3. Organization of safety notices

The safety notices in this manual are organized as follows:

Safety notice	Description
Danger!	Disregarding the safety regulations and guidelines can be life-threatening.
Caution!	Disregarding the safety regulations and guidelines can result in severe injury or major damage to material.
Warning!	Disregarding the safety regulations and guidelines can result in injury or damage to material.
Information:	Important information for preventing errors.

Table 3: Organization of safety notices

4. Guidelines



European dimension standards apply to all dimensions (e.g. dimension diagrams, etc.).

5. Model numbers

5.1 System units

Model number	Short description	Note
5PC810.SX01-00	**APC810 System 1CS[1] 1SI[2]** APC810 system unit 1 card slot (PCI, PCI Express, depending on bus), 1 slide-in compact slot for drive, 2 CompactFlash slots; Smart Display Link/DVI/Monitor, connections for 2x RS232, 5x USB 2.0, 2x ETH 10/100/1000, AC97 sound, 24 VDC	See page 47
5PC810.SX02-00	**APC810 System 2CS[1] 2SI[2] 1LS[3]** APC810 system unit 2 card slots (PCI, PCI Express, depending on bus), 1 slot for Automation Panel Link Transmitter; 1 slide-in compact slot and 1 slide-in slot for drives, 2 CompactFlash slots; Smart Display Link/DVI/Monitor, connections for 2x RS232, 5x USB 2.0, 2x ETH 10/100/1000, AC97 sound, 24 VDC	See page 52
5PC810.SX03-00	**APC810 System 3CS[1] 2SI[2] 1LS[3]** APC810 system unit, 3 slots (PCI Express, PCI, depending on bus); 1 slot for Automation Panel Link transmitter; 1 compact slide-in and 1 slide-in slot; Smart Display Link/DVI/Monitor, 2x RS232, 5x USB 2.0, 2x ETH 10/100/1000, AC97 sound, 24 VDC (order 0TB103.9 screw clamp or 0TB103.91 cage clamp terminals separately)	See page 57
5PC810.SX05-00	**APC810 System 5CS[1] 3SI[2] 1LS[3]** APC810 system unit 5 card slots (PCI, PCI Express, depending on bus), 1 slot for Automation Panel Link Transmitter; 1 slide-in compact slot and 2 slide-in slots for drives, 2 CompactFlash slots; Smart Display Link/DVI/Monitor, connections for 2x RS232, 5x USB 2.0, 2x ETH 10/100/1000, AC97 sound, 24 VDC.	See page 62

Table 4: Model numbers - System units

1) Card slot = PCI slot: PCI or PCI Express
2) Slide-in/Slide-in compact = Slide-in and Slide-in compact drive slot
3) Link slot = Slot for one AP Link card

5.2 Bus units

Model number	Short description	Note
5PC810.BX01-00	**APC810 bus 1PCI** APC810 bus unit with a PCI slot.	See page 117
5PC810.BX01-01	**APC810 bus 1PCIe.x4** APC810 bus unit with a PCIe slot.	See page 117
5PC810.BX02-00	**APC810 bus 2PCI** APC810 bus unit with 2 PCI slots.	See page 117
5PC810.BX02-01	**APC810 bus 1PCI 1PCIe.x4** APC810 bus unit with one PCI and one PCIe slot.	See page 117
5PC810.BX03-00	**APC810 Bus 2PCI 1PCIe.x4** APC810 bus unit with 2 PCI slots and one PCIe slot.	See page 117
5PC810.BX05-00	**APC810 bus 4PCI 1PCIe.x1** APC810 bus unit with 4 PCI slots and one PCIe slot.	See page 117
5PC810.BX05-01	**APC810 bus 2PCI 3PCIe.x1** APC810 bus unit with 2 PCI slots and 3 PCIe slots.	See page 117

Table 5: Model numbers - Bus units

Model number	Short description	Note
5PC810.BX05-02	**APC810 bus 5PCI** APC810 bus unit with 5 PCI slots.	See page 117

Table 5: Model numbers - Bus units (Forts.)

5.3 CPU boards 945GME COM Express

Model number	Short description	Note
5PC800.B945-00	**CPU board Intel® Core™ Duo L2400, 1.66 GHz** 667 MHz FSB, 2 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-01	**CPU board Intel® Core™2 Duo L7400, 1.5 GHz** 667 MHz FSB, 4 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-02	**CPU board Intel® Core™2 Duo U7500, 1.06 GHz** 533 MHz FSB, 2 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-03	**CPU board Intel® Celeron® M 423, 1.06 GHz** 533 MHz FSB, 1 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-04	**CPU board Intel® Core™2 Duo T7400, 2.16 GHz** 667 MHz FSB, 4 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-05	**CPU board Intel® Atom™ N270, 1.6 GHz** 533 MHz FSB, 512 kB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-10	**CPU board Intel® Core™ Duo L2400, 1.66 GHz** 667 MHz FSB, 2 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-11	**CPU board Intel® Core™2 Duo L7400, 1.5 GHz** 667 MHz FSB, 4 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-12	**CPU board Intel® Core™2 Duo U7500, 1.06 GHz** 533 MHz FSB, 2 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-13	**CPU board Intel® Celeron® M 423, 1.06 GHz** 533 MHz FSB, 1 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119
5PC800.B945-14	**CPU board Intel® Core™2 Duo T7400, 2.16 GHz** 667 MHz FSB, 4 MB L2 cache; 945GME chipset; 2 sockets for SO-DIMM DDR2 module	See page 119

Table 6: Model numbers - CPU boards 945GME

5.4 Heat sink

Model number	Short description	Note
5AC801.HS00-00	**APC810 heat sink** Heat sink APC810 for CPU boards with Dual Core processors L2400, L7400, U7500 and Celeron® M 423	See page 120
5AC801.HS00-01	**APC810 heat sink T7400** Heat sink APC810 for CPU board with Dual Core processor T7400	See page 120
5AC801.HS00-02	**APC810 heat sink 945GME N270** APC810 heat sink for CPU board with Atom processor N270	See page 120

Table 7: Model numbers - Heat sinks

5.5 Main memory

Model number	Short description	Note
5MMDDR.0512-01	**SO-DIMM DDR2 512MB PC2-5300**	See page 121
5MMDDR.1024-01	**SO-DIMM DDR2 1024MB PC2-5300**	See page 121
5MMDDR.2048-01	**SO-DIMM DDR2 2048MB PC2-5300**	See page 121

Table 8: Model numbers - Main memory

5.6 Drives

Model number	Short description	Note
5AC801.ADAS-00	**APC810 slide-in compact adapter** Adapter for operating slide-in compact drives in a slide-in slot drive slot (can only be used in slide-in slot 1).	See page 138
5AC801.HDDI-00	**APC810 slide-in compact HDD 40GB** 40 GB SATA hard disk (slide-in compact), 24/7 hard disk with extended temperature range.	See page 122
5AC801.HDDI-01	**APC810 slide-in compact HDD 80GB** 80 GB SATA hard disk (slide-in compact), 24/7 hard disk with extended temperature range.	See page 125 Cancelled since 02/2008, replacement type 5AC801.HDDI-02
5AC801.HDDI-02	**APC810 slide-in compact HDD 160GB 24x7 ET** 160 GB SATA hard disk (slide-in compact), 24/7 hard disk with extended temperature range.	See page 128
5AC801.HDDI-03	**APC810 slide-in C HDD 250 GB (M5400.6)** 250 GB SATA hard disk (slide-in compact), 24/7 hard disk.	See page 131
5AC801.HDDS-00	**APC810 slide-in HDD 40GB** 40 GB SATA hard disk (slide-in), 24/7 hard disk with extended temperature range.	See page 139
5AC801.SSDI-00	**APC810 slide-in compact SSD 32GB (SLC)** 32 GB SSD drive (slide-in)	See page 134
5AC801.DVDS-00	**APC810 slide-in DVD-ROM** DVD-ROM drive (slide-in)	See page 142
5AC801.DVRS-00	**APC810 slide-in DVD-R/RW** DVD-R/RW, DVD+R/RW drive (slide-in)	See page 145
5ACPCI.RAIC-01	**PCI SATA RAID System 2x60 GB** PCI RAID controller + 2 x 60 GB SATA hard disks; requires a free PCI slot.	See page 148 Discontinued since 07/2008
5ACPCI.RAIC-02	**Replacement SATA-HDD 60GB** Hard disk 60 GB SATA, replacement part for 5ACPCI.RAIC-01	See page 152
5ACPCI.RAIC-03	**PCI SATA RAID System 2x160 GB** PCI RAID controller + 2 x 160 GB SATA hard disks; requires a free PCI slot.	See page 155
5ACPCI.RAIC-04	**Replacement SATA-HDD 160GB** Hard disk 160 GB SATA, replacement part for 5ACPCI.RAIC-03	See page 159
5ACPCI.RAIC-05	**PCI RAID system SATA 2x250GB (M5400.6)** PCI RAID controller + 2 x 250 GB SATA hard disks; requires a free PCI slot.	See page 162
5MMHDD.0250-00	**Replacement SATA-HDD 250GB (M5400.6)** Hard disk 250 GB SATA, replacement part for 5ACPCI.RAIC-03 and 5ACPCI.RAIC-05.	See page 166

Table 9: Model numbers - Drives

5.7 Fan kits

Model number	Short description	Note
5PC810.FA01-00	**APC810 fan kit for system unit 5PC810.SX01-00** APC810 fan kit for system unit with 1CS, made up of 3 fans (40x40x10)	See page 169
5PC810.FA02-00	**APC810 fan kit for system unit 5PC810.SX02-00** APC810 fan kit for system unit with CS, made up of 2 fans (70x70x15)	See page 171 Discontinued since 04/2009
5PC810.FA02-01	**APC810 fan kit for system unit 5PC810.SX02-00** APC810 fan kit for system unit with CS, made up of 2 fans (70x70x15)	See page 171
5PC810.FA03-00	**APC810 fan kit for system unit 5PC810.SX03-00** APC810 fan kit for system unit with 3CS, made up of 2 fans (70x70x15)	See page 171
5PC810.FA05-00	**APC810 fan kit for system unit 5PC810.SX05-00** APC810 fan kit for system unit with 5CS, made up of 3 fans (70x70x15)	See page 173

Table 10: Model numbers - Fan kits

5.8 AP Link cards

Model number	Short description	Note
5AC801.SDL0-00	**APC810 AP Link SDL transmitter** Automation Panel SDL link transmitter	See page 174
5AC801.RDYR-00	**APC810 Ready relay** APC810 Ready relay	See page 177

Table 11: Model numbers - AP Link

5.9 Add-on interfaces (IF option)

Model number	Short description	Note
5AC600.CANI-00	**Add-on CAN interface** CAN interface for installation in an APC620, APC800 or PPC700.	See page 180
5AC600.485I-00	**Add-on RS232/422/485 interface** Add-on RS232/422/485 interface for installation in an APC620, AP800 and PPC700.	See page 184

Table 12: Model numbers - Add-on interfaces (IF option)

5.10 Uninterruptible power supply

Model number	Short description	Note
5AC600.UPSI-00	**Add-on UPS module** Order UPS module for Automation PC, cable (5CAUPS.0005-00 or 5CAUPS.0030-00) and battery unit (5AC600.UPSB-00) separately.	See page 415
5AC600.UPSB-00	**Battery unit 5 Ah** UPS battery unit for the add-on UPS module	See page 415
5CAUPS.0005-00	**UPS cable 0.5 m** Connection cable between add-on UPS module and UPS battery unit, length 0.5 meters	See page 415

Table 13: Model numbers - Uninterruptible power supply

Model number	Short description	Note
5CAUPS.0030-00	**UPS cable 3 m** Connection cable between add-on UPS module and UPS battery unit, length 3 meters	See page 415

Table 13: Model numbers - Uninterruptible power supply

5.11 Accessories

5.11.1 Supply voltage connectors

Model number	Short description	Note
0TB103.9	**Plug 24V 5.08 3-pin screw clamp** 24 VDC 3-pin connector, female. Screw clamp, 3.31 mm², protected against vibration by the screw flange.	See page 387
0TB103.91	**Plug 24V 5.08 3-pin cage clamp** 24 VDC 3-pin connector, female. Cage clamps, 3.31 mm², protected against vibration by the screw flange.	See page 387

Table 14: Model numbers - Supply voltage connectors

5.11.2 Batteries

Model number	Short description	Note
0AC201.91	**Lithium batteries, 4 pcs**. Lithium batteries, 4 pcs., 3 V / 950 mAh, button cell	See page 389
4A0006.00-000	**Lithium battery, 1 pc.** Lithium battery, 1 pc., 3 V / 950 mAh, button cell	See page 389

Table 15: Model numbers - Batteries

5.11.3 CompactFlash cards

Model number	Short description	Note
5CFCRD.0512-04	**CompactFlash 512 MB B&R** CompactFlash card with 512 MB SLC NAND flash and IDE/ATA interface	See page 392
5CFCRD.1024-04	**CompactFlash 1024 MB B&R** CompactFlash card with 1024 MB SLC NAND flash and IDE/ATA interface	See page 392
5CFCRD.2048-04	**CompactFlash 2048 MB B&R** CompactFlash card with 2048 MB SLC NAND flash and IDE/ATA interface	See page 392
5CFCRD.4096-04	**CompactFlash 4096 MB B&R** CompactFlash card with 4096 MB SLC NAND flash and IDE/ATA interface	See page 392
5CFCRD.8192-04	**CompactFlash 8192 MB B&R** CompactFlash card with 8192 MB SLC NAND flash and IDE/ATA interface	See page 392
5CFCRD.016G-04	**16 GB B&R CompactFlash card** CompactFlash card with 16 GB SLC NAND flash and IDE/ATA interface	See page 392
5CFCRD.0064-03	**CompactFlash 64 MB SSI** CompactFlash card with 64 MB SLC NAND flash and IDE/ATA interface	See page 397

Table 16: Model numbers - CompactFlash cards

Model number	Short description	Note
5CFCRD.0128-03	**CompactFlash 128 MB SSI** CompactFlash card with 128 MB SLC NAND flash and IDE/ATA interface	See page 397
5CFCRD.0256-03	**CompactFlash 256 MB SSI** CompactFlash card with 256 MB SLC NAND flash and IDE/ATA interface	See page 397
5CFCRD.0512-03	**CompactFlash 512 MB SSI** CompactFlash card with 512 MB SLC NAND flash and IDE/ATA interface	See page 397
5CFCRD.1024-03	**CompactFlash 1024 MB SSI** CompactFlash card with 1024 MB SLC NAND flash and IDE/ATA interface	See page 397
5CFCRD.2048-03	**CompactFlash 2048 MB SSI** CompactFlash card with 2048 MB SLC NAND flash and IDE/ATA interface	See page 397
5CFCRD.4096-03	**CompactFlash 4096 MB SSI** CompactFlash card with 4096 MB SLC NAND flash and IDE/ATA interface	See page 397
5CFCRD.8192-03	**CompactFlash 8192 MB SSI** CompactFlash card with 8192 MB SLC NAND flash and IDE/ATA interface	See page 397

Table 16: Model numbers - CompactFlash cards (Forts.)

5.11.4 USB accessories

Model number	Short description	Note
5MMUSB.2048-00	**USB flash drive 2 GB SanDisk** USB 2.0 flash drive 2 GB	See page 409
5MMUSB.2048-01	**USB flash drive 2 GB B&R** USB 2.0 flash drive 2 GB	See page 412
5MD900.USB2-01	**USB 2.0 drive DVD-RW/CD-RW FDD CF USB** USB 2.0 drive combination; Consists of DVD-R/RW/DVD+R/RW/CD-RW, FDD, CompactFlash slot (type II), USB connection (type A front side, type B back side); 24 VDC.	See page 401
5A5003.03	**Front cover for the USB Media Drive 5MD900.USB2-01** Front cover for the remote USB 2.0 drive combination 5MD900.USB2-01.	See page 407

Table 17: Model numbers - USB flash drives

5.11.5 Cables

Model number	Short description	Note
5CADVI.0018-00	**DVI-D cable 1.8 m** Single cable, DVI-D/m:DVI-D/m; length: 1.8 m	See page 432
5CADVI.0050-00	**DVI-D cable 5 m** Single cable, DVI-D/m:DVI-D/m; length: 5 m	See page 432
5CADVI.0100-00	**DVI-D cable 10 m** Single cable, DVI-D/m:DVI-D/m; length: 10 m	See page 432
5CASDL.0018-00	**SDL cable 1.8 m** SDL cable for a fixed type of layout; length: 1.8 m	See page 436
5CASDL.0018-01	**SDL cable 1.8 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 1.8 m	See page 440
5CASDL.0018-03	**SDL flex cable 1.8 m** SDL cable for fixed and flexible type of layout; length: 1.8 m	See page 444

Table 18: Model numbers - Cables

Model number	Short description	Note
5CASDL.0050-00	**SDL cable 5 m** SDL cable for a fixed type of layout; length: 5 m	See page 436
5CASDL.0050-01	**SDL cable 5 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 5 m	See page 440
5CASDL.0050-03	**SDL flex cable 5 m** SDL cable for fixed and flexible type of layout; length: 5 m	See page 444
5CASDL.0100-00	**SDL cable 10 m** SDL cable for a fixed type of layout; length: 10 m	See page 436
5CASDL.0100-01	**SDL cable 10 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 10 m	See page 440
5CASDL.0100-03	**SDL flex cable 10 m** SDL cable for fixed and flexible type of layout; length: 10 m	See page 444
5CASDL.0150-00	**SDL cable 15 m** SDL cable for a fixed type of layout; length: 15 m	See page 436
5CASDL.0150-01	**SDL cable 15 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 15 m	See page 440
5CASDL.0150-03	**SDL flex cable 15 m** SDL cable for fixed and flexible type of layout; length: 15 m	See page 444
5CASDL.0200-00	**SDL cable 20 m** SDL cable for a fixed type of layout; length: 20 m	See page 436
5CASDL.0200-03	**SDL flex cable 20 m** SDL cable for fixed and flexible type of layout; length: 20 m	See page 444
5CASDL.0250-00	**SDL cable 25 m** SDL cable for a fixed type of layout; length: 25 m	See page 436
5CASDL.0250-03	**SDL flex cable 25 m** SDL cable for fixed and flexible type of layout; length: 25 m	See page 444
5CASDL.0300-00	**SDL cable 30 m** SDL cable for a fixed type of layout; length: 30 m	See page 436
5CASDL.0300-03	**SDL flex cable 30 m** SDL cable for fixed and flexible type of layout; length: 30 m	See page 444
5CASDL.0300-13	**SDL flex cable with extender 30 m** SDL cable with extender for fixed and flexible type of layout; length: 30 m	See page 449
5CASDL.0400-13	**SDL flex cable with extender 40 m** SDL cable with extender for fixed and flexible type of layout; length: 40 m	See page 449
9A0014.02	**RS232 cable DB9/f:DB9/m 1.8 m** RS232 extension cable for remote operation of a display unit with touch screen; length 1.8 m.	See page 453
9A0014.05	**RS232 cable DB9/f:DB9/m 5 m** RS232 extension cable for remote operation of a display unit with touch screen; length 5 m.	See page 453
9A0014.10	**RS232 cable DB9/f:DB9/m 10 m** RS232 extension cable for remote operation of a display unit with touch screen; length 10 m.	See page 453
5CAUSB.0018-00	**USB 2.0 cable, A/m:B/m 1.8 m** USB 2.0 connection cable; plug type A - type B; length 1.8 m	See page 455
5CAUSB.0050-00	**USB 2.0 cable, A/m:B/m 5 m** USB 2.0 connection cable; plug type A - type B; length 5 m	See page 455
5CAMSC.0001-00	**APC810 internal supply cable**	See page 457

Table 18: Model numbers - Cables (Forts.)

5.11.6 PCI cards

Model number	Short description	Note
5ACPCI.ETH1-01	**PCI Ethernet card 10/100** half size PCI Ethernet card, 1 Ethernet connection	See page 426
5ACPCI.ETH3-01	**PCI Ethernet card 10/100 3port** half size PCI Ethernet card, 3 Ethernet connections	See page 429

Table 19: Model numbers - PCI cards

5.11.7 Power supplies

Model number	Short description	Note
0PS102.0	**Power supply, 1-phase, 2.1 A** 24 VDC power supply, 1-phase, 2.1 A, input 100-240 VAC, wide range, DIN rail mounting	See page 424
0PS104.0	**Power supply, 1-phase, 4.2 A** 24 VDC power supply, 1 phase, 4.2 A, input 115/230 VAC, auto select, DIN rail mounting	See page 424
0PS105.1	**Power supply, 1-phase, 5 A** 24 VDC power supply, 1 phase, 5 A, input 115/230 VAC, manual select, DIN rail mounting	See page 424
0PS105.2	**Power supply, 1-phase, 5 A, redundant** 24 VDC power supply, 1 phase, 5 A, redundant through parallel operation, input 115/230 VAC, manual select, DIN rail mounting	See page 424
0PS110.1	**Power supply, 1-phase, 10 A** 24 VDC power supply, 1 phase, 10 A, input 115/230 VAC, manual select, DIN rail mounting	See page 424
0PS110.2	**Power supply, 1-phase, 10 A, redundant** 24 VDC power supply, 1 phase, 10 A, redundant through parallel operation, input 115/230 VAC, manual select, DIN rail mounting	See page 424
0PS120.1	**Power supply, 1-phase, 20 A** 24 VDC power supply, 1 phase, 20 A, input 115/230 VAC, auto select, DIN rail mounting	See page 424
0PS305.1	**Power supply, 3-phase, 5 A** 24 VDC power supply, 3-phase, 5 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	See page 424
0PS310.1	**Power supply, 3-phase, 10 A** 24 VDC power supply, 3-phase, 10 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	See page 424
0PS320.1	**Power supply, 3-phase, 20 A** 24 VDC power supply, 3-phase, 20 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	See page 424
0PS340.1	**Power supply, 3-phase, 40 A** 24 VDC power supply, 3-phase, 40 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	See page 424

Table 20: Model numbers - Power supplies

5.11.8 Replacement fan

5AC801.FA01-00	**APC810 replacement fan filter for system units with 1CS 5 pcs**	See page 390

Table 21: Model numbers - Replacement fan filters

5AC801.FA02-00	**APC810 replacement fan filter for system units with 2CS 5 pcs**	See page 390
5AC801.FA03-00	**APC810 replacement fan filter for system units with 3CS 5 pcs**	See page 390
5AC801.FA05-00	**APC810 replacement fan filter for system units with 5CS 5 pcs**	See page 390

Table 21: Model numbers - Replacement fan filters

5.11.9 Miscellaneous

Model number	Short description	Note
5AC900.1000-00	**Adapter DVI-A/m to CRT DB15HD/f** Adapter DVI (plug) to CRT (socket), for connecting a standard monitor to a DVI-I interface.	See page 391
5AC801.FRAM-00	**HDD replacement tray** APC810 SATA hard disk replacement tray	See page 458
5AC801.RDYR-01	**APC810 Ready relay /2** Ready relay for APC810 for installation on an add-on UPS slot	See page 458
1A4600.10	**B&R Automation Runtime ARwin, incl. License Label and Security Key**	See page 414
1A4600.10-2	**B&R Automation Runtime ARwin, ARNC0**	See page 414
1A4600.10-3	**B&R Automation Runtime ARwin+PVIControls, incl. License Label and Security Key**	See page 414
1A4600.10-4	**B&R Automation Runtime ARwin+ARNC0+PVIControls**	See page 414
5SWHMI.0000-00	**HMI Drivers & Utilities DVD**	See page 462

Table 22: Model numbers - Other items

5.12 Software

Model number	Short description	Note
9S0000.01-010	**OEM MS-DOS 6.22 German (disk)** OEM MS-DOS 6.22 German disks Only delivered with a new PC.	See page 328
9S0000.01-020	**OEM MS-DOS 6.22 English (disk)** OEM MS-DOS 6.22 English disks Only delivered with a new PC.	See page 328
9S0000.08-010	**OEM Microsoft Windows XP Professional German** CD, German; Only delivered with a new PC.	See page 330 Discontinued since 10/2008
9S0000.08-020	**OEM Microsoft Windows XP Professional English** CD, English; Only delivered with a new PC.	See page 330 Discontinued since 10/2008
9S0000.09-090	**OEM Microsoft Windows XP Professional Multilanguage** CDs; Only delivered with a new PC.	See page 330 Discontinued since 10/2008
5SWWXP.0600-ENG	**WinXP Professional with SP3, ENG** Microsoft OEM Windows XP Professional Service Pack 3, CD, English. Only available with a new device.	See page 330

Table 23: Model numbers - Software

Model number	Short description	Note
5SWWXP.0600-GER	**WinXP Professional with SP3, GER** Microsoft OEM Windows XP Professional Service Pack 3, CD, German. Only available with a new device.	See page 330
5SWWXP.0600-MUL	**WinXP Professional with SP3, MUL** Microsoft OEM Windows XP Professional Service Pack 3, CD, multi-language. Only available with a new device.	See page 330
5SWWXP.0500-ENG	**WinXP Professional with SP 2c, ENG** Microsoft OEM Windows XP Professional Service Pack 2c, CD, English. Only available with a new device.	See page 330
5SWWXP.0500-GER	**WinXP Professional with SP 2c, GER** Microsoft OEM Windows XP Professional Service Pack 2c, CD, German. Only available with a new device.	See page 330
5SWWXP.0500-MUL	**WinXP Professional with SP 2c, MUL** Microsoft OEM Windows XP Professional Service Pack 2c, CD, multi-language. Only available with a new device.	See page 330
5SWWI7.0100-GER	**Win7 Pro 32-bit DVD, GER** Microsoft OEM Windows 7 Professional 32-bit, DVD, German. Only available with a new device.	See page 333
5SWWI7.0100-ENG	**Win7 Pro 32-bit DVD, ENG** Microsoft OEM Windows 7 Professional 32-bit, DVD, English. Only available with a new device.	See page 333
5SWWI7.0200-GER	**Win7 Pro 64-bit DVD, GER** Microsoft OEM Windows 7 Professional 64-bit, DVD, German. Only available with a new device.	See page 333
5SWWI7.0200-ENG	**Win7 Pro 64-bit DVD, ENG** Microsoft OEM Windows 7 Professional 64-bit, DVD, English. Only available with a new device.	See page 333
5SWWI7.0300-MUL	**Win7 Ult 32-bit DVD, MUL** Microsoft OEM Windows 7 Ultimate 32-bit, DVD, Multilanguage. Only available with a new device.	See page 333
5SWWI7.0400-MUL	**Win7 Ult 64-bit DVD, MUL** Microsoft OEM Windows 7 Ultimate 64-bit, DVD, Multilanguage. Only available with a new device.	See page 333
5SWWXP.0426-ENG	**WinXPe FP2007 APC810 945GME** Microsoft OEM Windows XP Embedded Feature Pack 2007, English; for APC810 with 945GME chipset; order CompactFlash separately (at least 512 MB).	See page 336
5SWWXP.0726-ENG	**Windows Embedded Standard 2009 APC810 945GME** Microsoft OEM Windows Embedded Standard 2009, English; for APC810 with 945GME chipset; order CompactFlash separately (at least 1 GB).	See page 339
5SWWI7.0526-ENG	**WES7E 32bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 32-bit, English; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 8 GB).	See page 342
5SWWI7.0626-ENG	**WES7E 64bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 64-bit, English; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 16 GB).	See page 342
5SWWI7.0726-MUL	**WES7P 32bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 Premium 32-bit, multilanguage; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 8 GB).	See page 342

Table 23: Model numbers - Software

Model number	Short description	Note
5SWWI7.0826-MUL	**WES7P 64bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 Premium 64-bit, multilanguage; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 8 GB).	See page 342
5SWWI7.0900-MUL	**WES7P 32bit Language Pack DVD**	See page 342
5SWWI7.1000-MUL	**WES7P 64bit Language Pack DVD**	See page 342
5SWWCE.0826-ENG	**WinCE6.0 Pro APC810 945GME** Microsoft OEM Windows CE 6.0 Professional, English; for APC810 with 945GME chipset; order CompactFlash separately (at least 128 MB).	See page 345

Table 23: Model numbers - Software

6. Typical topology

6.1 APC810 for central control and visualization

The control program runs on the APC810 parallel to Windows. The visualization project is integrated with Visual Components. Up to four display units are connected to the PC either locally or remotely. The PC is networked over Ethernet TCP/IP; additional Power Panel-based operator terminals can also be connected via Ethernet. Fieldbus systems (CAN bus, POWERLINK) are used to handle communication to I/O systems with axis control.



Figure 1: APC810 for central control and visualization

6.2 APC810 as a visualization device

The visualization runs as a SCADA application on the APC810. Up to four display units are connected to the PC either locally or remotely. The control tasks interact with one or more underlying PLC stations where I/O systems and drives are connected locally or remotely over fieldbus systems. Additional SCADA stations can be networked via Ethernet TCP/IP.



Figure 2: APC810 as a visualization device

Chapter 2 • Technical data

1. Introduction

The APC810 is the sophisticated upgrade to the APC620 product series. Based on the latest Intel® Core™2 Duo technology, the APC810 offers the highest level of performance for any application that requires maximum computing power.

The APC810 saves space in the switching cabinet. Drive inserts (DVD, HDD) and two CompactFlash slots are protected behind a cover on the front of the device. The modular plug-in technology makes it easy for the user to switch drives. All connections and interfaces are located on the top side of the housing. The installation depth is not increased by protruding connectors. The different APC810 sizes with one, two or five card slots (for PCI/PCI Express cards) provide the optimum design for every type of installation - a perfect fit without wasting valuable space in the switching cabinet.

1.1 Features

- Latest processor technologies - Core Duo, Core 2 Duo, Celeron M and Atom N270
- Up to 3 GB main memory (Dual Channel Memory Support)
- 2 CompactFlash slots (type I)
- 1, 2 or 5 card slots (for PCI / PCI Express (PCIe) cards)
- SATA drives (slide-in and slide-in compact slots)
- 5x USB 2.0
- 2x Ethernet 10/100/1000 MBit interfaces
- 2x RS232 Interface, modem compatible
- 24 VDC supply voltage
- Fan-free operation[1)]
- BIOS (AMI)
- Real-time clock, RTC (battery-buffered)
- 512 KB SRAM (with battery back-up)
- Connection of various display devices to the "Monitor/Panel" video output (supports RGB, DVI, and SDL - Smart Display Link - signals)
- 2nd graphics line with installation of the optional AP Link card
- Easy slide-in drive exchange (SATA hot plug capable)
- Optional installation of the add-on UPS module
- Optional CAN interface
- Optional RS232/422/485 interface
- Optional RAID controller (requires an open PCI slot)

1.2 System components / configuration

The AP810 system can be assembled to meet individual requirements and operating conditions.

The following components are absolutely essential for operation:

- System unit
- Bus unit
- CPU board
- Heat sink
- Main memory
- Drive (mass memory such as CompactFlash card or hard disk) for the operating system
- Software

1) Dependent on the device configuration and the ambient temperature.

1.3 Configuration - Basic system



Figure 3: Configuration - Basic system

1.4 Configuration - Drives, software, accessories

Configuration - drives, software, accessories				
System unit				
A system unit consists of a housing and main board. Variations: Card slots (1,2,3 or 5) Slide-in slots (0,1 or 2) AP Link slot (0 or 1) Example: (2 / 1 /1) = 2 PCI, 1 slide-in, 1 AP Link	 5PC810.SX01-00 (1 / 0 / 0)	 5PC810.SX02-00 (2 / 1 / 1)	 5PC810.SX03-00 (3 / 1 / 1)	 5PC810.SX05-00 (5 / 2 / 1)
Fan kit	Select 1			
	5PC810.FA01-00	5PC810.FA02-01	5PC810.FA03-00	5PC810.FA05-00
Slide-in compact drive	Select 1			
	5AC801.HDDI-00 (40 GB) 5AC801.HDDI-03 (250 GB) 5AC801.SSDI-00 (32 GB)			
CompactFlash	Select 1 or 2			
	5CFCRD.0512-04, 5CFCRD.1024-04, 5CFCRD.2048-04, 5CFCRD.4096-04, 5CFCRD.8192-04, 5CFCRD.016G-04		5CFCRD.0064-03, 5CFCRD.0128-03, 5CFCRD.0256-03, 5CFCRD.0512-03, 5CFCRD.1024-03, 5CFCRD.2048-03, 5CFCRD.4096-03, 5CFCRD.8192-03	
Slide-in drive	not possible	1 possible	2 possible	
		5AC801.HDDS-00 (40 GB) 5AC801.DVDS-00 (DVD drive) 5AC801.ADAS-00 (adapter) 5AC801.DVRS-00 (DVD burner)		
AP Link card		Select 1		
		5AC801.SDL0-00 (= 2nd graphics line) 5AC801.RDYR-00 (= ready relay)		
RAID system	Select 1			
	5ACPCI.RAIC-05 (2x250 GB, occupies 1 PCI slot) 5MMHDD.0250-00 (replacement SATA-HDD 250GB)			
Interface option	Select 1			
	5AC600.CANI-00 (CAN) 5AC600.485I-00 (combined RS232/RS422/RS485)			
UPS module + battery	Select 1			
	5AC600.UPSI-00 (Add-On UPS module) + 5AC600.UPSB-00 (UPS battery unit) connection cable APC -> battery: 5CAUPS.0005-00 (0,5 meter) or 5CAUPS.0030-00 (3 meter)			
Supply voltage connetcor	Select 1			
	0TB103.9 (screw clamp) 0TB103.91 (cage clamp)			
Software	Select 1			
Windows XP Professional Windows XP Embedded	5SWWXP.0600-GER (XP Pro SP3 German) 5SWWXP.0600-ENG (XP Pro SP3 English) 5SWWXP.0600-MUL (XP Pro SP3 Multilanguage) 5SWWXP.0500-GER (XP Pro SP2 German) 5SWWXP.0500-ENG (XP Pro SP2 English) 5SWWXP.0500-MUL (XP Pro SP2 Multilanguage) 5SWWI7.0100-GER (Win7 32 Bit German) 5SWWI7.0100-ENG (Win7 32 Bit English) 5SWWI7.0200-GER (Win7 64 Bit German) 5SWWI7.0200-ENG (Win7 64 Bit English) 5SWWI7.0300-MUL (Win7 32 Bit Multilanguage)		5SWWI7.0400-MUL (Win7 64 Bit Multilanguage) 5SWWXP.0426-ENG (XP embedded English) 5SWWXP.0726-ENG (WES2009 English) 5SWWI7.0526-ENG (WES7 English) 5SWWI7.0626-ENG (WES7 English) 5SWWI7.0726-MUL (WES7 Multilanguage) 5SWWI7.0826-MUL (WES7 Multilanguage) 5SWWCE.0826-ENG (WinCE 6.0 Pro English) 9S0000.01-010 (MS-DOS 6.22 German) 9S0000.01-020 (MS-DOS 6.22 English)	

Figure 4: Configuration - Drives, software, accessories

2. Entire device

2.1 Overview of APC810 1 card slot variations

2.1.1 Interfaces



Figure 5: Interface overview - APC810, 1 card slot variant (top)

Warning!

Do not remove mounting screws from the heat sink, as it is connected to the processor and chipset by a thermal coupling. If this connection is broken, the APC810 must be sent for repair. Removal of the mounting screws, which can be determined by a broken seal, voids all warranty.

During operation, surface temperatures of the heat sink may reach 70°C (warning "hot surface").



Figure 6: Interface overview - APC810, 1 card slot variant (front)

Information:

The orange front doors contain two permanent magnets. Contact between a data carrier that saves data magnetically (hard disk, diskette, the magnetic strip of a credit card, etc.) and a magnet can cause loss of data.

2.1.2 Technical data

Features	5PC810.SX01-00
B&R ID code	$A3ED
Boot loader / Operating system	BIOS
Processor Cooling Method	Component-dependent, see technical data for the "CPU boards 945GME", on page 119 Passive via heat sink and optionally supported with an active fan kit
Main memory	Max. 3 GB
Graphics Controller	 Component-dependent, see technical data for the "CPU boards 945GME", on page 119
Power failure logic Controller Buffer time	 MTCX[1] (see also page 498) 10 ms
Real-time clock (RTC) Battery-buffered Accuracy	 Yes see technical data of the "CPU boards 945GME", on page 119
SRAM Battery-buffered Quantity Remanent variables for AR (Automation Runtime) in power fail mode	 Yes 512 kB 192 kB
Battery Type removable Lifespan	See also page 108 Renata 950 mAh Yes, accessible behind the orange front doors 2 1/2 years[2]
Ethernet Amount Speed Controller	 2 10/100/1000 Mbit/s See also page 96 or page 98
CAN bus	Optional using add-on interface (5AC600.CANI-00)
CompactFlash Type Amount	See also page 110 or page 111 Type I 2
Serial interface Amount Type UART Transfer rate Connection	See also page 94 or page 95 2 RS232, modem-capable, not electrically isolated 16550-compatible, 16-byte FIFO Max. 115 kBaud 9-pin DSUB
USB interface Type Amount Transfer rate Connection Current load	Also see page 99 USB 2.0 5 Low speed (1.5 Mbit/s), full speed (12 Mbit/s), to high speed (480 Mbit/s) Type A Max. 500 mA or 1 A per connection
Reset button	Yes, accessible behind the orange front doors
LEDs	4 directed outwards via fiber optic lines, also see section "Status LEDs", on page 105
Buzzer	Yes

Table 24: Technical data - APC810, 1 card slot variant

Features	5PC810.SX01-00
Card slots Amount half-size	See also section "Card slot (PCI / PCIe)", on page 104 1 Dimensions of the PCI / PCIe cards vary
Add-on UPS slot	Yes
AP Link slot	-
Electrical characteristics	
Power supply Rated voltage Rated current Starting current Power consumption	 24 VDC ±25% 6 A Typ. 7 A, max. 50 A < 300µs Component-dependent, see section "Power calculation with 5PC810.SX01-00 revision >= D0", on page 76
Mechanical characteristics	
Housing[3] Item Paint Front cover	 Galvanized plate, plastic Light gray (similar to Pantone 427CV), dark gray (similar to Pantone 432CV) Colored orange plastic (similar to Pantone 144CV)
Outer dimensions	See "Dimensions - APC810 1 card slot variant", on page 51
Weight	Approx. 2.2 kg (component-dependent)
Environmental characteristics	
Ambient temperature Operation Bearings Transport	 Component-dependent - see section 2.5 "Ambient temperatures", on page 67 -20 to 60°C -20 to 60°C
Relative humidity Operation Bearings Transport	 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74
Vibration[4] Operation (continuous) Operation (occasional) Bearings Transport	 2 - 9 Hz: 1.75 mm amplitude / 9 - 200 Hz: 0.5 g 2 - 9 Hz: 3.5 mm amplitude / 9 - 200 Hz: 1 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g
Shock[4] Operation Bearings Transport	 15 g, 11 ms 30 g, 15 ms 30 g, 15 ms
Protection	IP20
Altitude Operation	 max. 3000 m[5] (component-dependent)

Table 24: Technical data - APC810, 1 card slot variant (Forts.)

1) Maintenance controller extended.

2) At 50°C, 8.5 µA of the supplied components and a self discharge of 40%.

3) Depending on the process or batch, there may be visible deviations in the color and surface structure.

4) Maximum values, as long as no other individual component specifies any other.

5) Derating the maximum ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

2.1.3 Dimensions



Figure 7: Dimensions - APC810 1 card slot variant

2.2 Overview of APC810 2 card slot variations

2.2.1 Interfaces



Figure 8: Interface overview - APC810, 2 card slot variant (top)

Warning!

Do not remove mounting screws from the heat sink, as it is connected to the processor and chipset by a thermal coupling. If this connection is broken, the APC810 must be sent for repair. Removal of the mounting screws, which can be determined by a broken seal, voids all warranty.

During operation, surface temperatures of the heat sink may reach 70°C (warning "hot surface").



Figure 9: Interface overview - APC810, 2 card slot variant (front)

Information:

The orange front doors contain two permanent magnets. Contact between a data carrier that saves data magnetically (hard disk, diskette, the magnetic strip of a credit card, etc.) and a magnet can cause loss of data.

2.2.2 Technical data

Features	5PC810.SX02-00
B&R ID code	$A3C7
Boot loader / Operating system	BIOS
Processor Cooling Method	Component-dependent, see technical data for the "CPU boards 945GME", on page 119 Passive via heat sink and optionally supported with an active fan kit
Main memory	Max. 3 GB
Graphics Controller	 Component-dependent, see technical data for the "CPU boards 945GME", on page 119
Power failure logic Controller Buffer time	 MTCX[1] (see also page 498) 10 ms
Real-time clock (RTC) Battery-buffered Accuracy	 Yes see technical data of the "CPU boards 945GME", on page 119
SRAM Battery-buffered Quantity Remanent variables for AR (Automation Runtime) in power fail mode	 Yes 512 kB 192 kB
Battery Type removable Lifespan	See also page 108 Renata 950 mAh Yes, accessible behind the orange front doors 2 1/2 years[2]
Ethernet Amount Speed Controller	 2 10/100/1000 Mbit/s See also page 96 or page 98
CAN bus	Optional using add-on interface (5AC600.CANI-00)
CompactFlash Type Amount	See also page 110 or page 111 Type I 2
Serial interface Amount Type UART Transfer rate Connection	See also page 94 or page 95 2 RS232, modem-capable, not electrically isolated 16550-compatible, 16-byte FIFO Max. 115 kBaud 9-pin DSUB
USB interface Type Amount Transfer rate Connection Current load	Also see page 99 USB 2.0 5 Low speed (1.5 MBit/s), full speed (12 MBit/s), to high speed (480 MBit/s) Type A Max. 500 mA or 1 A per connection
Reset button	Yes, accessible behind the orange front doors
LEDs	4 directed outwards via fiber optic lines, also see section "Status LEDs", on page 105
Buzzer	Yes

Table 25: Technical data - APC810, 2 card slot variant

Features	5PC810.SX02-00
Card slots Amount half-size	See also section "Card slot (PCI / PCIe)", on page 104 2 Dimensions of the PCI / PCIe cards vary
Add-on UPS slot	Yes
AP Link slot	Yes
Electrical characteristics	
Power supply Rated voltage Rated current Starting current Power consumption	 24 VDC ±25% 6 A Typ. 7 A, max. 50 A < 300µs Component-dependent, see section "Power calculation with 5PC810.SX02-00 revision>= D0", on page 78
Mechanical characteristics	
Housing[3] Item Paint Front cover	 Galvanized plate, plastic Light gray (similar to Pantone 427CV), dark gray (similar to Pantone 432CV) Colored orange plastic (similar to Pantone 144CV)
Outer dimensions	See "Dimensions - APC810 2 card slot variant", on page 56
Weight	Approx. 2.8 kg (component-dependent)
Environmental characteristics	
Ambient temperature Operation Bearings Transport	 Component-dependent - see section 2.5 "Ambient temperatures", on page 67 -20 to 60°C -20 to 60°C
Relative humidity Operation Bearings Transport	 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74
Vibration[4] Operation (continuous) Operation (occasional) Bearings Transport	 2 - 9 Hz: 1.75 mm amplitude / 9 - 200 Hz: 0.5 g 2 - 9 Hz: 3.5 mm amplitude / 9 - 200 Hz: 1 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g
Shock[4] Operation Bearings Transport	 15 g, 11 ms 30 g, 15 ms 30 g, 15 ms
Protection	IP20
Altitude Operation	 max. 3000 m[5] (component-dependent)

Table 25: Technical data - APC810, 2 card slot variant (Forts.)

1) Maintenance controller extended.

2) At 50°C, 8.5 µA of the supplied components and a self discharge of 40%.

3) Depending on the process or batch, there may be visible deviations in the color and surface structure.

4) Maximum values, as long as no other individual component specifies any other.

5) Derating the maximum ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

2.2.3 Dimensions



Figure 10: Dimensions - APC810 2 card slot variant

2.3 Overview of APC810 3 card slot variations

2.3.1 Interfaces



Figure 11: Interface overview - APC810, 3 card slot variant (top)

Warning!

Do not remove mounting screws from the heat sink, as it is connected to the processor and chipset by a thermal coupling. If this connection is broken, the APC810 must be sent for repair. Removal of the mounting screws, which can be determined by a broken seal, voids all warranty.

During operation, surface temperatures of the heat sink may reach 70°C (warning "hot surface").



Figure 12: Interface overview - APC810, 3 card slot variant (front)

Information:

The orange front doors contain two permanent magnets. Contact between a data carrier that saves data magnetically (hard disk, diskette, the magnetic strip of a credit card, etc.) and a magnet can cause loss of data.

2.3.2 Technical data

Features	5PC810.SX03-00
B&R ID code	$B2C3
Boot loader / Operating system	BIOS
Processor Cooling Method	Component-dependent, see technical data for the "CPU boards 945GME", on page 119 Passive via heat sink and optionally supported with an active fan kit
Main memory	Max. 3 GB
Graphics Controller	 Component-dependent, see technical data for the "CPU boards 945GME", on page 119
Power failure logic Controller Buffer time	 MTCX[1] (see also page 498) 10 ms
Real-time clock (RTC) Battery-buffered Accuracy	 Yes see technical data of the "CPU boards 945GME", on page 119
SRAM Battery-buffered Quantity Remanent variables for AR (Automation Runtime) in power fail mode	 Yes 512 kB 192 kB
Battery Type removable Lifespan	See also page 108 Renata 950 mAh Yes, accessible behind the orange front doors 2 1/2 years[2]
Ethernet Amount Speed Controller	 2 10/100/1000 Mbit/s See also page 96 or page 98
CAN bus	Optional using add-on interface (5AC600.CANI-00)
CompactFlash Type Amount	See also page 110 or page 111 Type I 2
Serial interface Amount Type UART Transfer rate Connection	See also page 94 or page 95 2 RS232, modem-capable, not electrically isolated 16550-compatible, 16-byte FIFO Max. 115 kBaud 9-pin DSUB
USB interface Type Amount Transfer rate Connection Current load	Also see page 99 USB 2.0 5 Low speed (1.5 MBit/s), full speed (12 MBit/s), to high speed (480 MBit/s) Type A Max. 500 mA or 1 A per connection
Reset button	Yes, accessible behind the orange front doors
LEDs	4 directed outwards via fiber optic lines, also see section "Status LEDs", on page 105
Buzzer	Yes

Table 26: Technical data - APC810, 3 card slot variant

Features	5PC810.SX03-00
Card slots Amount half-size	See also section "Card slot (PCI / PCIe)", on page 104 3 Dimensions of the PCI / PCIe cards vary
Add-on UPS slot	Yes
AP Link slot	Yes
Electrical characteristics	
Power supply Rated voltage Rated current Starting current Power consumption	 24 VDC ±25% 6 A Typ. 7 A, max. 50 A < 300µs Component-dependent, see section "Power calculation with 5PC810.SX03-00", on page 80
Mechanical characteristics	
Housing[3] Item Paint Front cover	 Galvanized plate, plastic Light gray (similar to Pantone 427CV), dark gray (similar to Pantone 432CV) Colored orange plastic (similar to Pantone 144CV)
Outer dimensions	See "Dimensions - APC810 3 card slot variant", on page 61
Weight	Approx. 3.2 kg (component-dependent)
Environmental characteristics	
Ambient temperature Operation Bearings Transport	 Component-dependent - see section 2.5 "Ambient temperatures", on page 67 -20 to 60°C -20 to 60°C
Relative humidity Operation Bearings Transport	 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74
Vibration[4] Operation (continuous) Operation (occasional) Bearings Transport	 2 - 9 Hz: 1.75 mm amplitude / 9 - 200 Hz: 0.5 g 2 - 9 Hz: 3.5 mm amplitude / 9 - 200 Hz: 1 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g
Shock[4] Operation Bearings Transport	 15 g, 11 ms 30 g, 15 ms 30 g, 15 ms
Protection	IP20
Altitude Operation	 max. 3000 m[5] (component-dependent)

Table 26: Technical data - APC810, 3 card slot variant (Forts.)

1) Maintenance controller extended.

2) At 50°C, 8.5 µA of the supplied components and a self discharge of 40%.

3) Depending on the process or batch, there may be visible deviations in the color and surface structure.

4) Maximum values, as long as no other individual component specifies any other.

5) Derating the maximum ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

2.3.3 Dimensions



Figure 13: Dimensions - APC810 3 card slot variant

2.4 Overview of APC810 5 card slot variations

2.4.1 Interfaces



Figure 14: Interface overview - APC810, 5 card slot variant (top)

Warning!

Do not remove mounting screws from the heat sink, as it is connected to the processor and chipset by a thermal coupling. If this connection is broken, the APC810 must be sent for repair. Removal of the mounting screws, which can be determined by a broken seal, voids all warranty.

During operation, surface temperatures of the heat sink may reach 70°C (warning "hot surface").



Figure 15: Interface overview - APC810, 5 card slot variant (front)

Information:

The orange front doors contain two permanent magnets. Contact between a data carrier that saves data magnetically (hard disk, diskette, the magnetic strip of a credit card, etc.) and a magnet can cause loss of data.

2.4.2 Technical data

Features	5PC810.SX05-00
B&R ID code	$A3EE
Boot loader / Operating system	BIOS
Processor Cooling Method	Component-dependent, see technical data for the "CPU boards 945GME", on page 119 Passive via heat sink and optionally supported with an active fan kit
Main memory	Max. 3 GB
Graphics Controller	 Component-dependent, see technical data for the "CPU boards 945GME", on page 119
Power failure logic Controller Buffer time	 MTCX[1] (see also page 498) 10 ms
Real-time clock (RTC) Battery-buffered Accuracy	 Yes see technical data of the "CPU boards 945GME", on page 119
SRAM Battery-buffered Quantity Remanent variables for AR (Automation Runtime) in power fail mode	 Yes 512 kB 192 kB
Battery Type removable Lifespan	See also page 108 Renata 950 mAh Yes, accessible behind the orange front doors 2 1/2 years[2]
Ethernet Amount Speed Controller	 2 10/100/1000 Mbit/s See also page 96 or page 98
CAN bus	Optional using add-on interface (5AC600.CANI-00)
CompactFlash Type Amount	See also page 110 or page 111 Type I 2
Serial interface Amount Type UART Transfer rate Connection	See also page 94 or page 95 2 RS232, modem-capable, not electrically isolated 16550-compatible, 16-byte FIFO Max. 115 kBaud 9-pin DSUB
USB interface Type Amount Transfer rate Connection Current load	Also see page 99 USB 2.0 5 Low speed (1.5 Mbit/s), full speed (12 Mbit/s), to high speed (480 Mbit/s) Type A Max. 500 mA or 1 A per connection
Reset button	Yes, accessible behind the orange front doors
LEDs	4 directed outwards via fiber optic lines, also see section "Status LEDs", on page 105
Buzzer	Yes

Table 27: Technical data - APC810, 5 card slot variant

Features	5PC810.SX05-00
Card slots Amount half-size	See also section "Card slot (PCI / PCIe)", on page 104 5 Dimensions of the PCI / PCIe cards vary
Add-on UPS slot	Yes
AP Link slot	Yes
Electrical characteristics	
Power supply Rated voltage Rated current Starting current Power consumption	 24 VDC ±25% 6 A Typ. 7 A, max. 50 A < 300µs Component-dependent, see section "Power calculation with 5PC810.SX05-00", on page 81
Mechanical characteristics	
Housing[3] Item Paint Front cover	 Galvanized plate, plastic Light gray (similar to Pantone 427CV), dark gray (similar to Pantone 432CV) Colored orange plastic (similar to Pantone 144CV)
Outer dimensions	See "Dimensions - APC810 5 card slot variant", on page 66
Weight	Approx. 3.9 kg (component-dependent)
Environmental characteristics	
Ambient temperature Operation Bearings Transport	 Component-dependent - see section 2.5 "Ambient temperatures", on page 67 -20 to 60°C -20 to 60°C
Relative humidity Operation Bearings Transport	 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74 Component-dependent, see section "Humidity specifications", on page 74
Vibration[4] Operation (continuous) Operation (occasional) Bearings Transport	 2 - 9 Hz: 1.75 mm amplitude / 9 - 200 Hz: 0.5 g 2 - 9 Hz: 3.5 mm amplitude / 9 - 200 Hz: 1 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g 2 - 8 Hz: 7.5 mm amplitude / 8 - 200 Hz: 2 g / 200 - 500 Hz: 4 g
Shock[4] Operation Bearings Transport	 15 g, 11 ms 30 g, 15 ms 30 g, 15 ms
Protection	IP20
Altitude Operation	 max. 3000 m[5] (component-dependent)

Table 27: Technical data - APC810, 5 card slot variant (Forts.)

1) Maintenance controller extended.

2) At 50°C, 8.5 µA of the supplied components and a self discharge of 40%.

3) Depending on the process or batch, there may be visible deviations in the color and surface structure.

4) Maximum values, as long as no other individual component specifies any other.

5) Derating the maximum ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

2.4.3 Dimensions



Figure 16: Dimensions - APC810 5 card slot variant

2.5 Ambient temperatures

It is possible to combine CPU boards with various other components, such as drives, main memory, additional insert cards, etc. depending on system unit and fan kit. The various configurations result in varying maximum possible ambient temperatures, which can be seen in the following graphics.

Information:

The maximum specified ambient temperatures for operation with and without a fan kit were determined under worst-case conditions. Experience has shown that higher ambient temperatures can be reached under typical conditions, e.g. using Microsoft Windows. The testing and evaluation is to be done on-site by the user (temperatures can be read in BIOS or using the B&R Control Center).

Information regarding the worst-case conditions

- Thermal Analysis Tool (TAT V2.02) from Intel for simulating 100% processor load
- BurnIn testing tool (BurnIn V4.0 Pro from Passmark Software) to simulate a 100% load on the interface via loop-back adapters (serial interfaces, add-on and slide-in drives, USB ports, audio outputs)
- Maximum system extension and power consumption

What must be considered when determining the maximum ambient temperature?

- Operation of the Ethernet interfaces (ETH1/ETH2) in 10/100MBit or 1 Gbit mode
- Operating the entire device with or without fan kit
- Revision of heat sink being used

2.5.1 Maximum ambient temperature without a fan kit

Information:

- **Differentiating the ETH2 interface in up to 100 MBit or 1 GBit operation**
- **Operation without the fan kit is only permitted with a vertical mounting orientation (see also Chapter 3 "Commissioning", Section "Mounting orientation", on page 192).**
- **The specifications in the following table are only valid for system units with with heat sinks 5AC801.HS00-00 < Rev. D0 and 5AC801.HS00-01 < Rev. D0.**

All temperature values in degrees celsius (°C) at 500 meters above sea level. Derating of them maximum ambient temperature, generally 1°C per 1000 meters starting at 500 meters above sea level.		ETH1: up to 100 Mbit operation ETH2: up to 100 Mbit operation						ETH1: up to 100 Mbit operation ETH2: up to 100 Gbit operation							
		L2400	L7400	U7500	CM 423	T7400		L2400	L7400	U7500	CM 423	T7400		Temperature limits	Location of sensor(s)
		5PC800.B945-00	5PC800.B945-01	5PC800.B945-02	5PC800.B945-03	5PC800.B945-04		5PC800.B945-00	5PC800.B945-01	5PC800.B945-02	5PC800.B945-03	5PC800.B945-04			
	Maximem ambient temperature	35	35	35	45	/		30	30	30	40	/			
	What can also be operated at the max. ambient temperature, or are there limits? ⇩														
Slide-in compact	On-board CompactFlash[1]	✓	✓	✓	✓			✓	✓	✓	✓			80	I/O
	5AC801.HDDI-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5AC801.HDDI-01	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5AC801.HDDI-02	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5AC801.HDDI-03	✓	✓	✓	✓			✓	✓	✓	✓			60	
	5AC801.SSDI-00	✓	✓	✓	✓			✓	✓	✓	✓			70	
Slide-in option	5AC801.HDDS-00	✓	✓	✓	✓			✓	✓	✓	✓			80	Slide-in drive
	5AC801.DVDS-00	✓	✓	✓	40			✓	✓	✓	✓			50	
	5AC801.DVRS-00	✓	✓	✓	40			✓	✓	✓	✓			50	
Main memory	5MMDDR.0512-01	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5MMDDR.1024-01	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5MMDDR.2048-01	✓	✓	✓	✓			✓	✓	✓	✓			-	
System units	5PC810.SX01-00	✓	✓	✓	✓			✓	✓	✓	✓			80	Power supply
	5PC810.SX02-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5PC810.SX03-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5PC810.SX05-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
Additional insert cards Interfaces / AP Link	5AC600.CANI-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5AC600.485I-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5AC801.SDL0-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5AC801.RDYR-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5ACPCI.RAIC-01(24 hours / default)	30/✓	30/✓	30/✓	30/40			✓	✓	✓	30/✓			-	
	5ACPCI.RAIC-03	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5ACPCI.RAIC-05	✓	✓	✓	✓			✓	✓	✓	✓			-	

1) Only possible with a CompactFlash card from B&R (5CFCRD.xxxx-04 or 5CFCRD.xxxx-03).

Figure 17: Ambient temperatures without a fan kit with heat sink < Rev. D0

Information:

- **Differentiating between up to 100 MBit or 1 Gbit operation of ETH1 and ETH2.**
- **Operation without the fan kit is only permitted with a vertical mounting orientation (see also Chapter 3 "Commissioning", Section "Mounting orientation", on page 192).**
- **The specifications in the following table are only valid for system units with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0.**

		ETH1: up to 100 Mbit operation ETH2: up to 100 Mbit operation						ETH1: up to 1 Gbit operation ETH2: up to 1 Gbit operation							
All temperature values in degrees celsius (°C) at 500 meters above sea level. Derating of the maximum ambient temperature , generally 1°C per 1000 meters starting at 500 meters above sea level.		L2400 5PC800.B945-00	L7400 5PC800.B945-01	U7500 5PC800.B945-02	CM 423 5PC800.B945-03	T7400 5PC800.B945-04		L2400 5PC800.B945-00	L7400 5PC800.B945-01	U7500 5PC800.B945-02	CM 423 5PC800.B945-03	T7400 5PC800.B945-04		Temperature limits	Location of sensor(s)
	Maximum ambient temperature	35	35	45	45	/		30	30	40	40	/			
	What can also be operated at the max. ambient temperature, or are there limits? ⇩														
Slide-in compact	On-board CompactFlash[1)]	✓	✓	✓	✓			✓	✓	✓	✓			80	I/O
	5AC801.HDDI-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5AC801.HDDI-01	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5AC801.HDDI-02	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5AC801.HDDI-03	✓	✓	✓	✓			✓	✓	✓	✓			60	
	5AC801.SSDI-00	✓	✓	✓	✓			✓	✓	✓	✓			70	
Slide-in option	5AC801.HDDS-00	✓	✓	✓	✓			✓	✓	✓	✓			80	Slide-in drive
	5AC801.DVDS-00	✓	✓	40	40			✓	✓	✓	✓			50	
	5AC801.DVRS-00	✓	✓	40	40			✓	✓	✓	✓			50	
Main memory	5MMDDR.0512-01	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5MMDDR.1024-01	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5MMDDR.2048-01	✓	✓	✓	✓			✓	✓	✓	✓			-	
System units	5PC810.SX01-00	✓	✓	✓	✓			✓	✓	✓	✓			80	Power supply
	5PC810.SX02-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5PC810.SX03-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
	5PC810.SX05-00	✓	✓	✓	✓			✓	✓	✓	✓			80	
Additional insert cards Interfaces / AP Link	5AC600.CANI-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5AC600.485I-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5AC801.SDL0-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5AC801.RDYR-00	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5ACPCI.RAIC-01(24 hours / default)	30/✓	30/✓	30/✓	30/40			✓	✓	✓	30/✓			-	
	5ACPCI.RAIC-03	✓	✓	✓	✓			✓	✓	✓	✓			-	
	5ACPCI.RAIC-05	✓	✓	✓	✓			✓	✓	✓	✓			-	

1) Only possible with a CompactFlash card from B&R (5CFCRD.xxxx-04 or 5CFCRD.xxxx-03).

Figure 18: Ambient temperatures without a fan kit with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0

Information:

- **NO differentiation between the up to 100 MBit vs up to 1 Gbit operation of ETH1 and ETH2.**
- **Operation without the fan kit is only permitted with a vertical mounting orientation (see also Chapter 3 "Commissioning", Section "Mounting orientation", on page 192).**
- **The specifications in the following table are only valid for system units with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0 and the CPU board 5PC800.B945-05 with heat sink 5AC801.HS00-02.**

	All temperature values in degrees celsius (°C) at 500 meters above sea level. Derating of the maximum ambient temperature, generally 1°C per 1000 meters starting at 500 meters above sea level.	L2400 5PC800.B945-10	L7400 5PC800.B945-11	U7500 5PC800.B945-12	CM 423 5PC800.B945-13	T7400 5PC800.B945-14	N270 5PC800.B945-05	Temperature limits	Location of sensor(s)
	Maximum ambient temperature	35	35	45	45	/	50		
	What can also be operated at the max. ambient, temperature, or are there limits?								
Slide-in compact	On-board CompactFlash[1)]	✓	✓	✓	✓		✓	80	I/O
	5AC801.HDDI-00	✓	✓	✓	✓		✓	80	
	5AC801.HDDI-01	✓	✓	✓	✓		✓	80	
	5AC801.HDDI-02	✓	✓	✓	✓		✓	80	
	5AC801.HDDI-03	✓	✓	✓	✓		45	60	
	5AC801.SSDI-00	✓	✓	✓	✓		✓	70	
Slide-in option	5AC801.HDDS-00	✓	✓	✓	✓		✓	80	Slide-in drive
	5AC801.DVDS-00	✓	✓	40	40		40	50	
	5AC801.DVRS-00	✓	✓	40	40		40	50	
Main memory	5MMDDR.0512-01	✓	✓	✓	✓		✓	-	
	5MMDDR.1024-01	✓	✓	✓	✓		✓	-	
	5MMDDR.2048-01	✓	✓	✓	✓		✓	-	
System units	5PC810.SX01-00	✓	✓	✓	✓		✓	80	Power supply
	5PC810.SX02-00	✓	✓	✓	✓		✓	80	
	5PC810.SX03-00	✓	✓	✓	✓		✓	80	
	5PC810.SX05-00	✓	✓	✓	✓		✓	80	
Additional insert cards Interfaces / AP Link	5AC600.CANI-00	✓	✓	✓	✓		✓	-	
	5AC600.485I-00	✓	✓	✓	✓		✓	-	
	5AC801.SDL0-00	✓	✓	✓	✓		✓	-	
	5AC801.RDYR-00	✓	✓	✓	✓		✓	-	
	5ACPCI.RAIC-01(24 hours / default)	30/✓	30/✓	30/✓	30/40		30/40	-	
	5ACPCI.RAIC-03	✓	✓	✓	✓		✓	-	
	5ACPCI.RAIC-05	✓	✓	✓	✓		45	-	

1) Only possible with a CompactFlash card from B&R (5CFCRD.xxxx-04 or 5CFCRD.xxxx-03).

Figure 19: Ambient temperatures without a fan kit with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0 and 5AC801.HS00-02

2.5.2 Maximum ambient temperature with a fan kit

Information:

- **Differentiating between up to 100 MBit or 1 Gbit operation of ETH1 and ETH2.**
- **Vertical and horizontal (minus 5°C) mounting orientations are permitted (see also Chapter 3 "Commissioning", Section "Mounting orientation", on page 192).**

	All temperature values in degrees Celsius (°C) at 500 meters NN. Derating the maximum ambient temperature (typically 1°C per 1000 meters above 500 NN).	ETH1: up to 100 MBit operation ETH2: up to 100 MBit operation						ETH1: up to 1 GBit operation ETH2: up to 1 GBit operation						Temperature limits	Location of sensor(s)
		L2400 5PC800.B945-00	L7400 5PC800.B945-01	U7500 5PC800.B945-02	CM 423 5PC800.B945-03	T7400 5PC800.B945-04		L2400 5PC800.B945-00	L7400 5PC800.B945-01	U7500 5PC800.B945-02	CM 423 5PC800.B945-03	T7400 5PC800.B945-04			
	Maximum ambient temperature [1]	55	55	55	55	55		50	50	50	50	45			
	What can also be operated at the max. ambient temperature, or are there limits? ⇩														
Slide-in compact	On-Board CompactFlash [2]	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	I/O
	5AC801.HDDI-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	
	5AC801.HDDI-01	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	
	5AC801.HDDI-02	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	
	5AC801.HDDI-03	50	50	50	50	50		✓	✓	✓	✓	✓		60	
	5AC801.SSDI-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		70	
Slide-in Option	5AC801.HDDS-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	Slide-in Drive
	5AC801.DVDS-00	50	50	50	50	50		✓	✓	✓	✓	✓		50	
	5AC801.DVRS-00	50	50	50	50	50		✓	✓	✓	✓	✓		50	
Main memory	5MMDDR.0512-01	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5MMDDR.1024-01	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5MMDDR.2048-01	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
System unit	5PC810.SX01-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	Power supply
	5PC810.SX02-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	
	5PC810.SX03-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	
	5PC810.SX05-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		80	
Additional insert cards Interfaces / AP Link	5AC600.CANI-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5AC600.485I-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5AC801.SDL0-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5AC801.RDYR-00	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5ACPCI.RAIC-01(24 hours/standard)	30/40	30/40	30/40	30/40	30/40		30/40	30/40	30/40	30/40	30/40		-	
	5ACPCI.RAIC-03	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		-	
	5ACPCI.RAIC-05	50	50	50	50	50		✓	✓	✓	✓	✓		-	

1) The maximum ambient temperature must be reduced by 5°C for horizontal installation!
2) Only possible with a CompactFlash card 5CFCRD.xxxx-04 or 5CFCRD.xxxx-03 available from B&R

Figure 20: Ambient temperatures with fan kit on CPU boards 5PC800.B945-0x

Information:

- **NO differentiation between the up to 100 MBit vs up to 1 Gbit operation of ETH1 and ETH2.**
- **Vertical and horizontal (minus 5°C) mounting orientations are permitted (see also Chapter 3 "Commissioning", Section "Mounting orientation", on page 192).**
- **The specifications in the following table are only valid for system units with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0 and the CPU board 5PC800.B945-05 with heat sink 5AC801.HS00-02.**

	All temperature values in degrees celsius (°C) at 500 meters above sea level. Derating of the maximum ambient temperature, generally 1°C per 1000 meters starting at 500 meters above sea level.	L2400 5PC800.B945-10	L7400 5PC800.B945-11	U7500 5PC800.B945-12	CM 423 5PC800.B945-13	T7400 5PC800.B945-14	N270 5PC800.B945-05	Temperature limits	Location of sensor(s)
	Maximum ambient temperature [1]	55	55	55	55	55	60		
	What can also be operated at the max. ambient temperature, or are there limitations?								
Slide-in compact	On-board CompactFlash [2]	✓	✓	✓	✓	✓	✓	80	I/O
	5AC801.HDDI-00	✓	✓	✓	✓	✓	✓	80	
	5AC801.HDDI-01	✓	✓	✓	✓	✓	✓	80	
	5AC801.HDDI-02	✓	✓	✓	✓	✓	✓	80	
	5AC801.HDDI-03	50	50	50	50	50	50	60	
	5AC801.SSDI-00	✓	✓	✓	✓	✓	✓	70	
Slide-in option	5AC801.HDDS-00	✓	✓	✓	✓	✓	✓	80	Slide-in drive
	5AC801.DVDS-00	50	50	50	50	50	50	50	
	5AC801.DVRS-00	50	50	50	50	50	50	50	
Main memory	5MMDDR.0512-01	✓	✓	✓	✓	✓	✓	-	
	5MMDDR.1024-01	✓	✓	✓	✓	✓	✓	-	
	5MMDDR.2048-01	✓	✓	✓	✓	✓	✓	-	
System units	5PC810.SX01-00	✓	✓	✓	✓	✓	✓	80	Power supply
	5PC810.SX02-00	✓	✓	✓	✓	✓	✓	80	
	5PC810.SX03-00	✓	✓	✓	✓	✓	✓	80	
	5PC810.SX05-00	✓	✓	✓	✓	✓	✓	80	
Additional insert cards Interfaces / AP Link	5AC600.CANI-00	✓	✓	✓	✓	✓	✓	-	
	5AC600.485I-00	✓	✓	✓	✓	✓	✓	-	
	5AC801.SDL0-00	✓	✓	✓	✓	✓	✓	-	
	5AC801.RDYR-00	✓	✓	✓	✓	✓	✓	-	
	5ACPCI.RAIC-01(24 hours / default)	30/40	30/40	30/40	30/40	30/40	30/40	-	
	5ACPCI.RAIC-03	✓	✓	✓	✓	✓	✓	-	
	5ACPCI.RAIC-05	50	50	50	50	50	50	-	

1) With horizontal mounting, the maximum ambient temperature must be reduced by 5°C!
2) Only possible with a CompactFlash card from B&R (5CFCRD.xxxx-04 or 5CFCRD.xxxx-03).

Figure 21: Ambient temperatures with fan kit on CPU boards 5PC800.B945-05 and 5PC800.B945-1x

2.5.3 Minimum ambient temperature

For systems containing one of the following components, the minimum ambient temperature is +5°C: 5AC801.DVDS-00, 5AC801.DVRS-00, 5ACPCI.RAIC-01, 5ACPCI.RAIC-02. If none of these components are used, then the minimum ambient temperature is 0°C.

2.5.4 How is the the maximum ambient temperature determined?

1) Selection of the CPU board (use **with** or **without** fan kit).

2) The "maximum ambient temperature" line shows the maximum ambient temperature for the entire system when using the respective CPU board.

Information:

Maximum temperature data is for operation at 500 meters. Derating the maximum ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

3) Incorporating additional drives (add-on, slide-in), main memory, additional insert cards, etc. can change the temperature limits of an APC810 system.

If there is a ✓ (checkmark) next to the component, it can be used at the maximum ambient temperature of the whole system without problems.

If there is a specific temperature, for example "35", next to the component, then the ambient temperature of the whole APC810 system cannot exceed this temperature.

2.5.5 Temperature monitoring

Sensors monitor temperature values in various places (CPU, board, board I/O, board ETH2, board power supply, ETH2 controller, power supply and slide-in drives 1/2) on the APC810. The position of the temperature sensors can be found in the figure "Temperature sensor locations", on page 497. The value listed in the table represents the defined maximum temperature for this measurement point[1)] . An alarm is not triggered when this temperature is exceeded. The temperatures[1)] can be read in BIOS (menu item "Advanced" - Baseboard/panel features - Baseboard monitor) or in Microsoft Windows XP/Embedded or Windows Embedded Standard 2009, using the B&R Control Center.
Additionally, the hard disks for PPC810 systems available from B&R are equipped with S.M.A.R.T, or Self Monitoring, Analysis, and Reporting Technology. This makes it possible to read various parameters, for example the temperature, using software (e.g. HDD thermometer - freeware) in Microsoft Windows XP/Embedded and Windows Embedded Standard 2009.

1) The measured temperature is a guideline for the immediate ambient temperature, but can be influenced by neighboring components.

2.6 Humidity specifications

The following table displays the minimum and maximum relative humidity for the individual components that are relevant for the humidity limitations of the entire device. The lowest and highest common values are always used when establishing these limits.

Component		Operation	Storage / Transport
CPU boards 945GME COM Express		10 - 90%	5 - 95%
System units (all models)		5 - 90%	5 - 95%
Main memory for CPU boards		10 - 90%	5 - 95%
Slide-in drives	5AC801.HDDI-00	5 - 90%	5 - 95%
	5AC801.HDDI-01	5 - 90%	5 - 95%
	5AC801.HDDI-02	8 - 80%	5 - 95%
	5AC801.HDDI-03	5 - 95%	5 - 95%
	5AC801.HDDS-00	5 - 90%	5 - 90%
	5AC801.DVDS-00	8 - 90%	5 - 95%
	5AC801.DVRS-00	8 - 90%	5 - 95%
Additional insert cards Interfaces AP Link	5AC600.CANI-00	5 - 90%	5 - 95%
	5AC600.485I-00	5 - 90%	5 - 95%
	5AC801.SDL0-00	5 - 90%	5 - 95%
	5AC801.RDYR-00	5 - 90%	5 - 95%
	5ACPCI.RAIC-01 (24 hours/default)	5 - 90%	5 - 95%
	5ACPCI.RAIC-02 (24 hours/default)	5 - 90%	5 - 95%
	5ACPCI.RAIC-03 (24 hours/default)	8 - 90%	5 - 95%
	5ACPCI.RAIC-04 (24 hours/default)	8 - 90%	5 - 95%
	5ACPCI.RAIC-05 (24 hours/default)	5 - 95%	5 - 95%
	5MMHDD.0250-00 (24 hours/default)	5 - 95%	5 - 95%
Accessories	CompactFlash cards 5CFCRD.xxxx-04	85%	85%
	CompactFlash cards - 5CFCRD.xxxx-03	8 - 95%	8 - 95%
	Flash drive 5MMUSB.2048-xx	10 - 90%	5 - 90%
	USB Media Drive 5MD900.USB2-01	20 - 80%	5 - 90%

Table 28: Overview of humidity specifications for individual components

The listed specifications correspond to the relative humidity at an ambient temperature of 30°C. More detailed information about the specific temperature-dependent humidity values can be found in the technical data for the individual components.

2.7 Power management

2.7.1 Block diagram - supply voltage

The following block diagram presents the simplified structure of the APC810 supply voltage for system units.



Figure 22: Supply voltage for system units

Description

The supply voltage is converted to 15 V with a DC/DC converter. These electrically isolated 15 V feed further DC/DC converters, which generate the remaining voltages.

After the system is turned on (e.g. using the power button), the voltages 3V3 and 5 V are placed on the bus. At the 5 V output, yet another DC/DC converter generates -12 V, and places these on the bus. An additional DC/DC converter generates +12 V.

The optional Add-on UPS (with battery unit) is supplied with 15 V and provides an uninterrupted power supply from the 15 V bus during power failures.

2.7.2 Power calculation with 5PC810.SX01-00 revision >= D0

Information:	CPU Boards						This system
	L2400	L7400	U7500	CM423	T7400	N270	
All entries in watts The entries for the **Generator** are maximum values. Entries for the **Device** are determined maximum values, but not peak values.	5PC800.B945-00 5PC800.B945-10	5PC800.B945-01 5PC800.B945-11	5PC800.B945-02 5PC800.B945-12	5PC800.B945-03 5PC800.B945-13	5PC800.B945-04 5PC800.B945-14	5PC800.B945-05	Enter values in this column
Total power supply (max.)							130
Add-on UPS module, optional	7.5	7.5	7.5	7.5	7.5	7.5	
max. possible at +12V							75
CPU Board, fixed device	26	30	18	14	43	11	
512MB RAM, max. 2 pcs. each 1.5 watts							
1024MB RAM, max. 2 pcs. each 2.5 watts							
2048MB RAM, max. 2 pcs. each 3 watts							
Fan kit, optional	1.8	1.8	1.8	1.8	1.8	1.8	
External keyboard, optional (via Baseboard)	10	10	10	10	10	10	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 6 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
Devices +12V Σ							
max. possible at +5V							65
System unit, fixed device	4	4	4	4	4	4	
Hard Disk (slide-in compact)	4	4	4	4	4	4	
USB Peripheral USB2 and USB4, each 2.5 watts							
USB Peripheral USB1, USB3 and USB5, each 5 watts							
Interface option (Add-on interface), optional	0.5	0.5	0.5	0.5	0.5	0.5	
External device, optional (via BaseBoard)	5	5	5	5	5	5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
max. possible at -12V							1,2
PCI card manufacturer limit, optional (max. 1.2 watts with and without fan kit) [1]							
Devices -12V Σ							
Devices 5V Σ							
max. possible at 3V3							40
System unit, fixed device	4	4	4	4	4	4	
CompactFlash, each 1 watt							
Interface option (Add-on interface), optional	0.25	0.25	0.25	0.25	0.25	0.25	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 15 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 10 watts with fan kit) [1]							
Devices 3V3 Σ							
Devices Σ							

Total power supply: +12V, +5V, -12V, 3V3

1) The total performance of one PCI/PCIe card per PCI slot (= sum of power consumptions for each voltage area) may not exceed the limits stated for operation with or without a fan kit.

Figure 23: Power calculation with 5PC810.SX01-00 revision >= D0

2.7.3 Power calculation with 5PC810.SX01-00 revision < D0

Information:	CPU boards						This system
All entries in watts The entries for the **Generator** are maximum values. Entries for the **Device** are determined maximum values, but not peak values.	L2400 5PC800.B945-00 5PC800.B945-10	L7400 5PC800.B945-01 5PC800.B945-11	U7500 5PC800.B945-02 5PC800.B945-12	CM423 5PC800.B945-03 5PC800.B945-13	T7400 5PC800.B945-04 5PC800.B945-14	N270 5PC800.B945-05	Enter values in this column
Total power supply (max.)							85
Add-on UPS module, optional	7.5	7.5	7.5	7.5	7.5	7.5	
+12V: max. possible at +12V							75
CPU Board, fixed device	26	30	18	14	43	11	
512MB RAM, max. 2 pcs. each 1.5 watts							
1024MB RAM, max. 2 pcs. each 2.5 watts							
2048MB RAM, max. 2 pcs. each 3 watts							
Fan kit, optional	1.8	1.8	1.8	1.8	1.8	1.8	
External keyboard, optional (via Baseboard)	10	10	10	10	10	10	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 6 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
+12V: Devices +12V Σ							
+5V: max. possible at +5V							65
System unit, fixed device	4	4	4	4	4	4	
Hard Disk (slide-in compact)	4	4	4	4	4	4	
USB Peripheral USB2 and USB4, each 2.5 watts							
USB Peripheral USB1, USB3 and USB5, each 5 watts							
Interface option (Add-on interface), optional	0.5	0.5	0.5	0.5	0.5	0.5	
External device, optional (via BaseBoard)	5	5	5	5	5	5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
-12V: max. possible at -12V							1,2
PCI card manufacturer limit, optional (max. 1.2 watts with and without fan kit) [1]							
-12V: Devices -12V Σ							
+5V: Devices 5V Σ							
3V3: max. possible at 3V3							40
System unit, fixed device	4	4	4	4	4	4	
CompactFlash, each 1 watt							
Interface option (Add-on interface), optional	0.25	0.25	0.25	0.25	0.25	0.25	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 15 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 10 watts with fan kit) [1]							
3V3: Devices 3V3 Σ							
Total power supply: Devices Σ							

1) The total performance of one PCI/PCIe card per PCI slot (= sum of power consumptions for each voltage area) may not exceed the limits stated for operation with or without a fan kit.

Figure 24: Power calculation with 5PC810.SX01-00 revision < D0

2.7.4 Power calculation with 5PC810.SX02-00 revision>= D0

Information:	CPU boards						This system
	L2400	L7400	U7500	CM423	T7400	N270	
All entries in watts The entries for the **Generator** are maximum values. Entries for the **Device** are determined maximum values, but not peak values.	5PC800.B945-00 5PC800.B945-10	5PC800.B945-01 5PC800.B945-11	5PC800.B945-02 5PC800.B945-12	5PC800.B945-03 5PC800.B945-13	5PC800.B945-04 5PC800.B945-14	5PC800.B945-05	Enter values in this column
Total power supply (max.)							130
Add-on UPS module, optional	7.5	7.5	7.5	7.5	7.5	7.5	
max. possible at +12V							75
CPU Board, fixed device	26	30	18	14	43	11	
512MB RAM, max. 2 pcs. each 1.5 watts							
1024MB RAM, max. 2 pcs. each 2.5 watts							
2048MB RAM, max. 2 pcs. each 3 watts							
Fan kit, optional	1.8	1.8	1.8	1.8	1.8	1.8	
External keyboard, optional (via Baseboard)	10	10	10	10	10	10	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 6 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
Devices +12V Σ							
max. possible at +5V							65
System unit, fixed device	4	4	4	4	4	4	
Hard Disk (slide-in compact)	4	4	4	4	4	4	
Slide-in drive (hard disk, DVD-ROM,...)	4	4	4	4	4	4	
USB Peripheral USB2 and USB4, each 2.5 watts							
USB Peripheral USB1, USB3 and USB5, each 5 watts							
Interface option (Add-on interface), optional	0.5	0.5	0.5	0.5	0.5	0.5	
Graphics adapter (AP Link), optional	5	5	5	5	5	5	
External device, optional (via BaseBoard)	5	5	5	5	5	5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
max. possible at -12V							1.2
PCI card manufacturer limit, optional (max. 1.2 watts with and without fan kit) [1]							
Devices -12V Σ							
Devices 5V Σ							
max. possible at 3V3							40
System unit, fixed device	4	4	4	4	4	4	
CompactFlash, each 1 watt							
Interface option (Add-on interface), optional	0.25	0.25	0.25	0.25	0.25	0.25	
Graphics adapter (AP Link), optional	1.5	1.5	1.5	1.5	1.5	1.5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 15 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 10 watts with fan kit) [1]							
Devices 3V3 Σ							
Devices Σ							

Total power supply: +12V, +5V, -12V, 3V3

1) The total performance of one PCI/PCIe card per PCI slot (= sum of power consumptions for each voltage area) may not exceed the limits stated for operation with or without a fan kit.

Figure 25: Power calculation with 5PC810.SX02-00 revision >= D0

2.7.5 Power calculation with 5PC810.SX02-00 revision < D0

Information:	CPU boards						This system
	L2400	L7400	U7500	CM423	T7400	N270	
	5PC800.B945-00 5PC800.B945-10	5PC800.B945-01 5PC800.B945-11	5PC800.B945-02 5PC800.B945-12	5PC800.B945-03 5PC800.B945-13	5PC800.B945-04 5PC800.B945-14	5PC800.B945-05	Enter values in this column
All entries in watts The entries for the **Generator** are maximum values. Entries for the **Device** are determined maximum values, but not peak values.							
Total power supply (max.)							85
Add-on UPS module, optional	7.5	7.5	7.5	7.5	7.5	7.5	
+12V: max. possible at +12V							75
CPU Board, fixed device	26	30	18	14	43	11	
512MB RAM, max. 2 pcs. each 1.5 watts							
1024MB RAM, max. 2 pcs. each 2.5 watts							
2048MB RAM, max. 2 pcs. each 3 watts							
Fan kit, optional	1.8	1.8	1.8	1.8	1.8	1.8	
External keyboard, optional (via Baseboard)	10	10	10	10	10	10	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 6 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
+12V: Devices +12V Σ							
+5V: max. possible at +5V							65
System unit, fixed device	4	4	4	4	4	4	
Hard Disk (slide-in compact)	4	4	4	4	4	4	
Slide-in drive (hard disk, DVD-ROM,...)	4	4	4	4	4	4	
USB Peripheral USB2 and USB4, each 2.5 watts							
USB Peripheral USB1, USB3 and USB5, each 5 watts							
Interface option (Add-on interface), optional	0.5	0.5	0.5	0.5	0.5	0.5	
Graphics adapter (AP Link), optional	5	5	5	5	5	5	
External device, optional (via BaseBoard)	5	5	5	5	5	5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
-12V: max. possible at -12V							1.2
PCI card manufacturer limit, optional (max. 1.2 watts with and without fan kit) [1]							
-12V: Devices -12V Σ							
+5V: Devices 5V Σ							
3V3: max. possible at 3V3							40
System unit, fixed device	4	4	4	4	4	4	
CompactFlash, each 1 watt							
Interface option (Add-on interface), optional	0.25	0.25	0.25	0.25	0.25	0.25	
Graphics adapter (AP Link), optional	1.5	1.5	1.5	1.5	1.5	1.5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 15 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 10 watts with fan kit) [1]							
3V3: Devices 3V3 Σ							
Total power supply: Devices Σ							

1) The total performance of one PCI/PCIe card per PCI slot (= sum of power consumptions for each voltage area) may not exceed the limits stated for operation with or without a fan kit.

Figure 26: Power calculation with 5PC810.SX02-00 revision < D0

2.7.6 Power calculation with 5PC810.SX03-00

Information:	CPU boards						This system
All entries in watts The entries for the **Generator** are maximum values. Entries for the **Device** are determined maximum values, but not peak values.	L2400 5PC800.B945-00 5PC800.B945-10	L7400 5PC800.B945-01 5PC800.B945-11	U7500 5PC800.B945-02 5PC800.B945-12	CM423 5PC800.B945-03 5PC800.B945-13	T7400 5PC800.B945-04 5PC800.B945-14	N270 5PC800.B945-05	Enter values in this column
Total power supply (max.)							130
Add-on UPS module, optional	7.5	7.5	7.5	7.5	7.5	7.5	
max. possible at +12V							75
+12V: CPU Board, fixed device	26	30	18	14	43	11	
+12V: 512MB RAM, max. 2 pcs. each 1.5 watts							
+12V: 1024MB RAM, max. 2 pcs. each 2.5 watts							
+12V: 2048MB RAM, max. 2 pcs. each 3 watts							
+12V: Fan kit, optional	3.7	3.7	3.7	3.7	3.7	3.7	
+12V: External keyboard, optional (via Baseboard)	10	10	10	10	10	10	
+12V: PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 6 watts with fan kit) [1]							
+12V: PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
Devices +12V Σ							
max. possible at +5V							65
+5V: System unit, fixed device	4	4	4	4	4	4	
+5V: Hard Disk (slide-in compact)	4	4	4	4	4	4	
+5V: Slide-in drive (hard disk, DVD-ROM,...)	4	4	4	4	4	4	
+5V: USB Peripheral USB2 and USB4, each 2.5 watts							
+5V: USB Peripheral USB1, USB3 and USB5, each 5 watts							
+5V: Interface option (Add-on interface), optional	0.5	0.5	0.5	0.5	0.5	0.5	
+5V: Graphics adapter (AP Link), optional	5	5	5	5	5	5	
+5V: External device, optional (via BaseBoard)	5	5	5	5	5	5	
+5V: PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
max. possible at -12V							1.2
-12V: PCI card manufacturer limit, optional (max. 1.2 watts with and without fan kit) [1]							
Devices -12V Σ							
Devices 5V Σ							
max. possible at 3V3							40
3V3: System unit, fixed device	4	4	4	4	4	4	
3V3: CompactFlash, each 1 watt							
3V3: Interface option (Add-on interface), optional	0.25	0.25	0.25	0.25	0.25	0.25	
3V3: Graphics adapter (AP Link), optional	1.5	1.5	1.5	1.5	1.5	1.5	
3V3: PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 15 watts with fan kit) [1]							
3V3: PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 10 watts with fan kit) [1]							
Devices 3V3 Σ							
Devices Σ							

Total power supply

1) The total performance of one PCI/PCIe card per PCI slot (= sum of power consumptions for each voltage area) may not exceed the limits stated for operation with or without a fan kit.

Figure 27: Power calculation with 5PC810.SX03-00

2.7.7 Power calculation with 5PC810.SX05-00

Information:	CPU boards						This system
All entries in watts The entries for the **Generator** are maximum values. Entries for the **Device** are determined maximum values, but not peak values.	L2400 5PC800.B945-00 5PC800.B945-10	L7400 5PC800.B945-01 5PC800.B945-11	U7500 5PC800.B945-02 5PC800.B945-12	CM423 5PC800.B945-03 5PC800.B945-13	T7400 5PC800.B945-04 5PC800.B945-14	N270 5PC800.B945-05	Enter values in this column
Total power supply (max.)							130
Add-on UPS module, optional	7.5	7.5	7.5	7.5	7.5	7.5	
+12V — **max. possible at +12V**							75
CPU Board, fixed device	26	30	18	14	43	11	
512MB RAM, max. 2 pcs. each 1.5 watts							
1024MB RAM, max. 2 pcs. each 2.5 watts							
2048MB RAM, max. 2 pcs. each 3 watts							
Fan kit, optional	2.8	2.8	2.8	2.8	2.8	2.8	
External keyboard, optional (via Baseboard)	10	10	10	10	10	10	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 6 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
Devices +12V Σ							
+5V — **max. possible at +5V**							65
System unit, fixed device	4	4	4	4	4	4	
Hard Disk (slide-in compact)	4	4	4	4	4	4	
Slide-in drive (hard disk, DVD-ROM,...)	4	4	4	4	4	4	
USB Peripheral USB2 and USB4, each 2.5 watts							
USB Peripheral USB1, USB3 and USB5, each 5 watts							
Interface option (Add-on interface), optional	0.5	0.5	0.5	0.5	0.5	0.5	
Graphics adapter (AP Link), optional	5	5	5	5	5	5	
External device, optional (via BaseBoard)	5	5	5	5	5	5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 20 watts with fan kit) [1]							
-12V — **max. possible at -12V**							1.2
PCI card manufacturer limit, optional (max. 1.2 watts with and without fan kit)[1]							
Devices -12V Σ							
Devices 5V Σ							
3V3 — **max. possible at 3V3**							40
System unit, fixed device	4	4	4	4	4	4	
CompactFlash, each 1 watt							
Interface option (Add-on interface), optional	0.25	0.25	0.25	0.25	0.25	0.25	
Graphics adapter (AP Link), optional	1.5	1.5	1.5	1.5	1.5	1.5	
PCI card manufacturer limit, optional (max. 3 watts without fan kit, max. 15 watts with fan kit) [1]							
PCIe x4 card manufacturer limit, optional (max. 3 watts without fan kit, max. 10 watts with fan kit) [1]							
Devices 3V3 Σ							
Devices Σ							

Total power supply

1) The total performance of one PCI/PCIe card per PCI slot (= sum of power consumptions for each voltage area) may not exceed the limits stated for operation with or without a fan kit.

Figure 28: Power calculation with 5PC810.SX05-00

2.8 Serial number sticker

Each B&R device is assigned a unique serial number label with a bar code (type 128), which allows the device to be clearly identified. The serial number for the entire device is located behind the front door. This serial number represents all of the components built into the system (model number, name, revision, serial number, delivery date and duration of warranty).



Figure 29: Serial number sticker (front)

A sticker with detailed information about the individual components can also be found on the back side of the mounting plate.



Figure 30: Serial number sticker (back)

This information can also be found on the B&R homepage. Enter the serial number of the entire device (found behind the front door) in the serial number search field on the start page **www.br-automation.com**. The search provides you with a detailed list of the individual components.



Figure 31: Example of serial number search - A3C70168444

2.9 Block diagram

The following block diagrams show the simplified structure of system units with a CPU board that depend on different bus units.

2.9.1 System unit 5PC810.SX01-00 + bus unit 5PC810.BX01-00



Figure 32: Block diagram 5PC810.SX01-00 + 5PC810.BX01-00

2.9.2 System unit 5PC810.SX01-00 + bus unit 5PC810.BX01-01



Figure 33: Block diagram 5PC810.SX01-00 + 5PC810.BX01-01

2.9.3 System unit 5PC810.SX02-00 + bus unit 5PC810.BX02-00



Figure 34: Block diagram 5PC810.SX02-00 + 5PC810.BX02-00

2.9.4 System unit 5PC810.SX02-00 + bus unit 5PC810.BX02-01



Figure 35: Block diagram 5PC810.SX02-00 + 5PC810.BX02-01

2.9.5 System unit 5PC810.SX03-00 + bus unit 5PC810.BX03-00



Figure 36: Block diagram 5PC810.SX03-00 + 5PC810.BX03-00

2.9.6 System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-00



Figure 37: Block diagram 5PC810.SX05-00 + 5PC810.BX05-00

2.9.7 System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-01



Figure 38: Block diagram 5PC810.SX05-00 + 5PC810.BX05-01

2.9.8 System unit 5PC810.SX05-00 + bus unit 5PC810.BX05-02



Figure 39: Block diagram 5PC810.SX05-00 + 5PC810.BX05-02

2.10 Device interfaces

2.10.1 +24 VDC supply voltage

The 3-pin socket required for the supply voltage connection is not included in delivery. This can be ordered from B&R using the model number 0TB103.9 (screw clamp) or 0TB103.91 (cage clamp).

The pin assignments can be found either in the following table or printed on the APC810 housing. The supply voltage is protected internally by a soldered fuse (15A, fast-acting), so that the device cannot be damaged if there is an overload (fuse replacement necessary) or if the voltage supply is connected incorrectly (reverse polarity protection - fuse replacement not necessary). The device must be returned to B&R for repairs if the fuse is blown because of an error.

Supply voltage		
Protected against reverse polarity		3-pin, male
Pin	**Description**	
1	-	
2	Functional ground	
3	+	
Accessories		
0TB103.9	Plug 24 V 5.08 3p screw clamps	
0TB103.91	Plug 24 V 5.08 3p cage clamps	

Table 29: Supply voltage connection + 24VDC

Ground

Caution!

The pin's connection to the functional ground (pin 2) should be as short as possible (e.g. in the switching cabinet). We recommend using the largest possible conductor cross section on the supply plug.

The grounding connection is located on the bottom of the APC810 systems.



Figure 40: Ground connection

The M4 self-locking nut can be used, for example, to fasten a copper strip that is built into the APC810 at a central grounding point in the switching cabinet or system. The largest possible conductor cross section should be used (at least 2.5 mm²).

2.10.2 Serial interface COM1

Serial interfaces - COM1[1)]		
Type	RS232, modem-capable, not electrically isolated	9-pin DSUB, male 
UART	16550-compatible, 16-byte FIFO	
Transfer rate	Max. 115 kBaud	
Cable length	Max. 15 meters	
Pin	**Assignment**	
1	DCD	
2	RXD	
3	TXD	
4	DTR	
5	GND	
6	DSR	
7	RTS	
8	CTS	
9	RI	

Table 30: Pin assignments - COM1

1) The interfaces, etc. available on the device or module were numbered accordingly for easy identification. This numbering can differ from the numbering used by the particular operating system.

2.10.3 Serial interface COM2

Serial interfaces - COM2[1)]		
Type	RS232, modem-capable, not electrically isolated	9-pin DSUB, male 
UART	16550-compatible, 16-byte FIFO	
Transfer rate	Max. 115 kBaud	
Cable length	Max. 15 meters	
Pin	**Assignment**	
1	DCD	
2	RXD	
3	TXD	
4	DTR	
5	GND	
6	DSR	
7	RTS	
8	CTS	
9	RI	

Table 31: Pin assignments - COM2

1) The interfaces, etc. available on the device or module were numbered accordingly for easy identification. This numbering can differ from the numbering used by the particular operating system.

2.10.4 Monitor / Panel connection - SDL (Smart Display Link / DVI)

Monitor / Panel connection - SDL (Smart Display Link / DVI)	
The following will provide an overview of the video signals available on the monitor/panel output. For details, see technical data for the CPU board being used.	
CPU board	**Video signals with all system unit variations**
5PC800.B945-00 / -10	RGB, DVI, SDL
5PC800.B945-01 / -11	RGB, DVI, SDL
5PC800.B945-02 / -12	RGB, DVI, SDL
5PC800.B945-03 / -13	RGB, DVI, SDL
5PC800.B945-04 / -14	RGB, DVI, SDL
5PC800.B945-05	RGB, DVI, SDL

Table 32: Monitor / Panel connection - RGB, DVI, SDL

2.10.5 Ethernet 1 (ETH1)

This Ethernet controller is integrated in the CPU board and is fed outwards via the system unit.

Ethernet 1 connection (ETH1[1])			
Controller	Realtek RTL8111B/C[2]		RJ45 twisted pair (10BaseT/100BaseT), female 
Cabling	S/STP (Cat5e)		
Transfer rate	10/100/1000 Mbit/s [3]		
Cable length	max. 100 m (min. Cat5e)		
Speed LED	**On**	**Off**	
Green	100 Mbit/s	10 Mbit/s[4]	
Orange	1000 Mbit/s	-	
Link LED	**On**	**Off**	
Orange	Link (Ethernet network connection available)	Activity (blinking) (Data transfer in progress)	

Table 33: Ethernet connection (ETH1)

1) The interfaces, etc. available on the device or module were numbered accordingly for easy identification. This numbering can differ from the numbering used by the particular operating system.

2) The Realtek 8111B is integrated in the CPU boards 5PC800.B945-00, -01, -02, -03, -04.
The Realtek 8111C is integrated in the CPU boards 5PC800.B945-05 and 5PC800.945-10, -11, -12, -13, -14.

3) Switching takes place automatically.

4) The 10 MBit/s transfer speed / connection is only present if the Link LED is simultaneously active.

Important information on transfer speed

Due to thermal factors, operation of the ETH1 in 1000 MBit/s mode with the CPU boards 5PC800.B945-00, -01, -02, -03, -04 is only permitted with use of a fan kit or heat sinks (5AC801.HS00-00, 5AC801.HS00-01) Rev. D0 or higher (see also section 2.5 "Ambient temperatures", on page 67).
This limitation does not apply to the CPU boards 5PC800.B945-10, -11, -12, -13, -14 with the heat sinks 5AC801.HS00-00 and 5AC801.HS00-01 and the CPU board 5PC800.B945-05 with the heat sink 5AC801.HS00-02.

Driver support

A special driver is necessary for operating the Realtek Ethernet controllers RTL8111B/C. The necessary software can be downloaded from the download area on the B&R homepage (www.br-automation.com).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

2.10.6 Ethernet 2 (ETH2)

This Ethernet controller is integrated in the main board and is fed outwards via the system unit.

Ethernet 2 connection (ETH2[1])			
Controller	Intel 82573L		RJ45 twisted pair (10BaseT/100BaseT), female 
Cabling	S/STP (Cat5e)		
Transfer rate	10/100/1000 Mbit/s [2]		
Cable length	max. 100 m (min. Cat5e)		
Speed LED	**On**	**Off**	
Green	100 Mbit/s	10 Mbit/s[3]	
Orange	1000 Mbit/s	-	
Link LED	**On**	**Off**	
Orange	Link (Ethernet network connection available)	Activity (blinking) (Data transfer in progress)	

Table 34: Ethernet connection (ETH2)

1) The interfaces, etc. available on the device or module were numbered accordingly for easy identification. This numbering can differ from the numbering used by the particular operating system.

2) Switching takes place automatically.

3) The 10 MBit/s transfer speed / connection is only present if the Link LED is simultaneously active.

Driver support

A special driver is necessary for operating the Intel Ethernet controller 82573L. The necessary software can be downloaded from the download area on the B&R homepage (**www.br-automation.com**).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

2.10.7 USB interfaces (USB1, 2, 3, 4, 5)

The APC810 devices have a USB 2.0 (Universal Serial Bus) host controller with multiple USB ports, two of which are on the outside for easy access.

Warning!

Peripheral USB devices can be connected to the USB ports. Due to the vast number of USB devices available on the market, B&R cannot guarantee their performance. B&R does ensure the performance of all USB devices that they provide.
See Chapter 3 "Commissioning", Section "Connection of USB peripheral devices", on page 229 for additional information.

Caution!

Because of general PC specifications, this interface should be handled with extreme care with regard to EMC, location of cables, etc.

USB1,2,3,4

Universal Serial Bus (USB1, USB2, USB3, USB4)[1]		
Transfer rate	Low speed (1,5 MBit/s), Full speed (12 MBit/s) up to High speed (480 MBit/s)	4 x USB type A, female 
Power supply[2] USB1, USB3 USB2, USB4	 Max. 1 A Max. 500 mA	
Maximum Cable length	5 m (without hub)	

Table 35: USB1, USB2, USB3, USB4 connection

1) The interfaces, etc. available on the device or module were numbered accordingly for easy identification. This numbering can differ from the numbering used by the particular operating system.

2) For safety, every USB port is equipped with a maintenance free "USB current-limiting circuit breaker" (max. 500 mA or 1 A).

USB5

Universal Serial Bus (USB5)[1]		
Transfer rate	Low speed (1.5 MBit/s), full speed (12 MBit/s), to high speed (480 MBit/s)	4 x USB type A, female
Power supply[2] USB5	Max. 1 A	
Maximum Cable length	5 m (without hub)	

Table 36: USB5 connection

1) The interfaces, etc. available on the device or module were numbered accordingly for easy identification. This numbering can differ from the numbering used by the particular operating system.

2) For safety, the USB port is equipped with a maintenance free "USB current-limiting circuit breaker" (max. 1 A)

2.10.8 MIC, Line IN, Line OUT

All APC810 systems include an AC97 (Rev 2.2) compatible sound chip with access to the channels MIC, Line IN and Line OUT from the outside.

MIC, Line IN, Line OUT		
Controller	Realtek AC97 Rev. 2.2	3.5 mm jack, female
MIC	Connection for a mono microphone via 3.5 mm jack.	
Line IN	Stereo Line IN signals supplied via 3.5 mm jack.	
Line OUT	Connection for a stereo sound device (e.g. amplifier) via a 3.5 mm jack.	

Table 37: MIC, Line IN, Line OUT

Driver support

A special driver is necessary for operating the audio controller. The necessary software can be downloaded from the download area on the B&R homepage (www.br-automation.com).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

2.10.9 Add-on interface slot

An optional add-on interface (e.g. CAN, RS485) can be installed here. See also 3.9 "Add-on interfaces (IF option)", on page 179.

Add-on interface slot		
Available add-on interfaces		
5AC600.CANI-00	Add-on CAN interface	
5AC600.458I-00	Add-on RS232/422/458 interface	

Table 38: Add-on interface slot

2.10.10 Add-on UPS slot

An optional Automation PC add-on UPS module or the APC810 ready relay /2 can be installed here.

Add-on UPS slot	
	
Add-on UPS + accessories	
5AC600.UPSI-00	Add-on UPS module
5AC600.UPSB-00	Battery unit 5 Ah
5CAUPS.0005-00	UPS cable 0.5 m
5CAUPS.0030-00	UPS cable 3 m
APC810 Ready relay	
5AC801.RDYR-01	APC810 Ready relay /2
Pin assignments with mounted add-on UPS module	
1	+
2	+
3	-
4	-
5	NTC (for battery temperature measurement
6	NTC (for battery temperature measurement

Table 39: Add-on UPS slot (with and without mounted UPS)

2.10.11 AP Link slot

When connected with the AP Link card 5AC801.SDL0-00, it is possible to implement a second graphic line with DVI and SDL, but without RGB signals. Furthermore, the APC810 ready relay 5AC801.RDYR-00 can also be mounted.

Information:

Installation of AP Link cards is only possible in connection with the system units 5PC810.SX02-00, 5PC810.SX03-00 and 5PC810.SX05-00.

2.10.12 Card slot (PCI / PCIe)

Standard PCI 2.2 half-size cards or PCI Express (PCIe) half-size cards can be plugged in depending on the type of bus unit. They cannot exceed the following dimensions.



Figure 41: Dimensions - Standard half-size PCI card



Figure 42: Dimensions - Standard half-size PCIe card

2.10.13 Status LEDs

The status LEDs are in the system unit.

Status LEDs				
LED	**Color**		**Meaning**	
Power	Green	On	Supply voltage OK	
	Red	On	The system is in standby mode (S5: soft-off mode or S4: Hibernate mode -Suspend-to-Disk)	
	Orange 1)	On	Supply voltage not OK; the system is operating on battery power.	
HDD	Yellow	On	Signals IDE drive access (CF, HDD, CD, etc.)	
Link 1	Yellow	On	Indicates an active SDL connection on the monitor / panel plug.	
		blinking	An active SDL connection has been interrupted by a loss of power in the display unit.	
Link 2	Yellow	On	Indicates an active SDL connection on the AP Link.	
		blinking	An active SDL connection on the AP link has been interrupted by a loss of power in the display unit.	

Table 40: Data - status LEDs

1) Only lit when add-on UPS module is installed.

The light for the Status LEDs is fed to the front cover via fiber optic lines.



Figure 43: Front-side status LEDs

2.10.14 CMOS profile switch

CMOS profile switch	
Different BIOS default value profiles can be defined using the 16-position CMOS profile switch.	

Switch position	Description
0	Profile 0: Default profile reserved.
1	Profile 1: Optimized for system units 5PC810.SX01-00, 5PC810.SX02-00 and 5PC810.SX03-00
2	Profile 2: Optimized for 5PC810.SX05-00 system unit
3	Profile 3: Optimized for the 5PC820.SX01-00 system unit
4	Profile 4: Reserved
5	Profile 5: Optimized for system units 5PC820.1505-00 and 5PC820.1906-00

Table 41: CMOS profile switch

Information:

The switch position that is set upon delivery represents the optimum BIOS default values for this system and should therefore not be changed.

The position of the CMOS profile switch is is displayed in the BIOS setup pages and in the B&R ADI Control Center, among other places.

2.10.15 Power button

The power button has a variety of functions due to full ATX power supply support.

Power button	
The power button can be pressed with a pointed object (e.g. paper clip or tip of a pen). The power button acts like the on/off switch on a normal desktop PC with ATX power supply: **Press and release** ... Switches on APC810 or shuts down operating system and switches off the APC810. **Press and hold** ... ATX power supply switches off without shutting down the APC810 (**data could be lost!**). Pressing the power button does not reset the MTCX processor.	

Table 42: Power button

2.10.16 Reset button

Information:

From MTCX PX32 firmware V00.11 and higher, the reset button is only triggered by edges. This means that the device boots even when the reset button is pressed. In MTCX PX32 firmware < V00.11, the system does not start after pressing (ca. 10 seconds) and releasing the reset button.

Reset button	
The reset button can be pressed with a pointed object (e.g. paper clip or tip of a pen). Pushing the reset button triggers a hardware and PCI reset. The APC810 is restarted (cold restart). The MTCX processor is not reset when the reset button is pressed.	

Table 43: Reset button

Warning!

A system reset can result in data loss!

2.10.17 Battery

The lithium battery (3 V, 950 mAh) buffers the internal real-time clock (RTC) as well as the individually saved BIOS settings and data in the SRAM and is located behind the black cover. The buffer duration of the battery is at least 2½ years (at 50°C, 8.5 µA current requirements of the supplied components and a self discharge of 40%). The battery is subject to wear and should be replaced regularly (at least following the specified lifespan).

Battery		
Battery Type Removable Lifespan	 Renata 950 mAh Yes, accessible from the outside 2 1/2 years[1)]	
Accessories	**Short description**	
0AC201.91	**Lithium batteries, 4 pcs.** Lithium batteries (4 pcs.), 3 V / 950 mAh, button cell	
4A0006.00-000	**Lithium battery, 1 pc.** Lithium battery (1 pcs.), 3 V / 950 mAh, button cell	

Table 44: Battery

1) At 50°C, 8.5 µA of the supplied components and a self discharge of 40%.

Battery status evaluation

The battery status is evaluated immediately following start-up of the device and is subsequently checked by the system every 24 hours. The battery is subjected to a brief load (1 second) during the measurement and then evaluated. The evaluated battery status is displayed in the BIOS Setup pages (under Advanced - Baseboard monitor) and in the B&R Control Center (ADI driver), but can also be read in a customer application via the ADI Library.

Battery status	Meaning
N/A	Hardware, i.e. firmware used is too old and does not support read.
Good	Data buffering is guaranteed
Bad	Data buffering is guaranteed for approx. another 500 hours from the point in time that the battery capacity is determined to be BAD (insufficient).

Table 45: Meaning of battery status

2.10.18 Hardware security key

B&R recommends a hardware security key (dongle) based on the DS1425 from MAXIM (previously Dallas Semiconductors) for software copy protection.

Hardware security key	
A hardware security key (dongle) can be inserted behind the black cover.	

Table 46: Hardware security key

Warning!

Turn off power before removing or adding the hardware security key.

2.10.19 CompactFlash slot 1

This CompactFlash slot is a fixed part of an APC810 system and is internally connected with the chipset via IDE PATA. Type I CompactFlash cards are supported.

CompactFlash slot (CF1)		
Connection	PATA Master	
CompactFlash Type	Type I	
Accessories	**Short description**	
5CFCRD.0512-04	512 MB B&R CompactFlash card	
5CFCRD.1024-04	1024 MB B&R CompactFlash card	
5CFCRD.2048-04	2048 MB B&R CompactFlash card	
5CFCRD.4096-04	4096 MB B&R CompactFlash card	
5CFCRD.8192-04	8192 MB B&R CompactFlash card	
5CFCRD.016G-04	16 GB B&R CompactFlash card	
5CFCRD.0064-03	CompactFlash 64 MB SSI	
5CFCRD.0128-03	CompactFlash 128 MB SSI	
5CFCRD.0256-03	CompactFlash 256 MB SSI	
5CFCRD.0512-03	CompactFlash 512 MB SSI	
5CFCRD.1024-03	CompactFlash 1024 MB SSI	
5CFCRD.2048-03	CompactFlash 2048 MB SSI	
5CFCRD.4096-03	CompactFlash 4096 MB SSI	
5CFCRD.8192-03	CompactFlash 8192 MB SSI	

Table 47: CompactFlash slot (CF1)

Warning!

Turn off power before inserting or removing the CompactFlash card!

2.10.20 CompactFlash slot 2

This CompactFlash slot is a fixed part of an APC810 system and is internally connected with the chipset via IDE PATA. Type I CompactFlash cards are supported.

CompactFlash slot (CF2)		
Connection	PATA Slave	
CompactFlash Type	Type I	
Accessories	**Short description**	
5CFCRD.0512-04	512 MB B&R CompactFlash card	
5CFCRD.1024-04	1024 MB B&R CompactFlash card	
5CFCRD.2048-04	2048 MB B&R CompactFlash card	
5CFCRD.4096-04	4096 MB B&R CompactFlash card	
5CFCRD.8192-04	8192 MB B&R CompactFlash card	
5CFCRD.016G-04	16 GB B&R CompactFlash card	
5CFCRD.0064-03	CompactFlash 64 MB SSI	
5CFCRD.0128-03	CompactFlash 128 MB SSI	
5CFCRD.0256-03	CompactFlash 256 MB SSI	
5CFCRD.0512-03	CompactFlash 512 MB SSI	
5CFCRD.1024-03	CompactFlash 1024 MB SSI	
5CFCRD.2048-03	CompactFlash 2048 MB SSI	
5CFCRD.4096-03	CompactFlash 4096 MB SSI	
5CFCRD.8192-03	CompactFlash 8192 MB SSI	

Table 48: CompactFlash slot (CF2)

Warning!

Turn off power before inserting or removing the CompactFlash card!

2.10.21 Slide-in slot 1

The slide-in slot 1 is internally connected with the chipset via SATA I and USB.

Slide-in slot 1		
Connection	SATA I and USB	
Accessories	**Short description**	
5AC801.ADAS-00	APC810 slide-in compact adapter	
5AC801.HDDS-00	APC810 slide-in HDD EE25	
5AC801.DVRS-00	APC810 slide-in DVD-R/RW	
5AC801.DVDS-00	APC810 slide-in DVD-ROM	

Table 49: Slide-in slot 1

Information:

The SATA I interface allows data carriers to be exchanged during operation (hot-plug). To utilize this capability, it must be supported by the operating system.

2.10.22 Slide-in slot 2

The slide-in slot 2 is internally connected with the chipset via SATA I and USB.

Slide-in slot 2		
Connection	SATA I and USB	
Accessories	**Short description**	
5AC801.HDDS-00	APC810 slide-in HDD EE25	
5AC801.DVRS-00	APC810 slide-in DVD-R/RW	
5AC801.DVDS-00	APC810 slide-in DVD-ROM	

Table 50: Slide-in slot 2

Information:

The APC810 slide-in compact adapter 5AC801.ADAS-00 can only be inserted into slide-in slot 1 for mechanical reasons (closing the front door).

Information:

The SATA I interface allows data carriers to be exchanged during operation (hot-plug). To utilize this capability, it must be supported by the operating system.

2.10.23 Slide-in compact slot

The slide-in compact slot is internally connected with the chipset via SATA I.

Slide-in compact slot		
Connection	SATA I	
Accessories	**Short description**	
5AC801.HDDI-00	APC810 slide-in compact HDD 40GB EE25	
5AC801.HDDI-01	APC810 slide-in compact HDD 80GB EE25	
5AC801.HDDI-02	APC810 slide-in compact HDD 160GB	
5AC801.HDDI-03	APC810 slide-in compact HDD 250GB	
5AC801.SSDI-00	APC810 slide-in compact SSD 32GB (SLC)	

Table 51: Slide-in compact slot

Information:

The SATA I interface allows data carriers to be exchanged during operation (hot-plug). To utilize this capability, it must be supported by the operating system.

For information about installing / exchanging a slide-in compact drive, see the section "Installing / exchanging a slide-in compact drive", on page 470.

3. Individual components

3.1 System units

The system unit unites all of the individual components in one compact device. It consists of a housing with an integrated main board. The interfaces easily accessible on the front side, just behind the orange front doors or on the top. The system units are available in sizes with 1, 2, 3 or 5 card slots.

3.1.1 Technical data

Features	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00
Photo				
B&R ID code	$A3ED	$A3C7	$B2C3	$A3EE
Serial interface Amount	2			
Ethernet interface Amount	2			
USB interface Amount	5			
Monitor / Panel output	Yes			
AC97 sound	Yes			
IF optional slot	Yes			
Card slots (PCI / PCIe slots[1)])	1	2	3	5
CompactFlash slot Amount	2			
Slot for slide-in drive	-	1	1	2
Slot for slide-in compact drive	1			
Slot for add-on UPS module	Yes			
Reset button	Yes			
Power button	Yes			
CMOS profile switch	Yes			
Battery compartment	Yes			
Hardware security compartment	Yes			
Fan kit insert	Yes			

Table 52: Technical data - System units

Features	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00
AP Link slot	-	Yes		
Status LEDs	Yes			
MTCX[2)]	Yes			
Electrical characteristics				
Supply voltage Rated voltage Starting current Power consumption	24 VDC ±25% Typ. 7 A, max. 50 A < 300µs See 2.7 "Power management"			
Mechanical characteristics				
Housing[3)] Item Paint Front cover	Galvanized steel plate Light gray (similar to Pantone 427C), dark gray (similar to Pantone 432C) Orange colored plastic (similar to Pantone 144C)			
Outer dimensions (without heat sink) Width Length Height	 74 mm 252.7 mm 270 mm	 113.5 mm 254.6 mm 270 mm	 134 mm 254.5 mm 270 mm	 194.4 mm 254.5 mm 270 mm
Weight (without heat sink)	Approx. 2.2 kg	Approx. 2.8 kg	Approx. 3.2 kg	Approx. 3.9 kg
Mounting plates (for M4 screws)	4	4	4	6
Drilling templates for mounting	See Chapter 3 "Commissioning", section "Drilling templates", on page 190			

Table 52: Technical data - System units (Forts.)

1) Depends on the bus unit.

2) For more information about Maintenance Controller Extended, see the section "Maintenance Controller Extended (MTCX)", on page 498.

3) Depending on the process or batch, there may be visible deviations in the color and surface structure.

3.2 Bus units

The bus units are compatible with the system units in 1, 2, 3 or 5 card slot sizes, available with PCI and/or PCI Express support.



5PC810.BX01-00



5PC810.BX01-01

Figure 44: 1 slot bus units



5PC810.BX02-00



5PC810.BX02-01

Figure 45: 2 slot bus units



5PC810.BX03-00

Figure 46: 3 slot bus units



Figure 47: 5 slot bus units

3.2.1 Technical data

Features	5PC810.BX 01-00	5PC810.BX 01-01	5PC810.BX 02-00	5PC810.BX 02-01	5PC810.BX 03-00	5PC810.BX 05-00	5PC810.BX 05-01	5PC810.BX 05-02
PCI slot Amount Default PCI bus type Bus speed	 1 2.2 32-bit 33 MHz	 - 	 2 2.2 32-bit 33 MHz	 1 2.2 32-bit 33 MHz	 2 2.2 32-bit 33 MHz	 4 2.2 32-bit 33 MHz	 2 2.2 32-bit 33 MHz	 5 2.2 32-bit 33 MHz
PCI Express Amount Default Bus speed	 -	 1 1.0a x4 (10 GB/s)	 -	 1 1.0a x4 (10 GB/s)	 1 1.0a x4 (10 GB/s)	 1 1.0a x1 (2.5 GB/s)	 3 1.0a x1 (2.5 GB/s)	 -

Table 53: Technical data - Bus units

3.3 CPU boards 945GME



Figure 48: CPU board

3.3.1 Technical data

Features	5PC800.B945-00	5PC800.B945-01	5PC800.B945-02	5PC800.B945-03	5PC800.B945-04	5PC800.B945-05
	5PC800.B945-10	5PC800.B945-11	5PC800.B945-12	5PC800.B945-13	5PC800.B945-14	
Boot loader / Operating system	embedded AMI BIOS (for a description, see Chapter 4 "Software", section "BIOS options", on page 243)					
Processor Type Name Clock frequency Architectures L1 cache L2 cache Front side bus - FSB Intel 64 architecture	Intel® Core™ Duo L2400 1.66 GHz 65 nm 32 KB 2 MB 667 MHz No	Intel® Core™2 Duo L7400 1.5 GHz 65 nm 32 KB 4 MB 667 MHz Yes	Intel® Core™2 Duo U7500 1.06 GHz 65 nm 32 KB 2 MB 533 MHz Yes	Intel® Celeron® M 423 1.06 GHz 65 nm 32 KB 1 MB 533 MHz No	Intel® Core™2 Duo T7400 2.16 GHz 65 nm 32 KB 4 MB 667 MHz Yes	Intel® Atom™ N270 1.66 GHz 45 nm 24 KB 512 kB 533 MHz No
Chipset	Intel® 945GME / Intel 82801 GHM (ICH7M-DH)					
Memory	SO-DIMM DDR2 667/PC5300, max. 3 GByte					
Graphics Controller Memory Color depth Resolution RGB DVI	Intel® Graphics Media Accelerator 950 Up to 224 MB (reserved from main memory) Max 32 Bit 400 MHz RAMDAC, up to 2048 x 1536 @75 Hz (QXGA) including 1920 x 1080 @ 85 Hz (HDTV) 2x Intel compliant SDVO port, 1920 x 1080					
Real-time clock (RTC) Battery-buffered Accuracy	Yes At 25°C typ. 12 ppm (1 second)[1] per day					
Mass memory management	2 x SATA, 1 x IDE					

Table 54: Technical data - CPU boards

Features	5PC800.B945-00	5PC800.B945-01	5PC800.B945-02	5PC800.B945-03	5PC800.B945-04	5PC800.B945-05
	5PC800.B945-10	5PC800.B945-11	5PC800.B945-12	5PC800.B945-13	5PC800.B945-14	
Power management	ACPI 2.0, S3 Support (suspend to RAM)					

Table 54: Technical data - CPU boards

1) At max. specified ambient temperature: typically 58 ppm (5 seconds) - worst-case 220 ppm (19 seconds).

3.4 Heat sink



Figure 49: Heat sink

3.4.1 Technical data

Mechanical characteristics	5AC801.HS00-00	5AC801.HS00-01	5AC801.HS00-02
Ideal for CPU boards	5PC800.B945-00 / -10 5PC800.B945-01 / -11 5PC800.B945-02 / -12 5PC800.B945-03 / -13	5PC800.B945-04 / -14	5PC800.B945-05
Item	Aluminum, black-coated with copper heat pipes		
Outer dimensions Width Height Depth	 228.7 mm 218 mm 12.8 mm	 228.7 mm 218 mm 28 mm	 228.7 mm 218 mm 12.8 mm
Weight	Approx. 1.7 kg	Approx. 2 kg	Approx. 1.7 kg

Table 55: Technical data - Heat sink

3.5 Main memory

The CPU boards offer room for two main memory modules. Dual-Channel memory technology is supported when two modules of the same size (e.g. 1 GB) are plugged in. This technology is not supported when two modules of different sizes (e.g. 1 GB and 2 GB) are plugged in.

When two 2 GB modules are plugged in, only 3 GB of main memory can be used.



Figure 50: Main memory

3.5.1 Technical data

Features	5MMDDR.0512-01	5MMDDR.1024-01	5MMDDR.2048-01
Quantity	512 MB	1 GB	2 GB
Type	DDR2 SDRAM / PC2-5300		
Construction	200 Pin SO-DIMM		
Organization	64M x 64-bit	128M x 64-bit	256M x 64-bit

Table 56: Technical data - Main memory

Information:

A main memory module can only be replaced at the B&R plant.

3.6 Drives

3.6.1 Slide-in compact HDD 40GB EE25 - 5AC801.HDDI-00

This hard disk is specified for 24-hour operation and also provides an extended temperature specification.

Figure 51: Slide-in compact HDD 40GB EE25 - 5AC801.HDDI-00

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.HDDI-00
Manufacturer's product ID	Seagate ST940817SM
Formatted capacity	40 GB
Number of heads	1
Number of sectors (user)	78,140,160
Bytes per sector	512
Revolution speed	5400 rpm
Access time (average)	5.6 ms

Table 57: Technical data - Slide-in compact HDD - 5AC801.HDDI-00

Features	5AC801.HDDI-00
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1 ms 12.5 ms 23 ms
Starting time (0 rpm to read access)	3 seconds (typically)
Interface	SATA
Data transfer rate Internal To/from host	 Max. 450 Mbits/s Max. 150 MB/s (Ultra-DMA Mode 5)
Cache	8 MB
S.M.A.R.T. Support	Yes
MTBF	750,000 Power On Hours[1)]
Mechanical characteristics	
Slide-in compact mounting	Fixed
Outer dimensions Height Width Depth	 98 mm 13 mm 105 mm
Weight	134 g
Environmental characteristics	
Ambient temperature[2)] Operation - Standard / 24-hour Storage Transport	 -30 to 85°C -40 to 95°C -40 to 95°C
Relative humidity[3)] Operation Storage Transport	 5 to 90%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage	 2 g at 5 - 500 Hz, no non-recovered errors 5 g at 5 - 500 Hz, no non-recovered errors
Shock (pulse with a sine half-wave) Operation Storage 	 300 g and 2 ms duration, no non-recovered errors 150 g and 11 ms duration, no non-recovered errors 800 g and 2 ms duration, no non-recovered errors 400 g and 0.5 ms duration, no non-recovered errors
Altitude Operation Storage	 - 300 to 5000 m - 300 to 12,192 m

Table 57: Technical data - Slide-in compact HDD - 5AC801.HDDI-00 (Forts.)

1) With 8760 POH (Power On Hours) per year and 70°C surface temperature.

2) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3) Humidity gradient: Maximum 15% per hour.

Temperature humidity diagram



Figure 52: Temperature humidity diagram - 5AC801.HDDI-00

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3.6.2 Slide-in compact HDD 80GB EE25 - 5AC801.HDDI-01

This hard disk is specified for 24-hour operation and also provides an extended temperature specification.

Figure 53: Slide-in compact HDD 80GB EE25 - 5AC801.HDDI-01

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.HDDI-01
Manufacturer's product ID	Seagate ST980817SM
Formatted capacity	80 GB
Number of heads	2
Number of sectors (user)	156,301,488
Bytes per sector	512
Revolution speed	5400 rpm
Access time (average)	5.6 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1 ms 12.5 ms 23 ms

Table 58: Technical data - Slide-in compact HDD - 5AC801.HDDI-01

Features	5AC801.HDDI-01
Starting time (0 rpm to read access)	3 seconds (typically)
Interface	SATA
Data transfer rate Internal To/from host	 Max. 450 Mbits/s Max. 150 MB/s (Ultra-DMA Mode 5)
Cache	8 MB
S.M.A.R.T. Support	Yes
MTBF	750,000 Power On Hours[1)]
Mechanical characteristics	
Slide-in compact mounting	Fixed
Outer dimensions Height Width Depth	 98 mm 13 mm 105 mm
Weight	133 g
Environmental characteristics	
Ambient temperature[2)] Operation - Standard / 24-hour Storage Transport	 -30 to 85°C -40 to 95°C -40 to 95°C
Relative humidity[3)] Operation Storage Transport	 5 to 90%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage	 2 g at 5 - 500 Hz, no non-recovered errors 5 g at 5 - 500 Hz, no non-recovered errors
Shock (pulse with a sine half-wave) Operation Storage 	 300 g and 2 ms duration, no non-recovered errors 150 g and 11 ms duration, no non-recovered errors 800 g and 2 ms duration, no non-recovered errors 400 g and 0.5 ms duration, no non-recovered errors
Altitude Operation Storage	 - 300 to 5000 m - 300 to 12,192 m

Table 58: Technical data - Slide-in compact HDD - 5AC801.HDDI-01 (Forts.)

1) With 8760 POH (Power On Hours) per year and 70°C surface temperature.

2) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3) Humidity gradient: Maximum 15% per hour.

Temperature humidity diagram



Figure 54: Temperature humidity diagram - 5AC801.HDDI-01

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3.6.3 Slide-in compact HDD 160 GB 24x7 ET - 5AC801.HDDI-02

This hard disk is specified for 24-hour operation (24x7) and also provides an extended temperature specification (ET).

Figure 55: Slide-in compact HDD 160 GB - 5AC801.HDDI-02

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.HDDI-02
Manufacturer's product ID	Fujitsu MHY2160BH-ESW
Formatted capacity	160 GB
Number of heads	3
Number of sectors (user)	312,581,808
Bytes per sector	512
Revolution speed	5400 rpm
Access time (average)	12 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1.5 ms 12 ms 22 ms

Table 59: Technical data - Slide-in compact HDD - 5AC801.HDDI-02

Features	5AC801.HDDI-02
Starting time (0 rpm to read access)	4 seconds (typically)
Interface	SATA
Data transfer rate Internal To/from host	 Max. 84.6 Mbits/s Max. 150 MB/s (Ultra-DMA Mode 5)
Cache	8 MB
S.M.A.R.T. Support	Yes
MTBF	300,000 Power On Hours[1)]
Mechanical characteristics	
Slide-in compact mounting	Fixed
Outer dimensions Height Width Depth	 98 mm 13 mm 105 mm
Weight	135 g
Environmental characteristics	
Ambient temperature[2)] Operation - Standard / 24-hour Storage Transport	 -15 to 80°C -40 to 95°C -40 to 95°C
Relative humidity[3)] Operation Storage Transport	 8 to 90% non-condensing (maximum humidity at 29°C) 5 to 95% non-condensing (maximum humidity at 40°C) 5 to 95% non-condensing (maximum humidity at 40°C)
Vibration Operation Storage	 5 - 500 Hz: 1 g, no unrecoverable errors 5 - 500 Hz: 5 g, no damage
Shock (pulse with a sine half-wave) Operation Storage	 325 g, 2 ms, no unrecoverable errors 900 g, 1 ms, no damage 120 g, 11 ms, no damage
Altitude Operation Storage	 - 300 to 3000 m - 300 to 12,192 m

Table 59: Technical data - Slide-in compact HDD - 5AC801.HDDI-02 (Forts.)

1) With 8760 POH (Power On Hours) per year and 70°C surface temperature.

2) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3) Humidity gradient: Maximum 15% per hour.

Temperature humidity diagram



Figure 56: Temperature humidity diagram - 5AC801.HDDI-02

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3.6.4 Slide-in compact HDD 250GB - 5AC801.HDDI-03

This hard disk is specified for 24-hour operation.

Figure 57: Slide-in compact HDD 250GB - 5AC801.HDDI-03

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.HDDI-03
Manufacturer's product ID	Seagate ST9250315AS
Formatted capacity	250 GB
Number of heads	1
Number of sectors (user)	488,397,168
Bytes per sector	512
Revolution speed	5400 rpm ±0.2%
Access time (average)	5.56 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1 ms 14 ms 30 ms
Starting time (0 rpm to read access)	3.6 seconds (typically)

Table 60: Technical data - Slide-in compact HDD - 5AC801.HDDI-03

Features	5AC801.HDDI-03
Interface	SATA
Supported transfer modes	SATA 1.0, Serial ATA Revision 2.6 PIO mode 0-4, multiword DMA mode 0-2, UDMA mode 0-6
Data transfer rate Internal To/from host	 Max. 1175 Mbits/s Max. 150 MB/s (SATA I), max. 300 MB/s (SATA II)
Cache	8 MB
S.M.A.R.T. Support	Yes
MTBF	550,000 Power On Hours[1)]
Mechanical characteristics	
Slide-in compact mounting	Fixed
Outer dimensions Height Width Depth	 98 mm 13 mm 105 mm
Weight	134 g
Environmental characteristics	
Ambient temperature[2)] Operation - Standard / 24-hour[3)] Storage Transport	 0 to 60°C -40 to 70°C -40 to 70°C
Relative humidity[4)] Operation Storage Transport	 5 to 95%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage	 0.5 g at 5 - 500 Hz, no non-recovered errors 5 g at 5 - 500 Hz, no non-recovered errors
Shock (pulse with a sine half-wave) Operation Storage	 350 g and 2 ms duration, no non-recovered errors 800 g and 2 ms duration, no non-recovered errors 1000 g and 1 ms duration, no non-recovered errors 600 g and 0.5 ms duration, no non-recovered errors
Altitude Operation Storage	 -300 to 3048 m -300 to 12,192 m

Table 60: Technical data - Slide-in compact HDD - 5AC801.HDDI-03 (Forts.)

1) With 8760 POH (Power On Hours) per year and 25°C surface temperature.

2) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3) 24-hour operation means 732 POH (power-on hours) per month.

4) Humidity gradient: Maximum 30% per hour.

Temperature humidity diagram



Figure 58: Temperature humidity diagram - 5AC801.HDDI-03

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3.6.5 Slide-in compact SSD - 5AC801.SSDI-00

Figure 59: Slide-in compact SSD 5AC801.SSDI-00

Technical data

Caution!

A sudden loss of power can cause data to be lost! In very rare cases, the mass memory may also become damaged.

To prevent damage and loss of data, it is recommended to use a UPS device.

Information:

The slide-in compact SSD cannot be used in the 5 card slot version of the APC810 in slide-in slot 2 with the 5AC801.ADAS-00 adapter.

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.SSDI-00
Manufacturer's product ID	Intel SSDSA2SH032G1
Formatted capacity	32 GB
Interface	SATA
Continuous reading	Max. 250 MB/s
Continuous writing	Max. 170 MB/s
IOPS[1)] 4k write 4k read	 3,300 35,000
S.M.A.R.T support	Yes
MTBF	2,000,000 hours
Maintenance	None
Data reliability	< 1 unrecoverable error in 10^{15} bit read accesses
Power on/off cycles	50,000
Endurance	
Guaranteed amount of data Results for 5 years	700 TB 350 GB/day
SLC-Flash	Yes
Wear leveling	Static
Error Correction Coding (ECC)	Yes
Compatibility	SATA revision 2.6 compliant, compatible with SATA 1.5 Gbit/s and 3 Gbit/s interface rates ATA/ATAPI-7 SSD Enhanced SMART ATA feature set Native Command Queuing (NCQ) command
Mechanical characteristics	
Slide-in compact mounting	Fixed
Outer dimensions Height Width Depth	 98 mm 13 mm 105 mm
Weight	118 g
Environmental characteristics	
Ambient temperature Operation Storage Transport	 0 to 70°C -55 to 95°C -55 to 95°C
Relative humidity Operation Storage Transport	 5 to 95% 5 to 95% 5 to 95%
Vibration Operation Storage Transport	 2.17 g at 7 - 800 Hz 3.13 g at 10 - 500 Hz 3.13 g at 10 - 500 Hz

Table 61: Technical data - Slide-in compact SSD - 5AC801.SSDI-00

Environmental characteristics	5AC801.SSDI-00
Shock	
Operation	1000 g / 0.5 ms
Storage	1000 g / 0.5 ms
Transport	1000 g / 0.5 ms
Altitude	
Operation	-300 to 12,192 m
Storage	-300 to 12,192 m
Transport	-300 to 12,192 m

Table 61: Technical data - Slide-in compact SSD - 5AC801.SSDI-00 (Forts.)

1) IOPS: Random read and write input/output operations per second

Temperature humidity diagram



Figure 60: Temperature humidity diagram - 5AC801.SSDI-00

Benchmark

The following two benchmarks show a comparison of the Intel Solid State Drive (5AC801.SSDI-00) and the Seagate Hard Disk (5AC801.HDDI-00) for cyclic reading and writing.



Figure 61: ATTO disk benchmark v2.34 - cyclic read



Figure 62: ATTO disk benchmark v2.34 - cyclic write

3.6.6 Hard disk adapter (slide-in compact) - 5AC801.ADAS-00



Figure 63: Hard disk adapter (slide-in compact) 5AC801.ADAS-00

Information:

The APC810 slide-in compact adapter 5AC801.ADAS-00 can only be inserted into slide-in slot 1 for mechanical reasons (closing the front door).

Technical data

Mechanical characteristics	5AC801.ADAS-00
Outer dimensions Height Width Depth	 172.5 mm 22 mm 150 mm
Weight	328 g

Table 62: Technical data - Slide-in HDD adapter - 5AC801.ADAS-00

3.6.7 Slide-in HDD EE25 - 5AC801.HDDS-00

Figure 64: Slide-in HDD EE25 5AC801.HDDS-00

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.HDDS-00
Manufacturer's product ID	Seagate ST940817SM
Formatted capacity	40 GB
Number of heads	1
Number of sectors (user)	78,140,160
Bytes per sector	512
Revolution speed	5400 rpm
Access time (average)	5.6 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1 ms 12.5 ms 23 ms

Table 63: Technical data - Slide-in HDD EE25 - 5AC801.HDDS-00

Features	5AC801.HDDS-00
Starting time (0 rpm to read access)	3 seconds (typically)
Interface	SATA
Data transfer rate Internal To/from host	 Max. 450 Mbits/s Max. 150 MB/s (Ultra-DMA Mode 5)
Cache	8 MB
S.M.A.R.T. Support	Yes
MTBF	750,000 Power On Hours[1)]
Mechanical characteristics	
Slide-in compact mounting	Fixed
Outer dimensions Height Width Depth	 172.5 mm 22 mm 150 mm
Weight	387 g
Environmental characteristics	
Ambient temperature[2)] Operation - Standard / 24-hour Storage Transport	 -30 to 85°C -40 to 95°C -40 to 95°C
Relative humidity[3)] Operation Storage Transport	 5 to 90%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage	 2 g at 5 - 500 Hz, no non-recovered errors 5 g at 5 - 500 Hz, no non-recovered errors
Shock (pulse with a sine half-wave) Operation Storage	 300 g and 2 ms duration, no non-recovered errors 150 g and 11 ms duration, no non-recovered errors 800 g and 2 ms duration, no non-recovered errors 400 g and 0.5 ms duration, no non-recovered errors
Altitude Operation Storage	 - 300 to 5000 m - 300 to 12,192 m

Table 63: Technical data - Slide-in HDD EE25 - 5AC801.HDDS-00 (Forts.)

1) With 8760 POH (Power On Hours) per year and 70°C surface temperature.

2) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3) Humidity gradient: Maximum 15% per hour.

Temperature humidity diagram



Figure 65: Temperature humidity diagram - 5AC801.HDDS-00

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3.6.8 Slide-in DVD-ROM - 5AC801.DVDS-00

Figure 66: Slide-in DVD-ROM 5AC801.DVDS-00

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.DVDS-00
Reading rate CD DVD	 24x 8x
Data transfer rate	Max. 1.5 Gbits/s
Access time (average) CD DVD	 130 ms 140 ms
Revolution speed	Max. 5090 rpm ±1%
Starting time (0 rpm to read access)	19 seconds (maximum)
Host interface	SATA

Table 64: Technical data - Slide-in DVD-ROM - 5AC801.DVDS-00

Features	5AC801.DVDS-00
Readable media CD DVD	 CD-ROM (12 cm, 8 cm), CD-A CD-R, CD-RW DVD-ROM, DVD-R, DVD-R DL, DVD-RW, DVD+R DVD+R DL, DVD+RW, DVD-RAM
Compatible formats	CD-DA, CD-ROM mode 1/mode 2 CD-ROM XA mode 2 (form 1, form 2) Photo CD (single/multi-session) Enhanced CD, CD text DVD-ROM, DVD-Video (Double Layer), DVD-R (Single/Multi-border), DVD-R DL (Single/Multi-border), DVD-RW (Single/Multi-border), DVD+R (Single/Multi session), DVD+R DL (Single/Multi session), DVD+RW (Single/Multi session), DVD-RAM (4.7 GB, 2.6 GB)
Laser class	Class 1 laser
Noise level (complete read access)	Approx. 45 dBA in a distance of 50 cm
Lifespan Opening/closing the drawer	60,000 POH (Power-On Hours) > 10,000 times
Mechanical characteristics	
Outer dimensions Height Width Depth	 172.5 mm 22 mm 150 mm
Weight	455 g
Environmental characteristics	
Ambient temperature[1)] Operation Storage Transport	 +5 to 55°C[2)] -20 to 60°C -40 to 65°C
Relative humidity Operation Storage Transport	 8 to 80%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage Transport	 0.2 g at 5 - 500 Hz 2 g at 5 - 500 Hz 2 g at 5 - 500 Hz
Shock Operation Storage Transport	 5 g and 11 ms duration 60 g and 11 ms duration 200 g and 2 ms duration 60 g and 11 ms duration 200 g and 2 ms duration

Table 64: Technical data - Slide-in DVD-ROM - 5AC801.DVDS-00 (Forts.)

1) Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

2) Drive surface temperature

Temperature humidity diagram



Figure 67: Temperature humidity diagram - Slide-in DVD-ROM/CD-RW - 5AC801.DVDS-00

Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

Hot plug capable

Hardware revision B0 of the slide-in DVD-ROM - 5AC801.DVDS-00 does not offer SATA hot plug capability. Other hardware revisions are hot plug capable.

3.6.9 Slide-in DVD-R/RW - 5AC801.DVRS-00

Figure 68: Slide-in DVD-R/RW - 5AC801.DVRS-00

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5AC801.DVRS-00
Write speed	
CD-R	24x, 16x, 10x and 4x
CD-RW	24x, 16x, 10x and 4x
DVD-R	8x, 4x and 2x
DVD-R (Double Layer)	6x, 4x and 2x
DVD-RW	6x, 4x and 2x
DVD-RAM[1)]	5x, 3x and 2x
DVD+R	8x, 4x and 2, 4x
DVD+R (double layer)	6x, 4x and 2, 4x
DVD+RW	4x and 2x
Reading rate	
CD	max. 24x
DVD	max. 8x
Data transfer rate	Max. 33.3 MB/s

Table 65: Technical data - Slide-in DVD-R/RW, DVD+R/RW - 5AC801.DVRS-00

Features	5AC801.DVRS-00
Access time (average) CD DVD	 140 ms (24x) 150 ms (8x)
Revolution speed	Max. 5160 rpm ±1%
Starting time (0 rpm to read access) CD DVD	 14 seconds (maximum) 15 seconds (maximum)
Host interface	SATA
Readable media CD DVD	 CD/CD-ROM (12 cm, 8 cm), CD-R, CD-RW DVD-ROM, DVD-R, DVD-R (double layer), DVD-RW. DVD-RAM, DVD+R, DVD+R (double layer), DVD+RW, DVD-RAM
Non-write protected media CD DVD	 CD-R, CD-RW DVD-R/RW, DVD-R (double layer), DVD-RAM (4.7 GB), DVD+R/RW, DVD+R (double layer)
Compatible formats	CD-DA, CD-ROM mode 1/mode 2 CD-ROM XA mode 2 (form 1, form 2) Photo CD (single/multi-session), Enhanced CD, CD text DVD-ROM, DVD-R, DVD-R (double layer), DVD-RW, DVD-Video DVD-RAM (4.7 GB, 2.6 GB) DVD+R, DVD+R (double layer), DVD+RW
Write-methods CD DVD	 Disk at once, session at once, packet write, track at once Disk at once, incremental, over-write, sequential, multi-session
Laser class	Class 1 laser
Data buffer capacity	2 MB
Noise level (complete read access)	Approx. 45 dBA at 50 cm
Lifespan Opening/closing the drawer	60,000 POH (Power-On Hours) > 10,000 times
Mechanical characteristics	
Outer dimensions Height Width Depth	 172.5 mm 22 mm 150 mm
Weight	400 g
Environmental characteristics	
Ambient temperature[2)] Operation Storage Transport	 +5 to 55°C[3)] -20 to 60°C -40 to 65°C
Relative humidity Operation Storage Transport	 8 to 80%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage Transport	 At max. 5 - 500 Hz and 0.2 g At max. 5 - 500 Hz and 2 g At max. 5 - 500 Hz and 2 g

Table 65: Technical data - Slide-in DVD-R/RW, DVD+R/RW - 5AC801.DVRS-00

Environmental characteristics	5AC801.DVRS-00
Shock (pulse with a sine half-wave)	
Operation	At max. 5 g for 11 ms
Storage	At max. 60 g for 11 ms At max. 200 g for 2 ms
Transport	At max. 60 g for 11 ms At max. 200 g for 2 ms

Table 65: Technical data - Slide-in DVD-R/RW, DVD+R/RW - 5AC801.DVRS-00

1) RAM drivers are not provided by the manufacturer. Support of RAM function by the burning software "Nero" (model number 5SWUTI.0000-00) or other burning software packages and drivers from third party providers.

2) Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

3) Drive surface temperature

Temperature humidity diagram



Figure 69: Temperature humidity diagram - Slide-in DVD-R/RW, DVD+R/RW - 5AC801.DVRS-00

Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

3.6.10 PCI SATA RAID controller - 5ACPCI.RAIC-01

Features

- SATA RAID controller
- RAID Level 0 (striped) and 1 (mirrored)
- 2 SATA hard disk drives (suitable for 24 hour operation)
- Only requires 1 PCI slot
- Transfer rates up to 150 MB/s



Figure 70: PCI SATA RAID controller - 5ACPCI.RAIC-01

Information:

The PCI SATA RAID controller can not be used in place of a Universal Power Supply (UPS). If the operating system is shut down improperly, the next time it is started it is detected as an error by the RAID 1, and a complete rebuild is executed. This generally takes at least 50 minutes (configurable) to complete.

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5ACPCI.RAIC-01
SATA RAID controller Type Specifications Data transfer rate RAID level BIOS Extension ROM - requirements	 Sil 3512 SATA link Serial ATA 1.0 Max. 1.5 GB/s (150 MB/s) Supports RAID 0, 1 Approx. 32 KB
Hard disks Amount	Seagate Momentus 7200.1 ST96023AS 2
Formatted capacity (512 bytes/sector)	60 GB
Number of heads	3
Number of sectors (user)	117,210,240
Bytes per sector	512
Revolution speed	7200 rpm ±1%
Access time (average)	4.2 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1.5 ms 10.5 ms 22 ms
Starting time (0 rpm to read access)	4 seconds (typically)
Supported transfer mode	SATA 1.0, PIO mode 0-4, multiword DMA mode 0-2, UDMA 0-5
Data transfer rate On the medium To/from host	 Max. 539 Mbits/s Max. 150 MB/s
Cache	8 MB
S.M.A.R.T. Support	Yes
Lifespan	5 years
Electrical characteristics	
Power consumption	0.3 A at 3.3 V (PCI bus) 1 A at 5 V (PCI bus)
Mechanical characteristics	
Mounted on PCI insert	Fixed
Weight	350 g

Table 66: Technical data - RAID hard disk - 5ACPCI.RAIC-01

Environmental characteristics	5ACPCI.RAIC-01
Ambient temperature[1)]	
Operation - standard [2)]	5 to 55°C
Operation - 24-hour[3)]	5 to 40°C
Storage	-40 to 70°C
Transport	-40 to 70°C
Relative humidity	
Operation	5 to 90%, non-condensing
Storage	5 to 95%, non-condensing
Transport	5 to 95%, non-condensing
Vibration[4)]	
Operation (continuous)	At max. 5 - 500 Hz and 0.125 g (1.225 m/s^2 0-peak) duration 1 octave per minute no damage
Operation (occasional)	At max. 5 - 500 Hz and 0.25 g (2.45 m/s^2 0-peak) duration 1 octave per minute no damage
Storage	At max. 5 - 500 Hz and 5 g (49 m/s^2 0-peak) duration 0.5 octave/minute no damage
Transport	At max. 5 - 500 Hz and 5 g (49 m/s^2 0-peak) duration 0.5 octave/minute no damage
Shock[4)] (pulse with a sine half-wave)	
Operation	No non-recovered errors at max. 125 g (1226 m/s2 0-peak) and [2] ms duration
Storage	No damage at max. 400 g (3924 m/s^2 0-peak) and 2 ms duration
	No damage at max. 450 g (4424 m/s^2 0-peak) and 1 ms duration
	No damage at max. 200 g (1962 m/s^2 0-peak) and 0.5 ms duration
Altitude	
Operation	- 300 to 3048 m
Storage	- 300 to 12,192 m

Table 66: Technical data - RAID hard disk - 5ACPCI.RAIC-01 (Forts.)

1) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 3°C per minute.

2) Standard operation means 333 POH (power-on hours) per month.

3) 24-hour operation means 732 POH (power-on hours) per month.

4) Operation in areas prone to vibration and shock can affect performance negatively (reduction of transfer rate).

Temperature humidity diagram



Figure 71: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-01

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 3°C per minute.

Driver support

Special drivers are necessary for operating the PCI SATA RAID controller. Drivers for Windows XP Professional and Windows XP Embedded are available for download on the B&R Homepage in the download area (**www.br-automation.com**).

The .NET-based SATARaid™ serial ATA RAID management software can also be found on the B&R homepage.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

Configuration

For configuration of a SATA RAID network, see Chapter 3 "Commissioning", section "Configuration of a SATA RAID array", on page 232.

Exchanging a HDD

A hard drive can be easily exchanged in the event of an error when using the RAID1 (mirroring) configuration without having to re-install the system. The replacement SATA HDD 60GB 5ACPCI.RAIC-02 is available as a replacement part for a HDD.

For instructions on exchanging the drive, see Chapter 7 "Maintenance / Servicing", section "Mounting the side cover", on page 489.

3.6.11 Replacement PCI SATA RAID HDD 60GB - 5ACPCI.RAIC-02

The hard disk can be used as replacement for a HDD in a PCI SATA RAID controller 5ACPCI.RAIC-01. For instructions on exchanging the drive, see Chapter 7 "Maintenance / Servicing", section "Mounting the side cover", on page 489.

Figure 72: Replacement SATA HDD 60 GB - 5ACPCI.RAIC-02

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5ACPCI.RAIC-02
Hard disks Amount	Seagate Momentus 7200.1 ST96023AS 1
Formatted capacity (512 bytes/sector)	60 GB
Number of heads	3
Number of sectors (user)	117,210,240
Bytes per sector	512
Revolution speed	7200 rpm ±1%
Access time (average)	4.2 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1.5 ms 10.5 ms 22 ms
Starting time (0 rpm to read access)	4 seconds (typically)
Supported transfer mode	SATA 1.0, PIO mode 0-4, multiword DMA mode 0-2, UDMA 0-5

Table 67: Technical data - RAID hard disk - 5ACPCI.RAIC-02

Features	5ACPCI.RAIC-02
Data transfer rate	
On the medium	max. 539 MBits/s
To/from host	Max. 150 MB/s
Cache	8 MB
S.M.A.R.T. Support	Yes
Lifespan	5 years
Environmental characteristics	
Ambient temperature[1]	
Operation - standard [2]	5 to 55°C
Operation - 24-hour[3]	5 to 40°C
Storage	-40 to 70°C
Transport	-40 to 70°C
Relative humidity	
Operation	5 to 90%, non-condensing
Storage	5 to 95%, non-condensing
Transport	5 to 95%, non-condensing
Vibration[4]	
Operation (continuous)	No damage at max. 5 - 500 Hz and 0.125 g (1.225 m/s^2 0-peak) duration 1 oct/min
Operation (occasional)	No damage at max. 5 - 500 Hz and 0.25 g (2.45 m/s^2 0-peak) duration 1 oct/min
Storage	No damage at max. 5 - 500 Hz and 5 g (49 m/s^2 0-peak) duration 0.5 oct/min
Transport	No damage at max. 5 - 500 Hz and 5 g (49 m/s^2 0-peak) duration 0.5 oct/min
Shock[4] (pulse with a sine half-wave)	
Operation	No non-recovered errors at max. 125 g (1226 m/s^2 0-peak) and 2 ms duration
Storage	No damage at max. 400 g (3924 m/s^2 0-peak) and 2 ms duration
	No damage at max. 450 g (4424 m/s^2 0-peak) and 1 ms duration
	No damage at max. 200 g (1962 m/s^2 0-peak) and 0.5 ms duration
Altitude	
Operation	- 300 to 3048 m
Storage	- 300 to 12,192 m

Table 67: Technical data - RAID hard disk - 5ACPCI.RAIC-02 (Forts.)

1) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 3°C per minute.

2) Standard operation means 333 POH (power-on hours) per month.

3) 24-hour operation means 732 POH (power-on hours) per month.

4) Operation in areas prone to vibration and shock can affect performance negatively (reduction of transfer rate).

Temperature humidity diagram



Figure 73: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-02

3.6.12 PCI SATA RAID 2 x 160 GB 24x7 ET - 5ACPCI.RAIC-03

The hard disks being used are specified for 24-hour operation (24x7) and also provides an extended temperature specification (ET).

Features

- SATA RAID controller
- RAID Level 0 (striped) and 1 (mirrored)
- 2 SATA hard disk drives (suitable for 24 hour operation)
- Only requires 1 PCI slot
- Transfer rates up to 150 MB/s



Figure 74: PCI SATA RAID controller - 5ACPCI.RAIC-03

Information:

The PCI SATA RAID controller can not be used in place of a Universal Power Supply (UPS). If the operating system is shut down improperly, the next time it is started it is detected as an error by the RAID 1, and a complete rebuild is executed. This generally takes at least 120 minutes (configurable) to complete.

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5ACPCI.RAIC-03
SATA RAID controller Type Specifications Data transfer rate RAID level BIOS Extension ROM - requirements	 Sil 3512 SATA link Serial ATA 1.0 Max. 1.5 GB/s (150 MB/s) Supports RAID 0, 1 Approx. 32 KB
Hard disks Amount	Fujitsu M120-ESW MHY2160BH-ESW 2
Formatted capacity (512 bytes/sector)	160 GB
Number of heads	3
Number of sectors (user)	312,581,808
Bytes per sector	512
Revolution speed	5400 rpm ±1%
Access time (average)	5.56 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1.5 ms 12 ms 22 ms
Starting time (0 rpm to read access)	4 seconds (typically)
Supported transfer mode	SATA 1.0, PIO mode 0-4, multiword DMA mode 0-2, UDMA 0-5
Data transfer rate On the medium To/from host	 Max. 84.6 Mbits/s Max. 150 MB/s
Cache	8 MB
S.M.A.R.T. Support	Yes
Lifespan	5 years
Electrical characteristics	
Power consumption	0.3 A at 3.3 V (PCI bus) 1 A at 5 V (PCI bus)
Mechanical characteristics	
Mounted on PCI insert	Fixed
Weight	350 g

Table 68: Technical data - RAID hard disk - 5ACPCI.RAIC-03

Environmental characteristics	5ACPCI.RAIC-03
Ambient temperature[1)]	
Operation - Standard / 24-hour[2)]	-15 to 80°C
Storage	-40 to 95°C
Transport	-40 to 95°C
Relative humidity	
Operation	8 to 90% non-condensing (maximum humidity at 29°C)
Storage	5 to 95% non-condensing (maximum humidity at 40°C)
Transport	5 to 95% non-condensing (maximum humidity at 40°C)
Vibration[3)]	
Operation (continuous)	5 - 500 Hz: max. 0.125 g; duration 1 octave per minute; no unrecoverable errors
Operation (occasional)	5 - 500 Hz: max. 0.25 g; duration 1 octave per minute; no unrecoverable errors
Storage	5 - 500 Hz: max. 5 g; duration 0.5 octaves per minute; no damage
Transport	5 - 500 Hz: max. 5 g; duration 0.5 octaves per minute; no damage
Shock[3)] (pulse with a sine half-wave)	
Operation	Max. 125 g, 2 ms; no unrecoverable errors
Storage	Max. 400 g, 2 ms; no damage
	Max. 450 g, 1 ms; no damage
	Max. 200 g, 0.5 ms; no damage
Altitude	
Operation	- 300 to 3048 m
Storage	- 300 to 12,192 m

Table 68: Technical data - RAID hard disk - 5ACPCI.RAIC-03 (Forts.)

1) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 3°C per minute.

2) 24-hour operation means 732 POH (power-on hours) per month.

3) Operation in areas prone to vibration and shock can affect performance negatively (reduction of transfer rate).

Temperature humidity diagram



Figure 75: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-03

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 3°C per minute.

Driver support

Special drivers are necessary for operating the PCI SATA RAID controller. Drivers for Windows XP Professional and Windows XP Embedded are available for download on the B&R Homepage in the download area (**www.br-automation.com**).

The .NET-based SATARaid™ serial ATA RAID management software can also be found on the B&R homepage.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

Configuration

For configuration of a SATA RAID network, see Chapter 3 "Commissioning", section "Configuration of a SATA RAID array", on page 232.

Exchanging a HDD

A hard drive can be easily exchanged in the event of an error when using the RAID1 (mirroring) configuration without having to re-install the system. The replacement SATA HDD 60GB 5ACPCI.RAIC-02 is available as a replacement part for a HDD.

For instructions on exchanging the drive, see Chapter 7 "Maintenance / Servicing", section "Mounting the side cover", on page 489.

3.6.13 Replacement PCI SATA RAID HDD 160 GB - 5ACPCI.RAIC-04

The hard disk can be used as a replacement part for 5ACPCI.RAIC-03.



Figure 76: Replacement SATA HDD 160 GB - 5ACPCI.RAIC-04

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5ACPCI.RAIC-04
Hard disks Amount	Fujitsu M120-ESW MHY2160BH-ESW 1
Formatted capacity (512 bytes/sector)	160 GB
Number of heads	3
Number of sectors (user)	312,581,808
Bytes per sector	512
Revolution speed	5400 rpm ±1%
Access time (average)	5.56 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1.5 ms 12 ms 22 ms
Starting time (0 rpm to read access)	4 seconds (typically)
Supported transfer mode	SATA 1.0, PIO mode 0-4, multiword DMA mode 0-2, UDMA 0-5
Data transfer rate On the medium To/from host	 Max. 84.6 Mbits/s Max. 150 MB/s

Table 69: Technical data - RAID hard disk - 5ACPCI.RAIC-04

Features	5ACPCI.RAIC-04
Cache	8 MB
S.M.A.R.T. Support	Yes
Lifespan	5 years
Environmental characteristics	
Ambient temperature[1)] Operation - Standard / 24-hour[2)] Storage Transport	 -15 to 80°C -40 to 95°C -40 to 95°C
Relative humidity Operation Storage Transport	 8 to 90% non-condensing (maximum humidity at 29°C) 5 to 95% non-condensing (maximum humidity at 40°C) 5 to 95% non-condensing (maximum humidity at 40°C)
Vibration[3)] Operation (continuous) Operation (occasional) Storage Transport	 5 - 500 Hz: max. 0.125 g; duration 1 octave per minute; no unrecoverable errors 5 - 500 Hz: max. 0.25 g; duration 1 octave per minute; no unrecoverable errors 5 - 500 Hz: max. 5 g; duration 0.5 octaves per minute; no damage 5 - 500 Hz: max. 5 g; duration 0.5 octaves per minute; no damage
Shock[3)] (pulse with a sine half-wave) Operation Storage	 Max. 125 g, 2 ms; no unrecoverable errors Max. 400 g, 2 ms; no damage Max. 450 g, 1 ms; no damage Max. 200 g, 0.5 ms; no damage
Altitude Operation Storage	 - 300 to 3048 m - 300 to 12,192 m

Table 69: Technical data - RAID hard disk - 5ACPCI.RAIC-04 (Forts.)

1) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 3°C per minute.

2) 24-hour operation means 732 POH (power-on hours) per month.

3) Operation in areas prone to vibration and shock can affect performance negatively (reduction of transfer rate).

Temperature humidity diagram



Figure 77: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-04

3.6.14 PCI SATA RAID 2 x 250 GB - 5ACPCI.RAIC-05

The hard disks that are used are specified for 24-hour operation (24x7).

Features

- SATA RAID controller
- RAID Level 0 (striped) and 1 (mirrored)
- 2 SATA hard disk drives (suitable for 24 hour operation)
- Only requires 1 PCI slot
- Transfer rates up to 150 MB/s



Figure 78: PCI SATA RAID controller - 5ACPCI.RAIC-05

Information:

The PCI SATA RAID controller can not be used in place of a Universal Power Supply (UPS). If the operating system is shut down improperly, the next time it is started it is detected as an error by the RAID 1, and a complete rebuild is executed. This generally takes at least 120 minutes (configurable) to complete.

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5ACPCI.RAIC-05
SATA RAID controller Type Specifications Data transfer rate RAID level BIOS Extension ROM - requirements	 Sil 3512 SATA link Serial ATA 1.0 Max. 1.5 GB/s (150 MB/s) Supports RAID 0, 1 Approx. 32 KB
Hard disks Amount	Seagate ST9250315AS 2
Formatted capacity (512 bytes/sector)	250 GB
Number of heads	1
Number of sectors (user)	488,397,168
Bytes per sector	512
Revolution speed	5400 rpm ±0.2%
Access time (average)	5.56 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1 ms 14 ms 30 ms
Starting time (0 rpm to read access)	3.6 seconds (typically)
Supported transfer modes	SATA 1.0, Serial ATA Revision 2.6 PIO mode 0-4, multiword DMA mode 0-2, UDMA mode 0-6
Data transfer rate On the medium To/from host	 Max. 1175 Mbits/s Max. 150 MB/s
Cache	8 MB
S.M.A.R.T. Support	Yes
Electrical characteristics	
Power consumption	0.3 A at 3.3 V (PCI bus) 1 A at 5 V (PCI bus)
Mechanical characteristics	
Mounted on PCI insert	Fixed
Weight	350 g

Table 70: Technical data - RAID Hard Disk - 5ACPCI.RAIC-05

Environmental characteristics	5ACPCI.RAIC-05
Ambient temperature[1)]	
Operation - Standard / 24-hour[2)]	0 to 60°C
Storage	-40 to 70°C
Transport	-40 to 70°C
Relative humidity[3)]	
Operation	5 to 95%, non-condensing
Storage	5 to 95%, non-condensing
Transport	5 to 95%, non-condensing
Vibration[4)]	
Operation (continuous)	5 - 500 Hz: max. 0.125 g; duration 1 octave per minute; no unrecoverable errors
Operation (occasional)	5 - 500 Hz: max. 0.25 g; duration 1 octave per minute; no unrecoverable errors
Storage	5 - 500 Hz: max. 5 g; duration 0.5 octaves per minute; no damage
Transport	5 - 500 Hz: max. 5 g; duration 0.5 octaves per minute; no damage
Shock[4)] (pulse with a sine half-wave)	
Operation	Max. 125 g, 2 ms; no unrecoverable errors
Storage	Max. 400 g, 2 ms; no damage
	Max. 500 g, 1 ms; no damage
	Max. 300 g, 0.5 ms; no damage
Altitude	
Operation	- 300 to 3048 m
Storage	- 300 to 12,192 m

Table 70: Technical data - RAID Hard Disk - 5ACPCI.RAIC-05 (Forts.)

1) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

2) 24-hour operation means 732 POH (power-on hours) per month.

3) Humidity gradient: Maximum 30% per hour.

4) Operation in areas prone to vibration and shock can affect performance negatively (reduction of transfer rate).

Temperature humidity diagram



Figure 79: Temperature humidity diagram - SATA RAID Hard Disk - 5ACPCI.RAIC-05

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

Driver support

Special drivers are necessary for operating the PCI SATA RAID controller. Drivers for Windows XP Professional and Windows XP Embedded are available for download on the B&R Homepage in the download area (**www.br-automation.com**).

The .NET-based SATARaid™ serial ATA RAID management software can also be found on the B&R homepage.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

Configuration

For configuration of a SATA RAID network, see Chapter 3 "Commissioning", section "Configuration of a SATA RAID array", on page 232.

Exchanging a HDD

A hard drive can be easily exchanged in the event of an error when using the RAID1 (mirroring) configuration without having to re-install the system. The replacement SATA HDD 250GB 5MMHDD.0250-00 is available as a replacement part for a HDD.

For instructions on exchanging the drive, see Chapter 7 "Maintenance / Servicing", section "Mounting the side cover", on page 489.

3.6.15 Replacement SATA HDD 250 GB - 5MMHDD.0250-00

The hard disk can be used as a replacement part for 5ACPCI.RAIC-05 and 5AC801.HDDI-03.



Figure 80: Replacement SATA HDD 250 GB - 5MMHDD.0250-00

Technical data

Information:

The following characteristics, features, and limit values only apply to this individual component and can deviate from those specified for the entire device. For the entire device in which this individual component is used, refer to the data given specifically for the entire device.

Features	5MMHDD.0250-00
Hard disks Amount	Seagate ST9250315AS 1
Formatted capacity (512 bytes/sector)	250 GB
Number of heads	1
Number of sectors (user)	488,397,168
Bytes per sector	512
Revolution speed	5400 rpm ±0.2%
Access time (average)	5.56 ms
Positioning time (seek, typical values) Minimum (track to track) Average (read access) Maximum (read access)	 1 ms 14 ms 30 ms
Starting time (0 rpm to read access)	3.6 seconds (typically)
Supported transfer modes	SATA 1.0, Serial ATA Revision 2.6 PIO mode 0-4, multiword DMA mode 0-2, UDMA mode 0-6
Interface	SATA

Table 71: Technical data - RAID hard disk - 5MMHDD.0250-00

Features	5MMHDD.0250-00
Data transfer rate On the medium To/from host	 Max. 1175 Mbits/s Max. 150 MB/s (SATA I), max. 300 MB/s (SATA II)
Cache	8 MB
S.M.A.R.T. Support	Yes
MTBF	550,000 Power On Hours[1]
Environmental characteristics	
Ambient temperature[2] Operation - Standard / 24-hour[3] Storage Transport	 0 to 60°C -40 to 70°C -40 to 70°C
Relative humidity[4] Operation Storage Transport	 5 to 95%, non-condensing 5 to 95%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage	 0.5 g at 5 - 500 Hz, no non-recovered errors 5 g at 5 - 500 Hz, no non-recovered errors
Shock (pulse with a sine half-wave) Operation Storage	 350 g and 2 ms duration, no non-recovered errors 800 g and 2 ms duration, no non-recovered errors 1000 g and 1 ms duration, no non-recovered errors 600 g and 0.5 ms duration, no non-recovered errors
Altitude Operation Storage	 - 300 to 3048 m - 300 to 12,192 m

Table 71: Technical data - RAID hard disk - 5MMHDD.0250-00 (Forts.)

1) With 8760 POH (Power On Hours) per year and 25°C surface temperature.

2) Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3) 24-hour operation means 732 POH (power-on hours) per month.

4) Humidity gradient: Maximum 30% per hour.

Temperature humidity diagram



Figure 81: Temperature humidity diagram - SATA RAID hard disk - 5MMHDD.0250-00

Temperature values for 305 meter altitude. The temperature specification must be reduced linearly by 1°C every 305 meters. The temperature increase and decrease can be a maximum of 20°C per hour.

3.7 Fan kit

Information:

Fans are necessary when using components which must work within certain temperature limits, e.g. RAID controller, DVD combos, PCI cards.

The fan and dust filter are subject to wear and must be checked with appropriate frequency and cleaned or replaced when not functioning properly (e.g. due to dirt and grime).

For more information about fan switching limits, see appendix, section 2.1 "Temperature monitoring - Fan control", on page 499.

3.7.1 Fan kit 1 card slot - 5PC810.FA01-00

This fan kit is an optional addition for system units with one card slot. For available replacement dust filters for this fan kit, see section "Replacement fan", on page 390.



Figure 82: Fan kit - 5PC810.FA01-00

Technical data

Features	5PC810.FA01-00
Fan type Width Length Height	 40 mm 40 mm 10 mm
Revolution speed	Max. 6100 rpm
Noise level	21 dB
Lifespan	29000 hours at 70°C 95000 hours at 20°C

Table 72: Technical data - 5PC810.FA01-00

Features	5PC810.FA01-00
Maintenance interval	The fans are subject to wear. Depending on the work environment, the dust filter should be checked with appropriate frequency to determine whether the air flow provides sufficient cooling. An exchange or cleaning of the filter kit is appropriate at that time.

Table 72: Technical data - 5PC810.FA01-00 (Forts.)

For information about installing or exchanging the fan kits, see the section "Installing / exchanging the fan kit", on page 474.

3.7.2 Fan kit 2 card slot - 5PC810.FA02-00 and 5PC810.FA02-01

These fan kits are an optional addition for system units with 2 card slots. For available replacement dust filters for these fan kits, see section "Replacement fan", on page 390.

The only difference between the fan kit 5PC810.5A02-01 and 5PC810.FA02-00 is that additional guide elements have been integrated like in the fan kits for the 1 and 5 slot models. This makes it easier to install or exchange the fan kit. Starting with Revision D0, only the fan kit 5PC810.5A02-01 can be installed for the system unit 5PC810.SX02-00.



Figure 83: Fan kit - 5PC810.FA02-00 and 5PC810.FA02-01

Technical data

Features	5PC810.FA02-00 and 5PC810.FA02-01
Fan type Width Length Height	 70 mm 70 mm 15 mm
Revolution speed	Max. 4300 rpm ±12.5%
Noise level	32 dB
Lifespan	60,000 hours at 40°C
Maintenance interval	The fans are subject to wear. Depending on the work environment, the dust filter should be checked with appropriate frequency to determine whether the air flow provides sufficient cooling. An exchange or cleaning of the filter kit is appropriate at that time.

Table 73: Technical data - 5PC810.FA02-00 and 5PC810.FA02-01

For information about installing or exchanging the fan kits, see the section "Installing / exchanging the fan kit", on page 474.

3.7.3 Fan kit 3 card slot - 5PC810.FA03-00

This fan kit is an optional addition for system units with 3 card slots. For available replacement dust filters for this fan kit, see section "Replacement fan", on page 390.



Figure 84: Fan kit - 5PC810.FA03-00

Technical data

Features	5PC810.FA03-00	
Fan type Width Length Height	 70 mm 70 mm 15 mm	 80 mm 80 mm 15 mm
Revolution speed	Max. 4300 rpm ±10%	Max. 3200 rpm ±10%
Noise level	32 dB	33 dB
Lifespan	60,000 hours at 40°C	75,000 hours at 40°C
Maintenance interval	The fans are subject to wear. Depending on the work environment, the dust filter should be checked with appropriate frequency to determine whether the air flow provides sufficient cooling. An exchange or cleaning of the filter kit is appropriate at that time.	

Table 74: Technical data - 5PC810.FA03-00

For information about installing or exchanging the fan kits, see the section "Installing / exchanging the fan kit", on page 474.

3.7.4 Fan kit 5 card slot - 5PC810.FA05-00

This fan kit is an optional addition for system units with 5 card slots. For available replacement dust filters for this fan kit, see section "Replacement fan", on page 390.



Figure 85: Fan kit - 5PC810.FA05-00

Technical data

Features	5PC810.FA05-00
Fan type Width Length Height	 70 mm 70 mm 15 mm
Revolution speed	Max. 4300 rpm ±10%
Noise level	32 dB
Lifespan	60,000 hours at 40°C
Maintenance interval	The fans are subject to wear. Depending on the work environment, the dust filter should be checked with appropriate frequency to determine whether the air flow provides sufficient cooling. An exchange or cleaning of the filter kit is appropriate at that time.

Table 75: Technical data - 5PC810.FA05-00

For information about installing or exchanging the fan kits, see the section "Installing / exchanging the fan kit", on page 474.

3.8 AP Link cards

AP Link cards can be installed in the APC810 system units 5PC810.SX02-00, 5PC810.SX03-00 and 5PC810.SX05-00 (also see the section "Configuration - Drives, software, accessories", on page 46).

3.8.1 AP Link SDL transmitter 5AC801.SDL0-00

A second graphics line can be created using an AP Link graphics adapter card. DVI and SDL signals are available with this. RGB signals are not supported. For details, see technical data for the CPU board being used.



Figure 86: AP Link SDL transmitter 5AC801.SDL0-00

Information:

Installation of AP Link SDL transmitters is only possible in connection with the system units 5PC810.SX02-00, 5PC810.SX03-00 and 5PC810.SX05-00.

You can find information on installing the AP link SDL transmitters under "AP Link installation", on page 491.



Figure 87: Mounting example with the system unit 5PC810.SX02-00

Pin assignments

PIN	Assignment	PIN	Assignment	
1	T.M.D.S. Data 2-	16	Hot Plug detect	DVI-I 24 pin, female 
2	T.M.D.S. Data 2-	17	T.M.D.S. Data 0-	
3	T.M.D.S. Data 2/SDL Shield	18	T.M.D.S. Data 0+	
4	SDL-	19	T.M.D.S. DATA 0/XUSB1 Shield	
5	SDL+	20	XUSB1-	
6	DDC clock	21	XUSB1+	
7	DDC data	22	T.M.D.S. Shield	
8	n.c.	23	T.M.D.S. Clock +	
9	T.M.D.S. Data 1-	24	T.M.D.S. Clock -	
10	T.M.D.S. Data 1+	c1	n.c.	
11	T.M.D.S. DATA 1/XUBS0 Shield	c2	n.c.	
12	XUSB0-	c3	n.c.	
13	XUSB0+	c4	n.c.	
14	+ 5V power[1)]	c5	n.c.	
15	Ground (return for + 5 V, HSync and VSync)		n.c.	

Table 76: Pin assignment for AP Link connection

1) Protected internally by a multifuse

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used.

Cables	Resolution				
Segment length	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -

Table 77: Segment lengths, resolutions and SDL cables

Cables Segment length	Resolution				
	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
20	5CASDL.0200-00 5CASDL.0200-30	5CASDL.0200-00 5CASDL.0200-30	5CASDL.0200-00 5CASDL.0200-30	5CASDL.0200-00 5CASDL.0200-30	- -
25	5CASDL.0250-00 5CASDL.0250-30	5CASDL.0250-00 5CASDL.0250-30	5CASDL.0250-00 5CASDL.0250-30	- -	- -
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-10 5CASDL.0300-13	5CASDL.0300-10 5CASDL.0300-13	- -
40	5CASDL.0400-10 5CASDL.0400-13	5CASDL.0400-10 5CASDL.0400-13	5CASDL.0400-10 5CASDL.0400-13	5CASDL.0400-10 5CASDL.0400-13	- -

Table 77: Segment lengths, resolutions and SDL cables

3.8.2 Ready relay 5AC801.RDYR-00



Figure 88: Ready relay 5AC801.RDYR-00

Information:

Installation of the ready relay is only possible in connection with the system units 5PC810.SX02-00, 5PC810.SX03-00 and 5PC810.SX05-00.



Figure 89: Mounting example with the system unit 5PC810.SX02-00

The relay contacts are closed when the APC810 is powered on.

Pin assignments

Ready relay pin assignments	
Pin assignments - 4-pin multipoint connector N.O. and N.C., max. 30 VDC, max. 10 A	
Pin	**Assignment**
1	Normally open contact
2	Root
3	Normally closed contact
4	n.c.
Accessories	
0TB704.90	Terminal block, 4-pin, Screw clamp, 1.5 mm²
TB704.91	Terminal block, 4-pin, Cage clamps, 2.5 mm²



Table 78: Pin assignments - Ready relay 5AC801.RDYR-00

3.9 Add-on interfaces (IF option)

An additional interface (CAN or combined RS232/422/485) can be installed in the APC810's IF optional slot.



Figure 90: Add-on interfaces (IF option)

Information:

It is possible to add or remove an add-on interface at any time.

Caution!

Turn off power before adding or removing an add-on interface.

3.9.1 Add-on CAN interface - 5AC600.CANI-00

The add-on CAN interface is equipped with an Intel 82527 CAN controller, which conforms to CAN specifications 2.0 part A/B. The CAN controller can trigger an NMI (non-maskable interrupt).

Order data

Model number	Description	Figure
5AC600.CANI-00	**Add-on CAN interface** CAN interface for installation in an APC620, APC800 or PPC700.	

Table 79: Add-on CAN interface - 5AC600.CANI-00

Technical data

Features	5AC600.CANI-00
CAN interface Controller Amount Connection	 Intel 82527 1 9-pin DSUB, male
Terminating resistor Default setting	Can be activated and deactivated using a sliding switch Disabled

Table 80: Technical data - Add-on CAN interface - 5AC600.CANI-00

Pin assignments

Add-on CAN		
Type	Electrically isolated	
Transfer rate	Max. 500 kBit/s	
Bus length	Max. 1000 Meter	
Pin	**Assignment**	
1	n.c.	
2	CAN low	
3	GND	
4	n.c.	
5	n.c.	
6	Reserved	
7	CAN high	
8	n.c.	
9	n.c.	



Table 81: Pin assignments - CAN

I/O address and IRQ

Resource	Default setting	Additional setting options
I/O address	384h / 385h	-
IRQ	IRQ10	NMI [1)]

Table 82: Add-on CAN - I/O Adresse und IRQ

1) NMI = Non Maskable Interrupt.

The IRQ setting can be changed in the BIOS setup. Please note any potential conflicts with other resources when changing this setting.

I/O address	Register	Function
384h	Address register	Defines the register number to access.
385h	Data register	Access to the register defined in the address register.

Table 83: CAN address register

Bus length and cable type

The type of cable used depends largely on the required bus length and the number of nodes. The bus length is mainly determined by the bit rate. In accordance with CiA (CAN in Automation) the maximum bus length is 1000 meters.

The following bus lengths are permitted with a maximum oscillator tolerance of 0.121%:

Distance [m]	Transfer rate [kBit/s]
≤ 1000	Typ. 50
≤ 200	Typ. 250
≤ 60	Typ. 500

Table 84: Bus length and transfer rate - CAN

The material used for the cable should preferably have all or most of the following properties in order to reach an optimal transfer rate.

CAN cable	Property
Signal lines Cable cross section Wire insulation Conductor resistance Stranding Shield	 2 x 0.25 mm² (24AWG/19), tinned Cu wire PE ≤ 82 Ω / km Wires stranded in pairs Paired shield with aluminum foil
Grounding line Cable cross section Wire insulation Conductor resistance	 1 x 0.34 mm² (22AWG/19), tinned Cu wire PE ≤ 59 Ω / km
Outer sheathing Item Features Entire shielding	 PUR mixture Halogen free From tinned cu wires

Table 85: CAN cable requirements

Terminating resistor

CAN networks are cabled using a bus structure where both ends of the bus are equipped with terminating resistors. The add-on CAN interface has an integrated terminating resistor (delivery state: disabled with the setting "Off").



Figure 91: Terminating resistor - Add-on CAN interface 5AC600.CANI-00

Contents of delivery

The screws included in the mounting kit are to be used for installation.



Figure 92: Contents of the delivery / mounting material - 5AC600.CANI-00

Driver support

Because of the Dual Core processors, the INACAN.SYS driver version 2.36, contained in the PVI setup 2.6.0.3105, is required for the operation.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

3.9.2 Add-on RS232/422/485 interface - 5AC600.485I-00

The serial interface is a combined RS232/RS422/RS485 interface. The operating mode (RS232/RS422/RS485) is selected automatically, depending on the electrical connection.

Order data

Model number	Description	Figure
5AC600.485I-00	**Add-on RS232/422/485 interface** Add-on RS232/422/485 interface for installation in an APC620, AP800 and PPC700.	

Table 86: Add-on RS232/422/485 interface - 5AC600.485I-00

Pin assignments

Add-on RS232/422/485			
	RS232	**RS422/485**	
Type	RS232 not modem compatible; Electrically isolated		
UART	16550 compatible, 16 byte FIFO		
Transfer rate	Max. 115 kBit/s		
Bus length	Max. 15 meters	Max. 1200 meters	
Pin	**Assignments (RS232)**	**Assignments (RS422)**	9-pin DSUB connector 
1	n.c.	TXD\	
2	RXD	n.c.	
3	TXD	n.c.	
4	n.c.	TXD	
5	GND	GND	
6	n.c.	RXD\	
7	RTS	n.c.	
8	CTS	n.c.	
9	n.c.	RXD	

Table 87: Pin assignments - RS232/RS422

I/O address and IRQ

Resource	Default setting	Additional setting options
I/O address	2E8h	238, 2F8, 338, 3E8, 3F8
IRQ	IRQ10	IRQ 3, 4, 5, 7, 11, 12

Table 88: Add-on RS232/422/485 - I/O address and IRQ

The setting for the I/O address and the IRQ can be changed in the BIOS setup (under "Advanced" - submenu "Main board/Panel Features" - submenu "Legacy Devices", setting "COM E"). Please note any potential conflicts with other resources when changing this setting.

Bus length and cable type RS232

The maximum transfer rate of 115 kBit/s depends on the cable type being used.

Distance [m]	Transfer rate [kBit/s]
≤ 15	Typ. 64
≤ 10	Typ. 115
≤ 5	Typ. 115

Table 89: RS232 - Bus length and transfer rate

The material used for the cable should preferably have all or most of the following properties in order to reach an optimal transfer rate.

RS232 cable	Property
Signal lines Cable cross section Wire insulation Conductor resistance Stranding Shield	 4 x 0.16 mm² (26AWG), tinned Cu wire PE ≤ 82 Ω / km Wires stranded in pairs Paired shield with aluminum foil
Grounding line Cable cross section Wire insulation Conductor resistance	 1 x 0.34 mm² (22AWG/19), tinned Cu wire PE ≤ 59 Ω / km
Outer sheathing Item Features Entire shielding	 PUR mixture Halogen free From tinned cu wires

Table 90: RS232 - Cable requirements

RS422 - Bus length and cable type

The RTS line must be switched on to activate the sender.

The maximum transfer rate of 115 kBit/s depends on the cable type being used.

Distance [m]	Transfer rate [kBit/s]
1200	Typ. 115

Table 91: RS422 - Bus length and transfer rate

The material used for the cable should preferably have all or most of the following properties in order to reach an optimal transfer rate.

RS422 cable	Property
Signal lines Cable cross section Wire insulation Conductor resistance Stranding Shield	 4 x 0.25 mm² (24AWG/19), tinned Cu wire PE ≤ 82 Ω / km Wires stranded in pairs Paired shield with aluminum foil
Grounding line Cable cross section Wire insulation Conductor resistance	 1 x 0.34 mm² (22AWG/19), tinned Cu wire PE ≤ 59 Ω / km
Outer sheathing Item Features Entire shielding	 PUR mixture Halogen free From tinned cu wires

Table 92: RS422 - Cable requirements

RS485 interface operation

The pins of the RS422 default interface (1, 4, 6 and 9) should be used for operation. The pins should be connected as shown.



Figure 93: Add-on RS232/422/485 interface - operated in RS485 mode

The RTS line must be switched each time the driver is sent and received; there is no automatic switch back. This cannot be configured in Windows.

The voltage drop caused by long line lengths can lead to greater potential differences between the bus stations, which can hinder communication. This can be improved by running ground wire with the others.

The line ends of the RS485 interface should (at least for longer line lengths or larger transfer rates) be closed. Normally a passive terminator can be used on the bus ends by connecting each of the signal lines with 120 Ω resistance.

RS485 - Bus length and cable type

The maximum transfer rate of 115 kBit/s depends on the cable type being used.

Distance [m]	Transfer rate [kBit/s]
1200	Typ. 115

Table 93: RS485 - Bus length and transfer rate

The material used for the cable should preferably have all or most of the following properties in order to reach an optimal transfer rate.

RS485 cable	Property
Signal lines	
Cable cross section	4 x 0.25 mm² (24AWG/19), tinned Cu wire
Wire insulation	PE
Conductor resistance	≤ 82 Ω / km
Stranding	Wires stranded in pairs
Shield	Paired shield with aluminum foil
Grounding line	
Cable cross section	1 x 0.34 mm² (22AWG/19), tinned Cu wire
Wire insulation	PE
Conductor resistance	≤ 59 Ω / km
Outer sheathing	
Item	PUR mixture
Features	Halogen free
Entire shielding	From tinned cu wires

Table 94: RS485 - Cable requirements

Contents of delivery

The screws included in the mounting kit are to be used for installation.



Figure 94: Contents of the delivery / mounting material - 5AC600.485I-00

Chapter 3 • Commissioning

1. Installation

The APC810 systems are mounted with the mounting plates found on the housing. The plates are designed for M5 screws.



Figure 95: Mounting plates

The exact positioning of the mounting holes can be seen in the following drilling templates.

1.1 Important mounting information

- The environmental conditions must be taken into consideration (see chapter 2 "Technical data", section 2.5 "Ambient temperatures", on page 67).
- The APC810 is only certified for operation in closed rooms.
- The APC810 cannot be situated in direct sunlight.
- The ventilation holes cannot be covered.
- When mounting the device, be sure to adhere to the allowable mounting orientations (see section "Mounting orientation", on page 192).
- Be sure the wall or switching cabinet can withstand four times the total weight of the the APC810.
- When connecting certain cable types (DVI, SDL, USB, etc.), keep the flex radius of the cable in mind (see section 2 "Cable connections", on page 194).

1.2 Drilling templates

APC810 1 card slot	APC810 2 card slot
	

Table 95: Drilling templates - 1 and 2 card slot system units

APC810 3 card slot	APC810 5 card slot
	

Table 96: Drilling templates - 3 and 5 card slot system units

1.3 Mounting orientation

The APC810 system must be mounted as described in the following sections.

1.3.1 Standard mounting - vertical

Standard mounting refers to vertical mounting orientation. APC810 systems with and without fan kit can be mounted this way.



Figure 96: Standard mounting - vertical

1.3.2 Optional mounting - horizontal

Operation in the optional horizontal mounting position (heat sink on top) requires the use of a fan kit. The maximum ambient temperature specification must be lowered to 5°C.



Figure 97: Optional mounting - horizontal

1.3.3 Spacing for air circulation.

In order to guarantee sufficient air circulation, mount the system so that the spacing on the top, bottom, and sides is as follows.



Figure 98: Standard mounting - Mounting distances

These defined distances are valid for both vertical and horizontal mounting of the APC810.

2. Cable connections

When making cable connections and installing cables, it is not permitted to have a flex radius smaller than the minimum value specified.



Figure 99: Flex radius - Cable connection

Information:

The specified flex radius can be found in the Automation Panel 800 or Automation Panel 900 user's manual, which can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

3. Grounding concept

The functional ground is a current path with low impedance between isolated circuits and ground, which is not a protective measure, but rather provides e.g. increased immunity to disturbances. It serves only as disturbance dissipation and not as contact protection for persons.

The APC810 functional ground has 2 connections:

- Supply voltage
- Ground connection

To guarantee secure dissipation of electric disturbances, the following points should be observed:

- The device should be connected to the ground using the shortest route possible.
- Use cable with a minimum cross section of 2.5 mm² per connection.
- Note the line shielding concept, all connected data cables are used as shielded lines.



Figure 100: Grounding concept

4. Connection examples

The following examples provide an overview of the configuration options for connecting Automation Panel 800 and Automation Panel 900 and/or Automation Panel 800 devices with the APC810. The following questions will be answered:

- How are Automation Panel 900 devices connected to the monitor / panel output of the APC810, and what needs to be considered?
- How are Automation Panel 800 devices connected to the monitor / panel output of the APC810, and what needs to be considered?
- How are Automation Panel 900 devices connected simultaneously to the Monitor / Panel output on the optional SDL AP Link of the APC810 and what needs to be considered?
- What are "Display Clone" and "Extended Desktop" modes?
- How many Automation Panel 900 devices can be connected per line?
- How many Automation Panel 900 devices can be connected to an Automation Panel 800 device per line?
- How are the connected devices internally numbered?
- Are there limitations to the segment length and if so, what are they?
- What cables and link modules are needed?
- Do BIOS settings have to be changed for a specific configuration?

4.1 Selecting the display units

If an Automation Panel 800 and an Automation Panel 900 should be connected on the same line, the devices must have the same display type. The following table lists the AP900 devices that can be connected on the same line with an AP800 device.

Automation Panel 800	Automation Panel 900
5AP820.1505-00	5AP920.1505-01 5AP951.1505-01 5AP980.1505-01 5AP981.1505-01
5AP880.1505-00	5AP920.1505-01 5AP951.1505-01 5AP980.1505-01 5AP981.1505-01

Table 97: Selecting the display units

4.2 One Automation Panel 900 via DVI (onboard)

An Automation Panel 900 with max. SXGA resolution is connected to the integrated DVI interface (onboard). As an alternative, an office TFT with DVI interface or an analog monitor (using adapter with model no. 5AC900.1000-00) can also be operated. A separate cable is used

for touch screen and USB. If USB devices are to be operated on the Automation Panel 900, the maximum distance is 5 meters. USB devices can only be connected directly to the Automation Panel (without a hub).



Figure 101: Configuration - One Automation Panel 900 via DVI (onboard)

4.2.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	✓	✓	✓	✓	Max. SXGA
5PC800.B945-01 5PC800.B945-11	✓	✓	✓	✓	Max. SXGA
5PC800.B945-02 5PC800.B945-12	✓	✓	✓	✓	Max. SXGA
5PC800.B945-03 5PC800.B945-13	✓	✓	✓	✓	Max. SXGA
5PC800.B945-04 5PC800.B945-14	✓	✓	✓	✓	Max. SXGA
5PC800.B945-05	✓	✓	✓	✓	Max. SXGA

Table 98: Possible combinations of system unit and CPU board

4.2.2 Link modules

Model number	Description	Note
5DLDVI.1000-01	**Automation Panel Link DVI receiver** connections for DVI-D, RS232 and USB 2.0 (Type B); 24VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900

Table 99: Link module for the configuration - One Automation Panel 900 via DVI

4.2.3 Cables

Select one Automation Panel 900 cable each from the 3 required types.

Model number	Type	Length
5CADVI.0018-00	DVI cable	1.8 m
5CADVI.0050-00	DVI cable	5 m
5CADVI.0100-00	DVI cable	10 m[1)]
9A0014.02	Touch screen cable - serial	1.8 m
9A0014.05	Touch screen cable - serial	5 m
9A0014.10	Touch screen cable - serial	10 m[1)]
5CAUSB.0018-00	USB cable	1.8 m
5CAUSB.0050-00	USB cable	5 m

Table 100: Cables for DVI configurations

1) USB support is not possible on the Automation Panel 900 because USB is limited to 5 m.

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

4.2.4 Possible Automation Panel units, resolutions und segment lengths

The following Automation Panel 900 units can be used. In rare cases, the segment length is limited according to the resolution.

Model number	Diagonal	Resolution	Touch screen	Keys	Max. segment length
5AP920.1043-01	10.4"	VGA	✓	-	5 m / 10 m[1)]
5AP920.1214-01	12.1"	SVGA	✓	-	5 m / 10 m[1)]
5AP920.1505-01	15.0"	XGA	✓	-	5 m / 10 m[1)]
5AP920.1706-01	17.0"	SXGA	✓	-	5 m / 10 m[1)]
5AP920.1906-01	19.0"	SXGA	✓	-	5 m / 10 m[1)]

Table 101: Possible Automation Panel units, resolutions und segment lengths

1) USB support is not possible on the Automation Panel 900 because USB is limited to 5 m.

Information:

The DVI transfer mode does not allow reading statistical values on Automation Panel 900 units.

4.2.5 BIOS settings

No special BIOS settings are necessary for operation.

4.3 An Automation Panel 900 via SDL (onboard)

An Automation Panel 900 is connected to the integrated SDL interface (onboard) via an SDL cable. USB devices can only be connected directly to the Automation Panel (without a hub).



Figure 102: Configuration - An Automation Panel 900 via SDL (onboard)

4.3.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	✓	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	✓	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	✓	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	✓	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	✓	✓	✓	✓	Max. UXGA
5PC800.B945-05	✓	✓	✓	✓	Max. UXGA

Table 102: Possible combinations of system unit and CPU board

4.3.2 Link modules

Model number	Description	Note
5DLSDL.1000-00	**Automation Panel Link SDL receiver** Connection for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900

Table 103: Link module for the configuration - One Automation Panel 900 via SDL

4.3.3 Cables

Select an Automation Panel 900 cable from the following table.

Model number	Type	Length
5CASDL.0018-00	SDL cable for a fixed type of layout	1.8 m
5CASDL.0018-01	SDL cable with 45° plug for fixed type of layout	1.8 m
5CASDL.0018-03	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-00	SDL cable for a fixed type of layout	5 m
5CASDL.0050-01	SDL cable with 45° plug for fixed type of layout	5 m
5CASDL.0050-03	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-00	SDL cable for a fixed type of layout	10 m
5CASDL.0100-01	SDL cable with 45° plug for fixed type of layout	10 m
5CASDL.0100-03	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-00	SDL cable for a fixed type of layout	15 m
5CASDL.0150-01	SDL cable with 45° plug for fixed type of layout	15 m
5CASDL.0150-03	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-00	SDL cable for a fixed type of layout	20 m
5CASDL.0200-03	SDL cable for fixed and flexible type of layout	20 m
5CASDL.0250-00	SDL cable for a fixed type of layout	25 m
5CASDL.0250-30	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-00	SDL cable for a fixed type of layout	30 m
5CASDL.0300-03	SDL cable for fixed and flexible type of layout	30 m
5CASDL.0300-13	SDL cable with extender for fixed and flexible type of layout	30 m
5CASDL.0400-13	SDL cable with extender for fixed and flexible type of layout	40 m

Table 104: Cables for SDL configurations

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables Segment length [m]	Resolution				
	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -
20	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	- -
25	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	- -	- -
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-13	5CASDL.0300-13	- -
40	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	-

Table 105: Segment lengths, resolutions and SDL cables

4.3.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM C must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.4 An Automation Panel 800 via SDL (onboard)

An Automation Panel 800 is connected to the integrated SDL interface (onboard) via an SDL cable. USB devices can only be connected directly to the extension keyboard (without a hub).



Figure 103: Configuration - An Automation Panel 800 via SDL (onboard)

4.4.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	✓	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	✓	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	✓	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	✓	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	✓	✓	✓	✓	Max. UXGA
5PC800.B945-05	✓	✓	✓	✓	Max. UXGA

Table 106: Possible combinations of system unit and CPU board

4.4.2 Cables

Select an Automation Panel 800 SDL cable from the following table.

Model number	Type	Length
5CASDL.0018-20	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-20	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-20	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-20	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-20	SDL cable for fixed and flexible type of layout	20 m
5CASDL.0250-20	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-30	SDL cable with extender for fixed and flexible type of layout	30 m
5CASDL.0400-30	SDL cable with extender for fixed and flexible type of layout	40 m

Table 107: Cables for SDL configurations

Information:

Detailed technical data about the cables can be found in the Automation Panel 800 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables	Resolution
Segment length [m]	XGA 1024 x 768
1.8	5CASDL.0018-20
5	5CASDL.0050-20
10	5CASDL.0100-20
15	5CASDL.0150-20
20	5CASDL.0200-20
25	5CASDL.0250-20
30	5CASDL.0300-30
40	5CASDL.0400-30

Table 108: Segment lengths, resolutions and SDL cables

4.4.3 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM C must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.5 An AP900 and an AP800 via SDL (onboard)

An Automation Panel 900 and an Automation Panel 800 are connected to the integrated SDL interface (onboard) via SDL.

USB is supported up to a maximum distance (segment 1 + segment 2) of 30 m on the two displays. Starting at a distance of 30 m, USB is only available on the first display (front and back) up to a maximum of 40 m. USB devices can only be connected directly to the Automation Panel 900 or extension keyboard (without a hub).



Figure 104: Configuration - One AP900 and an AP800 via SDL (onboard)

4.5.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	✓	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	✓	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	✓	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	✓	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	✓	✓	✓	✓	Max. UXGA
5PC800.B945-05	✓	✓	✓	✓	Max. UXGA

Table 109: Possible combinations of system unit and CPU board

4.5.2 Link modules

Model number	Description	Note
5DLSDL.1000-01	**Automation Panel Link SDL transceiver** Connections for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900 1 pieces required

Table 110: Link modules for configuration - One AP900 and one AP800 via SDL (onboard)

4.5.3 Cables

How to select an SDL cable for connecting the AP900 display to the AP900 display4.3 "An Automation Panel 900 via SDL (onboard)".

How to select an SDL cable for connecting the AP800 display to the AP900 display4.4 "An Automation Panel 800 via SDL (onboard)".

Information:

Detailed technical data about the cables can be found in the Automation Panel 800 or Automation Panel 900 User's Manual. These can be downloaded as .pdf files from the B&R homepage www.br-automation.com.

4.5.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM C must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.6 Four Automation Panel 900 units via SDL (onboard)

An Automation Panel 900 is connected to the integrated SDL interface (onboard) via an SDL cable. Up to three other Automation Panels of the same type are connected to this Automation Panel and operated via SDL. All four panels show the same content (Display Clone).

USB is supported up to a maximum distance (SDL segment 1 + SDL segment 2) of 30 m on the first two panels (front and back side). From a distance of 30 m and longer, USB is only available for the first panel (front and back side). USB devices can only be connected directly to the Automation Panel (without a hub).



Figure 105: Configuration - Four Automation Panel 900 units via SDL (onboard)

4.6.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	✓	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	✓	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	✓	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	✓	✓	✓	✓	Max. UXGA

Table 111: Possible combinations of system unit and CPU board

CPU board	with system unit				Resolution
	5PC810.SX01-00	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-04 5PC800.B945-14	✓	✓	✓	✓	Max. UXGA
5PC800.B945-05	✓	✓	✓	✓	Max. UXGA

Table 111: Possible combinations of system unit and CPU board

4.6.2 Link modules

Model number	Description	Note
5DLSDL.1000-00	**Automation Panel Link SDL receiver** Connection for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900
5DLSDL.1000-01	**Automation Panel Link SDL transceiver** Connections for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900 3 pieces required

Table 112: Link modules for the configuration: 4 Automation Panel 900 via SDL on 1 line

4.6.3 Cables

Select an Automation Panel 900 cable from the following table.

Model number	Type	Length
5CASDL.0018-00	SDL cable for a fixed type of layout	1.8 m
5CASDL.0018-01	SDL cable with 45° plug for fixed type of layout	1.8 m
5CASDL.0018-03	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-00	SDL cable for a fixed type of layout	5 m
5CASDL.0050-01	SDL cable with 45° plug for fixed type of layout	5 m
5CASDL.0050-03	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-00	SDL cable for a fixed type of layout	10 m
5CASDL.0100-01	SDL cable with 45° plug for fixed type of layout	10 m
5CASDL.0100-03	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-00	SDL cable for a fixed type of layout	15 m
5CASDL.0150-01	SDL cable with 45° plug for fixed type of layout	15 m
5CASDL.0150-03	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-00	SDL cable for a fixed type of layout	20 m
5CASDL.0200-03	SDL cable for fixed and flexible type of layout	20 m
5CASDL.0250-00	SDL cable for a fixed type of layout	25 m
5CASDL.0250-30	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-00	SDL cable for a fixed type of layout	30 m
5CASDL.0300-03	SDL cable for fixed and flexible type of layout	30 m
5CASDL.0300-13	SDL cable with extender for fixed and flexible type of layout	30 m

Table 113: Cables for SDL configurations

Model number	Type	Length
5CASDL.0400-13	SDL cable with extender for fixed and flexible type of layout	40 m

Table 113: Cables for SDL configurations

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables	Resolution				
Segment length [m]	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -
20	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	- -
25	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	- -	- -
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-13	5CASDL.0300-13	- -
40	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	-

Table 114: Segment lengths, resolutions and SDL cables

4.6.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM C must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.7 One Automation Panel 900 unit via SDL (AP Link)

An Automation Panel 900 unit is connected to the optional SDL transmitter (AP Link) via an SDL cable. USB devices can only be connected directly to the Automation Panel (without a hub).



Figure 106: Configuration - One Automation Panel 900 via SDL (AP Link)

4.7.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00[1)]	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	-	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	-	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	-	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	-	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	-	✓	✓	✓	Max. UXGA
5PC800.B945-05	-	✓	✓	✓	Max. UXGA

Table 115: Possible combinations of system unit and CPU board

1) AP Link cannot be installed.

4.7.2 Link modules

Model number	Description	Note
5DLSDL.1000-00	**Automation Panel Link SDL receiver** Connection for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900
5AC801.SDL0-00	**APC810 AP Link SDL transmitter** Automation Panel SDL link transmitter	For Automation PC 810

Table 116: Link modules for the configuration: 4 Automation Panel 900 via SDL on 1 line

4.7.3 Cables

Select an Automation Panel 900 cable from the following table.

Model number	Type	Length
5CASDL.0018-00	SDL cable for a fixed type of layout	1.8 m
5CASDL.0018-01	SDL cable with 45° plug for fixed type of layout	1.8 m
5CASDL.0018-03	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-00	SDL cable for a fixed type of layout	5 m
5CASDL.0050-01	SDL cable with 45° plug for fixed type of layout	5 m
5CASDL.0050-03	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-00	SDL cable for a fixed type of layout	10 m
5CASDL.0100-01	SDL cable with 45° plug for fixed type of layout	10 m
5CASDL.0100-03	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-00	SDL cable for a fixed type of layout	15 m
5CASDL.0150-01	SDL cable with 45° plug for fixed type of layout	15 m
5CASDL.0150-03	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-00	SDL cable for a fixed type of layout	20 m
5CASDL.0200-03	SDL cable for fixed and flexible type of layout	20 m
5CASDL.0250-00	SDL cable for a fixed type of layout	25 m
5CASDL.0250-30	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-00	SDL cable for a fixed type of layout	30 m
5CASDL.0300-03	SDL cable for fixed and flexible type of layout	30 m
5CASDL.0300-13	SDL cable with extender for fixed and flexible type of layout	30 m
5CASDL.0400-13	SDL cable with extender for fixed and flexible type of layout	40 m

Table 117: Cables for SDL configurations

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables Segment length [m]	Resolution				
	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -
20	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	- -
25	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	- -	- -
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-13	5CASDL.0300-13	- -
40	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	-

Table 118: Segment lengths, resolutions and SDL cables

4.7.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM D must be enabled in BIOS in order to operate the connected panel touch screen on the AP Link connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.8 Four Automation Panel 900 units via SDL (AP Link)

An Automation Panel 900 unit is connected to the optional SDL transmitter (AP Link) via an SDL cable. Three other Automation Panels of the same type are connected to this Automation Panel and operated via SDL. All four panels show the same content (Display Clone).

USB is supported up to a maximum distance (SDL segment 1 + SDL segment 2) of 30 m on the first two panels (front and back side). From a distance of 30 m and longer, USB is only available for the first panel (front and back side). USB devices can only be connected directly to the Automation Panel (without a hub).



Figure 107: Configuration - Four Automation Panel 900 units via SDL (AP Link)

4.8.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00[1)]	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	-	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	-	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	-	✓	✓	✓	Max. UXGA

Table 119: Possible combinations of system unit and CPU board

CPU board	with system unit				Resolution
	5PC810.SX01-00[1)]	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-03 5PC800.B945-13	-	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	-	✓	✓	✓	Max. UXGA
5PC800.B945-05	-	✓	✓	✓	Max. UXGA

Table 119: Possible combinations of system unit and CPU board

1) AP Link cannot be installed.

4.8.2 Link modules

Model number	Description	Note
5DLSDL.1000-00	**Automation Panel Link SDL receiver** Connection for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900
5DLSDL.1000-01	**Automation Panel Link SDL transceiver** Connections for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900 3 pieces required
5AC801.SDL0-00	**APC810 AP Link SDL transmitter** Automation Panel SDL link transmitter	For Automation PC 810

Table 120: Link modules for configuration - Four Automation Panel 900 units via SDL (AP Link)

4.8.3 Cables

Select four Automation Panel 900 cables from the following table.

Model number	Type	Length
5CASDL.0018-00	SDL cable for a fixed type of layout	1.8 m
5CASDL.0018-01	SDL cable with 45° plug for fixed type of layout	1.8 m
5CASDL.0018-03	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-00	SDL cable for a fixed type of layout	5 m
5CASDL.0050-01	SDL cable with 45° plug for fixed type of layout	5 m
5CASDL.0050-03	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-00	SDL cable for a fixed type of layout	10 m
5CASDL.0100-01	SDL cable with 45° plug for fixed type of layout	10 m
5CASDL.0100-03	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-00	SDL cable for a fixed type of layout	15 m
5CASDL.0150-01	SDL cable with 45° plug for fixed type of layout	15 m
5CASDL.0150-03	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-00	SDL cable for a fixed type of layout	20 m
5CASDL.0200-03	SDL cable for fixed and flexible type of layout	20 m

Table 121: Cables for SDL configurations

Model number	Type	Length
5CASDL.0250-00	SDL cable for a fixed type of layout	25 m
5CASDL.0250-30	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-00	SDL cable for a fixed type of layout	30 m
5CASDL.0300-03	SDL cable for fixed and flexible type of layout	30 m
5CASDL.0300-13	SDL cable with extender for fixed and flexible type of layout	30 m
5CASDL.0400-13	SDL cable with extender for fixed and flexible type of layout	40 m

Table 121: Cables for SDL configurations

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables	Resolution				
Segment length [m]	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -
20	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	- -
25	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	- -	- -
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-13	5CASDL.0300-13	- -
40	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	-

Table 122: Segment lengths, resolutions and SDL cables

4.8.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM D must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.9 Two Automation Panel 900 units via SDL (onboard) and SDL (AP Link)

An Automation Panel 900 (max. UXGA) is connected to the integrated SDL interface (onboard) via an SDL cable. A second Automation Panel 900 (max. UXGA) is connected to the optional SDL transmitter (AP Link) via an SDL cable. The Automation Panels show different content (Extended Desktop) and can be different types.



Figure 108: Configuration - Two Automation Panel 900 units via SDL (onboard) and SDL (AP Link)

4.9.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00[1)]	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	-	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	-	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	-	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	-	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	-	✓	✓	✓	Max. UXGA
5PC800.B945-05	-	✓	✓	✓	Max. UXGA

Table 123: Possible combinations of system unit and CPU board

1) AP Link cannot be installed.

4.9.2 Link modules

Model number	Description	Note
5DLSDL.1000-00	**Automation Panel Link SDL receiver** Connection for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	2 pieces for Automation Panel 900
5AC801.SDL0-00	**APC810 AP Link SDL transmitter** Automation Panel SDL link transmitter	For Automation PC 810

Table 124: Link modules for configuration - Two Automation Panel 900 units via SDL (onboard) and SDL (AP Link)

4.9.3 Cables

Select four Automation Panel 900 cables from the following table.

Model number	Type	Length
5CASDL.0018-00	SDL cable for a fixed type of layout	1.8 m
5CASDL.0018-01	SDL cable with 45° plug for fixed type of layout	1.8 m
5CASDL.0018-03	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-00	SDL cable for a fixed type of layout	5 m
5CASDL.0050-01	SDL cable with 45° plug for fixed type of layout	5 m
5CASDL.0050-03	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-00	SDL cable for a fixed type of layout	10 m
5CASDL.0100-01	SDL cable with 45° plug for fixed type of layout	10 m
5CASDL.0100-03	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-00	SDL cable for a fixed type of layout	15 m
5CASDL.0150-01	SDL cable with 45° plug for fixed type of layout	15 m
5CASDL.0150-03	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-00	SDL cable for a fixed type of layout	20 m
5CASDL.0200-03	SDL cable for fixed and flexible type of layout	20 m
5CASDL.0250-00	SDL cable for a fixed type of layout	25 m
5CASDL.0250-30	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-00	SDL cable for a fixed type of layout	30 m
5CASDL.0300-03	SDL cable for fixed and flexible type of layout	30 m
5CASDL.0300-13	SDL cable with extender for fixed and flexible type of layout	30 m
5CASDL.0400-13	SDL cable with extender for fixed and flexible type of layout	40 m

Table 125: Cables for SDL configurations

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables Segment length [m]	Resolution				
	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -
20	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	- -
25	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	- -	- -
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-13	5CASDL.0300-13	- -
40	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	-

Table 126: Segment lengths, resolutions and SDL cables

4.9.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM C or COM D must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel or AP Link connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.10 Eight Automation Panel 900 units via SDL (onboard) and SDL (AP Link)

Four Automation Panel 900 units (max. UXGA) are connected to the integrated SDL interface (onboard) via SDL. Four additional Automation Panel 900 units (max. UXGA) are connected to the optional SDL transmitter (AP Link). The Automation Panels in each line must be the same type. The two lines show different content (Extended Desktop), but panels in the same line show the same content (Display Clone).

USB is supported up to a maximum distance (SDL segment 1 + SDL segment 2) of 30 m on the first two panels (front and back side) of the two lines. From a distance of 30 m and longer, USB is only available for the first panel on each line. USB devices can only be connected directly to the Automation Panel (without hub).



Figure 109: Configuration - Eight Automation Panel 900 units via SDL (onboard) and SDL (AP Link)

4.10.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table (e.g. for connecting a non-B&R Automation Panel 900 device).

CPU board	with system unit				Resolution
	5PC810.SX01-00[1)]	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	-	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	-	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	-	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	-	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	-	✓	✓	✓	Max. UXGA
5PC800.B945-05	-	✓	✓	✓	Max. UXGA

Table 127: Possible combinations of system unit and CPU board

1) AP Link cannot be installed.

4.10.2 Link modules

Model number	Description	Note
5DLSDL.1000-00	**Automation Panel Link SDL receiver** Connection for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900 2 pieces required
5DLSDL.1000-01	**Automation Panel Link SDL transceiver** Connections for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900 6 pieces required
5AC801.SDL0-00	**APC810 AP Link SDL transmitter** Automation Panel SDL link transmitter	For Automation PC 810

Table 128: Link modules for configuration: 8 Automation Panel 900 units via SDL and SDL (optional)

4.10.3 Cables

Select four Automation Panel 900 cables from the following table.

Model number	Type	Length
5CASDL.0018-00	SDL cable for a fixed type of layout	1.8 m
5CASDL.0018-01	SDL cable with 45° plug for fixed type of layout	1.8 m
5CASDL.0018-03	SDL cable for fixed and flexible type of layout	1.8 m
5CASDL.0050-00	SDL cable for a fixed type of layout	5 m

Table 129: Cables for SDL configurations

Model number	Type	Length
5CASDL.0050-01	SDL cable with 45° plug for fixed type of layout	5 m
5CASDL.0050-03	SDL cable for fixed and flexible type of layout	5 m
5CASDL.0100-00	SDL cable for a fixed type of layout	10 m
5CASDL.0100-01	SDL cable with 45° plug for fixed type of layout	10 m
5CASDL.0100-03	SDL cable for fixed and flexible type of layout	10 m
5CASDL.0150-00	SDL cable for a fixed type of layout	15 m
5CASDL.0150-01	SDL cable with 45° plug for fixed type of layout	15 m
5CASDL.0150-03	SDL cable for fixed and flexible type of layout	15 m
5CASDL.0200-00	SDL cable for a fixed type of layout	20 m
5CASDL.0200-03	SDL cable for fixed and flexible type of layout	20 m
5CASDL.0250-00	SDL cable for a fixed type of layout	25 m
5CASDL.0250-30	SDL cable for fixed and flexible type of layout	25 m
5CASDL.0300-00	SDL cable for a fixed type of layout	30 m
5CASDL.0300-03	SDL cable for fixed and flexible type of layout	30 m
5CASDL.0300-13	SDL cable with extender for fixed and flexible type of layout	30 m
5CASDL.0400-13	SDL cable with extender for fixed and flexible type of layout	40 m

Table 129: Cables for SDL configurations (Forts.)

Cable lengths and resolutions for SDL transfer

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables	Resolution				
Segment length [m]	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-03
5	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-03
10	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-03
15	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-03	- - -
20	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	5CASDL.0200-00 5CASDL.0200-03	- -
25	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	5CASDL.0250-00 5CASDL.0250-03	- -	- -

Table 130: Segment lengths, resolutions and SDL cables

Cables Segment length [m]	Resolution				
	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
30	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-00 5CASDL.0300-03	5CASDL.0300-13	5CASDL.0300-13	- -
40	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	5CASDL.0400-13	-

Table 130: Segment lengths, resolutions and SDL cables (Forts.)

Information:

Detailed technical data about the cables can be found in the Automation Panel 900 User's Manual. This can be downloaded as a .pdf file from the B&R homepage www.br-automation.com.

4.10.4 BIOS settings

No special BIOS settings are necessary for operation.

Touch screen functionality

The COM C or COM D must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel or AP Link connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

4.11 Six AP900 and two AP800 devices via SDL (onboard) and SDL (AP Link)

Three Automation Panel 900 (max. UXGA) units and one Automation Panel 800 are connected to the integrated SDL interface (onboard) via SDL. Additionally, three Automation Panel 900 (max. UXGA) units and one Automation Panel 800 are operated on the optional SDL transmitters. The Automation Panels in each line must be the same type. The two lines show different content (Extended Desktop), but displays in the same line show the same content (Display Clone).

USB is supported up to a maximum distance (segment 1 + segment 2) of 30 m on the first two displays. Starting at a distance of 30 m, USB is only available on the first display (front and back) up to a maximum of 40 m. USB devices can only be connected directly to Automation Panel 900 devices (without a hub).



Figure 110: Configuration - Six AP900 and two AP800 devices via SDL (onboard) and SDL (AP Link)

4.11.1 Basic system requirements

The following table displays the possible combinations for the APC810 system unit with CPU board to implement the configuration shown in the figure above. If the maximum resolution is limited when making the combination then it is also shown in the following table.

If an Automation Panel 800 and an Automation Panel 900 should be connected on the same line, the devices must have the same display type.

CPU board	with system unit				Resolution
	5PC810.SX01-00[1)]	5PC810.SX02-00	5PC810.SX03-00	5PC810.SX05-00	
5PC800.B945-00 5PC800.B945-10	-	✓	✓	✓	Max. UXGA
5PC800.B945-01 5PC800.B945-11	-	✓	✓	✓	Max. UXGA
5PC800.B945-02 5PC800.B945-12	-	✓	✓	✓	Max. UXGA
5PC800.B945-03 5PC800.B945-13	-	✓	✓	✓	Max. UXGA
5PC800.B945-04 5PC800.B945-14	-	✓	✓	✓	Max. UXGA
5PC800.B945-05	-	✓	✓	✓	Max. UXGA

Table 131: Possible combinations of system unit and CPU board

1) AP Link cannot be installed.

4.11.2 Link modules

Model number	Description	Note
5DLSDL.1000-01	**Automation Panel Link SDL transceiver** Connections for SDL in, transfer of display data, touch screen, USB 1.1, matrix keys, and service data, 24 VDC (screw clamp 0TB103.9 or cage clamp 0TB103.91 sold separately).	For Automation Panel 900 6 pieces required
5AC801.SDL0-00	**APC810 AP Link SDL transmitter** Automation Panel SDL link transmitter	For Automation PC 810

Table 132: Link modules for configuration: 6 AP900 and 2 AP800 devices via SDL and SDL (optional)

4.11.3 Cables

How to select an SDL cable for connecting the AP900 display to the AP900 display4.3 "An Automation Panel 900 via SDL (onboard)".

How to select an SDL cable for connecting the AP800 display to the AP900 display4.4 "An Automation Panel 800 via SDL (onboard)".

Information:

Detailed technical data about the cables can be found in the Automation Panel 800 or Automation Panel 900 User's Manual. These can be downloaded as .pdf files from the B&R homepage www.br-automation.com.

The following table shows the relationship between segment lengths and the maximum resolution according to the SDL cable used:

Cables Segment length [m]	Resolution				
	VGA 640 x 480	SVGA 800 x 600	XGA 1024 x 768	SXGA 1280 x 1024	UXGA 1600 x 1200
1.8	- - - -	- - - -	5CASDL.0018-00 5CASDL.0018-01 5CASDL.0018-20 5CASDL.0018-03	- - - -	- - - -
5	- - - -	- - - -	5CASDL.0050-00 5CASDL.0050-01 5CASDL.0050-20 5CASDL.0050-03	- - - -	- - - -
10	- - - -	- - - -	5CASDL.0100-00 5CASDL.0100-01 5CASDL.0100-20 5CASDL.0100-03	- - - -	- - - -
15	- - - -	- - - -	5CASDL.0150-00 5CASDL.0150-01 5CASDL.0150-20 5CASDL.0150-03	- - - -	- - - -
20	- - -	- - -	5CASDL.0200-00 5CASDL.0200-20 5CASDL.0200-03	- - -	- - -
25	- - -	- - -	5CASDL.0250-00 5CASDL.0250-20 5CASDL.0250-03	- - -	- - -
30	- -	- -	5CASDL.0300-13 5CASDL.0300-30	- -	- -
40	- -	- -	5CASDL.0400-13 5CASDL.0400-30	- -	- -

Table 133: Segment lengths, resolutions and SDL cables

Touch screen functionality

Information:

The COM C or COM D must be enabled in BIOS in order to operate the connected panel touch screen on the monitor / panel or AP Link connection (found in the BIOS menu under "Advanced - Main board / Panel Features - Legacy Devices").

5. Connection of USB peripheral devices

Warning!

Peripheral USB devices can be connected to the USB ports. Due to the vast number of USB devices available on the market, B&R cannot guarantee their performance. B&R does ensure the performance of all USB devices that they provide.

5.1 Local on the APC810

Many different peripheral USB devices can be connected to the 5 USB ports. This means that the USB ports USB1, USB3, USB5 can each handle a load of 1A and USB ports USB2 and USB4 can each handle a load of 500mA. The maximum transfer rate is USB 2.0.



Figure 111: Local connection of USB peripheral devices on the APC810

5.2 Remote connection to Automation Panel 900 via DVI

Many different peripheral USB devices can be connected to the 2 or 3 USB ports on the Automation Panel 900. These can each handle a load of 500 mA. The maximum transfer rate is USB 2.0.

Information:

Only end devices (no hubs) can be connected to the Automation Panel 900.



Figure 112: Remote connection of USB peripheral devices to the APC900 via DVI

5.3 Remote connection to Automation Panel 800/900 via SDL

Many different peripheral USB devices can be connected to the 2 or 3 USB ports on Automation Panel 900 and/or USB connections on the Automation Panel 800 devices. These can each handle a load of 500 mA. The maximum transfer rate is USB 1.1.

Information:

Only end devices (no hubs) can be connected to the Automation Panel 800/900.



Figure 113: Remote connection of USB peripheral devices to the APC800/900 via SDL

6. Configuration of a SATA RAID array

Information:

The following software description is valid for PCI SATA controllers 5ACPCI.RAIC-01 and 5ACPCI.RAIC-03.

You must enter the BIOS "RAID Configuration Utility" in order to make the necessary settings. After the POST, enter <Ctrl+S> or <F4> to open RAID BIOS.



Figure 114: Open the RAID Configuration Utility



Figure 115: RAID Configuration Utility - Menu

The following keys can be used after entering the BIOS setup:

Key	Function
Cursor ↑	Go to previous item.
Cursor ↓	Go to the next item.
Enter	Select an item or open a submenu.
ESC	Go back to previous menu.
Ctrl+E	Exit setup and save the changed settings.

Table 134: BIOS-relevant keys in the RAID Configuration Utility

6.1 Create RAID set



Figure 116: RAID Configuration Utility - Menu

The RAID system can be recreated as "Striped" = RAID0 or "Mirrored" = RAID1 using the menu "Create RAID set".

6.1.1 Create RAID set - Striped



Figure 117: RAID Configuration Utility - Create RAID set - Striped

Auto configuration
Auto configuration optimizes all settings.

"Manual configuration"
It is possible to specify the first and second HDD as well as the "Chunk Size" (= block size, application-dependent).

6.1.2 Create RAID set - Mirrored



Figure 118: RAID Configuration Utility - Create RAID set - Mirrored

Auto configuration
Auto configuration optimizes all settings.

"Manual configuration"
It is possible to specify the "Source" and "Target" HDD, and also to specify whether a rebuild (mirror) should be performed immediately (approx. 50 minutes).

6.2 Delete RAID set



Figure 119: RAID Configuration Utility - Delete RAID set

An existing RAID set can be deleted using the menu "Delete RAID set".

6.3 Rebuild mirrored set



Figure 120: RAID Configuration Utility - Rebuild mirrored set

The "Rebuild mirrored set" menu can be used to restart a rebuild procedure in a RAID 1 network if an error occurs, after first interrupting the rebuild procedure or when exchanging a hard disk.

If "onlinerebuild" is selected, then the rebuild is executed during operation after the system is booted. E.g. an event pop-up is displayed by the installed SATA RAID configuration program: `SATARaid detected a new event` and the rebuild is started. The entire rebuild lasts approximately 50 minutes.

If "offlinerebuild" is selected, then a rebuild is performed immediately before starting the operating system (lasts approximately 30 minutes).

6.4 Resolve conflicts



Figure 121: RAID Configuration Utility - Resolve conflicts

Conflicts in a RAID set can be resolved using the "Resolve conflicts" menu. This function is only available if the status of the hard disk is "conflict".

6.5 Low level format



Figure 122: RAID Configuration Utility - Low level format

Individual hard disks can be configured using the "Low Level Format" menu. This can only be done if a RAID set is not configured. A low level format of a hard disk takes approx. 40 minutes.

7. Known problems / issues

The following points listed are known as of 2008-05-07 in the first production lot of APC800 devices:

- The hardware security key interface is supported beginning with MTXC FPGA version 00.06 and higher.
- The status indicator of the Link or Activity LED for the ETH1 interface did not function correctly. However, this did not affect the network connection. The status indicator functions correctly beginning with hardware revisions 5PC810.SX92-00 (revision B0) and 5PC800.B945-0x (revision B0).
- Sporadically, it was possible that the ETH2 interface was not initialized during a power-on and therefore it would not function. The problem could be corrected by a reset or warm restart (Ctrl+Alt+Del). This problem is corrected in MTXC FPGA version 00.03.
- First Boot Agent Windows XP embedded and built-in SATA HDD drive
  The BIOS setting "Legacy IDE Channels" under "Advanced - IDE Configuration" must be set to "PATA only" before inserting a CompactFlash card with a Windows XP embedded image and executing the First Boot Agent or the SATA drive can first be removed.
- When using two graphic lines, the Windows XP graphics driver assigns the labels "digital indicator" to the monitor / panel plug and "digital indicator 2" to the AP Link plug. In the "extended desktop" mode, the following behavior is observed: If the digital display device on the monitor / panel is removed (e.g. cable disconnected), digital display 2 is activated automatically, and the graphics driver settings also switch over accordingly. The next time the system is rebooted, the image content is diverted from the monitor / panel plug to the AP Link plug.
  If the BIOS option "SDVO/DVI Hotplug support" is set to "enabled" (found under the BIOS menu point "Advanced - Graphics - Configuration"), then the image content is automatically diverted from the separate monitor / panel plug to the second graphics line on the AP Link plug.
- Special features of "Quick Switching" - if the APC810 is in Standby mode - Power LED is red (e.g. Windows XP shutdown), then buffering takes a little more time due to capacitors and low power consumption. If the "Power Loss Control" option is set to "Power On" or "Last State" in BIOS, then the system might not restart because a Power Off/On was not detected. To make sure that these system units will restart after a Power Off/On, the turn-off time should be set to at least 10 seconds.
- From MTCX PX32 firmware V00.11 and higher, the reset button is only triggered by edges. This means that the device boots even when the reset button is pressed. In MTCX PX32 firmware < V00.11, the system does not start after pressing (ca. 10 seconds) and releasing the reset button.
- Hardware revision B0 of the slide-in DVD-ROM - 5AC801.DVDS-00 does not offer SATA hot plug capability. Other hardware revisions are hot plug capable.
- Using two different types of CompactFlash cards can cause problems in Automation PCs and Panel PCs. This can result in one of the two cards not being detected during system startup. This is caused by varying startup speeds. CompactFlash cards with older

technology require significantly more time during system startup than CompactFlash cards with newer technology. This behavior occurs near the limits of the time frame provided for startup. The problem described above can occur because the startup time for the CompactFlash cards fluctuates due to the variance of the components being used. Depending on the CompactFlash cards being used, this error might never, sometimes or always occur.

- During daisy chain operation of multiple AP800/AP900 devices via SDL, it's possible that the touch controller status shows a red "X" in the Control Center applet for the touch screen driver when the touch controller is detected. The functionality of the touch system is not affected by this. This can be avoided by setting a panel locking time of 50 ms. The panel locking time can be configured with the B&R Key Editor.

Chapter 4 • Software

1. BIOS options

Information:

The following diagrams and BIOS menu items including descriptions refer to BIOS version 1.17. It is therefore possible that these diagrams and BIOS descriptions do not correspond with the installed BIOS version.

1.1 General information

BIOS stands for "Basic Input Output System". It is the most basic standardized communication between the user and the system (hardware). The BIOS system used in the Automation PC 810 systems is produced by American Megatrends Inc.

The BIOS Setup Utility lets you modify basic system configuration settings. These settings are stored in CMOS and in EEPROM (as a backup).

The CMOS data is buffered by a battery (if present), and remains in the APC810 even when the power is turned off (no 24VDC supply).

1.2 BIOS setup and boot procedure

BIOS is immediately activated when switching on the power supply of the Automation PC 810 system or pressing the power button. The system checks if the setup data from the EEPROM is "OK". If the data is "OK", then it is transferred to the CMOS. If the data is "not OK", then the CMOS data is checked for validity. An error message is output if the CMOS data contains errors and the boot procedure can be continued by pressing the <F1> key. To prevent the error message from appearing at each restart, open the BIOS setup by pressing the <Del> key and re-save the settings.

BIOS reads the system configuration information in CMOS RAM, checks the system, and configures it using the Power On Self Test (POST).

When these "preliminaries" are finished, BIOS seeks an operating system in the data storage devices available (hard drive, floppy drive, etc.). BIOS launches the operating system and hands over control of system operations to it.

To enter BIOS Setup, the DEL key must be pressed after the USB controller has been initialized as soon as the following message appears on the monitor (during POST):

"Press DEL to run SETUP"



Figure 123: Boot screen

1.2.1 BIOS setup keys

The following keys are enabled during the POST:

Information:

The key signals from the USB keyboard are only registered after the USB controller has been initialized.

Key	Function
Del	Enters the BIOS setup menu.
F12	Using the F12 key, you can boot from the network.

Table 135: 945GME - Bios-relevant keys at POST

Key	Function
F11	Cues the boot menu. Lists all bootable devices that are connected to the system. With cursor ↑ and cursor ↓ and by pressing <ENTER>, select the device from which will be booted. 
<Break>	Pressing the <pause> key stops the POST. Press any other key to resume the POST.

Table 135: 945GME - Bios-relevant keys at POST

The following keys can be used after entering the BIOS setup:

Key	Function
F1	General help.
Cursor ↑	Moves to the previous item.
Cursor ↓	Go to the next item.
Cursor ←	Moves to the previous item.
Cursor →	Go to the next item.
+ -	Changes the setting of the selected function.
Enter	Changes to the selected menu.
PageUp ↑	Change to the previous page.
PageDown ↓	Change to the previous page.
Pos 1	Jumps to the first BIOS menu item or object.
End	Jumps to the last BIOS menu item or object.
F2 / F3	The colors of the BIOS Setup are switched.
F7	Changes are reset.
F9	These settings are loaded for all BIOS configurations.
F10	Save and close.
Esc	Exits the submenu.

Table 136: 945GME - Bios-relevant keys in the BIOS menu

1.3 Main

Immediately after the DEL button is pressed during startup, the main BIOS setup menu appears.



Figure 124: 945GME - BIOS Main Menu

BIOS setting	Meaning	Setting options	Effect
System Time	This is the current system time setting. The time is buffered by a battery (CMOS battery) after the system has been switched off.	Changes the System time	Set the system time in the format Hour:Minute:Second (hh:mm:ss).
System Date	This is the current system date setting. The time is buffered by a battery (CMOS battery) after the system has been switched off.	Changes the system date	Sets the system date in the format Month:Day:Year (mm:dd:yyyy).
BIOS ID	Displays the BIOS recognition.	None	-
Processor	Displays the processor type.	None	-
CPU Frequency	Displays the processor frequency.	None	-
System Memory	Displays the system memory size.	None	-
Product Revision	Displays the CPU board HW revision.	None	-
Serial Number	Displays the CPU board serial number.	None	-
BC Firmware Rev.	Displays the CPU board controller firmware revision.	None	-
MAC Address (ETH1)	Displays the MAC addresses assigned for the ETH1 interface.	None	-

Table 137: 945GME - Main Menu - Setting options

BIOS setting	Meaning	Setting options	Effect
Boot Counter	Displays the boot counter - each restart increments the counter by one (max. 16777215).	None	-
Running Time	Displays the runtime in whole hours. (max. 65535).	None	-

Table 137: 945GME - Main Menu - Setting options (Forts.)

1.4 Advanced



Figure 125: 945GME - Advanced Menu

BIOS setting	Meaning	Setting options	Effect
ACPI configuration	Configures the APCI devices.	Enter	Opens the submenu See "ACPI configuration", on page 249.
PCI Configuration	Configures PCI devices.	Enter	Opens the submenu See "PCI Configuration", on page 251.
PCI express configuration	Configures the PCI Express.	Enter	Opens the submenu See "PCI express configuration", on page 255.
Graphics configuration	Configures the graphics settings.	Enter	Opens the submenu See "Graphics configuration", on page 257.
CPU configuration	Configures the CPU settings.	Enter	Opens the submenu See "CPU configuration", on page 261.

Table 138: 945GME - Advanced Menu - Setting options

BIOS setting	Meaning	Setting options	Effect
Chipset configuration	Configures the chipset functions.	Enter	Opens the submenu See "Chipset configuration", on page 262.
I/O interface configuration	Configures the I/O devices.	Enter	Opens the submenu See "I/O interface configuration", on page 264.
Clock Configuration	Configures the clock settings.	Enter	Opens the submenu See "Clock Configuration", on page 265.
IDE Configuration	Configures the IDE functions.	Enter	Opens the submenu See "IDE Configuration", on page 266.
USB configuration	Configures the USB settings.	Enter	Opens the submenu See "USB configuration", on page 274.
Keyboard/mouse configuration	Configures the keyboard/mouse options.	Enter	Opens the submenu See "Keyboard/mouse configuration", on page 276.
Remote access configuration	Configures the remote access settings.	Enter	Opens the submenu See "Remote access configuration", on page 277.
CPU board monitor	Displays the current voltages and temperature of the processor in use.	Enter	Opens the submenu See "CPU board monitor", on page 279.
Main Board/Panel Features	Displays device specific information and setup of device specific values.	Enter	Opens the submenu See "Main Board/Panel Features", on page 280.

Table 138: 945GME - Advanced Menu - Setting options (Forts.)

1.4.1 ACPI configuration



Figure 126: 945GME - Advanced ACPI configuration

BIOS setting	Meaning	Setting options	Effect
ACPI Aware O/S	This function determines if the operating system supports the ACPI function (Advanced Configuration and Power Interface).	Yes	The operating system supports ACPI.
		No	The operating system does not support ACPI.
ACPI Version Features	Option for setting the power option specifications to be supported. The ACPI functions must be supported by the drivers and operating systems being used.	ACPI v1.0	ACPI functions in accordance with v1.0
		ACPI v2.0	ACPI functions in accordance with v2.0
		ACPI v3.0	ACPI functions in accordance with v3.0
ACPI APIC support	This option controls the support of the advanced programmable controller in the processor.	Enabled	Enables this function.
		Disabled	Disables the function
Suspend mode	Selects the ACPI status to be used when Suspend Mode is enabled.	S1 (POS)	Sets S1 as Suspend mode. Only a few functions are disabled and are available again at the touch of a button
		S3 (STR)	Sets S3 as Suspend Mode. The current state of the operating system is written to the RAM, which is then supplied solely with power.
USB Device Wakeup from S3/S4	This options makes it possible for activity on a connected USB device to wake the system up from the S3/S4 standby mode.	Enabled	Enables this function.
		Disabled	Disables the function

Table 139: 945GME - Advanced ACPI configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
Active Cooling Trip Point	With this function, an optional CPU fan above the operating system can be set to turn on when the CPU reaches the set temperature.	Disabled	Disables this function.
		50°C, 60°C, 70°C, 80°C, 90°C	Temperature setting for the active cooling trip point. Can be set in 10 degree increments.
Passive Cooling Trip Point	With this function, a temperature can be set at which the CPU automatically reduces its speed.	Disabled	Disables this function.
		50°C, 60°C, 70°C, 80°C, 90°C	Temperature setting for the passive cooling trip point. Can be set in 10 degree increments.
Critical Trip Point	With this function, a temperature can be set at which the operating system automatically shuts itself down.	80°C, 85°C, 90°C, 95°C, 100°C, 105°C, 110°C	Temperature setting for the critical trip point. Can be set in 5 degree increments.

Table 139: 945GME - Advanced ACPI configuration - Setting options (Forts.)

1.4.2 PCI Configuration



Figure 127: 945GME - Advanced PCI Configuration

BIOS setting	Meaning	Setting options	Effect
Plug & Play O/S	BIOS is informed if Plug & Play is capable on the operating system.	Yes	The operating system handles the distribution of resources.
		No	BIOS handles the distribution of resources.
PCI Latency Timer	This option controls how long (in PCI ticks) one PCI bus card can continue to use the master after another PCI card has requested access.	32, 64, 96, 128, 160, 192, 224, 248	Manually sets the value in PCI ticks.
Allocate IRQ to PCI VGA	This function is used to determine if an interrupt is assigned to the PCI VGA.	Yes	Automatic assignment of an interrupt.
		No	No assignment of an interrupt.
Allocate IRQ to SMBUS HC	Use this function to set whether or not the SM (System Management) bus controller is assigned a PCI interrupt.	Yes	Automatic assignment of a PCI interrupt.
		No	No assignment of an interrupt.
Allocate IRQ to PCIEX2	Use this function to set whether or not the PCIEX2 is assigned a PCI interrupt.	Yes	Automatic assignment of a PCI interrupt.
		No	No assignment of an interrupt.
PCI IRQ Resource Exclusion	Configures the PCI IRQ resource settings for ISA Legacy devices.	Enter	Opens the submenu See "PCI IRQ Resource Exclusion", on page 252
PCI Interrupt Routing	Configures PCI interrupt routing	Enter	Opens the submenu See "PCI Interrupt Routing", on page 253

Table 140: 945GME - Advanced PCI configuration - Setting options

PCI IRQ Resource Exclusion



Figure 128: 945GME - Advanced PCI IRQ Resource Exclusion

BIOS setting	Meaning	Setting options	Effect
IRQx	IRQ interrupt routing for Legacy ISA devices.	Allocated	Allocated by the system - cannot be used.
		Available	Available - can be used.
		Reserved	Reserved - cannot be used.

Table 141: 945GME - Advanced PCI IRQ Resource Exclusion - Setting options

PCI Interrupt Routing



Figure 129: 945GME - Advanced PCI Interrupt Routing

BIOS setting	Meaning	Setting options	Effect
PIRQ A (VGA,PCIEX0, ETH2,UHCI2)	Option for setting the PIRQ A.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment
PIRQ B (AC97,PCIEX1, ETH1)	Option for setting the PIRQ B.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.
PIRQ C (PCIEX2)	Option for setting the PIRQ C.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.
PIRQ D (SATA,UHCI1,SMB, PCIEX3)	Option for setting the PIRQ D.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.
PIRQ E (INTD,UHCI3,PATA)	Option for setting the PIRQ E.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.

Table 142: 945GME - Advanced PCI Interrupt Routing - Setting options

BIOS setting	Meaning	Setting options	Effect
PIRQ F (INTA)	Option for setting the PIRQ F.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.
PIRQ G (INTB)	Option for setting the PIRQ G.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.
PIRQ H (INTC,UHCI0,EHCI)	Option for setting the PIRQ H.	Auto	Automatic assignment by the BIOS and operating system.
		5,6,7,9,10,11,12	Manual assignment.
1st Exclusive PCI	With this option you can determine if the IRQ assigned to the PIRQ x is handled exclusively (no IRQ sharing). **Information:** **Is only displayed if a PIRQ is manually set (e.g. 5).**	None	No interrupt is assigned.
		x	Assigns the PIRQ as 1st exclusive PCI IRQ.
2nd Exclusive PCI	With this option you can determine if the IRQ assigned to the PIRQ x is handled exclusively (no IRQ sharing). **Information:** **Only displayed when two PIRQs are set manually.**	None	No interrupt is assigned.
		x	Assigns the PIRQ as 2nd exclusive PCI IRQ.

Table 142: 945GME - Advanced PCI Interrupt Routing - Setting options (Forts.)

1.4.3 PCI express configuration



Figure 130: 945GME - Advanced PCI Express Configuration

BIOS setting	Meaning	Setting options	Effect
Active State Power-Management	Option for setting a power saving function (L0s/L1) for PCIE slots if they do not require full power.	Disabled	Disables this function.
		Enabled	Enables this function.
PCIE Port 0	This option activates or deactivates the PCI Express connection function. **Information:** **If you are not using any PCI Express devices, this option should be deactivated.**	Auto	Automatic assignment by the BIOS and operating system.
		Enabled	Enables this function.
		Disabled	Disables this function.
PCIE Port 1	This option activates or deactivates the PCI Express connection function. **Information:** **If you are not using any PCI Express devices, this option should be deactivated.**	Auto	Automatic assignment by the BIOS and operating system.
		Enabled	Enables this function.
		Disabled	Disables this function.

Table 143: 945GME - Advanced PCI Express Configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
PCIE Port 2	This option activates or deactivates the PCI Express connection function. **Information:** **If you are not using any PCI Express devices, this option should be deactivated.**	Auto	Automatic assignment by the BIOS and operating system.
		Enabled	Enables this function.
		Disabled	Disables this function.
PCIE Port 3	This option activates or deactivates the PCI Express connection function. **Information:** **If you are not using any PCI Express devices, this option should be deactivated.**	Auto	Automatic assignment by the BIOS and operating system.
		Enabled	Enables this function.
		Disabled	Disables this function.
PCIE Port 4 (ETH2)	This option activates or deactivates the PCI Express connection function. **Information:** **If you are not using any PCI Express devices, this option should be deactivated.**	Auto	Automatic assignment by the BIOS and operating system.
		Enabled	Enables this function.
		Disabled	Disables this function.
PCIE Port 5 (ETH1)	This option activates or deactivates the PCI Express connection function. **Information:** **If you are not using any PCI Express devices, this option should be deactivated.**	Auto	Automatic assignment by the BIOS and operating system.
		Enabled	Enables this function.
		Disabled	Disables this function.
PCIE High Priority Port	This option activates or deactivates the priority port for PCIE.	Disabled	Disables this function.
		Port 0	Activates Port 0 as priority port.
		Port 1	Activates Port 1 as priority port.
		Port 2	Activates Port 2 as priority port.
		Port 3	Activates Port 3 as priority port.
		ETH2	Activates ETH2 as priority port.
		ETH1	Activates ETH1 as priority port.
Res. PCIE Hotplug Resource	This option can be used to reserve an I/O and memory resource for a free PCIE port. A PCIE port must be set to enabled and resources must be reserved to support ExpressCard hot-plugging on a port.	No	Resource is not reserved.
		Yes	Resource is reserved.
PCIE Port 0 IOxAPCI Enable	This option is used to enable or disable the APIC (Advanced Programmable Interrupt Controller) on the PCIE port 0. The IRQ resources available to the system are expanded when the APIC mode is enabled.	Disabled	Disables this function.
		Enabled	Enables this function.

Table 143: 945GME - Advanced PCI Express Configuration - Setting options (Forts.)

BIOS setting	Meaning	Setting options	Effect
PCIE Port 1 IOxAPCI Enable	This option is used to enable or disable the APIC (Advanced Programmable Interrupt Controller) on the PCIE port 1. The IRQ resources available to the system are expanded when the APIC mode is enabled.	Disabled	Disables this function.
		Enabled	Enables this function.
PCIE Port 2 IOxAPCI Enable	This option is used to enable or disable the APIC (Advanced Programmable Interrupt Controller) on the PCIE port 2. The IRQ resources available to the system are expanded when the APIC mode is enabled.	Disabled	Disables this function.
		Enabled	Enables this function.
PCIE Port 3 IOxAPCI Enable	This option is used to enable or disable the APIC (Advanced Programmable Interrupt Controller) on the PCIE port 3. The IRQ resources available to the system are expanded when the APIC mode is enabled.	Disabled	Disables this function.
		Enabled	Enables this function.

Table 143: 945GME - Advanced PCI Express Configuration - Setting options (Forts.)

1.4.4 Graphics configuration



Figure 131: 945GME - Advanced Graphics Configuration

BIOS setting	Meaning	Setting options	Effect
Primary Video Device	Option for selecting the primary video device.	Internal VGA	The internal graphics chip on the CPU board is used as video device (monitor / panel connection).
		PCI / Int. VGA	The graphics chip of a connected graphics card is used as video device.
Internal Graphics Mode Select	Option for setting the memory size that can be used for the internal graphics controller.	Disabled	No reservation - Disables the graphics controller.
		Enabled, 1MB	1MB main memory provided.
		Enabled, 8MB	8MB main memory provided.
DVMT Mode Select	Option for determining the DVMT mode (Dynamic Video Memory Technology) of the DVMT graphics driver.	Fixed Mode	A fixed amount of memory is allocated to the graphics chip, which is no longer available to the PC.
		DVMT Mode	Memory consumption is controlled dynamically by the DVMT graphics driver. Only the amount of memory that is required is used.
		Combo Mode	The DVMT graphics driver reserves at least 64MB, but can use up to 224MB if necessary.
DVMT/FIXED Memory	Option for setting the amount of memory used for the DVMT mode.	64MB	64MB of main memory can be used.
		128MB	128MB of main memory can be used.
		Maximum DVMT	The remaining available main memory can be used.
Boot Display Device	Determines which video channel should be enabled for a video device during the boot procedure.	Auto	Automatic selection.
		CRT only	Only use the CRT (Cathode Ray Tube) channel.
		SDVO only	Only use the SDVO (Serial Digital Video Out) channel.
		CRT + SDVO	Use CRT and SDVO channel.
		LFP only	Only use the LFP (Local Flat Panel) channel.
		CRT + LFP	Use CRT + LFP channel.
Boot Display Preference	This option determines the order in which the devices on the connected channels LFP and SDVO should be checked and booted. **Information:** **The setting is only needed when the Boot Display Device option is set to "Auto".**	LFP SDVO-B SDVO-C	Local Flat Panel - Serial Digital Video B output - Serial Video C output.
		LFP SDVO-C SDVO-B	Local Flat Panel - Serial Digital Video C output - Serial Video B output.
		SDVO-B SDVO-C LFP	Serial Digital Video B output - Serial Digital Video C output - Local Flat Panel.
		SDVO-C SDVO-B LFP	Serial Digital Video C output - Serial Digital Video B output - Local Flat Panel.

Table 144: 945GME - Advanced Graphics Configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
Local Flat Panel Type	This option can be used to set a pre-defined profile for the LVDS channel.	Auto	Automatic detection and setting using the EDID data.
		VGA 1x18 (002h)	640 x 480
		VGA 1x18 (013h)	640 x 480
		SVGA 1x18 (004h)	800 x 600
		XGA 1x18 (006h)	1024 x 768
		XGA 2x18 (007h)	1024 x 768
		XGA 1x24 (008h)	1024 x 768
		XGA 2x24 (012h)	1024 x 768
		SXGA 2x24 (00Ah)	1280 x 1024
		SXGA 2x24 (018h)	1280 x 1024
		UXGA 2x24 (00Ch)	1600 x 1200
		Customized EDID 1	User-defined profile
		Customized EDID 2	User-defined profile
		Customized EDID 3	User-defined profile
Local flat panel scaling	Determines the screen content should be output according to the defined Local Flat Panel Type.	Centering	The screen content is output centered on the display.
		Expand Text	The text is stretched across the entire surface of the display.
		Expand Graphics	The graphics are stretched across the entire surface of the display.
		Expand Text & Graphics	Text and graphics are stretched across the entire surface of the display.
SDVO Port B Device	Option for selecting the video device that is connected to the SDVO Port B.	None	No video device connected.
		DVI	Video signal output is optimized for a DVI-compatible video device.
		TV	Video signal output is optimized for a TV-compatible video device.
		CRT	Video signal output is optimized for a CRT-compatible video device.
		LVDS	Video signal output is optimized for a LVDS-compatible video device.
		DVI-Analog	Video signal output is optimized for an analog DVI-compatible video device.

Table 144: 945GME - Advanced Graphics Configuration - Setting options (Forts.)

BIOS setting	Meaning	Setting options	Effect
SDVO Port C Device	Option for selecting the video device that is connected to the SDVO Port A.	None	No video device connected.
		DVI	Video signal output is optimized for a DVI-compatible video device.
		TV	Video signal output is optimized for a TV-compatible video device.
		CRT	Video signal output is optimized for a CRT-compatible video device.
		LVDS	Video signal output is optimized for a LVDS-compatible video device.
		DVI-Analog	Video signal output is optimized for an analog DVI-compatible video device.
SDVO/DVI Hotplug Support	If this option is set to enabled, the Windows XP graphics driver supports "hotplug" and "configuration mode persistence" for DVI monitors connected to a DVI SDVO transmitter. "Hotplug" support means that when a DVI monitor is connected while the operating system is running, it is detected automatically and activated. "Configuration mode persistence" means that, for example, a dual DVI configuration is automatically restored when both DVI monitors are reconnected, even if only one of them was connected and activated during a previous boot.	Enabled	"Hotplug" and "Configuration mode persistence" mode enabled.
		Disabled	"Hotplug" and "Configuration mode persistence" mode disabled.
Display Mode Persistence	"Display mode persistence" means that the operating system can remember and restore the previous display configuration. For example, a dual DVI configuration is automatically restored when both DVI monitors are reconnected, even if only one of them was connected and activated during a previous boot.	Enabled	Enables this function.
		Disabled	Disables this function.

Table 144: 945GME - Advanced Graphics Configuration - Setting options (Forts.)

1.4.5 CPU configuration



Figure 132: 945GME - Advanced CPU Configuration

BIOS setting	Meaning	Setting options	Effect
MPS Revision	This option supports the use of multiple CPUs (MPS=multi-processor system).	1.1	Sets MPS support Revision 1.1
		1.4	Sets MPS support Revision 1.4
Max CPUID value limit	Option for limiting the CPUID input value. This could be necessary for older operating systems.	Enabled	The processor limits the maximum CPUID input value to 03h if necessary when the the processor supports a higher value.
		Disabled	The processor returns the current maximum value upon request of the CPUID input value.
Execute Disable Bit	Option for enabling or disabling hardware support for prevention of data execution.	Enabled	Enables this function.
		Disabled	Disables this function.
Core Multi-Processing	When using a Dual Core processor, this option can be used to disable a core.	Enabled	Both cores are used in a Dual Core processor.
		Disabled	Only one core is used in a Dual Core processor.
Intel(R) Speedster(TM) tech.	Option for controlling the Intel(R) SpeedStep(TM) technology. The processor clock speed is increased or decreased according to the amount of calculations that must be made. As a result, the power consumption depends largely on the processor load.	Automatic	The processor speed is regulated by the operating system.
		Maximum speed	The processor speed is set to a maximum.
		Minimum speed	The processor speed is set to a minimum.
		Disabled	Disables SpeedStep technology.

Table 145: 945GME - Advanced CPU Configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
Max. CPU frequency	Option for setting the maximum processor speed if the value "Automatic" or "Maximum Speed" is set for the option "Intel(R) SpeedStep(TM) tech.".	xxxx MHz	The processor speed is limited to the set value.
C1 Config	Power Management for Intel Core Duo processor.	Default	Standard C1 support.
		Enhanced	Enhanced C1 support.
C2 Config	Power Management for Intel Core Duo processor.	Default	Standard C2 support.
		Enhanced	Enhanced C2 support.
		Disabled	Disabled C2 support.
C3 Config	Power Management for Intel Core Duo processor.	Default	Standard C3 support.
		Enhanced	Enhanced C3 support.
		Disabled	Disabled C3 support.
C4 Config	Power Management for Intel Core Duo processor.	Default	Standard C4 support.
		Enhanced	Enhanced C4 support.
		Disabled	Disabled C4 support.

Table 145: 945GME - Advanced CPU Configuration - Setting options (Forts.)

1.4.6 Chipset configuration



Figure 133: 945GME Advanced Chipset Configuration

BIOS setting	Meaning	Setting options	Effect
DRAM Frequency	Option for setting the RAM frequency.	Auto	Frequency set automatically by the BIOS.
		400, 533, 667 MHz	Desired clock frequency set manually.
DRAM Refresh Rate	Option for setting the DRAM refresh rate.	Auto	DRAM Refresh is read from the SPD data of the DRAM module.
		7.8 µs	Manual setting for the DRAM refresh rate.
		3.9 µs	Manual setting for the DRAM refresh rate.
Memory Hole	Option for ISA cards with frame buffer. Not relevant for a APC810.	Disabled	Disables this function.
		15MB-16MB	This address area is reserved.
DIMM Thermal Control	Option for setting the maximum surface temperature of the DIMM module. The module is cooled by limiting the memory bandwidth if the defined surface temperature is reached.	Disabled	Surface temperature not limited.
		40°C, 50°C, 60°C, 70°C, 80°C, 85°C, 90°C	Temperature limit value for the limitation.
DT in SPD	Option to determine whether the GMCH (Graphics and Memory Controller Hub) supports DT (Delta Temperature) in the SPD (Serial Presence Detect) Management Algorithm of the DIMM module.	Disabled	Disables this function.
		Enabled	Enables this function.
TS on DIMM	Option to determine whether the GMCH (Graphics and Memory Controller Hub) supports TS (Thermal Sensor) in the Thermal Management Algorithm of the DIMM module.	Disabled	Disables this function.
		Enabled	Enables this function.
High Precision Event Timer	The HPET is a timer inside the PC. It is able to trigger an interrupt with a high degree of accuracy, which allows other programs to better synchronize a variety of applications.	Disabled	Disables this function.
		Enabled	Enables this function. This function is recommended for multimedia applications.
IOAPIC	This option is used to activate or deactivate the APIC (Advanced Programmable Interrupt Controller). **Information:** **The IRQ resources available to the system are expanded when the APIC mode is enabled.**	Disabled	Disables this function.
		Enabled	The IRQ resources available to the system are expanded when the APIC mode is enabled.
APIC ACPI SCI IRQ	This option is used to modify the SCI IRQ when in APIC (Advanced Programmable Interrupt Controller) mode.	Disabled	IRQ9 is used for SCI.
		Enabled	IRQ20 is used for SCI.
C4 On C3	Fine-tunes the power saving function on an ACPI operating system.	Disabled	Disables this function.
		Enabled	Processor is needed in C4 if the operating system is initiated in a C3 state.

Table 146: 945GME Advanced Chipset setting options

1.4.7 I/O interface configuration



Figure 134: 945GME Advanced I/O Interface Configuration

BIOS setting	Meaning	Setting options	Effect
Onboard Audio Controller	The audio mode can be selected or switched off here.	HDA	Enables High Definition Audio sound.
		AC97	Enables AC'97 sound.
		Disabled	Disables the audio controller.

Table 147: 945GME Advanced I/O Interface Configuration setting options

1.4.8 Clock Configuration



Figure 135: 945GME Advanced Clock Configuration

BIOS setting	Meaning	Setting options	Effect
Spread spectrum	With this option, the cycle frequency can be modulated by reducing electromagnetic disturbances.	Enabled	Enables this function.
		Disabled	Disables this function.

Table 148: 945GME Advanced Clock Configuration setting options

1.4.9 IDE Configuration



Figure 136: 945GME Advanced IDE Configuration

BIOS setting	Meaning	Setting options	Effect
ATA/IDE Configuration	Option for configuring the integrated PATA and SATA controller.	Compatible	Both controllers run in Legacy or Compatible Mode.
		Disabled	Both controllers disabled.
		Enhanced	Both controllers run in Enhanced or Native Mode.
Legacy IDE Channels[1)]	Option for configuring the Legacy IDE channels in Compatible Mode.	SATA Pri, PATA Sec	SATA drives are address primarily and PATA drive secondarily.
		SATA only	Only use SATA drives.
		PATA only	Only use PATA drives.
Configure SATA as[2)]	The Serial ATA connections supported by the Southbridge can be defined here.	IDE	The serial ATA hard drive is used as a parallel ATA physical memory drive.
		RAID	RAID 0, 1, 5, 10 or the Intel® Matrix storage technology can be configured here with the serial ATA hard drive.
		AHCI	The AHCI setting enables the internal memory driver for the SATA functions, which increase the storage performance for random read-write access by allowing the drive to determine the sequence of commands.

Table 149: 945GME Advanced IDE Configuration setting options

BIOS setting	Meaning	Setting options	Effect
Configure SATA as Channels [3]	You can define a SATA or PATA drive as Primary or Secondary Device.	Before PATA	The SATA drives are the Primary Devices, meaning PATA are Secondary.
		Behind PATA	The PATA drives are the Primary Devices, meaning SATA are Secondary.
AHCI/RAID SATA hot plug [4]	Hot plug support for AHCI/RAID systems can be set here.	Disabled	Enables hot plug support.
		Enabled	Disables hot plug support.
Primary IDE Master	The drive in the system that is connected to the IDE primary master port is configured here.	Enter	Opens the submenu See "Primary IDE Master", on page 268
Primary IDE slave	The drive in the system that is connected to the IDE primary slave port is configured here.	Enter	Opens the submenu See "Primary IDE slave", on page 270
Secondary IDE Master	The drive in the system that is connected to the IDE secondary master port is configured here.	Enter	Opens the submenu See "Secondary IDE Master", on page 271
Secondary IDE Slave	The drive in the system that is connected to the IDE secondary slave port is configured here.	Enter	Opens the submenu See "Secondary IDE slave", on page 273
Hard disk write protect	Write protection for the hard drive can be enabled/disabled here.	Disabled	Disables this function.
		Enabled	Enables this function.
IDE Detect Time Out (Sec)	Configuring the time overrun limit value for the ATA/ATAPI device identification.	0, 5, 10, 15, 20, 25, 30, 35	Time setting in seconds.
ATA(PI) 80Pin Cable Detection	Detects whether an 80 pin cable is connected to the drive, the controller or to both. **Information:** **This option is not available on the APC810 CPU board. Therefore this setting is not relevant.**	Host & device	Using both IDE controllers (motherboard, disk drive).
		Host	IDE controller motherboard used.
		Device	IDE disk drive controller used.

Table 149: 945GME Advanced IDE Configuration setting options

1) These settings are only possible if *ATA/IDE Configuration* is set to *Compatible*.

2) These settings are only possible if *ATA/IDE Configuration* is set to *Enhanced*.

3) These settings are only possible if *ATA/IDE Configuration* is set to *Enhanced* and *Configure SATA as* to *IDE*.

4) These settings are only possible if *ATA/IDE Configuration* is set to *Enhanced* and *Configure SATA as* to *RAID* or *AHCI*.

Primary IDE Master



Figure 137: 945GME - Primary IDE Master

BIOS setting	Meaning	Setting options	Effect
Type	The type of drive connected to the primary master is configured here.	Not installed	No drive installed.
		Auto	Automatic recognition of the drive and setup of appropriate values.
		CD/DVD	CD -/ DVD drive.
		ARMD	ARMD - drive (zip drive)
LBA/Large Mode	This option activates the logical block addressing / large mode for IDE.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.
Block (Multi-Sector Transfer)	This option enables the block mode for IDE hard drives. When this option is enabled, the number of blocks per request from the configuration sector of the hard drive is read.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.

Table 150: 945GME - Primary IDE Master - Setting options

BIOS setting	Meaning	Setting options	Effect
PIO Mode	The PIO mode determines the data rate of the hard drive. **Information:** **This option is not available on the APC810. Therefore this setting is not relevant.**	Auto	Automatic configuration of PIO mode.
		0, 1, 2, 3, 4	Manual configuration of PIO mode.
DMA Mode	The data transfer rate to and from the primary master drive is defined here. The DMA mode must be activated in the Windows device manager in order to guarantee maximum performance. Only possible when manually setting up the drive.	Auto	Automatic definition of the transfer rate.
		Disabled	Manual definition of the transfer rate.
S.M.A.R.T.	Monitoring function of modern hard drives (self-monitoring, analysis and reporting technology).	Auto	Automatic detection and enabling.
		Disabled	Disables this function.
		Enabled	Enables this function.
32 Bit Data Transfer	This function enables 32-bit data transfer.	Disabled	Disables this function.
		Enabled	Enables this function.

Table 150: 945GME - Primary IDE Master - Setting options (Forts.)

Primary IDE slave



Figure 138: 945GME - Primary IDE Slave

BIOS setting	Meaning	Setting options	Effect
Type	The type of drive connected to the primary master is configured here.	Not installed	No drive installed.
		Auto	Automatic recognition of the drive and setup of appropriate values.
		CD/DVD	CD -/ DVD drive.
		ARMD	ARMD - drive (zip drive)
LBA/Large Mode	This option activates the logical block addressing / large mode for IDE.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.
Block (Multi-Sector Transfer)	This option enables the block mode for IDE hard drives. When this option is enabled, the number of blocks per request from the configuration sector of the hard drive is read.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.

Table 151: 945GME - Primary IDE Slave - Setting options

BIOS setting	Meaning	Setting options	Effect
PIO Mode	The PIO mode determines the data rate of the hard drive. **Information:** **This option is not available on the APC810. Therefore this setting is not relevant.**	Auto	Automatic configuration of PIO mode.
		0, 1, 2, 3, 4	Manual configuration of PIO mode.
DMA Mode	The data transfer rate to and from the primary master drive is defined here. The DMA mode must be activated in the Windows device manager in order to guarantee maximum performance. Only possible when manually setting up the drive.	Auto	Automatic definition of the transfer rate.
		Disabled	Manual definition of the transfer rate.
S.M.A.R.T.	Monitoring function of modern hard drives (self-monitoring, analysis and reporting technology).	Auto	Automatic detection and enabling.
		Disabled	Disables this function.
		Enabled	Enables this function.
32 Bit Data Transfer	This function enables 32-bit data transfer.	Disabled	Disables this function.
		Enabled	Enables this function.

Table 151: 945GME - Primary IDE Slave - Setting options (Forts.)

Secondary IDE Master



Figure 139: 945GME - Secondary IDE Master

BIOS setting	Meaning	Setting options	Effect
Type	The type of drive connected to the primary master is configured here.	Not installed	No drive installed.
		Auto	Automatic recognition of the drive and setup of appropriate values.
		CD/DVD	CD -/ DVD drive.
		ARMD	ARMD - drive (zip drive)
LBA/Large Mode	This option activates the logical block addressing / large mode for IDE.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.
Block (Multi-Sector Transfer)	This option enables the block mode for IDE hard drives. When this option is enabled, the number of blocks per request from the configuration sector of the hard drive is read.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.
PIO Mode	The PIO mode determines the data rate of the hard drive. **Information:** **This option is not available on the APC810. Therefore this setting is not relevant.**	Auto	Automatic configuration of PIO mode.
		0, 1, 2, 3, 4	Manual configuration of PIO mode.
DMA Mode	The data transfer rate to and from the primary master drive is defined here. The DMA mode must be activated in the Windows device manager in order to guarantee maximum performance. Only possible when manually setting up the drive.	Auto	Automatic definition of the transfer rate.
		Disabled	Manual definition of the transfer rate.
S.M.A.R.T.	Monitoring function of modern hard drives (self-monitoring, analysis and reporting technology).	Auto	Automatic detection and enabling.
		Disabled	Disables this function.
		Enabled	Enables this function.
32 Bit Data Transfer	This function enables 32-bit data transfer.	Disabled	Disables this function.
		Enabled	Enables this function.

Table 152: 945GME - Secondary IDE Master - Setting options

Secondary IDE slave



Figure 140: 945GME - Secondary IDE Slave

BIOS setting	Meaning	Setting options	Effect
Type	The type of drive connected to the primary master is configured here.	Not installed	No drive installed.
		Auto	Automatic recognition of the drive and setup of appropriate values.
		CD/DVD	CD -/ DVD drive.
		ARMD	ARMD - drive (zip drive)
LBA/Large Mode	This option activates the logical block addressing / large mode for IDE.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.
Block (Multi-Sector Transfer)	This option enables the block mode for IDE hard drives. When this option is enabled, the number of blocks per request from the configuration sector of the hard drive is read.	Disabled	Disables this function.
		Auto	Automatic enabling of this function when supported by the system.

Table 153: 945GME - Secondary IDE Slave - Setting options

BIOS setting	Meaning	Setting options	Effect
PIO Mode	The PIO mode determines the data rate of the hard drive. **Information:** **This option is not available on the APC810. Therefore this setting is not relevant.**	Auto	Automatic configuration of PIO mode.
		0, 1, 2, 3, 4	Manual configuration of PIO mode.
DMA Mode	The data transfer rate to and from the primary master drive is defined here. The DMA mode must be activated in the Windows device manager in order to guarantee maximum performance. Only possible when manually setting up the drive.	Auto	Automatic definition of the transfer rate.
		Disabled	Manual definition of the transfer rate.
S.M.A.R.T.	Monitoring function of modern hard drives (self-monitoring, analysis and reporting technology).	Auto	Automatic detection and enabling.
		Disabled	Disables this function.
		Enabled	Enables this function.
32 Bit Data Transfer	This function enables 32-bit data transfer.	Disabled	Disables this function.
		Enabled	Enables this function.

Table 153: 945GME - Secondary IDE Slave - Setting options (Forts.)

1.4.10 USB configuration



Figure 141: 945GME - Advanced USB Configuration

BIOS setting	Meaning	Setting options	Effect
USB Function	USB ports can be enabled/disabled here. The USB numbers (e.g. USB1, USB3, etc.) are printed on the APC810 housing.	Disabled	Disables the USB port.
		2 USB Ports	USB1, USB3 are enabled.
		4 USB Ports	USB1, USB2, USB3, USB4 are enabled.
		6 USB Ports	USB1, USB2, USB3, USB4, USB5 are enabled.
		8 USB Ports	USB1, USB2, USB3, USB4, USB5, USB are enabled on an AP via SDL.
USB 2.0 Controller	Option for enabling or disabling USB 2.0 mode.	Enabled	All USB ports run in USB 2.0 mode.
		Disabled	All USB ports run in USB 1.1 mode.
Legacy USB Support	Legacy USB support can be enabled/disabled here. USB ports do not function during startup. USB is supported again after the operating system has started. A USB keyboard is still recognized during the POST.	Disabled	Disables this function.
		Enabled	Enables this function.
		Auto	Automatic enabling.
USB Legacy POST-Always	Option to enable Legacy USB Support during the POST (Power On Self Test) the same as the Legacy USB Support setting.	Enabled	The BIOS Setup can be called up during the POST using a USB keyboard.
		Disabled	Disables this function.
USB Keyboard Legacy Support	USB keyboard support can be enabled/disabled here.	Disabled	Disables this function.
		Enabled	Enables this function.
USB Mouse Legacy Support	USB mouse support can be enabled/disabled here.	Disabled	Disables this function.
		Enabled	Enables this function.
USB Storage Device Support	USB storage device support can be enabled/disabled here.	Disabled	Disables this function.
		Enabled	Enables this function.
Port 64/60 Emulation	Port 64/60 emulation can be enabled/disabled here.	Disabled	USB keyboard functions in all systems excluding Windows NT.
		Enabled	USB keyboard functions in Windows NT.
USB 2.0 Controller Mode	Settings can be made for the USB controller.	Full Speed	12 MBps
		Hi Speed	480 MBps
BIOS EHCI Hand-Off	The support for the operating system can be set up without the fully automatic EHCI function.	Disabled	Disables the function
		Enabled	Enables this function.
USB Beep Message	Option for outputting a tone each time a USB device is detected by the BIOS during the POST.	Disabled	Disables this function.
		Enabled	Enables this function.
USB Stick Default Emulation	You can set how the USB device is to be used.	Auto	USB devices with fewer than 530MB of memory are simulated as floppy disk drives and devices with larger capacities are simulated as hard drives.
		Hard disk	An HDD-formatted drive can be used as an FDD (e.g. zip drive) for starting the system.

Table 154: 945GME - Advanced USB Configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
USB Mass Storage Reset Delay	The waiting time that the USB device POST requires after the device start command can be set. **Information:** **The message "No USB mass storage device detected" is displayed if no USB memory device has been installed.**	10 Sec, 20 Sec, 30 Sec, 40 Sec	Value set manually.

Table 154: 945GME - Advanced USB Configuration - Setting options (Forts.)

1.4.11 Keyboard/mouse configuration



Figure 142: 945GME Advanced Keyboard/Mouse Configuration

BIOS setting	Meaning	Setting options	Effect
Bootup Num-lock	With this field you can define the state of the NumLock key when booting.	Off	Only the cursor functions of the numerical keypad are enabled.
		On	Numeric keypad is enabled.
Typematic rate	The key repeat function is set here.	Slow	Slow key repeat.
		Fast	Fast key repeat.

Table 155: 945GME Advanced Keyboard/Mouse Configuration setting options

1.4.12 Remote access configuration



Figure 143: 945GME - Advanced Remote Access Configuration

BIOS setting	Meaning	Setting options	Effect
Remote access	The remote access function can be enabled/disabled here.	Disabled	Disables this function.
		Enabled	Enables this function.
Serial port number	The serial interface can be set using this option, as long as disabled is not entered in the *remote access* field.	COM1	Enables the COM1 interface as remote access interface.
		COM2	Enables the COM2 interface as remote access interface.
Base address, IRQ	Serial connection display for the logical address and interrupt, as long as disabled is not entered in the *remote access* field.	None	-
Serial port mode	The serial interface transfer rate is defined here, as long as disabled is not entered in the *remote access* field.	115200 8,n,1 57600 8,n,1 38400 8,n,1 19200 8,n,1 09600 8,n,1	Value set manually.
Flow control	This setting determines how the transfer is controlled via the interface. **Information:** **The setting must be the same on the terminal and the server.**	None	The interface is operated without transfer control.
		Hardware	The interface transfer control is carried out through hardware. This mode must be supported by a cable.
		Software	The interface transfer control is carried out through software.

Table 156: 945GME - Advanced Remote Access Configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
Redirection after BIOS POST	The redirection after start up can be set here, as long as disabled is not entered in the *remote access* field.	Disabled	The redirection is switched off after start up.
		Boot loader	Redirection is enabled during system start up and charging.
		Always	Redirection is always enabled.
Terminal type	The type of connection can be chosen here, as long as disabled is not entered in the *remote access* field.	ANSI, VT100, VT-UTF8	Manual configuration of the connection type.
VT-UTF8 Combo Key Support	With this option, the VT-UTF8 Combo Key Support for the ANSI and VT100 connections can be enabled, as long as disabled is not entered in the *remote access* field.	Disabled	Disables this function.
		Enabled	Enables this function.
Sredir Memory Display Delay	The memory output delay can be set using this option, as long as disabled is not entered in the *remote access* field (Sredir -> serial redirection).	No delay	No delay.
		Delay 1 sec, Delay 2 sec, Delay 4 sec	Value set manually.
Serial port BIOS update	During system start up, the update is loaded via the serial interface in the processor. **Information:** **If this option is disabled, the boot time is reduced.**	Disabled	Disables this function.
		Enabled	Enables this function.

Table 156: 945GME - Advanced Remote Access Configuration - Setting options (Forts.)

1.4.13 CPU board monitor

Information:

The displayed voltage values (e.g. core voltage, battery voltage) on this BIOS Setup page represent uncalibrated information values. These cannot be used to draw any conclusions about any hardware alarms or error conditions. The hardware components used have automatic diagnostics functions that can be applied in the event of error.



Figure 144: 945GME Advanced CPU board monitor

BIOS setting	Meaning	Setting options	Effect
H/W Health Function	Option for displaying all values on this page.	Enabled	Displays all values.
		Disabled	No values are shown on this page.
Board temperature	Displays the board temperature in degrees Celsius and Fahrenheit.	None	-
CPU temperature	Displays the processor's temperature (in degrees Celsius and Fahrenheit).	None	-
Top DIMM Environment Temp.	Displays the temperature of the first DRAM module.	None	-

Table 157: 945GME - Advanced Remote Access Configuration - Setting options

BIOS setting	Meaning	Setting options	Effect
Bottom DIMM Environment Temp.	Displays the temperature of the second DRAM module.	None	-
CPU Fan Speed	Displays the rotating speed of the processor fan.	None	-
VcoreA	Displays the processor's core voltage A in volts.	None	-
+3.3VSB	Displays the current voltage of the 3.3 volt supply.	None	-
+5VSB	Displays the current voltage of the 5 volt supply.	None	-
+12Vin	Displays the current voltage of the 12 volt supply.	None	-
VRTC	Displays the battery voltage (in volts).	None	-

Table 157: 945GME - Advanced Remote Access Configuration - Setting options (Forts.)

1.4.14 Main Board/Panel Features



Figure 145: 945GME - Advanced Baseboard/Panel Features

BIOS setting	Meaning	Setting options	Effect
Panel control	For special setup of connected panels (display units).	Enter	Opens the submenu See "Panel control", on page 282
Baseboard monitor	Display of various temperatures and fan speeds.	Enter	Opens the submenu See "Baseboard monitor", on page 283
Legacy devices	Special settings for the interface can be changed here.	Enter	Opens the submenu See "Legacy devices", on page 284
BIOS	Displays the BIOS version.	None	-
MTCX PX32	Displays the MTCX PX32 firmware version.	None	-
MTCX FPGA	Displays the MTCX FPGA firmware version.	None	-
CMOS profile	Shows the CMOS profile number.	None	-
Device ID	Displays the hexadecimal value of the hardware device ID.	None	-
Compatibility ID	Displays the version of the device within the same B&R device code. This ID is needed for Automation Runtime.	None	-
Serial Number	Displays the B&R serial number.	None	-
Product name	Displays the B&R model number.	None	-
User serial ID	Displays the user serial ID. This 8 digit hex value can be freely assigned by the user (e.g. to give the device a unique ID) and can only be changed with using the "B&R Control Center" via the ADI driver.	None	-

Table 158: 945GME - Advanced Baseboard/Panel Features - Setting options

Panel control



Figure 146: 945GME - Panel Control

BIOS setting	Meaning	Setting options	Effect
Select panel number	Selection of the panel number for which the values should be read out and/or changed.	0...15	Selection of panel 0 ... 15. Panel 15 is specifically intended for panel PC 700 systems.
Version	Displays the firmware version of the SDLR controller.	None	-
Brightness	For setting the brightness of the selected panel.	0%, 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100%	For setting the brightness (in %) of the selected panel. Changes take effect after saving and restarting the system (e.g. by pressing <F10>).
Temperature	Displays the selected panel's temperature (in degrees Celsius and Fahrenheit).	None	-
Fan speed	Displays fan speed for the selected panel.	None	-
Keys/LEDs	Displays the available keys and LEDs on the selected panel.	None	-

Table 159: 945GME - Panel Control - Setting options

Baseboard monitor



Figure 147: 945GME Baseboard Monitor

BIOS setting	Meaning	Setting options	Effect
CMOS battery	Displays the battery status. **n.a.** - not available **Good** - Battery is OK **Bad** - Battery is damaged.	None	-
Board I/O	Displays the temperature in the I/O area in degrees Celsius and Fahrenheit.	None	-
Board ETH2	Displays the temperature in the ETH2 controller chip area in degrees Celsius and Fahrenheit.	None	-
Board Power	Displays the power supply temperature in degrees Celsius and Fahrenheit.	None	-
Power supply	Displays the temperature in the power supply in degrees Celsius and Fahrenheit.	None	
ETH2 Controller	Displays the temperature of the ETH2 controller in degrees Celsius and Fahrenheit.	None	
Slide-in drive 1	Displays the temperature of the slide-in drive 1 in degrees Celsius and Fahrenheit.	None	-
Slide-in drive 2	Displays the temperature of the slide-in drive 2 in degrees Celsius and Fahrenheit.	None	-

Table 160: 945GME Baseboard Monitor setting options

BIOS setting	Meaning	Setting options	Effect
Case 1	Displays the fan speed of housing fan 1.	None	-
Case 2	Displays the fan speed of housing fan 2.	None	-
Case 3	Displays the fan speed of housing fan 3.	None	-
Case 4	Displays the fan speed of housing fan 4.	None	-

Table 160: 945GME Baseboard Monitor setting options

Legacy devices



Figure 148: 945GME - Legacy Devices

BIOS setting	Meaning	Setting options	Effect
COM A	Settings for the **COM1** serial interface in the system.	Disabled	Disables the interface.
		Enabled	Enables the interface.
Base I/O address	Selection of the base I/O address for the COM port.	238, 2E8, 2F8, 328, 338, 3E8, 3F8	Selected base I/O address is assigned.
Interrupt	Selection of the interrupt for the COM port.	IRQ 3, IRQ 4, IRQ 5, IRQ 6, IRQ 7, IRQ 10, IRQ 11, IRQ 12	Selected interrupt is assigned.
COM B	Settings for the **COM2** serial interface in the system.	Disabled	Disables the interface.
		Enabled	Enables the interface.

Table 161: 945GME - Legacy Devices - Setting options

BIOS setting	Meaning	Setting options	Effect
Base I/O address	Selection of the base I/O address for the COM port.	238, 2E8, 2F8, 328, 338, 3E8, 3F8	Selected base I/O address is assigned.
Interrupt	Selection of the interrupt for the COM 2 port.	IRQ 3, IRQ 4, IRQ 5, IRQ 6, IRQ 7, IRQ 10, IRQ 11, IRQ 12	Selected interrupt is assigned.
COM C	Setting of the COM port for the **touch screen on the monitor/panel** connector.	Disabled	Disables the interface.
		Enabled	Enables the interface.
Base I/O address	Selection of the base I/O address for the COM port.	238, 2E8, 2F8, 328, 338, 3E8, 3F8	Selected base I/O address is assigned.
Interrupt	Selection of the interrupt for the COM port.	IRQ 3, IRQ 4, IRQ 5, IRQ 6, IRQ 7, IRQ 10, IRQ 11, IRQ 12	Selected interrupt is assigned.
COM D	Setting of the COM port for the **touch screen on the AP Link** connector.	Disabled	Disables the interface.
		Enabled	Enables the interface.
Base I/O address	Selection of the base I/O address for the COM port.	238, 2E8, 2F8, 328, 338, 3E8, 3F8	Selected base I/O address is assigned.
Interrupt	Selection of the interrupt for the COM port.	IRQ 3, IRQ 4, IRQ 5, IRQ 6, IRQ 7, IRQ 10, IRQ 11, IRQ 12	Selected interrupt is assigned.
COM E	Configuration of the COM port on the B&R add-on interface 5AC600.485I-00 (IF option).	Disabled	Disables the interface.
		Enabled	Enables the interface.
Base I/O address	Selection of the base I/O address for the COM port.	238, 2E8, 2F8, 328, 338, 3E8, 3F8	Selected base I/O address is assigned.
Interrupt	Selection of the interrupt for the COM port.	IRQ 3, IRQ 4, IRQ 5, IRQ 6, IRQ 7, IRQ 10, IRQ 11, IRQ 12	Selected interrupt is assigned.
CAN	Configuration of the CAN port of the B&R add-on CAN interface card 5AC600.CANI-00 (IF option).	Disabled	Disables the interface.
		Enabled	Enables the interface.
Base I/O address	Selection of the base I/O address for the CAN port.	None	-
Interrupt	Selection of the interrupt for the CAN port.	IRQ 10, NMI	Selected interrupt is assigned.
Hardware security key	Settings for the hardware security key (Dongle) are made here.	Disabled	Disables the interface.
		Enabled	Enables the interface.
Base I/O address	Selection of the base I/O address for the hardware security interface.	278, 378, 3BC	Selection of the base I/O address for the parallel port.
ETH2 LAN controller	For turning the onboard LAN controller (ETH2) on and off.	Disabled	Disables the controller.
		Enabled	Enables the controller.
ETH2 MAC Address	Displays the Ethernet 2 controller MAC address.	None	-

Table 161: 945GME - Legacy Devices - Setting options (Forts.)

1.5 Boot



Figure 149: 945GME - Boot Menu

BIOS setting	Meaning	Setting options	Effect
Boot Priority Selection	The method for when the drives should be booted can be set here.	Device Based	Only the devices that are recognized by the system are listed. The sequence of this list can be changed.
		Type Based	The boot sequence of a device type list can be changed. Device types that are not connected can also be entered to this list.

Table 162: 945GME - Boot Menu - Setting options

BIOS setting	Meaning	Setting options	Effect
1st Boot Device	The boot drives can be set using this option.	Disabled, primary master, primary slave, secondary master, secondary slave, Legacy floppy, USB floppy, USB hard disk, USB CDROM, USB removable device, onboard LAN, external LAN, PCI mass storage PCI SCSI Card, Any PCI BEV Device, Third Master, Third Slave, PCI RAID, Local BEV ROM	Select the desired sequence.
2nd Boot Device			
3rd Boot Device			
4th Boot Device			
5th Boot Device			
6th Boot Device			
7th Boot Device			
8th Boot Device			
Quick Boot	This function reduces the boot time by skipping some POST procedures.	Disabled	Disables this function.
		Enabled	Enables this function.
Quiet Boot	Determines if POST message or OEM logo (default = black background) is displayed.	Disabled	POST message display.
		Enabled	OEM logo display instead of POST message.
Automatic Boot List Retry	With this option, the operating system attempts to automatically restart following startup failure.	Disabled	Disables this function.
		Enabled	Enables this function.
Add-On ROM Display Mode	Sets the display mode for the ROM (during the booting procedure).	Force BIOS	An additional BIOS part can be displayed.
		Keep Current	BIOS information is displayed.
Halt On Error	This option sets whether the system should pause the Power On Self Test (POST) when it encounters an error.	Disabled	The system does not pause. All errors are ignored.
		Enabled	The system pauses. The system pauses every time an error is encountered.
Hit 'DEL' Message Display	Settings can be made here for the "Hit 'DEL' Message" display. **Information:** **When quiet boot is activated the message is not displayed.**	Disabled	The message is not displayed.
		Enabled	The message is displayed.
Interrupt 19 Capture	This function can be used to incorporate the BIOS interrupt.	Disabled	Disables this function.
		Enabled	Enables this function.
PXE boot to LAN (ETH1)	Enables/disables the function to boot from LAN (ETH1).	Disabled	Disables this function.
		Enabled	Enables this function.
Slide-in 2 Optional ROM	Activation/deactivation of an optional ROM for a slide-in 2 drive.	Disabled	Disables this function.
		Enabled	Enables this function.
Power Loss Control	Determines if the system is on/off following power loss.	Remain Off	Remains off.
		Turn On	Powers on.
		Last State	Enables the previous state.

Table 162: 945GME - Boot Menu - Setting options (Forts.)

1.6 Security



Figure 150: 945GME - Security Menu

BIOS setting	Meaning	Setting options	Effect
Supervisor Password	Displays whether or not a supervisor password has been set.	None	-
User Password	Displays whether or not a user password has been set.	None	-
Change Supervisor Password	To enter/change a supervisor password. A supervisor password is necessary to edit all BIOS settings.	Enter	Enter password.
Change User Password	To enter/change a user password. A user password allows the user to edit only certain BIOS settings.	Enter	Enter password.
Boot Sector Virus Protection	With this option, a warning is issued when the boot sector is accessed through a program or virus. **Information:** **With this option, only the boot sector is protected, not the entire hard drive.**	Disabled	Disables this function.
		Enabled	Enables this function.
Hard Disk Security User Passwords	The hard disk security user password can be created here.	Enter	Opens the submenu See "Hard disk security user password", on page 289

Table 163: 945GME - Security Menu - Setting options

BIOS setting	Meaning	Setting options	Effect
Hard Disk Security Master Passwords	The hard disk security master password can be created here.	Enter	Opens the submenu See "Hard disk security master password", on page 290

Table 163: 945GME - Security Menu - Setting options (Forts.)

1.6.1 Hard disk security user password



Figure 151: 945GME Hard disk security user password

BIOS setting	Meaning	Setting options	Effect
Primary slave HDD user password	This function makes it possible to use the user password to change or configure each hard drive without having to reboot the device. A user password allows the user to edit only certain BIOS settings.	Enter	Enter password.

Table 164: 945GME Hard disk security user password

1.6.2 Hard disk security master password



Figure 152: 945GME Hard Disk Security Master Password

BIOS setting	Meaning	Setting options	Effect
Primary Slave HDD Master Password	This function makes it possible to use the user password to change or configure each hard drive without having to reboot the device.	Enter	Enter password.

Table 165: 945GME Hard Disk Security Master Password

1.7 Power



Figure 153: 945GME - Power Menu

BIOS setting	Meaning	Setting options	Effect
Power Management/APM	This option switches the APM function on or off. This is an advanced plug & play and power management functionality.	Disabled	Disables this function.
		Enabled	Enables this function.
Suspend Time Out	Using this option, you can configure how long the system stays inactive (all components but the CPU are shut off, if possible) before entering suspend mode.	Disabled	Disables this function.
		1 Min, 2 Min, 4 Min, 8 Min, 10 Min, 20 Min, 30 Min, 40 Min, 50 Min, 60 Min;	Value set manually.
Video Power Down Mode	This option allows you to set the energy saving mode for the monitor.	Disabled	Do not switch off the monitor.
		Standby	Monitor goes to standby mode.
		Suspend	Monitor goes to suspend mode.
Hard Disk Power Down Mode	This option allows you to set the energy saving mode for the hard drive.	Disabled	Do not switch off the hard drive.
		Standby	Monitor goes to standby mode.
		Suspend	Hard drive goes to suspend mode.
Keyboard & PS/2 Mouse	The monitoring of activities during power saving mode is determined here.	MONITOR	Keyboard or PS/2 mouse activities return the system to its normal state from a particular energy saving mode.
		IGNORE	Activities are ignored.

Table 166: 945GME - Power Menu - Setting options

BIOS setting	Meaning	Setting options	Effect
FDC/LPT/COM ports	The monitoring of activities during power saving mode is determined here.	MONITOR	Activity on the parallel port, the serial 1&2 port, or the floppy port returns the system to its normal state from an energy saving mode.
		IGNORE	Activities are ignored.
Primary Master IDE	The monitoring of activities during power saving mode is determined here.	MONITOR	Activities in the IRQ of specific connections or devices return the system to its normal state from power saving mode.
		IGNORE	Activities are ignored.
Primary Slave IDE	The monitoring of activities during power saving mode is determined here.	MONITOR	Activities in the IRQ of specific connections or devices return the system to its normal state from power saving mode.
		IGNORE	Activities are ignored.
Secondary Master IDE	The monitoring of activities during power saving mode is determined here.	MONITOR	Activities in the IRQ of specific connections or devices return the system to its normal state from power saving mode.
		IGNORE	Activities are ignored.
Secondary Slave IDE	The monitoring of activities during power saving mode is determined here.	MONITOR	Activities in the IRQ of specific connections or devices return the system to its normal state from power saving mode.
		IGNORE	Activities are ignored.
Resume On Ring	When the modem receives an incoming call, the PC is brought out of power saving mode.	Disabled	Disables this function.
		Enabled	Enables this function.
Resume on PME#	With this option, you can switch the PME wakeup function on or off.	Disabled	Disables this function.
		Enabled	Enables this function.
Resume On RTC Alarm	With this option, you can activate the alarm and enter the date and time for the system start.	Disabled	Disables this function.
		Enabled	Enables this function.
Power Button Mode	This function determines the function of the power button.	On/Off	Power button switches on/off.
		Suspend	Suppresses the function.

Table 166: 945GME - Power Menu - Setting options (Forts.)

1.8 Exit



Figure 154: 945GME - Exit Menu

BIOS setting	Meaning	Setting options	Effect
Save Changes and Exit	BIOS setup is closed with this item. Changes made are saved in CMOS after confirmation, and the system is rebooted.	OK / Cancel	
Discard Changes and Exit	With this item you can close BIOS setup without saving the changes made. The system is then rebooted.	OK / Cancel	
Discard Changes	In the event that settings were made which the user can no longer remember, changes can be reset as long as they haven't been saved.	OK / Cancel	
Load CMOS Defaults	This item loads the CMOS default values, which are defined by the DIP switch settings. These settings are loaded for all BIOS configurations.	OK / Cancel	

Table 167: 855GME - (XTX) Exit menu - Setting options

1.9 BIOS default settings

The various positions of the CMOS profile hex switch (see figure "Interface overview - APC810, 2 card slot variant (front)", on page 53) can be used to load pre-defined BIOS profile settings.



Figure 155: CMOS profile hex switch

Information:

The switch position that is set upon delivery represents the optimum BIOS default values for this system and should therefore not be changed.

If the function "load setup defaults" is chosen in the main BIOS setup menu, or if exit is selected (or <F9> is pressed) in the individual setup screens, the following BIOS settings are the optimized values that will be used.

Profile number	Optimized for	Switch position	Note
Profile 0	**Reserved**	**0**	
Profile 1	**System unit - 5PC810.SX01-00 / 5PC810.SX02-00 / 5PC810.SX03-00**	**1**	
Profile 2	**System unit 5PC810.SX05-00**	**2**	
Profile 3	System unit 5PC820-SX01-00 / 5PC820.SX01-01	3	The default settings for this profile can be found in the APC820 User's Manual. This can be downloaded for free from the B&R homepage.
Profile 4	Reserved	4	
Profile 5	System unit 5PC820.1505-00 / 5PC820.1906-00	5	The default settings for this profile can be found in the PPC800 User's Manual. This can be downloaded for free from the B&R homepage.

Table 168: Profile overview

The following pages provide an overview of the BIOS default settings for the different CMOS profile switch positions. Settings highlighted in yellow are variations from the BIOS default profile (=profile 0).

1.9.1 Main

Setting / View	Profile 0	Profile 1	Profile 2	My setting
System Time	-	-	-	
System Date	-	-	-	
BIOS ID	-	-	-	
Processor	-	-	-	
CPU Frequency	-	-	-	
System Memory	-	-	-	
Product Revision	-	-	-	
Serial Number	-	-	-	
BC Firmware Rev.	-	-	-	
MAC Address (ETH1)	-	-	-	
Boot Counter	-	-	-	
Running Time	-	-	-	

Table 169: 945GME Main profile setting overview

1.9.2 Advanced

ACPI configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
ACPI Aware O/S	Yes	Yes	Yes	
ACPI Version Features	ACPI v2.0	ACPI v2.0	ACPI v2.0	
ACPI APIC support	Enabled	Enabled	Enabled	
Suspend mode	S1 (POS)	S1 (POS)	S1 (POS)	
USB Device Wakeup from S3/S4	Disabled	Disabled	Disabled	
Active Cooling Trip Point	Disabled	Disabled	Disabled	
Passive Cooling Trip Point	Disabled	Disabled	Disabled	
Critical Trip Point	105°C	105°C	105°C	

Table 170: 945GME Advanced - ACPI configuration profile setting overview

PCI Configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Plug & Play O/S	No	**Yes**	**Yes**	
PCI Latency Timer	64	64	64	
Allocate IRQ to PCI VGA	Yes	Yes	Yes	
Allocate IRQ to SMBUS HC	Yes	Yes	Yes	
Allocate IRQ to PCIEX2	Yes	Yes	Yes	
PCI IRQ Resource Exclusion				
IRQ3	Allocated	Allocated	Allocated	
IRQ4	Allocated	Allocated	Allocated	
IRQ5	Available	Available	Available	
IRQ6	Available	Available	Available	
IRQ7	Available	Available	Available	
IRQ9	Allocated	Allocated	Allocated	
IRQ10	Available	Available	Available	
IRQ11	Allocated	Allocated	Allocated	
IRQ12	Available	Available	Available	
IRQ14	Allocated	Allocated	Allocated	
IRQ15	Allocated	Allocated	Allocated	
PCI Interrupt Routing				
PIRQ A (VGA,PCIEX0, ETH2,UHCI2)	Auto	Auto	Auto	
PIRQ B (AC97,PCIEX1, ETH1)	Auto	Auto	Auto	
PIRQ C (PCIEX2)	Auto	Auto	Auto	
PIRQ D (SATA,UHCI1,SMB, PCIEX3)	Auto	Auto	Auto	
PIRQ E (INTD,UHCI3,PATA)	Auto	Auto	Auto	
PIRQ F (INTA)	Auto	Auto	Auto	
PIRQ G (INTB)	Auto	Auto	Auto	
PIRQ H (INTC,UHCI0,EHCI)	Auto	Auto	Auto	
1st Exclusive PCI	-	-	-	
2nd Exclusive PCI	-	-	-	

Table 171: 945GME Advanced - PCI configuration profile setting overview

PCI express configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Active State Power-Management	Disabled	Disabled	Disabled	
PCIE Port 0	Auto	Auto	Auto	
PCIE Port 1	Auto	Auto	Auto	
PCIE Port 2	Auto	Auto	Auto	
PCIE Port 3	Auto	Auto	Auto	
PCIE Port 4 (ETH2)	Auto	Auto	Auto	
PCIE Port 5 (ETH1)	Auto	Auto	Auto	
PCIE High Priority Port	Disabled	Disabled	Disabled	
Res. PCIE Hotplug Resource	No	No	No	
PCIE Port 0 IOxAPCI Enable	Disabled	Disabled	Disabled	
PCIE Port 1 IOxAPCI Enable	Disabled	Disabled	Disabled	
PCIE Port 2 IOxAPCI Enable	Disabled	Disabled	Disabled	
PCIE Port 3 IOxAPCI Enable	Disabled	Disabled	Disabled	

Table 172: 945GME Advanced - PCI Express configuration profile setting overview

Graphics configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Primary Video Device	Internal VGA	Internal VGA	Internal VGA	
Internal Graphics Mode Select	Enabled, 8MB	Enabled, 8MB	Enabled, 8MB	
DVMT Mode Select	DVMT Mode	DVMT Mode	DVMT Mode	
DVMT/FIXED Memory	128MB	128MB	128MB	
Boot Display Device	Auto	Auto	Auto	
Boot Display Preference	SDVO-B SDVO-C LFP	SDVO-B SDVO-C LFP	SDVO-B SDVO-C LFP	
Local Flat Panel Type	Auto	Auto	Auto	
Local flat panel scaling	Centering	Centering	Centering	
SDVO Port B Device	DVI	DVI	DVI	
SDVO Port C Device	DVI	DVI	DVI	
SDVO/DVI Hotplug Support	Enabled	Enabled	Enabled	
Display Mode Persistence	Enabled	Enabled	Enabled	

Table 173: 945GME Advanced - Graphics configuration profile setting overview

CPU configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
MPS Revision	1.4	1.4	1.4	
Max CPUID value limit	Disabled	Disabled	Disabled	
Execute Disable Bit	Enabled	Enabled	Enabled	
Core Multi-Processing	Enabled	Enabled	Enabled	
Intel(R) SpeedStep(tm) tech.	Automatic	Automatic	Automatic	
Max. CPU frequency	xxxx MHz	xxxx MHz	xxxx MHz	
C1 Config.	Default	Default	Default	
C2 Config.	Disabled	Disabled	Disabled	
C3 Config.	Disabled	Disabled	Disabled	
C4 Config.	Disabled	Disabled	Disabled	

Table 174: 945GME Advanced - CPU configuration profile setting overview

Chipset configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
DRAM Frequency	Auto	Auto	Auto	
DRAM Refresh Rate	Auto	Auto	Auto	
Memory Hole	Disabled	Disabled	Disabled	
DIMM Thermal Control	Disabled	Disabled	Disabled	
DT in SPD	Disabled	Disabled	Disabled	
TS on DIMM	Disabled	Disabled	Disabled	
High Precision Event Timer	Disabled	Disabled	Disabled	
IOAPIC	Enabled	Enabled	Enabled	
APIC ACPI SCI IRQ	Disabled	Disabled	Disabled	
C4 On C3	Disabled	Disabled	Disabled	

Table 175: 945GME Advanced - Chipset configuration profile setting overview

I/O interface configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Onboard Audio Controller	AC97	AC97	AC97	

Table 176: 945GME Advanced - I/O Interface Configuration profile setting overview

Clock Configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Spread spectrum	Disabled	Disabled	Disabled	

Table 177: 945GME Advanced - Clock configuration profile setting overview

IDE Configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
ATA/IDE Configuration	Compatible	Compatible	Compatible	
Legacy IDE Channels	SATA Pri, PATA Sec	SATA Pri, PATA Sec	SATA Pri, PATA Sec	
Configure SATA as	-	-	-	
Configure SATA as Channels	-	-	-	
AHCI/RAID SATA Hotplug	-	-	-	
Hard disk write protect	Disabled	Disabled	Disabled	
IDE Detect Time Out (Sec)	35	35	35	
ATA(PI) 80Pin Cable Detection	Host & device	Host & device	Host & device	
Primary IDE Master				
Type	Auto	Auto	Auto	
LBA/Large Mode	Auto	Auto	Auto	
Block (Multi-Sector Transfer)	Auto	Auto	Auto	
PIO Mode	Auto	Auto	Auto	
DMA Mode	Auto	Auto	Auto	
S.M.A.R.T.	Auto	Auto	Auto	
32Bit data transfer	Enabled	Enabled	Enabled	
Primary IDE slave				
Type	Auto	Auto	Auto	
LBA/Large Mode	Auto	Auto	Auto	
Block (Multi-Sector Transfer)	Auto	Auto	Auto	
PIO Mode	Auto	Auto	Auto	
DMA Mode	Auto	Auto	Auto	
S.M.A.R.T.	Auto	Auto	Auto	
32Bit data transfer	Enabled	Enabled	Enabled	
Secondary IDE Master				
Type	Auto	Auto	Auto	
LBA/Large Mode	Auto	Auto	Auto	

Table 178: 945GME Advanced - IDE configuration profile setting overview

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Block (Multi-Sector Transfer)	Auto	Auto	Auto	
PIO Mode	Auto	Auto	Auto	
DMA Mode	Auto	Auto	Auto	
S.M.A.R.T.	Auto	Auto	Auto	
32Bit data transfer	Enabled	Enabled	Enabled	

Table 178: 945GME Advanced - IDE configuration profile setting overview (Forts.)

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Secondary IDE slave				
Type	Auto	Auto	Auto	
LBA/Large Mode	Auto	Auto	Auto	
Block (Multi-Sector Transfer)	Auto	Auto	Auto	
PIO Mode	Auto	Auto	Auto	
DMA Mode	Auto	Auto	Auto	
S.M.A.R.T.	Auto	Auto	Auto	
32Bit data transfer	Enabled	Enabled	Enabled	

Table 178: 945GME Advanced - IDE configuration profile setting overview (Forts.)

USB configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
USB Functions	8 USB Ports	8 USB Ports	8 USB Ports	
USB 2.0 Controller	Enabled	Enabled	Enabled	
Legacy USB Support	Enabled	Enabled	Enabled	
USB Legacy POST-Always	Enabled	Enabled	Enabled	
USB Keyboard Legacy Support	Enabled	Enabled	Enabled	
USB Mouse Legacy Support	Disabled	Disabled	Disabled	
USB Storage Device Support	Enabled	Enabled	Enabled	
Port 64/60 Emulation	Disabled	Disabled	Disabled	
USB 2.0 Controller Mode	HiSpeed	HiSpeed	HiSpeed	
BIOS EHCI Hand-Off	Disabled	Disabled	Disabled	
USB Beep Message	Enabled	Enabled	Enabled	
USB Stick Default Emulation	Hard disk	Hard disk	Hard disk	
USB Mass Storage Reset Delay	20 Sec	20 Sec	20 Sec	

Table 179: 945GME Advanced - USB configuration profile setting overview

Keyboard/mouse configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Boot-up Num-lock	On	On	On	
Typematic rate	Fast	Fast	Fast	

Table 180: 945GME Advanced - Keyboard/Mouse Configuration profile setting overview

Remote access configuration

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Remote access	Disabled	Disabled	Disabled	
Serial port number	-	-	-	
Base address, IRQ	-	-	-	
Serial port mode	-	-	-	
Flow control	-	-	-	
Redirection after BIOS POST	-	-	-	
Terminal type	-	-	-	
VT-UTF8 Combo Key Support	-	-	-	
Sredir Memory Display Delay	-	-	-	
Serial port BIOS update	Disabled	Disabled	Disabled	

Table 181: 945GME Advanced - Remote Access Configuration profile setting overview

CPU board monitor

Setting / View	Profile 0	Profile 1	Profile 2	My setting
H/W Health Function	Enabled	Enabled	Enabled	

Table 182: 945GME Advanced - CPU board monitor profile setting overview

Main Board/Panel Features

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Panel control				
Select panel number	-	-	-	
Version	-	-	-	
Brightness	100%	100%	100%	
Temperature	-	-	-	
Fan speed	-	-	-	
Keys/LEDs	-	-	-	
Baseboard monitor				
CMOS battery	-	-	-	
Board I/O	-	-	-	
Board ETH2	-	-	-	
Board Power	-	-	-	
Power supply	-	-	-	
Slide-in drive 1	-	-	-	

Table 183: 945GME Advanced - Baseboard/Panel Features profile setting overview

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Slide-in drive 2	-	-	-	
ETH2 Controller	-	-	-	
Case 1	-	-	-	
Case 2	-	-	-	
Case 3	-	-	-	
Case 4	-	-	-	
Legacy devices				
COM A	Enabled	Enabled	Enabled	
Base I/O address	3F8	3F8	3F8	
Interrupt	IRQ4	IRQ4	IRQ4	
COM B	Enabled	Enabled	Enabled	
Base I/O address	2F8	2F8	2F8	
Interrupt	IRQ3	IRQ3	IRQ3	
COM C	Enabled	**Disabled**	**Disabled**	
Base I/O address	3E8	-	-	
Interrupt	IRQ11	-	-	
COM D	Disabled	Disabled	Disabled	
Base I/O address	-	-	-	
Interrupt	-	-	-	
COM E	Disabled	Disabled	Disabled	
Base I/O address	-	-	-	
Interrupt	-	-	-	
CAN	Disabled	Disabled	Disabled	
Hardware security key	Enabled	Enabled	Enabled	
Base I/O address	378	378	378	
ETH2 LAN Controller	Enabled	Enabled	Enabled	
ETH2 MAC Address	-	-	-	

Table 183: 945GME Advanced - Baseboard/Panel Features profile setting overview (Forts.)

1.9.3 Boot

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Boot Priority Selection	Type Based	Type Based	Type Based	
1st Boot Device	Onboard LAN	**Primary master**	**Primary master**	
2nd Boot Device	Primary master	**Primary slave**	**Primary slave**	
3rd Boot Device	Primary slave	**USB floppy**	**USB floppy**	
4th Boot Device	USB floppy	**USB removable device**	**USB removable device**	
5th Boot Device	USB removable device	**USB hard disk**	**USB hard disk**	

Table 184: 945GME Boot profile setting overview

Setting / View	Profile 0	Profile 1	Profile 2	My setting
6th Boot Device	USB CDROM	USB CDROM	USB CDROM	
7th Boot Device	Secondary Master	Secondary Master	Secondary Master	
8th Boot Device	Secondary Slave	Secondary Slave	Secondary Slave	
Quick Boot	Enabled	Enabled	Enabled	
Quiet Boot	Disabled	Disabled	Disabled	
Automatic Boot List Retry	Disabled	Disabled	Disabled	
Add-On ROM Display Mode	Keep Current	Keep Current	Keep Current	
Halt On Error	Disabled	Disabled	Disabled	
Hit "DEL" Message Display	Enabled	Enabled	Enabled	
Interrupt 19 Capture	Disabled	Disabled	Disabled	
PXE boot to LAN (ETH1)	Enabled	**Disabled**	**Disabled**	
Slide-in 2 optional ROM	Enabled	**Disabled**	Enabled	
Power Loss Control	Turn On	Turn On	Turn On	

Table 184: 945GME Boot profile setting overview

1.9.4 Security

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Supervisor Password	-	-	-	
User Password	-	-	-	
Boot Sector Virus Protection	Disabled	Disabled	Disabled	
Hard disk security user password	-	-	-	
Hard disk security master password	-	-	-	

Table 185: 945GME Security profile setting overview

1.9.5 Power

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Power Management/APM	Enabled	Enabled	Enabled	
Suspend Time Out	Disabled	Disabled	Disabled	
Video Power Down Mode	Suspend	Suspend	Suspend	
Hard Disk Power Down Mode	Suspend	Suspend	Suspend	
Keyboard & PS/2 Mouse	MONITOR	MONITOR	MONITOR	
FDC/LPT/COM ports	MONITOR	MONITOR	MONITOR	
Primary Master IDE	MONITOR	MONITOR	MONITOR	

Table 186: 945GME Power profile setting overview

Setting / View	Profile 0	Profile 1	Profile 2	My setting
Primary Slave IDE	MONITOR	MONITOR	MONITOR	
Secondary Master IDE	MONITOR	MONITOR	MONITOR	
Secondary Slave IDE	MONITOR	MONITOR	MONITOR	
Resume On Ring	Disabled	Disabled	Disabled	
Resume on PME#	Disabled	Disabled	Disabled	
Resume On RTC Alarm	Disabled	Disabled	Disabled	
Power Button Mode	On/Off	On/Off	On/Off	

Table 186: 945GME Power profile setting overview

1.10 BIOS Error signals (beep codes)

While the Automation PC 810 is booting, the following messages and errors can occur with BIOS. These errors are signaled by different beeping codes.

1.10.1 BIOS 945GME

Beeping code	Meaning	Necessary user action
1 x short	Memory refresh failed.	Load BIOS defaults. In the event that the error persists, send industrial PC to B&R for testing.
2 x short	Parity error: POST error (error in one of the hardware testing procedures)	Check the placement of the inserted card. In the event that the error persists, send industrial PC to B&R for testing.
3 x short	Base 64 KB memory failure: Basic memory defect, RAM error within the initial 64 KB.	Send industrial PC to B&R for checking.
4 x short	Timer not operational: System timer.	Send industrial PC to B&R for checking.
5 x short	Processor error: Processor defect.	Send industrial PC to B&R for checking.
6 x short	8042 gate A20 failure: Keyboard controller defect (block 8042/ A20 gate). Processor cannot switch to protected mode.	Send industrial PC to B&R for checking.
7 x short	Processor exception interrupt error: Virtual mode exception error (CPU generated an interrupt error.	Send industrial PC to B&R for checking.
8 x short	Display memory read/write error: Video memory not accessible; graphic card defect or not built in (no fatal error).	Check inserted graphic card position and eventually exchange. In the event that the error persists, send industrial PC to B&R for testing.
9 x short	ROM-checksum error: ROM-BIOS-checksum incorrect, EPROM, EEPROM or Flash-ROM component defect, BIOS defect or incorrectly updated.	Send industrial PC to B&R for checking.
10 x short	CMOS shutdown register read/write error: CMOS cannot be read/written.	Send industrial PC to B&R for checking.
11 x short	Cache Error / external Cache bad: L2 - Cache on the mainboard is defected.	Send industrial PC to B&R for checking.

Table 187: BIOS post code messages BIOS 945GME

1.11 Distribution of resources

1.11.1 RAM address assignment

RAM address	Address in Hex	Resource
(TOM - 192 kB) – TOM[1)]	N.A.	ACPI reclaim, MPS and NVS area[2)]
(TOM - 8 MB - 192 kB) – (TOM - 192 kB)	N.A.	VGA frame buffer[3)]
1024 kB – (TOM - 8 MB - 192 kB)	100000h - N.A.	Extended memory
869 kB – 1024 kB	0E0000h - 0FFFFFh	Runtime BIOS
832 kB – 869 kB	0D0000h - 0DFFFFh	Upper memory
640 kB – 832 kB	0A0000h - 0CFFFFh	Video memory and BIOS
639 kB – 640 kB	09FC00h - 09FFFFh	Extended BIOS data
0 – 639 kB	000000h - 09FC00h	Conventional memory

Table 188: RAM address assignment

1) TOM - **T**op **o**f **m**emory: max. installed DRAM
2) Only if ACPI Aware OS is set to "YES" in the setup.
3) The VGA frame buffer can be reduced to 1 MB in the setup.

1.11.2 I/O address assignment

I/O address	Resource
0000h - 00FFh	Motherboard resources
0170h - 0177h	Secondary IDE channel
01F0h - 01F7h	Primary IDE channel
0238h - 023Fh	COM5
0278h - 027Fh	Hardware Security Key (LPT2)
02E8h - 02EFh	COM4
02F8h - 02FFh	COM2
0376h - 0376h	Secondary IDE channel command port
0377h - 0377h	Secondary IDE channel status port
0378h - 037Fh	Hardware Security Key (LPT1)
0384h - 0385h	CAN controller
03B0h - 03DFh	Video system
03E8h - 03EFh	COM3
03F6h - 03F6h	Primary IDE channel command port
03F7h - 03F7h	Primary IDE channel status port
03F8h - 03FFh	COM1
0480h - 04BFh	Motherboard resources
04D0h - 04D1h	Motherboard resources
0800h - 087Fh	Motherboard resources
0CF8h - 0CFBh	PCI config address register
0CFCh - 0CFFh	PCI config data register
0D00h - FFFFh	PCI / PCI Express bus [1)]
4100h - 417Fh	MTCX
FF00h - FF07h	IDE bus master register

Table 189: I/O address assignment

1) The BIOS assigns the PCI and PCI Express Bus I/O resources from FFF0h downward. Devices that are not compatible with PnP/PCI/PCI Express cannot use the I/O resources in this area.

1.11.3 Interrupt assignments in PCI mode

IRQ		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	NMI	NONE
System timer		●																	
Keyboard			●																
IRQ cascade				●															
COM1 (Serial port A)					❍	●	❍	❍	❍			❍	❍	❍					
COM2 (Serial port B)					●	❍	❍	❍	❍			❍	❍	❍					
ACPI[1]											●								
Real-time clock										●									
Coprocessor (FPU)															●				
Primary IDE channel																●			
Secondary IDE channel																	●		
B&R	COM3 (COM C)				❍	❍	❍	❍	❍			❍	❍	❍					●
	COM4 (COM D)				❍	❍	❍	❍	❍			❍	❍	❍					●
	COM5 (COM E)				❍	❍	❍	❍	❍			❍	❍	❍					●
	CAN				❍	❍	❍	❍	❍			❍	❍	❍				❍	●

Table 190: IRQ interrupt assignments in PCI mode

1) **A**dvanced **C**onfiguration and **P**ower **I**nterface.

● ... Default setting
❍ ... Optional setting

1.11.4 Interrupt assignments in APIC mode

A total of 23 IRQs are available in the APIC mode (**A**dvanced **P**rogrammable **I**nterrupt **C**ontroller). The activation of this option is only effective if it takes place before the operating system (Windows XP) is activated.

IRQ		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	NMI	NONE
System timer		●																									
Keyboard			●																								
IRQ cascade				●																							
COM1 (Serial port A)					❍	●	❍	❍	❍			❍	❍	❍													
COM2 (Serial port B)					●	❍	❍	❍	❍			❍	❍	❍													
ACPI[1]										●																	
Real-time clock										●																	
Coprocessor (FPU)															●												
Primary IDE channel																●											
Secondary IDE channel																	●										
B&R	COM3 (COM C)				❍	❍	❍	❍	❍			❍	❍	❍													●
	COM4 (COM D)				❍	❍	❍	❍	❍			❍	❍	❍													●
	COM5 (COM E)				❍	❍	❍	❍	❍			❍	❍	❍													●
	CAN				❍	❍	❍	❍	❍			❍	❍	❍												❍	●
PIRQ A [2]																		●									
PIRQ B [3]																			●								
PIRQ C [4]																				●							
PIRQ D [5]																					●						
PIRQ E [6]																						●					
PIRQ F [7]																							●				
PIRQ G [8]																								●			
PIRQ H [9]																									●		

Table 191: IRQ interrupt assignments in APIC mode

1) **A**dvanced **C**onfiguration and **P**ower **I**nterface.

2) PIRQ A: for PCIe; UHCI host controller 3, VGA controller, PCI Express root port 0, Intel High Definition Audio controller, PCI-EX to SATA bridge

3) PIRQ B: for PCIe; AC'97 audio, PCI express root port 1, onboard gigabit LAN controller

4) PIRQ C: for PCIe; UHCI host controller 1, SMBus controller, PCI Express root port 3, Serial ATA controller in enhanced/native mode

5) PIRQ D: for PCIe, UHCI Host Controller 3, Parallel ATA controller in enhanced/native mode
6) PIRQ E: PCI Bus INTD
7) PIRQ F: PCI bus INTA
8) PIRQ G: PCI bus INTB
9) PIRQ H: PCI bus INTC, UHCI host controller 0, EHCI host controller

● ... Default setting
❍ ... Optional setting



Figure 156: PCI and PCIe routing with activated APIC CPU boards B945GME (COM Express) for BIOS version ≤ 1.12



Figure 157: PCI and PCIe routing with activated APIC CPU boards B945GME (COM Express) for BIOS version ≥ 1.14 (Bus units 5PC810.BX0x-0x)



Figure 158: PCI and PCIe routing with activated APIC CPU boards B945GME (COM Express) for BIOS version ≥ 1.14 (Bus unit 5PC810.BX05-02)

2. Upgrade information

Warning!

The BIOS and firmware on APC810 systems must be kept up to date. New versions can be downloaded from the B&R homepage (www.br-automation.com).

2.1 BIOS upgrade

An upgrade might be necessary for the following reason:

- To update implemented functions or to add newly implemented functions or components to the BIOS setup (information about changes can be found in the Readme files of the BIOS upgrade).

2.1.1 What information do I need?

Information:

Individually saved BIOS settings are deleted when upgrading the BIOS.

Before you begin the upgrade, it helps to determine the various software versions.

Which BIOS version and firmware are already installed on the APC810?

This information can be found on the following BIOS setup page:

- After switching on the APC810, you can get to the BIOS Setup by pressing "Del".
- From the BIOS main menu "Advanced", select "Main board/panel features".



Figure 159: Software version

Which firmware is installed on the Automation Panel Link transmitter?

This information can be found on the following BIOS setup page:

- After switching on the APC810, you can get to the BIOS Setup by pressing "Del".
- From the BIOS main menu "Advanced", select "Main board/panel features" and then "Panel control".

Information:

The version can only be displayed when an Automation Panel with an AP Link SDL transmitter (5AC801.SDL0-00) is connected.



Figure 160: Firmware version of the AP Link SDL transmitter

2.1.2 BIOS upgrade for 945GME COM Express

- Download ZIP file from the B&R homepage (www.br-automation.com)
- Create bootable media.

Information:

In MS-DOS, Win95 and Win98, a blank HD disk can be made bootable using the command line command "sys a:" or "format a: /s".
Information concerning creating a bootable diskette in Windows XP can be found on page 322.

Information concerning creating a USB flash drive for a B&R upgrade can be found on page 324.

Information concerning creating a CompactFlash card for a B&R upgrade can be found on page 326.

- Copy the contents of the *.zip file to the bootable media. If the B&R upgrade was already added when the bootable media was created using the B&R Embedded OS Installer, then this step is not necessary.
- Connect the bootable media to the APC810 and reboot the device.
- The following boot menu will be shown after startup:

```
1. Upgrade AMI BIOS for B945 (5PC800.B945-00,-01,-02,-03,-04)
```

or

```
1. Upgrade AMI BIOS for B945 (5PC800.B945-10,-11,-12,-13,-14)
2. Exit
```

Concerning item 1:
BIOS is automatically upgraded (default after 5 seconds).

Concerning item 2:
Returns to the shell (MS-DOS).

Information:

If you do not press a button within 5 seconds, then step 1 "Upgrade AMI BIOS for B945" is automatically carried out and the APC810 is automatically updated.

- The system must be rebooted after a successful upgrade.
- Reboot and press "Del" to enter the BIOS setup menu and load the setup defaults, then select "Save Changes and Exit".

2.2 Firmware upgrade

The "Upgrade APC800 MTCX" software makes it possible to update the firmware for multiple controllers (MTCX, SDLT, SDLR, UPSI), depending on the structure of the APC810 system.

Current "Upgrade APC800 MTCX" software can be downloaded directly from the service portal on the B&R homepage (**www.br-automation.com**).

2.2.1 Procedure

To carry out a firmware upgrade, the following steps should be taken:

- Download the zip file from the B&R homepage.
- Create bootable media.

Information:

In MS-DOS, Win95 and Win98, a blank HD disk can be made bootable using the command line command "sys a:" or "format a: /s".
Information concerning creating a bootable diskette in Windows XP can be found on page 322.

Information concerning creating a USB flash drive for a B&R upgrade can be found on page 324.

Information concerning creating a CompactFlash card for a B&R upgrade can be found on page 326.

- Copy the contents of the *.zip file to the bootable media. If the B&R upgrade was already added when the bootable media was created using the B&R OS Installer, then this step is not necessary.
- Connect the bootable media to the APC810 and reboot the device.
- The boot menu is shown after startup
- The system must be powered off and on again after a successful upgrade.

Information:

The following boot menu options including descriptions are based on Version 1.00 of the APC800 upgrade (MTCX, SDLR, SDLT, UPSI) disk. In some cases, these descriptions might not match the version you are currently using.

Boot menu options:

```
1. Upgrade MTCX (APC810) PX32 and FPGA

2. Upgrade SDLT (APC810) only
```

```
3. Upgrade SDLR (AP800/AP900) on monitor/panel

   3.1 Upgrade SDLR on AP 0 (AP800/AP900)

   3.2 Upgrade SDLR on AP 1 (AP800/AP900)

   3.3 Upgrade SDLR on AP 1 (AP800/AP900)

   3.4 Upgrade SDLR on AP 1 (AP800/AP900)

   3.5 Upgrade all SDLR (AP800/AP900)

   3.6 Return to main menu

4. Upgrade SDLR (AP800/AP900) on AP link slot

   4.1 Upgrade SDLR on AP 8 (AP800/AP900)

   4.2 Upgrade SDLR on AP 9 (AP800/AP900)

   4.3 Upgrade SDLR on AP 10 (AP800/AP900)

   4.4 Upgrade SDLR on AP 11 (AP800/AP900)

   4.5 Upgrade all SDLR (AP800/AP900)

   4.6 Return to main menu

5. Upgrade add-on UPS (firmware and battery settings)

   5.1 Upgrade Add-on UPS Firmware (5AC600.UPSI-00)

   5.2 Upgrade Battery Settings (5AC600.UPSB-00)

   5.3 Return to main menu

6. Exit
```

Concerning item 1:
Automatically upgrade PX32 and FPGA for MTCX (default after 5 seconds).

Concerning item 2:
The FPGA of the SDLT controller on the AP Link slot is automatically updated.

Concerning item 3:
Submenu 1 is opened for upgrading the SDLR controller on the Monitor/Panel plug.

3.1 Upgrade SDLR on AP 0 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 0.

3.2 Upgrade SDLR on AP 1 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 1.

3.3 Upgrade SDLR on AP 1 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 2.

3.4 Upgrade SDLR on AP 3 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 3.

3.5 Upgrade all SDLR (AP800/AP900)
All SDLR controllers are automatically updated on all Automation Panels on the Monitor/Panel (by default, after 5 sec).

3.6 Return to main menu
Returns to the main menu

Concerning item 4:
Submenu 2 is opened for upgrading the SDLR controller on the AP Link slot.

4.1 Upgrade SDLR on AP 8 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 8.

4.2 Upgrade SDLR on AP 9 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 9.

4.3 Upgrade SDLR on AP 10 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 10.

4.4 Upgrade SDLR on AP 11 (AP800/AP900)
The SDLR controller is automatically updated on Automation Panel 11.

4.5 Upgrade all SDLR (AP800/AP900)
All SDLR controllers are automatically updated on all Automation Panels on the AP Link slot (by default, after 5 sec).

4.6 Return to main menu
Returns to the main menu.

Concerning item 5:
Submenu 3 for the add-on UPS firmware and upgrade and the battery settings upgrade is opened.

5.1 Upgrade Add-on UPS Firmware (5AC600.UPSI-00)
The firmware for the add-on UPSI is updated.

5.2 Upgrade Battery Settings (5AC600.UPSB-00)
The battery settings for 5AC600.UPSB-00 are automatically updated.

5.3 Return to main menu
Returns to the main menu.

Concerning item 6:
Returns to the shell (MS-DOS).

Information:

The system must be powered off and on again after a successful upgrade.

2.2.2 Possible upgrade problems and software dependencies (for V1.00)

- The SDLR firmware can only be updated if an Automation Panel with Automation Panel Link Transceiver (5DLSDL.1000-01) and Automation Panel Link Receiver (5DLSDL.1000-00) is connected.
- Automation Panel Link transceivers (5DLSDL.1000-01) or Automation Panel Link receivers (5DLSDL.1000-00) with a Firmware version lower than or equal to V00.10 can no longer be combined with Automation Panel Link transceivers (5DLSDL.1000-01) or Automation Panel Link receivers (5DLSDL.1000-00) with a Firmware higher than or equal to V01.04. Daisy Chain mode is not possible with such a combination.
- If a UPS (e.g. 5AC600.UPSI-00) + battery unit (e.g.: 5AC600.UPSB-00) is connected to the system and operable, then after an upgrade of the MTCX or SDLT you must either disconnect the battery or push the Power button (to put the system in Standby mode), before executing the required power off/on. If not, the firmware upgrade will not work because the UPS buffers the system.
- The function Legacy Mouse Support and Keyboard Controller Reset is only provided with the combination of MTCX PX32 V00.12 and MTCX FPGA V00.09 (included in APC810 MTCX upgrade disk V00.05).

2.3 Creating an MS-DOS boot diskette in Windows XP

- Place an empty 1.44 MB HD diskette in the disk drive
- Open Windows Explorer
- Right-click on the 3½" Floppy icon and select "Format...".



Figure 161: Creating a bootable diskette in Windows XP - step 1

- Then select the checkbox **"Create an MS-DOS startup disk"**, press **"Start"** and acknowledge the warning message with "OK".



Figure 162: Creating a bootable diskette in Windows XP - step 2



Figure 163: Creating a bootable diskette in Windows XP - step 3

After creating the startup disk, some of the files must be deleted because of the size of the update.

When doing this, all files (hidden, system files, etc.) must be shown on the diskette.

In the Explorer, go to the "Tools" menu, select "Folder Options..." and open the "View" tab - now deactivate the option "Hide protected operating system files (Recommended)" (activated as default) and activate the option "Show hidden files and folders".



Figure 164: Creating a bootable diskette in Windows XP - step 4



Figure 165: Creating a bootable diskette in Windows XP - step 5

Now all files (marked) except Command.com, IO.sys and MSDOS.sys can be deleted.

2.4 Creating a bootable USB flash drive for B&R upgrade files

When used in connection with a B&R industrial PC, it is possible to upgrade BIOS from one of the USB flash drives available from B&R. To do this, the USB flash drive must be prepared accordingly. This is done with the B&R Embedded OS Installer, which can be downloaded for free from the B&R homepage (**www.br-automation.com**).

2.4.1 Requirements

The following peripherals are required for creating a bootable USB flash drive:

- B&R USB flash drive
- B&R Industrial PC
- USB Media Drive
- B&R Embedded OS Installer (V3.00 or higher)

2.4.2 Procedure

- Connect the USB flash drive to the PC.
- If the drive list is not refreshed automatically, the list must be updated using the command **Drives > Refresh**.
- Mark the desired USB flash drive in the drive list.
- Change to the **Action** tab and select **Install a B&R Update to a USB flash drive** as type of action.
- Enter the path to the MS-DOS operating system files. If the files are part of a ZIP archive, then click on the button **By ZIP file...**. If the files are stored in a directory on the hard drive, then click on the button **By folder...**.
- In the **B&R Upgrade** text box, it's also possible to enter the path to the ZIP file for the B&R Upgrade Disk and select the file.
- Click on the **Start action** button in the toolbar.



Figure 166: Creating a USB flash drive for B&R upgrade files

2.4.3 Where do I get MS-DOS?

Information concerning creating an MS-DOS boot diskette can be found in section 2.3 "Creating an MS-DOS boot diskette in Windows XP", on page 322. Then the files from the diskette are to be copied to your hard drive.

2.5 Creating a bootable CompactFlash card for B&R upgrade files

When used in connection with a B&R industrial PC, it is possible to upgrade BIOS from one of the CompactFlash cards available from B&R. To do this, the CompactFlash card must be prepared accordingly. This is done with the B&R Embedded OS Installer, which can be downloaded for free from the B&R homepage (**www.br-automation.com**).

2.5.1 Requirements

The following peripherals are required for creating a bootable CompactFlash card:

- CompactFlash card
- B&R Industrial PC
- B&R Embedded OS Installer (V3.10 or higher)

2.5.2 Procedure

- Insert the CompactFlash card in the CF slot on the industrial PC.
- If the drive list is not refreshed automatically, the list must be updated using the command **Drives > Refresh**.
- Select the desired CompactFlash card from the drive list.
- Change to the **Action** tab and select **Install a B&R Update to a CompactFlash card** as type of action.
- Enter the path to the MS-DOS operating system files. If the files are part of a ZIP archive, then click on the button **By ZIP file...**. If the files are stored in a directory on the hard drive, then click on the button **By folder...**.
- In the **B&R Upgrade** text box, it's also possible to enter the path to the ZIP file for the B&R Upgrade Disk and select the file.
- Click on the **Start action** button in the toolbar.



Figure 167: Creating a CompactFlash card for B&R upgrade files

2.5.3 Where do I get MS-DOS?

Information concerning creating an MS-DOS boot diskette can be found in section 2.3 "Creating an MS-DOS boot diskette in Windows XP", on page 322. Then the files from the diskette are to be copied to your hard drive.

2.6 Upgrade problems

Potential upgrade problems are listed in the Liesmich.txt or Readme.txt files on the upgrade disks.

3. Automation PC 810 with MS-DOS

Figure 168: Automation PC 810 with MS-DOS

Model number	Short description	Note
9S0000.01-010	**OEM MS-DOS 6.22 German (disk)** OEM MS-DOS 6.22 German disks Only delivered with a new PC.	
9S0000.01-020	**OEM MS-DOS 6.22 English (disk)** OEM MS-DOS 6.22 English disks Only delivered with a new PC.	

Table 192: Order data - MS-DOS

3.1 Known problems

Either no drivers are available for the following hardware components or only with limitations:

- AC97 Sound - no support
- USB 2.0 - only USB 1.1 rates can be reached.
- A second graphics line (and therefore Extended Desktop mode) also cannot be used.
- A few "ACPI control" BIOS functions cannot be used.

The following table shows the tested resolutions and color depths on the Monitor / Panel connector with 945GME CPU boards.

Resolutions for DVI	Color depth		
	8-bit	16-bit	24-bit
640 x 480	✓	✓	✓
800 x 600	✓	✓	✓
1024 x 768	✓	✓	✓
1280 x 1024	✓	✓	✓
Resolutions for RGB	**Color depth**		
	8-bit	**16-bit**	**24-bit**
640 x 480	✓	✓	✓
800 x 600	✓	✓	✓
1024 x 768	✓	✓	✓
1280 x 1024	✓	✓	✓
1600 x 1200	✓	✓	✓
1920 x 1440	✓	✓	

Table 193: Tested resolutions and color depths for DVI and RGB signals

4. Automation PC 810 with Windows XP Professional

Figure 169: Windows XP Professional Logo

Model number	Short description	Note
5SWWXP.0600-GER	**WinXP Professional with SP3, GER** Microsoft OEM Windows XP Professional Service Pack 3, CD, German. Only available with a new device.	
5SWWXP.0600-ENG	**WinXP Professional with SP3, ENG** Microsoft OEM Windows XP Professional Service Pack 3, CD, English. Only available with a new device.	
5SWWXP.0600-MUL	**WinXP Professional with SP3, MUL** Microsoft OEM Windows XP Professional Service Pack 3, CD, multi-language. Only available with a new device.	
5SWWXP.0500-GER	**WinXP Professional with SP 2c, GER** Microsoft OEM Windows XP Professional Service Pack 2c, CD, German. Only available with a new device.	
5SWWXP.0500-ENG	**WinXP Professional with SP 2c, ENG** Microsoft OEM Windows XP Professional Service Pack 2c, CD, English. Only available with a new device.	
5SWWXP.0500-MUL	**WinXP Professional with SP 2c, MUL** Microsoft OEM Windows XP Professional Service Pack 2c, CD, multi-language. Only available with a new device.	

Table 194: Oder data - Windows XP Professional

4.1 Installation

Upon request, B&R can pre-install the required Windows XP Professional version on the desired mass memory (add-on hard disk, slide-in hard disk). All of the drivers required for operation (graphics, network, etc.) are also installed when doing so.

4.1.1 Installation on PCI SATA RAID controller - 5ACPCI.RAIC-03, 5ACPCI.RAIC-05

The following steps are necessary for installing Windows XP Professional on the PCI SATA RAID controller:

1) Download the RAID driver from the B&R homepage (**www.br-automation.com**) and copy the files to a diskette.
2) Connect the Media Drive (5MD900.USB2-01 or 5MD900.USB2-00) to the USB port.
3) Insert the diskette and Windows XP Professional CD in the the Media Drive and boot from the CD.
4) Press the F6 key during setup to install a third-party SCSI or a driver.
5) Press the "s" key when asked about installing an additional drive. Insert the disk in the floppy drive. Press "Enter" and select the driver.
6) Follow the setup instructions.
7) The setup copies the files to the Windows XP Professional folder and restarts the Automation PC 810.

4.1.2 For 5PCI slot model

The following steps are necessary when installing to a slide-in HDD being operated in the slide-in slot 2 (located behind the PCI to SATA Bridge) on the APC810:

1) Download the Si3531 SATA driver from the B&R homepage (**www.br-automation.com**) and copy the files to a diskette.
2) Connect the Media Drive (5MD900.USB2-01 or 5MD900.USB2-00) to the USB port.
3) Insert the diskette and Windows XP Professional CD in the the Media Drive and boot from the CD.
4) Press the F6 key during setup to install a third-party SCSI or a driver.
5) Press the "s" key when asked about installing an additional drive. Insert the disk in the floppy drive. Press "Enter" and select the driver.
6) Follow the setup instructions.
7) The setup copies the files to the Windows XP Professional folder and restarts the Automation PC 810.

Information:

- **Windows XP setup supports not all USB-FDD drives (see Microsoft KB 916196).**
- **Depending on the system it could be neccesary to change the boot order in BIOS.**

4.2 Drivers

The latest drivers for all released operating systems can be found in the download area (Service - Material Related Downloads - BIOS / Drivers / Updates) on the B&R homepage (**www.br-automation.com**).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

5. Automation PC 810 with Windows 7

Figure 170: Windows 7 Logo

Model number	Short description	Note
5SWWI7.0100-GER	**Win7 Pro 32-bit DVD, GER** Microsoft OEM Windows 7 Professional 32-bit, DVD, German. Only available with a new device.	
5SWWI7.0100-ENG	**Win7 Pro 32-bit DVD, ENG** Microsoft OEM Windows 7 Professional 32-bit, DVD, English. Only available with a new device.	
5SWWI7.0200-GER	**Win7 Pro 64-bit DVD, GER** Microsoft OEM Windows 7 Professional 64-bit, DVD, German. Only available with a new device.	
5SWWI7.0200-ENG	**Win7 Pro 64-bit DVD, ENG** Microsoft OEM Windows 7 Professional 64-bit, DVD, English. Only available with a new device.	
5SWWI7.0300-MUL	**Win7 Ult 32-bit DVD, MUL** Microsoft OEM Windows 7 Ultimate 32-bit, DVD, Multilanguage. Only available with a new device.	
5SWWI7.0400-MUL	**Win7 Ult 64-bit DVD, MUL** Microsoft OEM Windows 7 Ultimate 64-bit, DVD, Multilanguage. Only available with a new device.	

Table 195: Model numbers - Windows 7

5.1 Installation

Upon request, B&R can pre-install the required Windows 7 version on the desired mass memory (add-on hard disk, slide-in hard disk). All of the drivers required for operation (graphics, network, etc.) are also installed when doing so.

5.1.1 Installation on PCI SATA RAID controller - 5ACPCI.RAIC-03, 5ACPCI.RAIC-05

The following steps are necessary for installing Windows 7 on the PCI SATA RAID controller:

1) Download the RAID driver for Windows 7 from the B&R homepage (**www.br-automation.com**) and copy the data to a folder on a flash drive.
2) Boot using the Windows 7 DVD.
3) Follow the installation steps until a page appears asking "Where do you want to install Windows?".
4) Plug the USB flash drive with the RAID drivers into an available USB port.
5) Click on "Load driver", and navigate to the directory containing the RAID drivers. Then click Next to continue.
6) Remove the USB flash drive.
7) The Windows 7 installation can now be performed as usual.

5.1.2 Special considerations for the 5PCI slot model

The following steps are necessary when installing to a slide-in HDD being operated in the slide-in slot 2 (located behind the PCI to SATA Bridge) on the APC810:

1) Download the Sil3531 SATA driver for Windows 7 from the B&R homepage (**www.br-automation.com**) and copy the data to a folder on a flash drive.
2) Boot using the Windows 7 DVD.
3) Follow the installation steps until a page appears asking "Where do you want to install Windows?".
4) Plug the USB flash drive with the RAID drivers into an available USB port.
5) Click on "Load driver", and navigate to the directory containing the RAID drivers. Then click Next to continue.
6) Remove the USB flash drive.
7) The Windows 7 installation can now be performed as usual.

Information:

Depending on the system it could be neccesary to change the boot order in BIOS.

5.2 Drivers

The latest drivers for all released operating systems can be found in the download area (Service - Material Related Downloads - BIOS / Drivers / Updates) on the B&R homepage (**www.br-automation.com**).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

5.3 Special considerations, limitations:

- Windows 7 system evaluation (system classification) is not currently supported.
- Windows 7 does not contain a Beep.sys file, which means that audible signal is no longer played (i.e. when touching a key or button).

6. Automation PC 810 with Windows XP Embedded

Figure 171: Windows XP Embedded Logo

Model number	Short description	Note
5SWWXP.0426-ENG	**WinXPe FP2007 APC810 945GME** Microsoft OEM Windows XP Embedded Feature Pack 2007, English; for APC810 with 945GME chipset; order CompactFlash separately (at least 512 MB).	

Table 196: Oder data - Windows XP Embedded

6.1 General information

Windows XP Embedded is the modular version of the desktop operating system Windows XP Professional. Windows XP Embedded is based on the same binary files as Windows XP Professional and is optimally tailored to the hardware being used. In other words, only the functions and modules required by the respective device are included. Windows XP Embedded is also based on the same reliable code as Windows XP Professional. It provides industry with leading reliability, improvements in security and performance, and the latest technology for Web browsing and extensive device support.

6.2 Features with FP2007 (Feature Pack 2007)

The feature list shows the most important device functions in Windows XP Embedded with Feature Pack 2007 (FP2007).

Function	Present
Enhanced write filter (EWF)	✓
File Based Write Filter	✓
Page file	Configurable
Administrator account	✓
User account	Configurable
Explorer shell	✓
Registry filter	✓
Internet Explorer 6.0 + SP2	✓
Internet information service (IIS)	-
Terminal service	✓
Windows Firewall	✓
MSN-Explorer	-
Outlook Express	-
Administrative Tools	✓
Remote Desktop	✓
Remote Assistance	-
.NET Framework	-
ASP.NET	-
Codepages/User Locale/Keyboard	✓
Disk Management Service	✓
Windows Installer Service	✓
Class Installer	✓
CoDevice Installer	✓
Media Player	-
DirectX	-
Accessories	✓
Number of fonts	89

Table 197: Device functions in Windows XP Embedded with FP2007

6.3 Installation

Upon request, Windows XP Embedded can be preinstalled at B&R Austria on a suitable CompactFlash card (min. 512MB). The APC810 system is then automatically configured after it has been switched on for the first time. This procedure takes approximately 30 minutes, and the device will be rebooted a number of times.

6.4 Drivers

All drivers required for operation are preinstalled on the operating system. If an older driver version is installed, the latest version can be downloaded from the B&R homepage (**www.br-automation.com**) and installed. A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration.

6.4.1 Touch screen driver

The touch screen driver must be manually installed in order to operate Automation Panel 800 or Automation Panel 900 touch screen devices. The driver can be downloaded from the download area on the B&R homepage (**www.br-automation.com**). A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

7. Automation PC 810 with Windows Embedded Standard 2009

Figure 172: Windows Embedded Standard 2009 Logo

Model number	Short description	Note
5SWWXP.0726-ENG	**Windows Embedded Standard 2009 APC810 945GME** Microsoft OEM Windows Embedded Standard 2009, English; for APC810 with 945GME chipset; order CompactFlash separately (at least 1 GB).	

Table 198: Order data - Windows Embedded Standard 2009

7.1 General information

Windows XP Embedded Standard 2009 is the modular version of the desktop operating system Windows XP Professional with Service Pack 3. Windows Embedded Standard 2009 is based on the same binary files as Windows XP Professional with Service Pack 3 and is optimally tailored to the hardware being used. In other words, only the functions and modules required by the respective device are included. Windows Embedded Standard 2009 is also based on the same reliable code as Windows XP Professional with SP3. It provides industry with leading reliability, improvements in security and performance, and the latest technology for Web browsing and extensive device support.

7.2 Features with WES2009 (Windows Embedded Standard 2009)

The feature list shows the most important device functions in Windows Embedded Standard 2009.

Function	Present
Enhanced write filter (EWF)	✓
File Based Write Filter	✓
Page file	Configurable
Administrator account	✓
User account	Configurable
Explorer shell	✓
Registry filter	✓
Internet Explorer 7.0	✓
Internet information service (IIS)	-
Terminal service	✓
Windows Firewall	✓
MSN-Explorer	-
Outlook Express	-
Administrative Tools	✓
Remote Desktop	✓
Remote Assistance	-
.NET Framework	-
ASP.NET	-
Local Network Bridge	✓
Codepages/User Locale/Keyboard	✓
Disk Management Service	✓
Windows Installer Service	✓
Class Installer	✓
CoDevice Installer	✓
Media Player 6.4	✓
DirectX 9.0c	✓
Accessories	✓
Number of fonts	89

Table 199: Device functions in Windows Embedded Standard 2009

7.3 Installation

Upon request, Windows Embedded Standard 2009 can be preinstalled at B&R Austria on a suitable CompactFlash card (min. 1GB). The APC810 system is then automatically configured after it has been switched on for the first time. This procedure takes approximately 30 minutes, and the device will be rebooted a number of times.

7.4 Drivers

All drivers required for operation are preinstalled on the operating system. If an older driver version is installed, the latest version can be downloaded from the B&R homepage (**www.br-automation.com**) and installed. A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration.

7.4.1 Touch screen driver

The touch screen driver must be manually installed in order to operate Automation Panel 800 or Automation Panel 900 touch screen devices. The driver can be downloaded from the download area on the B&R homepage (**www.br-automation.com**). A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

8. Automation PC 810 with Windows Embedded Standard 7

Abbildung 173: Windows Embedded Standard 7 Logo

Model number	Short description	Note
5SWWI7.0526-ENG	**WES7E 32bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 32-bit, English; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 8 GB).	
5SWWI7.0626-ENG	**WES7E 64bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 64-bit, English; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 16 GB).	
5SWWI7.0726-MUL	**WES7P 32bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 Premium 32-bit, multilanguage; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 8 GB).	
5SWWI7.0826-MUL	**WES7P 64bit APC810 945GME** Microsoft OEM Windows Embedded Standard 7 Premium 64-bit, multilanguage; for APC810 with 945GME chipset; please order CompactFlash separately (minimum 16 GB).	
5SWWI7.0900-MUL	**WES7P 32bit Language Pack DVD**	
5SWWI7.1000-MUL	**WES7P 64bit Language Pack DVD**	

Tabelle 200: Model numbers - Windows Embedded Standard 2009

8.1 General Information

The successor to Windows® XP Embedded has been given the name Windows® Embedded Standard 7. As with previous versions, this embedded operating system offers full system support of Automation PC 620, Automation PC 810, Panel PC 700, Panel PC 800 and Power Panel 500 devices. In addition to brand new features that are also included in Windows ® 7 Professional, Windows® Embedded Standard 7 includes embedded components such as Enhanced Write Filter, File-Based Write Filter, Registry Filter and USB Boot. Windows® Embedded Standard 7 is available in two different versions. The main difference between them has to do with multilanguage support. Windows® Embedded Standard 7 is only available in a single language, whereas Windows® Embedded Standard 7 Premium supports the installation of several languages simultaneously.

With Windows® Embedded Standard 7, Microsoft has made substantial improvements in the area of security. The AppLocker program, available in the premium version, can prevent the execution of unknown or potentially unwanted applications that should be installed over a network or from drives that are directly connected. A tiered approach allows the differentiation between scripts (.ps1, .bat, .cmd, .vbs and .js), installer files (.msi, .msp) and libraries (.dll, .ocx).

AppLocker can also be configured to record undesired activity and display it in the Event Viewer. Windows® Embedded Standard 7 is available in both 32-bit and 64-bit versions, which ensures that even the most demanding applications have the level of support they need.

8.2 Features with WES7 (Windows Embedded Standard 7)

The feature list shows the most important device functions in Windows Embedded Standard 7.

Function	Windows Embedded Standard 7	Windows Embedded Standard 7 Professional
Enhanced write filter (EWF)	✓	✓
File Based Write Filter	✓	✓
Administrator account	✓	✓
User account	Configurable	Configurable
Windows Explorer Shell	✓	✓
Registry filter	✓	✓
Internet Explorer 8.0	✓	✓
Internet Information Service (IIS) 7.0	✓	✓
AntiMalware (Windows Defender)	-	✓
Add-ons (Snipping tool, Sticky Notes)	-	✓
Windows Firewall	✓	✓
.NET Framework 3.5	✓	✓
Remote Desktop Protocol 7.0	✓	✓
File Compression Utility	✓	✓
Windows Installer Service	✓	✓
Windows XP Mode	-	-
Media Player 12	✓	✓
DirectX	✓	✓
Multilingual User Interface Packs in the same image	-	✓
International Components and Language Services	✓	✓
Language Pack Setup	✓	✓
Windows Update	Configurable	Configurable
Windows PowerShell 2.0	✓	✓
Bitlocker	-	✓
Applocker	-	✓
Tablet PC Support	-	✓
Windows Touch	-	✓
Boot from USB Stick	✓	✓
Accessories	✓	✓
Page file	Configurable	Configurable

Table 201: Device functions in Windows Embedded Standard 7

Function	Windows Embedded Standard 7	Windows Embedded Standard 7 Professional
Number of fonts	134	134

Table 201: Device functions in Windows Embedded Standard 7

8.3 Installation

Upon request, Windows Embedded Standard 7 can be preinstalled at B&R Austria on a suitable CompactFlash card (32-Bit: min. 8 GB; 64-Bit: min. 16 GByte). The APC810 system is then automatically configured after it has been switched on for the first time. This procedure takes approximately 30 minutes, and the device will be rebooted a number of times.

8.4 Drivers

All drivers required for operation are preinstalled on the operating system. If an older driver version is installed, the latest version can be downloaded from the B&R homepage (**www.br-automation.com**) and installed. A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration.

8.4.1 Touch screen driver

A touch screen driver will be automatically installed if a touch controller is detected during the Windows Embedded Standard 7 setup.

The touch screen driver must be installed manually if a touch controller was not detected during the Windows Embedded Standard 7 setup or if a an Automation Panel 800/900 has been connected after setup. The driver can be downloaded from the download area on the B&R homepage (**www.br-automation.com**). A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration.

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

9. Automation PC 810 with Windows CE

Model number	Short description	Note
5SWWCE.0826-ENG	**WinCE6.0 Pro APC810 945GME** Microsoft OEM Windows CE 6.0 Professional, English; for APC810 with 945GME chipset; order CompactFlash separately (at least 128 MB).	

Table 202: Oder data - Windows CE

9.1 General information

B&R Windows CE is an operating system which is optimally tailored to B&R's devices. It includes only the functions and modules which are required by each device. This makes this operating system extremely robust and stable. A further advantage of B&R Windows CE compared to other operating systems are the low licensing costs.

9.2 Windows CE 6.0 features

Detailed information about Windows CE for B&R devices can be downloaded in the download area on the B&R homepage (www.br-automation.com).

Features	Windows CE 6.0
Supported screen resolutions	VGA (TFT), SVGA (TFT), XGA (TFT)
Chipset	Intel 945GME
Color depth	16 bit or 65536 colors[1)]
Graphics card driver	Intel® embedded graphics driver
Main memory	Automatic detection and use of up to 512 MB RAM
Boot time / Startup time	Approx. 25 seconds
Screen rotation	not supported
Web browser	Internet Explorer
.NET	Compact Framework
Image size	Approx. 36 MB[2)] , uncompressed
Custom keys	Supported
PVI	Supported
Automation Device Interface	Supported
Remote Desktop Protocol for thin clients	Supported
B&R VNC Viewer	Supported
B&R Task Manager	Supported
B&R Picture Viewer	Supported
Compatible with zenOn	Yes
Compatible with Wonderware	No
Serial interfaces for any use	3
DirectX	No
Audio ports	"Line OUT" and "MIC" are supported. "Line IN" is not supported.

Table 203: Windows CE 6.0 features

1) The color depth depends on the display used.

2) Use the function *"Compress Windows CE Image"* in the B&R Embedded OS Installer to reduce the image size.

9.3 Requirements

The device must fulfill the following criteria to be able run the Windows CE operating system.

- At least 128 MB main memory.
- At least one 128 MB CompactFlash card (size should be specified when ordered).

9.4 Installation

Windows CE is usually preinstalled at the B&R plant.

9.4.1 B&R Embedded OS Installer

The B&R Embedded OS Installer allows you to install existing B&R Windows CE images. The four files (NK.BIN, BLDR, LOGOXRES.BMP, and LOGOQVGA.BMP) must be provided from an already functioning B&R Windows CE installation.

The B&R Embedded OS Installer can be downloaded from the download area on the B&R homepage (**www.br-automation.com**). Further information is available in the online help for the B&R Embedded OS Installer.

10. Automation PC 810 with Automation Runtime

10.1 General information

An integral component of Automation Studio™ is Automation Runtime, the software kernel which allows applications to run on a target system. This runtime environment offers numerous important advantages:

- Guaranteed highest possible performance for the hardware being used
- Runs on all B&R target systems
- Makes the application hardware-independent
- Applications can be easily ported between B&R target systems
- Cyclic system guarantees deterministic behavior
- Configurable jitter tolerance in all task classes
- Supports all relevant programming language such as IEC 61131-3 and C
- Extensive function library conforming to IEC 61131-3 as well as the expanded B&R Automation library
- Integrated into Automation NET. Access to all networks and bus systems via function calls or the Automation Studio™ configuration

10.2 Automation Runtime Windows (ARwin)

The system is supported by ARwin with an AS 2.7 / AR 2.xx upgrade.

The Automation Runtime Dongle must be connected to use ARwin on an Automation PC 810 (see section 10 "B&R Automation Runtime Dongle", on page 414).

10.3 Automation Runtime Embedded (ARemb)

The system is supported by ARemb with an AS 3.0.90 / AR 4.00 upgrade.

11. B&R Automation Device Interface (ADI) - Control Center

The ADI (Automation Device Interface) enables access to specific functions of B&R devices. Settings for this device can be read and edited using the B&R Control Center applet in the control panel.



Figure 174: ADI Control Center screenshots - Examples (symbol photo)

Information:

The displayed temperature and voltage values (e.g. CPU temperature, core voltage, battery voltage) on the corresponding ADI page represent uncalibrated information values. These cannot be used to draw any conclusions about any hardware alarms or error conditions. The hardware components used have automatic diagnostics functions that can be applied in the event of error.

11.1 Functions

Information:

The functions provided by the Automation Device Interface (ADI) - Control Center vary according to device series.

- Adjusting the display-specific parameters of connected Panels
- Reading of device-specific keys
- Activation of device specific LEDs on a foil keypad
- Reading temperatures, fan speeds, statistical data, and switch settings
- Reading user settings and factory settings
- Reading software versions
- Updating and securing firmware
- Creating reports about the current system (support assistance)
- Setting the SDL equalizer value for the SDL cable adjustment
- Configuring an optional mounted UPS
- Change the user serial ID.

Supports following systems:

- Automation PC 620
- Automation PC 810
- Automation PC 820
- Panel PC 700
- Panel PC 725
- Panel PC 800
- Power Panel 100/200
- Power Panel 300/400
- Power Panel 500
- Mobile Panel 40/50
- Mobile Panel 100/200
- Automation Panel 800 (in connection with Automation PCs and Panel PCs)
- Automation Panel 900 (in connection with Automation PCs and Panel PCs)

11.2 Installation

A detailed description of the Control Center can be found in the integrated online help. The B&R Automation Device Interface (ADI) driver (also contains Control Center) can be downloaded for free from the download area on the B&R homepage (**www.br-automation.com**).

1. Download and unzip the ZIP archive

2. Close all applications

3. Run BrSetup.exe (e.g. double-click on it in Explorer).

- or -

1. Right click on BrSetup.inf in explorer and select "Install".

Information:

The ADI driver is already included in the B&R images of embedded operating systems.

If a more current ADI driver version exists (see the B&R homepage download area), it can be installed later. A potentially activated "Enhanced Write Filter (EWF)" must be taken into consideration when installing.

11.3 SDL equalizer setting

1) Start the **Control Center** in the **Control Panel**.

2) Then select the **Display** tab.

3) Click on **Settings**. This opens the following dialog box:



Figure 175: ADI Control Center - SDL equalizer settings

You can change the display's SDL equalizer settings in this dialog box. The equalizer is integrated in the Automation Panel and adapts the DVI signal to various cable lengths. The equalizer value is automatically calculated based on the cable length: You may set a different equalizer value in order to obtain the best possible display quality (e.g. with low-quality cables or poor DVI signal quality).

The value is optimally defined for the cable length when using the "Automatic setting".

The equalizer value can only be changed if the function is supported by Automation Panel 900 (starting with Panel Firmware version 1.04 or higher).

11.4 UPS configuration

Here you can view the status values for an optionally installed B&R APC add-on UPS as well as change, update or save the battery settings for the UPS. You can also configure the system settings for the UPS.



Figure 176: ADI Control Center - UPS settings

Caution!

The installed UPS must be selected and configured in the Control Panel using the energy options in order for battery operation to be supported.

Information:

The UPS service is supported starting with B&R Windows Embedded Version 2.10 or higher.

11.4.1 Installing the UPS service for the B&R APC add-on UPS

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.
3) Under **UPS settings**, click on **System**. This opens the **Power Options** in the **Control Panel**. (The **Power Options** can also be opened directly from the **Control Panel**.)
4) Select the **UPS** tab and click **Select...**.
5) Choose 'Bernecker + Rainer' as manufacturer and 'APC Add-On UPS' as model and then click **Finish**. The value for the COM connection is only required for a serially connected UPS and is ignored by the APC add-on UPS driver.
6) Click on **Apply** to start the UPS service. After a few seconds the UPS status and details are displayed.
7) Click **OK**.

The text field beside **System** (on the **UPS** tab in the **Control Center**) also indicates whether the B&R UPS driver is active.

Information:

Administrator rights are required in order to change the energy options or display the UPS status.

11.4.2 Displaying UPS status values

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.

The displayed values are updated automatically.

Information:

The "reversed battery polarity" status is only displayed in UPS firmware Version 1.08 or higher.

In UPS firmware Version 1.07 or smaller, a change between battery operation and normal operation can lead to communication errors.

3) **Select UPS monitor** to display UPS status changes since the last time the system or UPS driver was started.



Figure 177: ADI Control Center - UPS monitor

The dialog box is updated automatically when the status changes.

To remove a status from the list, click on **delete**.

Information:

The current status of the UPS is also displayed when the UPS service is started in the Windows Control Panel on the UPS page in the energy options.

Information:

In a German version of Windows XP Professional the battery status is displayed as "low" in the energy options, even if the battery is OK (Windows error). In an English version, three battery status levels are displayed: unknown, OK, replace A low battery status is never displayed.

11.4.3 Changing UPS battery settings

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.
3) Under Battery settings, click on **Edit**. Clicking on "Open" opens a dialog box.
4) Select and **open** the file containing the battery settings.



Figure 178: ADI Control Center - UPS battery settings

In this dialog box you can change the settings for the UPS battery.

The changed settings are written to the file by clicking on the **OK** button. The battery settings for the UPS can then be updated with this file.

Information:

To make settings for batteries not from B&R, it is best to make a copy of a file with battery settings from B&R under a new name and make adjust the settings in this file for the battery being used.

Current files with settings for batteries from B&R can be updated using B&R's "Upgrade PPC800 MTCX" software.

Information:

- **The current UPS firmware version 1.10 does not use charge end voltage, deep discharge voltage, lifespan and deep discharge cycles.**
- **Lifespan is only included in version 2 (and higher) of the UPS battery settings and only valid for B&R UPS batteries at 25°C ambient temperature.**
- **Deep discharge cycles are only included in version 3 (and higher) of the UPS battery settings and only valid for B&R UPS batteries.**

Information:

If you would like to change the current battery settings on the UPS, they must first be saved in a file.

11.4.4 Updating UPS battery settings

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.
3) Under **Battery settings**, click on **Update**. Clicking on "Open" opens a dialog box.
4) Select and **open** the file containing the battery settings. The "Download" dialog box is opened.

The transfer can be aborted by clicking on **Cancel** in the Download dialog box. **Cancel** is disabled when the flash memory is being written to.

Caution!

- **The UPS cannot be operated while updating the battery settings.**
- **If the transfer is interrupted, then the procedure must be repeated until the battery settings have been updated successfully. Otherwise battery operation will no longer be possible.**

Deleting the data in flash memory can take several seconds depending on the memory block being used. The progress indicator is not updated during this time.

Information:

The UPS is automatically restarted after a successful download. This can cause a brief failure in the UPS communication.

11.4.5 Saving UPS battery settings

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.
3) Under Battery settings, click on **Save**. "Save under" dialog box opened.
4) Enter a file name or select an existing file and click on **Save**.

Information:

UPS settings can only be saved using UPS firmware version 1.10 and higher.

The transfer can be aborted by clicking on **Cancel** in the Download dialog box.

11.4.6 Configuring UPS system settings

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.
3) Under **UPS** settings, click on **Change**. This opens the following dialog box:



Figure 179: ADI Control Center - UPS settings

Further information regarding the UPD system settings can be found in the Windows help.

Information:

- **UPS settings can only be changed using UPS firmware version 1.10 and higher. If there are no changed settings on the UPS, then the factory or default settings are used.**
- **The UPS is automatically restarted after UPS settings have been changed. This can cause a brief disruption in communication with the UPS.**
- **Administrator rights are required in order to change the energy options or display the UPS status.**

Disabling 8 A current limitation

Information:

It is not UL compliant to switch off the 8 A current limitation on devices during battery operation!

"Low Battery" shutdown caused by an overcurrent > 8 A on devices during battery operation is not UL compliant!

Select the checkbox **Disable current limitation** (8 A).

If current limitation is enabled (checkbox deselected), then the UPS uses battery operation to check whether the UPS battery is discharged with 8 A for longer than 16 seconds. If so, then an overcurrent alarm is sent to the PC.

Information:

Current limitation is only supported with UPS firmware version 1.10 and higher.

Enabling one of the two following options determines how the UPS should perform when an overcurrent alarm occurs:

If **Turn-off within 1 minute** is selected, then the UPS will turn-off within one when an overcurrent alarm occurs.

Warning!

The operating system will not be properly shut down if an overcurrent alarm occurs!

If Perform **"low battery"** shutdown is selected, then the UPS will also signal a "Low battery alarm" in addition to the overcurrent alarm and will turn off after the defined **Low battery shutdown time**. This will allow the operating system to shut down properly when UPS service is enabled.

Changing the UPS shutdown time when battery is low

Enter the **"Low Battery" shutdown time** in seconds. This is the amount of time that the UPS will wait before shutting off the power supply when the battery level is low.

This prevents the UPS battery from becoming too discharged if the Windows UPS service is not enabled and the UPS is therefore not turned off by the operating system.

If the UPS service is enabled, then the UPS will be turned off by the operating system when the battery level is low, based on the Windows UPS service **Shutdown time** (see "Changing additional UPS settings", on page 360). The **low battery** shutdown time will then be ignored.

Information:

- **The low battery shutdown time must be set to at least 60 seconds, so that the operating system has enough time to send the shutdown command to the UPS when the battery level is low (normally occurs after approximately 30 seconds).**
- **The low battery shutdown time can only be set in UPS firmware version 1.10 and later. UPS firmware version 1.08 always uses a turn off delay time of 180 seconds. UPS firmware versions earlier than 1.08 do not shut down automatically when the battery level is low.**

11.4.7 Changing additional UPS settings

1) Open the **Control Center** in the **Control** Panel.
2) Select **UPS** tab.
3) Under **UPS settings**, click on **Advanced**. This opens the following dialog box:



Figure 180: ADI Control Center - Advanced UPS settings

Information:

Administer rights are required in order to display this dialog box.

Change shutdown time for UPS

Under **Windows UPS Service**, you can enter the **turn-off time** in seconds. This is the length of time that the UPS waits before switching off the power supply. When a critical alarm occurs (e.g. at low battery level), the Windows UPS service will send a shutdown command with the turn off delay time to the UPS and will shut down the system.

Information:

This time is evaluated by the Windows UPS Service, but can not be set in the UPS system settings of the energy options. This value should only be changed if the system requires longer than the default setting of 180 seconds to shut down.

Caution!

The time entered must be longer than the time required to shut down the operating system.

Activate UPS messages

Under **B&R UPS driver**, activate the checkbox **UPS status messages**. Any changes to the UPS status will then trigger a message from the B&R UPS driver.

Information:

Shutting down the system is only reported by the Windows UPS Service. The UPS Service also sends other messages if they are activated in the UPS system settings energy options. These messages are only displayed when the Windows Alerter and Windows Messenger[1)] are active and the PC is connected to a network. Additionally, some conditions of the B&R APC add-on UPS are not detected by the Windows UPS Service, and are therefore do not trigger messages (e.g. when there are no battery settings on the UPS). The Windows services can be found by opening the Control Panel and selecting "Services" from the Administrative Tools.

1) The Windows Alerter is supported starting with B&R Windows Embedded Version 2.10 or higher.

If the checkbox **Display UPS status with UPS monitor** is also activated, a new message is not displayed for every change, but only a general message and request for you to start the B&R UPS monitor. As long as the UPS monitor is active, no new messages are displayed.

Information:

Regardless of these options, all changes to the UPS status are logged in Windows event protocol (under "Application").

11.4.8 Procedure following power failure

Overcurrent shutdown

If an overcurrent >8 A is present during battery operation for a duration of 16 seconds, the overcurrent shutdown is executed. A turn-off time of one minute is available to the system.

If the supply is regenerated during this time, then the shut down process is aborted.

Information:

The overcurrent shutdown has the highest priority.

Low battery shutdown

If the LowBatteryFlag is set during power failure, then the "low battery" shutdown is executed, preventing the battery from fully discharging. Once the turn-off time expires (3 minutes by default), the UPS shuts down.

If an "overcurrent" shutdown or "standard" shutdown is detected during the shutdown process, the "low battery" shutdown is replaced by the respective process.

Standard shutdown

The standard shutdown is effective when the UPS service is active, the turn-off time is 3 minutes by default.

If the supply voltage returns during the turn-off time, then the shutdown procedure will be stopped.

If the supply voltage returns during the shutdown process, then the shutdown timer will run until the APC810 enters standby mode and will then reboot the system.

Chapter 5 • Standards and certifications

1. Applicable European directives

- EMC directive 2004/108/EG
- Low-voltage directive 2006/95/EG
- Machine directives 98/37/EG beginning 12/29/2009: 2006/42/EG

2. Overview of standards

Standard	Description
EN 55011 Class A	Electromagnetic compatibility (EMC), radio disturbance product standard, industrial, scientific, and medical high-frequency devices (ISM devices), limit values and measurement procedure; group 1 (devices that do not create HF during material processing) and group 2 (devices that create HF during material processing)
EN 55022 Class A	Electromagnetic compatibility (EMC), radio disturbance characteristics, information technology equipment (ITE devices), limits and methods of measurement
EN 60060-1	High-voltage test techniques - part 1: General specifications and testing conditions
EN 60068-2-1	Environmental testing - part 2: Tests; test A: Dry cold
EN 60068-2-2	Environmental testing - part 2: Tests; test B: Dry heat
EN 60068-2-3	Environmental testing - part 2: Tests; test and guidance: Damp heat, constant
EN 60068-2-6	Environmental testing - part 2: Tests; test: Vibration (sinusoidal)
EN 60068-2-14	Environmental testing - part 2: Tests; test N: Change of temperature
EN 60068-2-27	Environmental testing - part 2: Tests; test and guidance: Shock
EN 60068-2-30	Environmental testing - part 2: Tests; test and guidance: Damp heat, cyclic
EN 60068-2-31	Environmental testing - part 2: Tests; test: Drop and topple, primarily for equipment-type specimens
EN 60068-2-32	Environmental testing - part 2: Tests; test: Free fall
EN 60204-1	Safety of machinery, electrical equipment on machines - part 1: General requirements
EN 60529	Degrees of protection provided by enclosures (IP code)
EN 60664-1	Insulation coordination for equipment within low-voltage systems - part 1: Principles, requirements and tests
EN 60721-3-2	Classification of environmental conditions - part 3: Classification of groups of environmental parameters and their severities, section 2: Transport
EN 60721-3-3	Classification of environmental conditions - part 3: Classification of groups of environmental parameters and their severities, section 3: Stationary use at weather-protected locations

Table 204: Overview of standards

Standard	Description
EN 61000-3-2	Electromagnetic compatibility (EMC) - part 3-2: Limits for harmonic current emissions (equipment input current ≤ 16 A per phase)
EN 61000-3-3	Electromagnetic compatibility (EMC) - part 3-3: Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, equipment with rated current ≤ 16 A per phase, and not subject to conditional connection.
EN 61000-3-11	Electromagnetic compatibility (EMC) - part 3-11: Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, equipment with rated current ≤ 75 A per phase, and subject to conditional connection.
EN 61000-4-2	Electromagnetic compatibility (EMC) - part 4-2: Testing and measuring techniques; electrostatic discharge immunity test
EN 61000-4-3	Electromagnetic compatibility (EMC) - part 4-3: Testing and measuring techniques; radiated radio-frequency electromagnetic field immunity test
EN 61000-4-4	Electromagnetic compatibility (EMC) - part 4-4: Testing and measuring techniques; electrical fast transient/burst immunity test
EN 61000-4-5	Electromagnetic compatibility (EMC) - part 4-5: Testing and measuring techniques; surge immunity test
EN 61000-4-6	Electromagnetic compatibility (EMC) - part 4-6: Testing and measuring techniques; immunity to conducted disturbances, induced by radio-frequency fields
EN 61000-4-8	Electromagnetic compatibility (EMC) - part 4-8: Testing and measuring techniques; power frequency magnetic field immunity test
EN 61000-4-11	Electromagnetic compatibility (EMC) - part 4-11: Testing and measuring techniques; voltage dips, short interruptions and voltage variations immunity tests
EN 61000-4-12	Electromagnetic compatibility (EMC) - part 4-12: Testing and measuring techniques; oscillatory waves immunity test
EN 61000-6-2	Electromagnetic compatibility (EMC), generic immunity standard - part 2: Industrial environment
EN 61000-6-4	Electromagnetic compatibility (EMC), generic emission standard - part 2: Industrial environment
EN 61131-2	Product standard, programmable logic controllers - part 2: Equipment requirements and tests
UL 508	Industrial control equipment (UL = Underwriters Laboratories)
47 CFR	Federal Communications Commission (FCC), 47 CFR Part 15 Subpart B Class A

Table 204: Overview of standards (Forts.)

3. Emission requirements

Emissions	Test carried out according to	Limits according to
Network-related emissions	EN 55011 / EN 55022	EN 61000-6-4: Generic standard (industrial areas)
		EN 55011: Industrial, scientific, and medical (ISM) radio-frequency equipment, class A (industrial areas)
		EN 55022: Information technology equipment (ITE devices), class A (industrial areas)
		EN 61131-2: Programmable logic controllers
		EN 50091-2: Uninterruptible power systems (UPS), class A
		47 CFR Part 15 Subpart B Class A (FCC)
Emissions, Electromagnetic emissions	EN 55011 / EN 55022	EN 61000-6-4: Generic standard (industrial areas)
		EN 55011: Industrial, scientific, and medical (ISM) radio-frequency equipment, class A (industrial areas)
		EN 55022: Information technology equipment (ITE devices), class A (industrial areas)
		EN 61131-2: Programmable logic controllers
		EN 50091-2: Uninterruptible power systems (UPS), class A
		47 CFR Part 15 Subpart B Class A (FCC)
Harmonic currents for devices with an input current of ≤ 16 A per line	EN 61000-3-2	EN 61000-3-2: Limits for harmonic current emissions (equipment input current ≤ 16 A per phase)
Voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, equipment with rated current ≤ 16 A per phase, and not subject to conditional connection.	EN 61000-3-3	EN 61000-3-3: Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, for equipment with rated current less than or equal to ≤ 16 A per phase and not subject to conditional connection, class A/D
Voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, equipment with rated current ≤ 75 A per phase, and subject to conditional connection.	EN 61000-3-11	EN 61000-3-11: Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, for equipment with rated current less than or equal to ≤ 75 A per phase and subject to conditional connection, class A/D

Table 205: Overview of limits and testing guidelines for emissions

3.1 Network-related emissions

Test carried out according to EN 55011 / EN 55022	Limits according to EN 61000-6-4	Limits according to EN 55011 Class A	Limits according to EN 55022 Class A
Power mains connections 150 kHz - 500 kHz	-	79 dB (µV) Quasi-peak value 66 dB (µV) Average	79 dB (µV) Quasi-peak value 66 dB (µV) Average
Power mains connections 500 kHz - 30 MHz	-	73 dB (µV) Quasi-peak value 60 dB (µV) Average	73 dB (µV) Quasi-peak value 60 dB (µV) Average
AC mains connections 150 kHz - 500 kHz	79 dB (µV) Quasi-peak value 66 dB (µV) Average	-	-
AC mains connections 500 kHz - 30 MHz	73 dB (µV) Quasi-peak value 60 dB (µV) Average	-	-
Other connections 150 kHz - 500 kHz	-	-	97 - 87 dB (µV) und 53 - 43 dB (µA) Quasi-peak value 84 - 74 dB (µV) und 40 - 30 dB (µA) Average
Other connections 500 kHz - 30 MHz	-	-	87 dB (µV) and 43 dB (µA) Quasi-peak value 74 dB (µV) and 30 dB (µA) Average
Test carried out according to EN 55011 / EN 55022	**Limits according to EN 61000-6-4**	**Limits according to EN 61131-2**	**Limits according to 47 CFR Part 15 Subpart B class A**
Power mains connections [1)] 150 kHz - 500 kHz	79 dB (µV) Quasi-peak value 66 dB (µV) Average	-	-
Power mains connections 500 kHz - 30 MHz	73 dB (µV) Quasi-peak value 60 dB (µV) Average	-	-
AC mains connections 150 kHz - 500 kHz	-	79 dB (µV) Quasi-peak value 66 dB (µV) Average	79 dB (µV) Quasi-peak value 66 dB (µV) Average
AC mains connections 500 kHz - 30 MHz	-	73 dB (µV) Quasi-peak value 60 dB (µV) Average	73 dB (µV) Quasi-peak value 60 dB (µV) Average

Table 206: Test requirements - Network-related emissions for industrial areas

Other connections 150 kHz - 500 kHz	Only informative For line lengths > 10 m 40 - 30 dB (ÊA) Quasi-peak value 30 - 20 dB (ÊA) Average	-	-
Other connections 500 kHz - 30 MHz	Only informative For line lengths > 10 m 30 dB (ÊA) Quasi-peak value 20 dB (ÊA) Average	-	-

Table 206: Test requirements - Network-related emissions for industrial areas (Forts.)

1) AC network connections only with EN 61131-2

3.2 Emissions, electromagnetic emissions

Test carried out according to EN 55011 / EN 55022	**Limits according to EN 61000-6-4**	**Limits according to EN 55011 Class A**	**Limits according to EN 55022 Class A**
30 MHz - 230 MHz measured at a distance of 10 m	< 40 dB (µV/m) Quasi-peak value	< 40 dB (µV/m) Quasi-peak value	< 40 dB (µV/m) Quasi-peak value
230 MHz - 1 GHz measured at a distance of 10 m	< 47 dB (µV/m) Quasi-peak value	< 47 dB (µV/m) Quasi-peak value	< 47 dB (µV/m) Quasi-peak value
Test carried out according to EN 55011 / EN 55022	**Limits according to EN 61131-2**	**Limits according to EN 50091-2 Class A**	
30 MHz - 230 MHz measured at a distance of 10 m	< 40 dB (µV/m) Quasi-peak value	< 40 dB (µV/m) Quasi-peak value	
230 MHz - 1 GHz measured at a distance of 10 m	< 47 dB (µV/m) Quasi-peak value	< 47 dB (µV/m) Quasi-peak value	
Test carried out	**Limits according to 47 CFR Part 15 Subpart B class A**		
30 MHz - 88 MHz measured at a distance of 10 m	< 90 dB (µV/m) Quasi-peak value		
88 MHz - 216 MHz measured at a distance of 10 m	< 150 dB (µV/m) Quasi-peak value		
216 MHz - 960 MHz measured at a distance of 10 m	< 210 dB (µV/m) Quasi-peak value		
> 960 MHz measured at a distance of 10 m	< 300 dB (µV/m) Quasi-peak value		

Table 207: : Test requirements - Electromagnetic emissions for industrial areas

4. Requirements for immunity to disturbances

Immunity	Test carried out according to	Limits according to
Electrostatic discharge (ESD)	EN 61000-4-2	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity to high-frequency electromagnetic fields (HF field)	EN 61000-4-3	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity to high-speed transient electrical disturbances (burst)	EN 61000-4-4	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity to surge voltages	EN 61000-4-5	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity to conducted disturbances	EN 61000-4-6	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity against magnetic fields with electrical frequencies	EN 61000-4-8	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity to voltage dips, short-term interruptions and voltage fluctuations	EN 61000-4-11	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers
Immunity to damped vibration	EN 61000-4-12	EN 61000-6-2: Generic standard (industrial areas)
		EN 61131-2: Programmable logic controllers

Table 208: Overview of limits and testing guidelines for immunity

Evaluation criteria according to EN 61000-6-2

Criteria A:
The operating equipment must continue to work as intended **during** the test. There should be no interference in the operating behavior and no system failures below a minimum operating quality as defined by the manufacturer.

Criteria B:
The operating equipment must continue to work as directed **after** the test. There should be no interference in the operating behavior and no system failures below a minimum operating quality as defined by the manufacturer.

Criteria C:
A temporary function failure is permitted if the function restores itself, or the function can be restored by activating configuration and control elements.

Criteria D:
Deterioration or failure of the function, which can no longer be established (operating equipment destroyed).

4.1 Electrostatic discharge (ESD)

Test carried out according to EN 61000-4-2	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
Contact discharge to powder-coated and bare metal housing parts	±4 kV, 10 discharges, criteria B	±4 kV, 10 discharges, criteria B	
Discharge through the air to plastic housing parts	±8 kV, 10 discharges, criteria B	±8 kV, 10 discharges, criteria B	

Table 209: Test requirements - Electrostatic discharge (ESD)

4.2 High-frequency electromagnetic fields (HF field)

Test carried out according to EN 61000-4-3	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
Housing, completely wired	80 MHz - 1 GHz, 10 V/m, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	2 GHz - 2.7 GHz, 1 V/m, 1.4 GHz - 2 GHz, 3 V/m, 80 MHz - 1 GHz, 10 V/m, 80% amplitude modulation at 1 kHz, duration 3 seconds, criteria A	

Table 210: Test requirements - High-frequency electromagnetic fields (HF field)

4.3 High-speed transient electrical disturbances (burst)

Test carried out according to EN 61000-4-4	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
AC mains inputs/outputs	±2 kV, criteria B	-	
AC power inputs	-	±2 kV, criteria B	
AC power outputs	-	±1 kV, criteria B	
DC power I/O >10 m [1)]	±2 kV, criteria B	-	
DC power inputs >10 m	-	±2 kV, criteria B	
DC power outputs >10 m	-	±1 kV, criteria B	
Functional ground connections, signal lines and I/Os >3 m	±1 kV, criteria B	±1 kV, criteria B	
Unshielded AC I/O >3 m	-	±2 kV, criteria B	
Analog I/O	±1 kV, criteria B	±1 kV, criteria B	

Table 211: Test requirements - High-speed transient electrical disturbances (burst)

1) For EN 55024 without length limitation.

4.4 Surges

Test carried out according to EN 61000-4-5	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
AC power I/O, L to L	±1 kV, criteria B	±1 kV, criteria B	
AC power I/O, L to PE	±2 kV, criteria B	±2 kV, criteria B	
DC power I/O, L+ to L-, >10 m	±0.5 kV, criteria B	-	
DC power I/O, L to PE, >10 m	±0.5 kV, criteria B	-	
DC power inputs, L+ to L-	-	±0.5 kV, criteria B	
DC power inputs, L to PE	-	±1 kV, criteria B	
DC power outputs, L+ to L-	-	±0.5 kV, criteria B	
DC power outputs, L to PE	-	±0.5 kV, criteria B	
Signal connections >30 m	±1 kV, criteria B	±1 kV, criteria B	
All shielded cables	-	±1 kV, criteria B	

Table 212: Test requirements - Surge voltages

4.5 Conducted disturbances

Test carried out according to EN 61000-4-6	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
AC mains inputs/outputs	150 kHz - 80 MHz, 10 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	150 kHz - 80 MHz, 3 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	
DC mains inputs/outputs	150 kHz - 80 MHz, 10 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	150 kHz - 80 MHz, 3 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	
Functional ground connections	150 kHz - 80 MHz, 10 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	150 kHz - 80 MHz, 3 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	
Signal connections >3 m	150 kHz - 80 MHz, 10 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	150 kHz - 80 MHz, 3 V, 80% amplitude modulation with 1 kHz, length 3 seconds, criteria A	

Table 213: Test requirements - Conducted disturbances

4.6 Magnetic fields with electrical frequencies

Test carried out according to EN 61000-4-8	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
Test direction x, test in the field of an induction coil 1 m x 1 m	30 A/m, criteria A	30 A/m, criteria A	
Test direction y, test in the field of an induction coil 1 m x 1 m	30 A/m, criteria A	30 A/m, criteria A	
Test direction z, test in the field of an induction coil 1 m x 1 m	30 A/m, criteria A	30 A/m, criteria A	

Table 214: Test requirements - Magnetic fields with electrical frequencies

4.7 Voltage dips, fluctuations and short-term interruptions

Test carried out according to EN 61000-4-11	Limits according to EN 61000-6-2	Limits according to EN 61131-2	
AC power inputs	Voltage dip 70% (30% reduction), 0.5 periods, criteria B	-	
AC power inputs	Voltage dip 40% (60% reduction), 5 periods, criteria C	-	
AC power inputs	Voltage dip 40% (60% reduction), 50 periods, criteria C	-	
AC power inputs	Voltage interruptions < 5% (> 95% reduction), 250 periods, criteria C	-	
AC power inputs	-	20 interruptions, 0.5 periods, criteria A	
DC power inputs	-	20 interruptions for 10 ms < UN - 15%, criteria A	

Table 215: Test requirements - Voltage dips, fluctuations, and short-term interruptions

4.8 Damped vibration

Test carried out according to EN 61000-4-12	Limits according to EN 61131-2		
Mains inputs/outputs, L to L	±1 kV, 1 MHz, repeat rate 400/seconds, length 2 seconds, connection lengths 2 m, criteria B		
Power I/O, L to PE	±2.5 kV, 1 MHz, repeat rate 400/seconds, length 2 seconds, connection lengths 2 m, criteria B		

Table 216: Test requirements - Damped vibration

5. Mechanical conditions

Vibration	Test carried out according to	Limits according to
Vibration operation	EN 60068-2-6	EN 61131-2: Programmable logic controllers
		EN 60721-3-3 class 3M4
Vibration during transport (packaged)	EN 60068-2-6	EN 60721-3-2 class 2M1
		EN 60721-3-2 class 2M2
		EN 60721-3-2 class 2M3
Shock during operation	EN 60068-2-27	EN 61131-2: Programmable logic controllers
		EN 60721-3-3 class 3M4
Shock during transport (packaged)	EN 60068-2-27	EN 60721-3-2 class 2M1
		EN 60721-3-2 class 2M2
		EN 60721-3-2 class 2M3
Toppling (packaged)	EN 60068-2-31	EN 60721-3-2 class 2M1
		EN 60721-3-2 class 2M2
		EN 60721-3-2 class 2M3
Free fall (packaged)	EN 60068-2-32	EN 61131-2: Programmable logic controllers

Table 217: Overview of limits and testing guidelines for vibration

5.1 Vibration operation

Test carried out according to EN 60068-2-6	Limits according to EN 61131-2		Limits according to EN 60721-3-3 class 3M4		
Vibration during operation: Uninterrupted duty with moveable frequency in all 3 axes (x, y, z), 1 octave per minute	10 sweeps for each axis		10 sweeps for each axis		
	Frequency	**Limit value**	**Frequency**	**Limit value**	
	5 - 9 Hz	Amplitude 3.5 mm	2 - 9 Hz	Amplitude 3 mm	
	9 - 150 Hz	Acceleration 1 g	9 - 200 Hz	Acceleration 1 g	

Table 218: Test requirements - Vibration during operation

5.2 Vibration during transport (packaged)

Test carried out according to EN 60068-2-6	Limits according to EN 60721-3-2 class 2M1		Limits according to EN 60721-3-2 class 2M2		Limits according to EN 60721-3-2 class 2M3	
Vibration during transport: Uninterrupted duty with moveable frequency in all 3 axes (x, y, z)	10 sweeps for each axis, packaged		10 sweeps for each axis, packaged		10 sweeps for each axis, packaged	
	Frequency	**Limit value**	**Frequency**	**Limit value**	**Frequency**	**Limit value**
	2 - 9 Hz	Amplitude 3.5 mm	2 - 9 Hz	Amplitude 3.5 mm	2 - 8 Hz	Amplitude 7.5 mm
	9 - 200 Hz	Acceleration 1 g	9 - 200 Hz	Acceleration 1 g	8 - 200 Hz	Acceleration 2 g
	200 - 500 Hz	Acceleration 1.5 g	200 - 500 Hz	Acceleration 1.5 g	200 - 500 Hz	Acceleration 4 g

Table 219: Test requirements - Vibration during transport (packaged)

5.3 Shock during operation

Test carried out according to EN 60068-2-27	Limits according to EN 61131-2	Limits according to EN 60721-3-3 class 3M4	
Shock during operation: Pulse (half-sine) stress in all 3 axes (x, y, z)	Acceleration 15 g, length 11 ms, 18 shocks	Acceleration 10 g, Duration 11 ms	

Table 220: Test requirements - Shock during operation

5.4 Shock during transport (packaged)

Test carried out according to EN 60068-2-27	Limits according to EN 60721-3-2 class 2M1	Limits according to EN 60721-3-2 class 2M2	Limits according to EN 60721-3-2 class 2M3
Pulse (half-sine) stress in all 3 axes (x, y, z)	Acceleration 10 g, Duration 11 ms, each 3 shocks, packaged	Acceleration 30 g, Duration 6 ms, each 3 shocks, packaged	Acceleration 100 g, Duration 6 ms, each 3 shocks, packaged

Table 221: Test requirements - Shock during transport

5.5 Toppling

Test carried out according to EN 60068-2-31	Limits according to EN 60721-3-2 class 2M1		Limits according to EN 60721-3-2 class 2M2		Limits according to EN 60721-3-2 class 2M3	
Drop and topple	Devices: Drop/topple on each edge, packaged		Devices: Drop/topple on each edge, packaged		Devices: Drop/topple on each edge, packaged	
	Weight	**Required**	**Weight**	**Required**	**Weight**	**Required**
	< 20 kg	Yes	< 20 kg	Yes	< 20 kg	Yes
	20 - 100 kg	-	20 - 100 kg	Yes	20 - 100 kg	Yes
	> 100 kg	-	> 100 kg	-	> 100 kg	Yes

Table 222: Test requirements - Toppling

5.6 Free fall (packaged)

Test carried out according to EN 60068-2-32	Limits according to EN 61131-2		Limits according to EN 60721-3-2 class 2M1		Limits according to EN 60721-3-2 class 2M2		Limits according to EN 60721-3-2 class 2M3	
Free fall	Devices with delivery packaging each with 5 fall tests		Devices packaged		Devices packaged		Devices packaged	
	Weight	**Height**	**Weight**	**Height**	**Weight**	**Height**	**Weight**	**Height**
	< 10 kg	1.0 m	< 20 kg	0.25 m	< 20 kg	1.2 m	< 20 kg	1.5 m
	10 - 40 kg	0.5 m	20 - 100 kg	0.25 m	20 - 100 kg	1.0 m	20 - 100 kg	1.2 m
	> 40 kg	0.25 m	> 100 kg	0.1 m	> 100 kg	0.25 m	> 100 kg	0.5 m
	Devices with product packaging each with 5 fall tests							
	Weight	**Height**						
	< 10 kg	0.3 m						
	10 - 40 kg	0.3 m						
	> 40 kg	0.25 m						

Table 223: Test requirements - Free fall

6. Climate conditions

Temperature / humidity	Test carried out according to	Limits according to
Worst case operation	UL 508	UL 508: Industrial control equipment EN 61131-2: Programmable logic controllers
Dry heat	EN 60068-2-2	EN 61131-2: Programmable logic controllers
Dry cold	EN 60068-2-1	EN 61131-2: Programmable logic controllers
Large temperature fluctuations	EN 60068-2-14	EN 61131-2: Programmable logic controllers
Temperature fluctuations in operation	EN 60068-2-14	EN 61131-2: Programmable logic controllers
Humid heat, cyclic	EN 60068-2-30	EN 61131-2: Programmable logic controllers
Humid heat, constant (storage)	EN 60068-2-3	EN 61131-2: Programmable logic controllers

Table 224: Overview of limits and testing guidelines for temperature and humidity

6.1 Worst case operation

Test carried out according to UL 508	Limits according to UL 508	Limits according to EN 61131-2	
Worst case during operation. Operation of the device with the max. ambient temperature specified in the data sheet at the max. specified load	3 hours at max. ambient temperature (min. +40°C) duration approx. 5 hours	3 hours at max. ambient temperature (min. +40°C) duration approx. 5 hours	

Table 225: Test requirements - Worst case during operation

6.2 Dry heat

Test carried out according to EN 60068-2-2	Limits according to EN 61131-2		
Dry heat	16 hours at +70°C for 1 cycle, then 1 hour acclimatization and function testing, duration approximately 17 hours		

Table 226: Test requirements - Dry heat

6.3 Dry cold

Test carried out according to EN 60068-2-1	Limits according to EN 61131-2		
Dry cold	16 hours at -40°C for 1 cycle, then 1 hour acclimatization and function testing, duration approximately 17 hours		

Table 227: Test requirements - Dry cold

6.4 Large temperature fluctuations

Test carried out according to EN 60068-2-14	Limits according to EN 61131-2		
Large temperature fluctuations	3 hours at -40°C and 3 hours at +70°C, 2 cycles, then 2 hours acclimatization and function testing, duration approximately 14 hours		

Table 228: Test requirements - Large temperature fluctuations

6.5 Temperature fluctuations in operation

Test carried out according to EN 60068-2-14	Limits according to EN 61131-2		
Open devices: These can also have a housing and are installed in switching cabinets	3 hours at +5°C and 3 hours at 55°C, 5 cycles, temperature gradient 3°C / min, the unit is occasionally supplied with voltage during testing, duration approximately 30 hours		
Closed devices: These are devices whose data sheet specifies a surrounding housing (enclosure) with the corresponding safety precautions	3 hours at +5°C and 3 hours at +55°C, 5 cycles, temperature gradient 3°C / min, the unit is occasionally supplied with voltage during testing, duration approximately 30 hours		

Table 229: Test requirements - Temperature fluctuations during operation

6.6 Humid heat, cyclic

Test carried out according to EN 60068-2-30	Limits according to EN 61131-2		
Alternating climate	24 hours at +25°C / +55°C and 97% / 83% RH, 2 cycles, then 2 hours acclimatization, function testing and insulation, duration approximately 50 hours		

Table 230: Test requirements - Humid heat, cyclic

6.7 Humid heat, constant (storage)

Test carried out according to EN 60068-2-3	Limits according to EN 61131-2		
Humid heat, constant (storage)	48 hours at +40°C and 92.5% RH, then insulation test within 3 hours, duration approximately 49 hours		

Table 231: Test requirements - Humid heat, constant (storage)

7. Safety

Safety	Test carried out according to	Limits according to
Ground resistance	EN 61131-2	EN 60204-1: Electrical equipment of machines
		EN 61131-2: Programmable logic controllers
Insulation resistance		EN 60204-1: Electrical equipment of machines
High voltage	EN 60060-1	EN 61131-2: Programmable logic controllers
		UL 508: Industrial control equipment
Residual voltage	EN 61131-2	EN 60204-1: Electrical equipment of machines
		EN 61131-2: Programmable logic controllers
Leakage current		VDE 0701-1: Service, changes and testing of electrical devices
Overload	UL 508	EN 61131-2: Programmable logic controllers
		UL 508: Industrial control equipment
Simulation component defect	UL 508	EN 61131-2: Programmable logic controllers
		UL 508: Industrial control equipment
Voltage range		EN 61131-2: Programmable logic controllers

Table 232: Overview of limits and testing guidelines for safety

7.1 Ground resistance

Test carried out according to EN 61131-2	Limits according to EN 60204-1[1)]		Limits according to EN 61131-2
Ground resistance: housing (from any metal part to the ground terminal)	Smallest effective cross section of the protective ground conductor for the branch being tested	Maximum measured voltage drop at a test current of 10 A	Test current 30 A for 2 min, < 0.1 Ω
	1.0 mm²	3.3 V	
	1.5 mm²	2.6 V	
	2.5 mm²	1.9 V	
	4.0 mm²	1.4 V	
	> 6.0 mm²	1.0 V	

Table 233: Test requirements - Ground resistance

1) See EN 60204-1:1997 page 62, table 9.

7.2 Insulation resistance

Test carried out	Limits according to EN 60204-1[1)]		
Insulation resistance: main circuits to protective ground conductor	> 1 MΩ at 500 V DC voltage		

Table 234: Test requirements - Insulation resistance

1) See EN 60204-1:1997 page 62, table 9.

7.3 High voltage

Test carried out according to EN 60060-1	Limits according to EN 61131-2[1)]				Limits according to UL 508		
High voltage: Primary circuit to secondary circuit and to protective ground circuit (transformers, coils, varistors, capacitors and components used to protect against overvoltage can be removed before the test)	Input voltage	Test voltage			Input voltage	Test voltage	
		1.2/50 µs voltage surge peak	AC, 1 min	DC, 1 min		AC, 1 min	DC, 1 min
	0 - 50 VAC 0 - 60 VDC	850 V	510 V	720 V	≤ 50 V	500 V	707 V
	50 - 100 VAC 60 - 100 VDC	1360 V	740 V	1050 V	> 50 V	1000 V + 2 x U_N	(1000 V + 2 x U_N) x 1.414
	100 - 150 VAC 100 - 150 VDC	2550 V	1400 V	1950 V			
	150 - 300 VAC 150 - 300 VDC	4250 V	2300 V	3250 V			
	300 - 600 VAC 300 - 600 VDC	6800 V	3700 V	5250 V			
	600 - 1000 VAC 600 - 1000 VDC	10200 V	5550 V	7850 V			

Table 235: Test requirements - High voltage

1) See EN 61131-2:2003 page 104, table 59.

7.4 Residual voltage

Test carried out according to EN 61131-2	Limits according to EN 60204-1	Limits according to EN 61131-2	
Residual voltage after switching off	< 60 V after 5 sec (active parts) < 60 V after 1 sec (plug pins)	< 60 V after 5 sec (active parts) < 60 V after 1 sec (plug pins)	

Table 236: Test requirements - Residual voltage

7.5 Leakage current

Test carried out	Limits according to VDE 0701-1		
Leakage current: Phase to ground	< 3,5 mA		

Table 237: Test requirements - Leakage current

7.6 Overload

Test carried out according to UL 508	Limits according to EN 61131-2	Limits according to UL 508	
Overload of transistor outputs	50 switches, 1.5 I_N, 1 sec on / 9 sec off	50 switches, 1.5 I_N, 1 sec on / 9 sec off	

Table 238: Test requirements - Overload

7.7 Defective component

Test carried out according to UL 508	Limits according to EN 61131-2	Limits according to UL 508	
Simulation of how components in power supply became defective	Non-flammable surrounding cloth No contact with conductive parts	Non-flammable surrounding cloth No contact with conductive parts	

Table 239: Test requirements - Defective component

7.8 Voltage range

Test carried out according to	Limits according to EN 61131-2			
Supply voltage	Measurement value	Tolerance min/max		
	24 VDC 48 VDC 125 VDC	-15% +20%		
	24 VAC 48 VAC 100 VAC 110 VAC 120 VAC 200 VAC 230 VAC 240 VAC 400 VAC	- 15% +10%		

Table 240: Test requirements - Voltage range

8. Other tests

Other tests	Test carried out according to	Limits according to
Protection	-	EN 60529: Degrees of protection provided by enclosures (IP code)
Degree of pollution	-	EN 60664-1: Insulation coordination for equipment within low-voltage systems - part 1: Principles, requirements and tests

Table 241: Overview of limits and testing guidelines for other tests

8.1 Protection

Test carried out according to	Limits according to EN 60529		
Protection of the operating equipment	IP2. Protection against large solid foreign bodies 12.5 mm diameter		
Protection of personnel	IP2. Protection against touching dangerous parts with fingers		
Protection against water permeation with damaging consequences	IP.0 Not protected		

Table 242: Test requirements - Protection

9. International certifications

B&R products and services comply with applicable standards. They are international standards from organizations such as ISO, IEC and CENELEC, as well as national standards from organizations such as UL, CSA, FCC, VDE, ÖVE, etc. We give special consideration to the reliability of our products in an industrial environment.

Certifications	
USA and Canada	All important B&R products are tested and listed by Underwriters Laboratories and checked quarterly by a UL inspector. This mark is valid for the USA and Canada and simplifies certification of your machines and systems in these areas.
Europe	All harmonized EN standards for the applicable directives are met.

Table 243: International Certifications

Chapter 6 • Accessories

1. Overview

Model number	Short description	Note
0TB103.9	**Plug 24V 5.08 3-pin screw clamp** 24 VDC 3-pin connector, female. Screw clamp, 3.31 mm², protected against vibration by the screw flange.	
0TB103.91	**Plug 24V 5.08 3-pin cage clamp** 24 VDC 3-pin connector, female. Cage clamps, 3.31 mm², protected against vibration by the screw flange.	
0AC201.91	**Lithium batteries, 4 pcs**. Lithium batteries, 4 pcs., 3 V / 950 mAh, button cell	
4A0006.00-000	**Lithium battery, 1 pc.** Lithium battery, 1 pc., 3 V / 950 mAh, button cell	
5CFCRD.0512-04	**CompactFlash 512 MB B&R** CompactFlash card with 512 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.1024-04	**CompactFlash 1024 MB B&R** CompactFlash card with 1024 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.2048-04	**CompactFlash 2048 MB B&R** CompactFlash card with 2048 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.4096-04	**CompactFlash 4096 MB B&R** CompactFlash card with 4096 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.8192-04	**CompactFlash 8192 MB B&R** CompactFlash card with 8192 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.016G-04	**16 GB B&R CompactFlash card** CompactFlash card with 16 GB SLC NAND flash and IDE/ATA interface	
5CFCRD.0064-03	**CompactFlash 64 MB SSI** CompactFlash card with 64 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.0128-03	**CompactFlash 128 MB SSI** CompactFlash card with 128 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.0256-03	**CompactFlash 256 MB SSI** CompactFlash card with 256 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.0512-03	**CompactFlash 512 MB SSI** CompactFlash card with 512 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.1024-03	**CompactFlash 1024 MB SSI** CompactFlash card with 1024 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.2048-03	**CompactFlash 2048 MB SSI** CompactFlash card with 2048 MB SLC NAND flash and IDE/ATA interface	
5CFCRD.4096-03	**CompactFlash 4096 MB SSI** CompactFlash card with 4096 MB SLC NAND flash and IDE/ATA interface	

Table 244: Model numbers - Accessories

Model number	Short description	Note
5CFCRD.8192-03	**CompactFlash 8192 MB SSI** CompactFlash card with 8192 MB SLC NAND flash and IDE/ATA interface	
5MMUSB.2048-00	**USB flash drive 2 GB SanDisk** USB 2.0 flash drive 2 GB	
5MMUSB.2048-01	**USB flash drive 2 GB B&R** USB 2.0 flash drive 2 GB	
5MD900.USB2-01	**USB 2.0 drive DVD-RW/CD-RW FDD CF USB** USB 2.0 drive combination; Consists of DVD-R/RW/DVD+R/RW/CD-RW, FDD, CompactFlash slot (type II), USB connection (type A front side, type B back side); 24 VDC.	
5A5003.03	**Front cover for the USB Media Drive 5MD900.USB2-01** Front cover for the remote USB 2.0 drive combination 5MD900.USB2-01.	
1A4600.10	**B&R Automation Runtime ARwin, incl. License Label and Security Key**	
1A4600.10-2	**B&R Automation Runtime ARwin, ARNC0**	
1A4600.10-3	**B&R Automation Runtime ARwin+PVIControls, incl. License Label and Security Key**	
1A4600.10-4	**B&R Automation Runtime ARwin+ARNC0+PVIControls**	
5AC600.UPSI-00	**Add-on UPS module** Order UPS module for Automation PC, cable (5CAUPS.0005-00 or 5CAUPS.0030-00) and battery unit (5AC600.UPSB-00) separately.	
5AC600.UPSB-00	**Battery unit 5 Ah** UPS battery unit for the add-on UPS module	
5CAUPS.0005-00	**UPS cable 0.5 m** Connection cable between add-on UPS module and UPS battery unit, length 0.5 meters	
5CAUPS.0030-00	**UPS cable 3 m** Connection cable between add-on UPS module and UPS battery unit, length 3 meters	
5CADVI.0018-00	**DVI-D cable 1.8 m** Single cable, DVI-D/m:DVI-D/m; length: 1.8 m	
5CADVI.0050-00	**DVI-D cable 5 m** Single cable, DVI-D/m:DVI-D/m; length: 5 m	
5CADVI.0100-00	**DVI-D cable 10 m** Single cable, DVI-D/m:DVI-D/m; length: 10 m	
5CASDL.0018-00	**SDL cable 1.8 m** SDL cable for a fixed type of layout; length: 1.8 m	
5CASDL.0018-01	**SDL cable 1.8 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 1.8 m	
5CASDL.0018-03	**SDL flex cable 1.8 m** SDL cable for fixed and flexible type of layout; length: 1.8 m	
5CASDL.0050-00	**SDL cable 5 m** SDL cable for a fixed type of layout; length: 5 m	
5CASDL.0050-01	**SDL cable 5 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 5 m	
5CASDL.0050-03	**SDL flex cable 5 m** SDL cable for fixed and flexible type of layout; length: 5 m	
5CASDL.0100-00	**SDL cable 10 m** SDL cable for a fixed type of layout; length: 10 m	
5CASDL.0100-01	**SDL cable 10 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 10 m	

Table 244: Model numbers - Accessories

Model number	Short description	Note
5CASDL.0100-03	**SDL flex cable 10 m** SDL cable for fixed and flexible type of layout; length: 10 m	
5CASDL.0150-00	**SDL cable 15 m** SDL cable for a fixed type of layout; length: 15 m	
5CASDL.0150-01	**SDL cable 15 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 15 m	
5CASDL.0150-03	**SDL flex cable 15 m** SDL cable for fixed and flexible type of layout; length: 15 m	
5CASDL.0200-00	**SDL cable 20 m** SDL cable for a fixed type of layout; length: 20 m	
5CASDL.0200-03	**SDL flex cable 20 m** SDL cable for fixed and flexible type of layout; length: 20 m	
5CASDL.0250-00	**SDL cable 25 m** SDL cable for a fixed type of layout; length: 25 m	
5CASDL.0250-03	**SDL flex cable 25 m** SDL cable for fixed and flexible type of layout; length: 25 m	
5CASDL.0300-00	**SDL cable 30 m** SDL cable for a fixed type of layout; length: 30 m	
5CASDL.0300-03	**SDL flex cable 30 m** SDL cable for fixed and flexible type of layout; length: 30 m	
5CASDL.0300-13	**SDL flex cable with extender 30 m** SDL cable with extender for fixed and flexible type of layout; length: 30 m	
5CASDL.0400-13	**SDL flex cable with extender 40 m** SDL cable with extender for fixed and flexible type of layout; length: 40 m	
9A0014.02	**RS232 cable DB9/f:DB9/m 1.8 m** RS232 extension cable for remote operation of a display unit with touch screen; length 1.8 m.	
9A0014.05	**RS232 cable DB9/f:DB9/m 5 m** RS232 extension cable for remote operation of a display unit with touch screen; length 5 m.	
9A0014.10	**RS232 cable DB9/f:DB9/m 10 m** RS232 extension cable for remote operation of a display unit with touch screen; length 10 m.	
5CAUSB.0018-00	**USB 2.0 cable, A/m:B/m 1.8 m** USB 2.0 connection cable; plug type A - type B; length 1.8 m	
5CAUSB.0050-00	**USB 2.0 cable, A/m:B/m 5 m** USB 2.0 connection cable; plug type A - type B; length 5 m	
5CAMSC.0001-00	**APC810 internal supply cable**	
5ACPCI.ETH1-01	**PCI Ethernet card 10/100** half size PCI Ethernet card, 1 Ethernet connection	
5ACPCI.ETH3-01	**PCI Ethernet card 10/100 3port** half size PCI Ethernet card, 3 Ethernet connections	
0PS102.0	**Power supply, 1-phase, 2.1 A** 24 VDC power supply, 1-phase, 2.1 A, input 100-240 VAC, wide range, DIN rail mounting	
0PS104.0	**Power supply, 1-phase, 4.2 A** 24 VDC power supply, 1 phase, 4.2 A, input 115/230 VAC, auto select, DIN rail mounting	
0PS105.1	**Power supply, 1-phase, 5 A** 24 VDC power supply, 1 phase, 5 A, input 115/230 VAC, manual select, DIN rail mounting	

Table 244: Model numbers - Accessories

Model number	Short description	Note
0PS105.2	**Power supply, 1-phase, 5 A, redundant** 24 VDC power supply, 1 phase, 5 A, redundant through parallel operation, input 115/230 VAC, manual select, DIN rail mounting	
0PS110.1	**Power supply, 1-phase, 10 A** 24 VDC power supply, 1 phase, 10 A, input 115/230 VAC, manual select, DIN rail mounting	
0PS110.2	**Power supply, 1-phase, 10 A, redundant** 24 VDC power supply, 1 phase, 10 A, redundant through parallel operation, input 115/230 VAC, manual select, DIN rail mounting	
0PS120.1	**Power supply, 1-phase, 20 A** 24 VDC power supply, 1 phase, 20 A, input 115/230 VAC, auto select, DIN rail mounting	
0PS305.1	**Power supply, 3-phase, 5 A** 24 VDC power supply, 3-phase, 5 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	
0PS310.1	**Power supply, 3-phase, 10 A** 24 VDC power supply, 3-phase, 10 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	
0PS320.1	**Power supply, 3-phase, 20 A** 24 VDC power supply, 3-phase, 20 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	
0PS340.1	**Power supply, 3-phase, 40 A** 24 VDC power supply, 3-phase, 40 A, input 400..500 VAC (3 phases), wide range, DIN rail mounting	
5AC801.FA01-00	**APC810 replacement fan filter for system units with 1CS 5 pcs**	
5AC801.FA02-00	**APC810 replacement fan filter for system units with 2CS 5 pcs**	
5AC801.FA03-00	**APC810 replacement fan filter for system units with 3CS 5 pcs**	
5AC801.FA05-00	**APC810 replacement fan filter for system units with 5CS 5 pcs**	
5AC900.1000-00	**Adapter DVI-A/m to CRT DB15HD/f** Adapter DVI (plug) to CRT (socket), for connecting a standard monitor to a DVI-I interface.	
5AC801.FRAM-00	**HDD replacement tray** APC810 SATA hard disk replacement tray	
5AC801.RDYR-01	**APC810 Ready relay /2** Ready relay for APC810 for installation on an add-on UPS slot	
5SWHMI.0000-00	**HMI Drivers & Utilities DVD**	

Table 244: Model numbers - Accessories

2. TB103 3-pin supply voltage connector

2.1 General information

This single row 3-pin terminal block is mainly used to connect the supply voltage.

2.2 Order data

Model number	Description	Figure
0TB103.9	Plug for the 24 V supply voltage (screw clamps)	0TB103.9 0TB103.91
0TB103.91	Plug for the 24 V supply voltage (cage clamps)	

Table 245: Order data - Supply plug

2.3 Technical data

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Name	0TB103.9	0TB103.91
Number of pins	3	
Type of terminal	Screw clamps	Cage clamps
Distance between contacts	5.08 mm	

Table 246: Technical data - TB103 supply plug

Name	0TB103.9	0TB103.91
Resistance between contacts	≤ 5 mΩ	
Nominal voltage according to VDE / UL,CSA	250 V / 300 V	
Current load according to VDE / UL,CSA	14.5 A / 10 A per contact	
Terminal size	0.08 mm² - 3.31 mm²	
Cable type	Copper wires only (no aluminum wires!)	

Table 246: Technical data - TB103 supply plug (Forts.)

3. Replacement CMOS batteries

The lithium battery is needed for buffering the BIOS CMOS data, the real-time clock (RTC), and SRAM data.

3.1 Order data

Model number	Description	Figure
0AC201.91	Lithium batteries, 4 pcs., 3 V / 950 mAh button cell	
4A0006.00-000	Lithium battery, 1 piece, 3 V / 950 mAh button cell	

Table 247: Order data Lithium batteries

3.2 Technical data

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Features	0AC201.91	4A0006.00-000
Capacity	950 mAh	
Voltage	3 V	
Self discharge at 23°C	< 1% per year	
Storage time	Max. 3 years at 30° C	
Environmental characteristics		
Storage temperature	-20 to +60°C	
Relative humidity	0 to 95% (non-condensing)	

Table 248: Technical data - Lithium batteries

4. Replacement fan

Information:

The fan filters are subject to wear, and should be checked with appropriate frequency to determine whether the air flow provides sufficient cooling. An exchange or cleaning of the filter kit is appropriate at that time.



Figure 181: Replacement fan

Model number	Short description	Note
5AC801.FA01-00	APC810 replacement fan filter 1CS 5 pcs.	
5AC801.FA02-00	APC810 replacement fan filter 2CS 5 pcs.	
5AC801.FA03-00	APC810 replacement fan filter 3CS 5 pcs.	
5AC801.FA05-00	APC810 replacement fan filter 5CS 5 pcs.	

Table 249: Order data - Replacement fan filters

5. DVI - monitor adapter 5AC900.1000-00

This adapter enables a standard monitor to be connected to the DVI-I interface.

5.1 Order data

Model number	Description	Figure
5AC900.1000-00	Adapter DVI-A/m to CRT DB15HD/f Adapter DVI (plug) to CRT (socket), for connecting a standard monitor to a DVI-I interface.	

Table 250: Order data - DVI - CRT adapter

6. CompactFlash cards 5CFCRD.xxxx-04

6.1 General information

Information:

B&R CompactFlash cards 5CFCRD.xxxx-04 and CompactFlash cards from a different manufacturer cannot be used in the same system at the same time. Due to differences in technology (older vs. newer technologies), problems can occur during system startup that are caused by the different boot times.

See chapter 3 "Commissioning", section 7 "Known problems / issues", on page 240.

Information:

The 5CFCRD.xxxx-04 CompactFlash cards are supported on B&R devices with WinCE Version 6.0 or higher.

6.2 Order data

Model number	Description	Figure
5CFCRD.0512-04	512 MB B&R CompactFlash card	CompactFlash card
5CFCRD.1024-04	1024 MB B&R CompactFlash card	
5CFCRD.2048-04	2048 MB B&R CompactFlash card	
5CFCRD.4096-04	4096 MB B&R CompactFlash card	
5CFCRD.8192-04	8192 MB B&R CompactFlash card	
5CFCRD.016G-04	16 GB B&R CompactFlash card	

Table 251: Order data - CompactFlash cards

6.3 Technical data

Caution!

A sudden loss of power can cause data to be lost! In very rare cases, the mass memory may also become damaged.

To prevent damage and loss of data, it is recommended to use a UPS device.

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Features	5CFCRD.0512-04	5CFCRD.1024-04	5CFCRD.2048-04	5CFCRD.4096-04	5CFCRD.8192-04	5CFCRD.016G-04
MTBF (at 25°C)	> 3,000,000 hours					
Maintenance	None					
Data reliability	< 1 unrecoverable error in 10^{14} bit read accesses					
Data retention	10 years					
Lifetime monitoring	Yes					
Supported operating modes	PIO Mode 0-6, Multiword DMA Mode 0-4, Ultra DMA Mode 0-4					
Continuous reading	Typically 35 MB/s(240X)[1)2)] Max. 37 MB/s (260X)[1) 2)]	Typically 35 MB/s (240X)[1) 2)] Max. 37 MB/s (260X)[1) 2)]	Typically 35 MB/s (240X)[1) 2)] Max. 37 MB/s (260X)[1) 2)]	Typically 33 MB/s (220X)[1) 2)] Max. 34 MB/s (226X)[1) 2)]	Typically 27 MB/s (180X)[1) 2)] Max. 28 MB/s (186X)[1) 2)]	Typically 36 MB/s (240X)[1) 2)] Max. 37 MB/s (247X)[1) 2)]
Continuous writing	Typically 17 MB/s (110X) Max. 20 MB/s (133X)	Typically 17 MB/s (110X) Max. 20 MB/s (133X)	Typically 17 MB/s (110X) Max. 20 MB/s (133X)	Typically 16 MB/s (106X) Max. 18 MB/s (120X)	Typically 15 MB/s (100X) Max. 17 MB/s (110X)	Typically 18 MB/s (120X) Max. 19 MB/s (126X)
Endurance						
Guaranteed amount of data [3)] Results in 5 years [3)]	50 TB 27.40 GB/day	100 TB 54.79 GB/day	200 TB 109.59 GB/day	400 TB 219.18 GB/day	800 TB 438.36 GB/day	1600 TB 876.72 GB/day
Clear/write cycles Guaranteed Typical[4)]	100,000 2,000,000					
SLC flash	Yes					
Wear leveling	Static					
Endurance	**5CFCRD.0512-04**	**5CFCRD.1024-04**	**5CFCRD.2048-04**	**5CFCRD.4096-04**	**5CFCRD.8192-04**	**5CFCRD.016G-04**
Error Correction Coding (ECC)	Yes					

Table 252: Technical data - CompactFlash cards 5CFCRD.xxxx-04

Support						
Hardware	PP300/400, PPC300, PPC700, PPC725, PPC800, APC620, APC810, APC820					
Windows XP Professional	-	-	-	Yes	Yes	Yes
Windows XP Embedded	Yes	Yes	Yes	Yes	Yes	Yes
Windows Embedded Standard 2009	No	Yes	Yes	Yes	Yes	Yes
Windows CE 6.0	Yes	Yes	Yes	Yes	Yes	Yes [5]
Windows CE 5.0	-	-	-	-	-	-
PVI Transfer Tool	V3.2.3.8 (part of PVI Development Setup V2.06.00.3011)					-
B&R Embedded OS Installer	V3.10					-
Mechanical characteristics						
Dimensions Length Width Thickness	36.4 ±0.15 mm 42.8 ±0.10 mm 3.3 ±0.10 mm					
Weight	10 g					
Environmental characteristics						
Ambient temperature Operation Storage Transport	0 to +70°C -65 to +150°C -65 to +150°C					
Relative humidity Operation/Storage/Transport	Max. 85% at 85°C					
Vibration Operation/Storage/Transport	20 G peak, 20- 2000 Hz, 4 in each direction (JEDEC JESD22, method B103) 5.35 G RMS, 15 min per level (IEC 68-2-6)					
Shock Operation/Storage/Transport	1.5k G peak, 0.5 ms 5 times (JEDEC JESD22, method B110) 30 G, 11 ms 1 time (IEC 68-2-27)					
Altitude	Max. 15,000 feet (4,572 m)					

Table 252: Technical data - CompactFlash cards 5CFCRD.xxxx-04 (Forts.)

1) Speed specification with 1X = 150 KB/s. All specifications refer to the Samsung Flash chips, CompactFlash cards in UDMA mode 4, 30 ns cycle time in True-IDE mode with sequential write/read test.

2) The file is written/read sequentially in True IDE mode with the DOS program Thruput.exe.

3) Endurance of B&R CF cards (linear written block size with 128 kB)

4) Depending on the average file size.

5) Not supported by B&R Embedded OS installer.

6.3.1 Temperature humidity diagram



Figure 182: Temperature humidity diagram - CompactFlash cards 5CFCRD.xxxx-04

6.4 Dimensions



Figure 183: Dimensions - CompactFlash card Type I

6.5 Benchmark



Figure 184: ATTO disk benchmark v2.34 comparison (reading)



Figure 185: ATTO disk benchmark v2.34 comparison (writing)

7. CompactFlash cards - 5CFCRD.xxxx-03

7.1 General information

Information:

Silicon Systems CompactFlash cards 5CFCRD.xxxx-03 and CompactFlash cards from a different manufacturer cannot be used in the same system at the same time. Due to differences in technology (older vs. newer technologies), problems can occur during system startup that are caused by the different boot times.

See chapter 3 "Commissioning", section 7 "Known problems / issues", on page 240.

Information:

On Windows CE 5.0 devices, 5CFCRD.xxxx-03 CompactFlash cards up to 1GB are supported.

7.2 Order data

Model number	Description	Figure
5CFCRD.0064-03	CompactFlash 64 MB SSI	CompactFlash card
5CFCRD.0128-03	CompactFlash 128 MB SSI	
5CFCRD.0256-03	CompactFlash 256 MB SSI	
5CFCRD.0512-03	CompactFlash 512 MB SSI	
5CFCRD.1024-03	CompactFlash 1024 MB SSI	
5CFCRD.2048-03	CompactFlash 2048 MB SSI	
5CFCRD.4096-03	CompactFlash 4096 MB SSI	
5CFCRD.8192-03	CompactFlash 8192 MB SSI	

Table 253: Order data - CompactFlash cards

7.3 Technical data

Caution!

A sudden loss of power can cause data to be lost! In very rare cases, the mass memory may also become damaged.

To prevent damage and loss of data, B&R recommends that you use a UPS device.

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Features	5CFCRD. 0064-03	5CFCRD. 0128-03	5CFCRD. 0256-03	5CFCRD. 0512-03	5CFCRD. 1024-03	5CFCRD. 2048-03	5CFCRD. 4096-03	5CFCRD. 8192-03
MTBF (at 25°C)	> 4,000,000 hours							
Maintenance	None							
Data reliability	< 1 unrecoverable error in 10^{14} bit read accesses							
Data retention	10 years							
Lifetime monitoring	Yes							
Supported operating modes	PIO Mode 0-4, Multiword DMA Mode 0-2							
Continuous reading	Typically 8 MB/s							
Continuous writing	Typically 6 MB/s							
Endurance								
Clear/write cycles Typical	> 2,000,000							
SLC flash	Yes							
Wear leveling	Static							
Error Correction Coding (ECC)	Yes							
Support								
Hardware	MP100/200, PP100/200, PP300/400, PPC300, PPC700, PPC725 PPC800, Provit 2000, Provit 5000, APC620, APC680, APC810, APC820							
Windows XP Professional	-	-	-	-	-	-	Yes	Yes
Windows XP Embedded	-	-	-	Yes	Yes	Yes	Yes	Yes
Windows CE 6.0	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes[1)]
Windows CE 5.0	Yes	Yes	Yes	Yes	Yes	-	-	-

Table 254: Technical data - CompactFlash cards 5CFCRD.xxxx-03

Support	5CFCRD. 0064-03	5CFCRD. 0128-03	5CFCRD. 0256-03	5CFCRD. 0512-03	5CFCRD. 1024-03	5CFCRD. 2048-03	5CFCRD. 4096-03	5CFCRD. 8192-03
PVI Transfer Tool	V2.57 (part of PVI Development Setup V2.5.3.3005)							
B&R Embedded OS Installer	V2.21							
Mechanical characteristics								
Dimensions Length Width Thickness	36.4 ±0.15 mm 42.8 ±0.10 mm 3.3 ±0.10 mm							
Weight	11.4 g							
Environmental characteristics								
Ambient temperature Operation Storage Transport	0 to +70°C -50 to +100°C -50 to +100°C							
Relative humidity Operation/Storage/Transport	8 to 95%, non-condensing							
Vibration Operation Storage/Transport	Max. 16.3 g (159 m/s^2 0-peak) Max. 30 g (294 m/s^2 0-peak)							
Shock Operation Storage/Transport	Max. 1000 g (9810 m/s^2 0-peak) Max. 3000 g (29,430 m/s^2 0-peak)							
Altitude	Maximum 80,000 feet (24,383 meters)							

Table 254: Technical data - CompactFlash cards 5CFCRD.xxxx-03 (Forts.)

1) Not supported by B&R Embedded OS installer.

7.3.1 Temperature humidity diagram



Figure 186: Temperature humidity diagram - CompactFlash cards 5CFCRD.xxxx-03

7.4 Dimensions



Figure 187: Dimensions - CompactFlash card Type I

8. USB Media Drive - 5MD900.USB2-01

Data carriers not included in delivery

Figure 188: USB Media Drive - 5MD900.USB2-01

8.1 Order data

Model number	Description	Note
5MD900.USB2-01	**USB 2.0 drive DVD-RW/CD-RW FDD CF USB** USB 2.0 drive combination, consists of DVD-R/RW/DVD+R/RW/CD-RW, FDD, CompactFlash slot (type II), USB connection (type A front, type B back); 24V DC.	

Table 255: Order data - Uninterruptible power supply

8.2 Features

- Desk-top or rack-mount operation (mounting rail brackets)
- Integrated USB diskette drive
- Integrated DVD-RW/CD-RW drive
- Integrated CompactFlash slot IDE/ATAPI (Hot Plug capable)
- Integrated USB 2.0 connection (up to 480 MBit high speed)
- +24 VDC supply (back side)
- USB/B 2.0 connection (back side)
- Optional front cover (see also section 8.9 "Front cover 5A5003.03 for the USB Media Drive", on page 407)

8.3 Technical data

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Features - entire device	5MD900.USB2-01 Rev. D0 and higher
Transfer rate	Low speed (1.5 Mbit/s), full speed (12 Mbit/s), to high speed (480 Mbit/s)
Maximum cable length	5 m (without hub)
Power supply Rated voltage	 24 VDC ±25%
Features - diskette drive	
Data capacity	720 KB / 1.25 MB / 1.44 MB (formatted)
Data transfer rate	250 kBits (720 KB) or 500 kBits (1.25 MB and 1.44 MB)
Rotation speed	Up to 360 rpm
Diskette media	High density (2HD) or normal density (2DD) 3.5" diskettes
MTBF	30,000 POH (Power-On Hours)
Features - DVD-RW/CD-RW drive	
Write speed CD-R CD-RW DVD-R DVD-RW DVD+R DVD+RW DVD+R (double layer) DVD-R (Double Layer) DVD-RAM[1)]	 10-24x 10-24x 2-6x 2-6x 3.3-8x 3.3-8x 2.4-4x 2-4x 3-5x
Reading rate CD DVD	 24x 8x
Data transfer rate	Max. 33.3 MB/s
Access time (average) CD / DVD	 130 ms (24x) / 130 ms (8x)
Revolution speed	Max. 5090 rpm ± 1%
Starting time (0 rpm to read access) CD DVD	 14 seconds (maximum) 15 seconds (maximum)
Host interface	IDE (ATAPI)

Table 256: Technical data - USB Media Drive 5MD900.USB2-01 Rev D0 and higher

Features - DVD-RW/CD-RW drive	5MD900.USB2-01
Readable media CD DVD	 CD/CD-ROM (12 cm, 8 cm), CD-R, CD-RW DVD-ROM, DVD-R, DVD-RW. DVD-RAM, DVD+R, DVD+R (double layer), DVD+RW
Non-write protected media CD DVD	 CD-R, CD-RW DVD-R/RW, DVD-RAM (4.7 GB), DVD+R/RW, DVD+R (double layer)
Compatible formats	CD-DA, CD-ROM mode 1/mode 2 CD-ROM XA mode 2 (form 1, form 2) Photo CD (single/multi-session), Enhanced CD, CD text DVD-ROM, DVD-R, DVD-RW, DVD-Video DVD-RAM (4.7 GB; 2.6 GB) DVD+R, DVD+R (double layer), DVD+RW
Write-methods CD DVD	 Disk at once, session at once, packet write, track at once Disk at once, incremental, over-write, sequential, multi-session
Laser class	Class 1 laser
Data buffer capacity	8 MB
Noise level (complete read access)	Approx. 48 dBA in a distance of 50 cm
Lifespan Opening/closing the drawer	60,000 POH (Power-On Hours) > 10,000 times
CompactFlash slot layout	
CompactFlash Type Amount Connection	 Type I 1 slot IDE/ATAPI
CompactFlash LED	Signals read or write access to an inserted CompactFlash card
Hot Plug capable	Yes
Features - USB connections	
USB A on the front side Power supply Type Transfer rate	Connection of further peripheral devices Max. 500 mA 2.0 Low speed (1.5 Mbit/s), full speed (12 Mbit/s), to high speed (480 Mbit/s)
USB B back side	Connection to the system
Mechanical characteristics	
Outer dimensions (without slide-in) Width Length Height	 70 mm 100 mm 9.5 mm
Weight	Approx. 1.1 kg (without front cover)
Environmental characteristics	
Ambient temperature[2)] Operation Storage Transport	 +5 to +45°C -20 to +60°C -40 to +60°C

Table 256: Technical data - USB Media Drive 5MD900.USB2-01 Rev D0 and higher (Forts.)

Environmental characteristics	5MD900.USB2-01
Relative humidity Operation Storage Transport	 20 to 80%, non-condensing 5 to 90%, non-condensing 5 to 95%, non-condensing
Vibration Operation Storage Transport	 5 - 500 Hz: 0.3 g (2.9 m/s^2 0-peak) 10 - 100 Hz: 2 g (19.6 m/s^2 0-peak) 10 - 100 Hz: 2 g (19.6 m/s^2 0-peak)
Shock Operation Storage Transport	 Max. 5 g (49 m/s ^{2} 0-peak) and 11 ms duration Max. 60 g (588 m/s ^{2} 0-peak) and 11 ms duration Max. 60 g (588 m/s ^{2} 0-peak) and 11 ms duration
Altitude	Max. 3000 meters

Table 256: Technical data - USB Media Drive 5MD900.USB2-01 Rev D0 and higher (Forts.)

1) DVD RAM drivers are not provided by the manufacturer. Support of DVD RAM function by the burning software "Nero" (model number 5SWUTI.0000-00) or other burning software packages and drivers from third party providers.

2) Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

8.4 Dimensions



Figure 189: Dimensions - 5MD900.USB2-01

8.5 Dimensions with front cover



Figure 190: Dimensions - USB Media Drive with front cover

8.5.1 Cutout installation



Figure 191: Installation cutout - USB Media Drive with front cover

8.6 Contents of delivery

Amount	Component
1	USB Media Drive complete unit
2	Mounting rail brackets

Table 257: Contents of delivery - USB Media Drive - 5MD900.USB2-01

8.7 Interfaces



Figure 192: Interfaces - 5MD900.USB2-01

8.8 Installation

The USB Media Drive can be operated as a desk-top device (rubber feet) or as a rack-mount device (2 mounting rail brackets included).

8.8.1 Mounting orientation

Because of limits to the mounting orientation with the components used (floppy, DVD-CDRW drive), the USB media drive is only permitted to be mounted and operated as shown in the following figure.



Figure 193: Mounting orientation - 5MD900.USB2-01

8.9 Front cover 5A5003.03 for the USB Media Drive

This front cover can also be mounted on the front of the USB media drive (model number 5MD900.USB2-00 or 5MD900.USB2-01) to protect the interface.

Figure 194: Front cover 5A5003.03

8.9.1 Technical data

Features	5A5003.03
Front cover design / colors	
Dark gray border around the cover	Pantone 432CV
Light gray background	Pantone 427CV

Table 258: Technical data - 5A5003.03

8.9.2 Dimensions



Figure 195: Dimensions - 5A5003.03

8.9.3 Installation

The front cover is attached with 2 mounting rail brackets (included with USB Media Drive) and 4 M3 locknuts. The USB media drive and front cover can be mounted as a whole in (for example) a switching cabinet door.



Figure 196: Front cover mounting and installation depth

8.9.4 Cutout installation

See the figure 191 "Installation cutout - USB Media Drive with front cover", on page 405.

9. USB flash drive

Information:

We reserve the right to supply alternative products due to the vast quantity of flash drives available on the market and their corresponding short product lifecycle. Therefore, the following measures might be necessary in order to boot from these flash drives:

- **The flash drive must be reformatted or in some cases even re-partitioned (set active partition).**
- **The flash drive must be at the top of the BIOS boot order, or alternatively the IDE controllers can also be deactivated in the BIOS. This can be avoided in most cases if a "`fdisk /mbr`" command is also executed on the USB flash drive.**

9.1 General information

USB flash drives are easy-to-exchange storage media. Because of the fast data transfer (USB 2.0), the USB flash drives are ideal for use as a portable memory medium. Without requiring additional drivers ("Hot Plug & Play" - except with Windows 98SE), the USB flash drive can be converted immediately into an additional drive where data can be read or written.

9.2 Order data

Model number	Description	Figure
5MMUSB.2048-00	USB flash drive 2 GB SanDisk Cruzer Micro	
5MMUSB.2048-01	**USB flash drive 2 GB B&R** USB 2.0 flash drive 2 GB	

Table 259: Order data - USB flash drives

9.3 Technical data - 5MMUSB.2048-00

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Features	5MMUSB.2048-00
LED	1 LED (green), signals data transfer (send and receive)
Power supply Current requirements	Via the USB port 650 µA in sleep mode, 150 mA read/write
Interface Type Transfer rate Sequential reading Sequential writing Connection	USB specification 2.0 high speed device, mass storage class, USB-IF and WHQL certified USB 1.1 and 2.0 compatible Up to 480 MBit (high speed) Max. 8.7 MB/second Max. 1.7 MB/second To each USB type A interface
MTBF (at 25°C)	100,000 hours
Data retention	10 years
Maintenance	None
Operating system support	Windows CE 4.2, CE 5.0, ME, 2000, XP and Mac OS 9.1.x+, OS X v10.1.2+
Mechanical characteristics	
Dimensions Length Width Thickness	 52.2 mm 19 mm 7.9 mm
Environmental characteristics	
Ambient temperature Operation Storage Transport	 0 to +45°C -20 to +60°C -20 to +60°C
Relative humidity Operation Storage Transport	 10 to 90%, non-condensing 5 to 90%, non-condensing 5 to 90%, non-condensing
Vibration Operation Storage Transport	 At 10 - 500 Hz: 2 g (19,6 m/s^2 0-peak), oscillation rate 1/minute At 10 - 500 Hz: 4 g (39,2 m/s^2 0-peak), oscillation rate 1/minute At 10 - 500 Hz: 4 g (39,2 m/s^2 0-peak), oscillation rate 1/minute
Shock Operation Storage Transport	 Max. 40 g (392 m/s^2 0-peak) and 11 ms duration Max. 80 g (784 m/s^2 0-peak) and 11 ms duration Max. 80 g (784 m/s^2 0-peak) and 11 ms duration

Table 260: Technical data - USB flash drive 5MMUSB.2048-00

Environmental characteristics	5MMUSB.2048-00
Altitude	
Operation	3,048 meters
Storage	12,192 meters
Transport	12,192 meters

Table 260: Technical data - USB flash drive 5MMUSB.2048-00 (Forts.)

9.3.1 Temperature humidity diagram



Figure 197: Temperature humidity diagram - USB flash drive - 5MMUSB.2048-00

Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

9.4 Technical data - 5MMUSB.2048-01

Information:

The following characteristics, features and limit values only apply to this accessory and can deviate those specified for the entire device. For the entire device where this accessory is installed, refer to the data provided specifically for the entire device.

Features	5MMUSB.2048-01
LED	1 LED (green), signals data transfer (send and receive)
Power supply Current requirements	Via the USB port max. 500 µA sleep mode, max. 120 mA read/write
Interface Type Transfer rate Sequential reading Sequential writing Connection	USB specification 2.0 high speed device, mass storage class, USB-IF and WHQL certified USB 1.1 and 2.0 compatible Up to 480 MBit (high speed) Max. 31 MB/second Max. 30 MB/second To each USB type A interface
MTBF	> 3,000,000 hours
Data retention	> 10 years
Maintenance	None
Operating system support	Windows CE, ME, 2000, XP, Vista und Mac OS 9 or newer, Linux 2.4 or newer
Mechanical characteristics	
Dimensions Length Width Thickness	 67.85 mm 17.97 mm 8.35 mm
Environmental characteristics	
Ambient temperature Operation Storage Transport	 0 to +70°C -50 to +100°C -50 to +100°C
Relative humidity Operation Storage Transport	 85%, non-condensing 85%, non-condensing 85%, non-condensing
Vibration Operation Storage Transport	 At 20 - 2000 Hz: 20 g (peak) At 20 - 2000 Hz: 20 g (peak) At 20 - 2000 Hz: 20 g (peak)
Shock Operation Storage Transport	 max. 1500 g (peak) max. 1500 g (peak) max. 1500 g (peak)

Table 261: Technical data - USB flash drive 5MMUSB.2048-01

Environmental characteristics	5MMUSB.2048-01
Altitude	
Operation	3,048 meters
Storage	12,192 meters
Transport	12,192 meters

Table 261: Technical data - USB flash drive 5MMUSB.2048-01 (Forts.)

9.4.1 Temperature humidity diagram



Figure 198: Temperature humidity diagram - USB flash drive - 5MMUSB.2048-01

Temperature data is for operation at 500 meters. Derating the max. ambient temperature - typically 1°C per 1000 meters (from 500 meters above sea level).

10. B&R Automation Runtime Dongle

10.1 General information

The Automation Runtime Dongle must be connected to use ARwin on B&R Industrial PC.

10.2 Order data

Model number	Description	Figure
1A4600.10	B&R Automation Runtime ARwin, incl. License Label and Security Key	
1A4600.10-2	B&R Automation Runtime ARwin, ARNC0	
1A4600.10-3	B&R Automation Runtime ARwin+PVIControls incl. License Label and Security Key	
1A4600.10-4	B&R Automation Runtime ARwin+ARNC0+PVIControls	

Table 262: Order data - B&R Automation Runtime Dongle

11. Uninterruptible power supply UPS

With the optionally integrated UPS, the Automation PC 810 makes sure that the PC system completes write operations even after a power failure occurs. When the UPS detects a power failure, it switches to battery operation immediately without interruption. This means that all running programs will be ended properly by the UPS software. This prevents the possibility of inconsistent data (only functions if the UPC is already configured and the driver is activated).

Information:

More detailed information about uninterruptible power supplies can be found in the UPS users manual (of the external UPS 24 VDC). This can be downloaded from the B&R homepage.

Information:

The monitor is not buffered by the UPS and will shut off when the power fails.

By integrating the charging circuit in the Automation PC 810 housing, the installation has been reduced to merely attaching the connection cable to the battery unit mounted next to the PC.

Special emphasis was placed on ease of maintenance when the battery unit was designed. The batteries are easily accessible from the front and can be switched in just a few moments when servicing.



Figure 199: UPS principle

11.1 Order data

Model number	Description	Note
5AC600.UPSI-00	**Add-on UPS module** Order UPS module for Automation PC, cable (5CAUPS.0005-00 or 5CAUPS.0030-00) and battery unit (5AC600.UPSB-00) separately.	
5AC600.UPSB-00	**5Ah battery unit** UPS battery unit for the add-on UPS module	
5CAUPS.0005-00	**0.5 meter UPS cable** Connection cable between add-on UPS module and UPS battery unit, length 0.5 meters	
5CAUPS.0030-00	**3 meter UPS cable** Connection cable between add-on UPS module and UPS battery unit, length 3 meters	

Table 263: Order data - Uninterruptible power supply

11.2 Features

- Long-lasting, maintenance-free rechargeable batteries
- Communication via integrated interfaces
- Temperature sensor
- Driver software
- Deep discharge protection

11.3 Requirements

1) Add-on UPS module 5AC600.UPSI-00
   For more on installing the add-on modules, see chapter 7 "Maintenance / Servicing", section "Installing the UPS module", on page 476.
2) Battery unit 5AC600.UPSB-00
3) UPS connection cable 0.5 m (5CAUPS.0005-00) or 3 m (5CAUPS.0030-00)
4) To configure: Automation Device Interface driver version 1.60 or higher (for the ADI Control Center)

   For info regarding configuration of the B&R UPS using the ADI Control Center, see chapter 11.4 "UPS configuration".

11.4 Individual components

11.4.1 Add-on UPS module 5AC600.UPSI-00

The add-on UPS module can easily be installed in an appropriate APC810 system unit (List of required revisions: see section 11.3 "Requirements", on page 416).



Figure 200: Add-on UPS module 5AC600.UPSI-00

Technical data

Features	5AC600.UPSI-00
Switching threshold mains / battery operation	15 / 13 V
Mains failure bridging	Max. 20 min at 150 W load
Charging current	Max. 0.5 A
Deep discharge protection	Yes, at 10 V on the battery unit
Short circuit protection	No
Power requirements	Max. 7.5 watts
Status indicators	Via the ADI Control Center (see section "Displaying UPS status values", on page 354)
Configuration	Via the ADI Control Center (see section "UPS configuration", on page 353)

Table 264: Technical data - 5AC600.UPSI-00

Installation

The module is installed using the materials included in the delivery. For installation instructions, see chapter 7 "Maintenance / Servicing", section "Installing the UPS module", on page 476.



Figure 201: Add-on UPS module 5AC600.UPSI-00 - Installation materials

11.4.2 Battery unit 5AC600.UPSB-00

The battery unit is subject to wear and should be replaced regularly (at least following the specified lifespan).



Figure 202: Battery unit 5AC600.UPSB-00

Technical data

Features	5AC600.UPSB-00
Battery Type Method	 Enersys Cyclon 2 V 5 Ah; (6 connected in series) Single cell (X cell)
Operating current	Max. 8 A
Deep discharge voltage	10 V
Dimensions (W x H x D)	Figure 205 "Dimensions - 5AC600.UPSB-00", on page 421
Temperature sensor	NTC resistance
Weight	Approx. 3.2 kg
Ambient temperature Operation Storage Transport	 -40 to +80°C -65 to +80°C -65 to +80°C
Relative humidity Operation Storage Transport	 5 to 95% (non-condensing) 5 to 95% (non-condensing) 5 to 95% (non-condensing)
Altitude	Max. 3000 meters
Mounting instructions	See "Mounting instructions", on page 422
Lifespan	10 years at 25°C (up to 80% battery capacity)
Maintenance interval during storage	6 month interval between charges
typ. recharge time at low battery	15 hours

Table 265: Technical data - 5AC600.UPSB-00

Temperature life span diagram up to 20% battery capacity.

Temperature	Lifespan (days)
25	14600
30	9467
35	6139
40	3980
45	2581
50	1674
55	1085
60	704
65	456
70	296
75	192
80	124



Figure 203: Temperature life span diagram

Deep discharge cycles



Figure 204: Deep discharge cycles

Dimensions



Figure 205: Dimensions - 5AC600.UPSB-00

Drilling template



Figure 206: Drilling template for the battery unit

Mounting instructions

Due to the unique construction of these batteries, they can be stored and operated in any position.

11.4.3 UPS connection cable



Figure 207: UPS connection cable

Technical data

Features	5CAUPS.0005-00	5CAUPS.0030-00
Length	0.5 m	3 m
Outer diameter	8.5 mm ± 0.2mm	
Connector type	6-pin plug connectors, tension clamp connection / 6-pin socket connectors, tension clamp connection	
Wire cross section Temperature sensor wire Voltage wire	 2 x 0.5 mm^2 (AWG 20) 4 x 2.5 mm^2 (AWG 13)	
Line resistance 0.5 mm^2 2.5 mm^2	 Max. 39 Ω/km Max. 7.98 Ω/km	
Flex radius Fixed installation Free-moving	 5 x wire cross-section 10 x wire cross-section	
Temperature range Moving Non-moving	 -5 to. +80°C -30 to +80°C	
Weight	Approx. 143 kg/km	
Materials Cable shield Color	 Thermoplastic PVC-based material Window gray (similar to RAL 7040)	
Peak operating voltage	12 V DC	
Testing AC voltage Wire / wire	 1500 V	
Operating voltage	Max. 300 V	
Current load	10 A at +20°C	

Table 266: Technical data - UPS connection cable

12. Power supplies

In order to meet demands for complete, comprehensive system solutions, power supplies are available in the B&R product line for mounting rail installation. This extensive spectrum ranges from single-phase power supplies that supply 2.1 A up to three-phase power supplies that supply 40 A. All switching power supplies can handle a wide range of AC and DC input voltages. This input ranges from 100 to 240 VAC or 400 to 500 VAC and from 85 to 375 VDC. Devices are protected against short circuit, overload, and open circuit, which allows them to be operated without functional limitations or derating even when overloads between 15% and 25% occur.

Figure 208: B&R power supplies (examples)

Two mini power supplies (PS102 and PS104) in robust plastic housing are available in the lower performance range. A well-designed cooling concept allows several different mounting orientations. The functional DIN rail allows fast mounting and removal. Wiring is essentially performed in seconds thanks to the spring clamps being used. The compact design, easy mounting and several different mounting orientations make the two smallest power supplies in this product line components that can be used practically anywhere.

12.1 Order data and brief technical overview

The technical data listed in the following tables should act as a brief selection guide. For more detailed technical data, data sheets are available for download from production description section of the B&R homepage (**www.br-automation.com**).

12.1.1 Single-phase power supplies

Features	0PS102.0	0PS104.0	0PS105.1	0PS105.2	0PS110.1	0PS110.2	0PS120.1
Output Power	50 W	100 W	120 W	120 W	240 W	240 W	480 W
AC input voltage	85-264 V	85-132 V 184-264 V	85-132 V 176-264 V	85-132 V 176-264 V	85-132 V 176-264 V	85-132 V 176-264 V	85-132 V 176-264 V
DC input voltage	85-375 V	220-375 V	210-375 V	210-375 V	210-375 V	210-375 V	-

Table 267: Single-phase power supplies

Features	0PS102.0	0PS104.0	0PS105.1	0PS105.2	0PS110.1	0PS110.2	0PS120.1
Output voltage	24-28 V	24-28 V	24 V	24 V	24-28 V	24-28 V	24-28 V
Output current at 24 V	2.1 A	4.2 A	5 A	5 A	10 A	10 A	20 A
Parallel operation	No	Yes	Yes	Yes	Yes	Yes	Yes
Current balancing	No	Yes	No	Yes	No	Yes	Yes

Table 267: Single-phase power supplies

12.1.2 Three-phase power supplies

Features	0PS305.1	0PS310.1	0PS320.1	0PS340.1
Output Power	120 W	240 W	490 W	960 W
AC input voltage	340-576 V	340-576 V	340-576 V	340-576 V
DC input voltage	450-820 V	450-820 V	450-820 V	450-820 V
Output voltage	24-28 V	24-28 V	24 V	24 V
Output current at 24 V	5 A	10 A	20 A	40 A
Parallel operation	Yes	Yes	Yes	Yes
Current balancing	No	Yes	Yes	Yes

Table 268: Three-phase power supplies

13. PCI cards

13.1 PCI Ethernet card 10/100 1port - 5ACPCI.ETH1-01

The universal (3.3 V and 5 V) half-size PCI Ethernet card has a 10/100 MBit/s network connection and can be inserted in a 16-bit PCI slot and operated as an additional network interface.



Figure 209: PCI Ethernet card 10/100 - 5ACPCI.ETH1-01

13.1.1 Order data

Model number	Description	Note
5ACPCI.ETH1-01	**PCI Ethernet card 10/100** half size PCI Ethernet card, 1 Ethernet connection	

Table 269: Order data - PCI Ethernet Card 10/100

13.1.2 Technical data

Ethernet connection			
Controller	Intel 82551ER		RJ45 twisted pair (10BaseT/100BaseT), female
Power supply	Universal card (2 notches) for 3.3 V or 5 V		
Cabling	S/STP (Cat5e)		
Transfer rate	10/100 Mbit/s [1)]		
Cable length	max. 100 m (min. Cat5e)		
LED	**On**	**Off**	
Green	100 Mbit/s	10 Mbit/s	
Orange	Link (Ethernet network connection available)	Activity (blinking) (Data transfer in progress)	



Table 270: Ethernet connection ETH

1) Both operating modes possible. Switching takes place automatically.

13.1.3 Driver support

A special driver is necessary for operating the Intel Ethernet controller 82551ER. Drivers for Windows XP Professional, Windows XP Embedded, and DOS are available for download on the B&R Homepage in the download area (**www.br-automation.com**).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

13.1.4 Dimensions



Figure 210: Dimensions - 5ACPCI.ETH1-01

13.2 PCI Ethernet card 10/100 - 5ACPCI.ETH3-01

The universal (3.3 V and 5 V) half-size PCI Ethernet card has three 10/100 MBit/s network connections and can be inserted in a 16-bit PCI slot and operated as an additional network interface.



Figure 211: PCI Ethernet card 10/100 - 5ACPCI.ETH3-01

13.2.1 Order data

Model number	Description	Note
5ACPCI.ETH3-01	**PCI Ethernet card 10/100 3port** half size PCI Ethernet card, 3 Ethernet connections	

Table 271: Order data - PCI Ethernet Card 10/100

13.2.2 Technical data

Ethernet connections		
Controller	each with Intel 82551ER	3 x RJ45 twisted pair (10BaseT/100BaseT), female 
Power supply	Universal card (2 notches) for 3.3 V or 5 V	
Cabling	each S/STP (Cat5e)	
Transfer rate	each 10/100 MBit/s 1)	
Cable length	each max. 100 m (min. Cat5e)	
LED	**On**	**Off**
Green	100 Mbit/s	10 Mbit/s
Orange	Link (Ethernet network connection available)	Activity (blinking) (Data transfer in progress)

Table 272: Ethernet connections ETH1, ETH2, ETH3

1) Both operating modes possible. Switching takes place automatically.

13.2.3 Driver support

A special driver is necessary for operating the Intel Ethernet controller 82551ER. Drivers for Windows XP Professional, Windows XP Embedded, and DOS are available for download on the B&R Homepage in the download area (**www.br-automation.com**).

Information:

Required drivers can only be downloaded from the B&R homepage, not from manufacturers' pages.

13.2.4 Dimensions



Figure 212: Dimensions - 5ACPCI.ETH3-01

14. Cables

14.1 DVI cable 5CADVI.0xxx-00

The DVI cables 5CADVI.0xxx-00 are designed for fixed layout.



Figure 213: DVI extension cable - 5CADVI.0xxx-00 (similar)

Caution!

The DVI cable can only be plugged in and unplugged when the device is turned off.

14.1.1 Order data

Model number	Description	Note
5CADVI.0018-00	**DVI-D cable 1.8 m** Single cable, DVI-D/m:DVI-D/m; length: 1.8 m	
5CADVI.0050-00	**DVI-D cable 5 m** Single cable, DVI-D/m:DVI-D/m; length: 5 m	
5CADVI.0100-00	**DVI-D cable 10 m** Single cable, DVI-D/m:DVI-D/m; length: 10 m	

Table 273: Order data - DVI cables

14.1.2 Technical data

Features	5CADVI.0018-00	5CADVI.0050-00	5CADVI.0100-00
Length Tolerance	1.8 m ±30 mm	5 m ±50 mm	10 m ±100 mm
Cable diameter Maximum	8.5 mm		
Shielding	Individual cable pairs and entire cable		
Connector type Connection cycles	2x DVI-D (18+1), male 100		
Wire cross section	AWG 28		
Line resistance	Max. 237 Ω/km		
Insulation resistance	Min. 100 MΩ/km		
Flexibility	Limited flexibility; valid for ferrite magnet - ferrite magnet (tested 100 cycles with 5x cable diameter, 20 cycles / minute)		
Flex radius Fixed layout	See figure "Flex radius specification", on page 433 5x cable diameter (plug - ferrite magnet and ferrite magnet - ferrite magnet)		
Weight	Approx. 300 g	Approx. 590 g	Approx. 2100 g

Table 274: Technical data - DVI cable 5CADVI.0xxx-00

14.1.3 Flex radius specification



Figure 214: Flex radius specification

14.1.4 Dimensions



Figure 215: Dimensions - DVI cable 5CADVI.0xxx-00

14.1.5 Contents of delivery

Amount	Component
1	DVI cable in desired length, plug covers are attached at the cable ends.

Table 275: Contents of delivery - DVI cable 5CADVI.0xxx-00

14.1.6 Cable specifications

The following figure shows the pin assignments for the DVI cable available at B&R. If you want to build a suitable cable yourself, it should be wired according to these specifications.

Warning!

If a self-built cable is used, B&R cannot guarantee that it will function properly. The DVI cables provided by B&R are guaranteed to function properly.



Figure 216: Pin assignments - DVI cable

14.2 SDL cable 5CASDL.0xxx-00

The SDL cables 5CASDL.0xxx-00 are designed for fixed layout. Use of the SDL flex cable 5CASDL.0xxx-03 is required for a flexible installation (e.g. in swing arm systems).



Figure 217: SDL extension cable (similar)

Caution!

The SDl cable can only be plugged in and unplugged when the device is turned off.

14.2.1 Order data

Model number	Description	Note
5CASDL.0018-00	**SDL cable 1.8 m** SDL cable for a fixed type of layout; length: 1.8 m	
5CASDL.0050-00	**SDL cable 5 m** SDL cable for a fixed type of layout; length: 5 m	
5CASDL.0100-00	**SDL cable 10 m** SDL cable for a fixed type of layout; length: 10 m	
5CASDL.0150-00	**SDL cable 15 m** SDL cable for a fixed type of layout; length: 15 m	
5CASDL.0200-00	**SDL cable 20 m** SDL cable for a fixed type of layout; length: 20 m	
5CASDL.0250-00	**SDL cable 25 m** SDL cable for a fixed type of layout; length: 25 m	
5CASDL.0300-00	**SDL cable 30 m** SDL cable for a fixed type of layout; length: 30 m	

Table 276: Order data - SDL cables

14.2.2 Technical data

Features	5CASDL.0018-00	5CASDL.0050-00	5CASDL.0100-00	5CASDL.0150-00	5CASDL.0200-00	5CASDL.0250-00	5CASDL.0300-00
Length Tolerance	1.8 m ±50 mm	5 m ±80 mm	10 m ±100 mm	15 m ±120 mm	20 m ±150 mm	25 m ±200 mm	30 m ±200 mm
Cable diameter Typical Maximum	8.6 ±0.2 mm 9 mm		11 ±0.2 mm 11.5 mm				
Shielding	Individual cable pairs and entire cable						
Connector type Connection cycles	2x DVI-D (24+1), male 100						
Wire cross section	AWG 28		AWG 24				
Line resistance	Max. 237 Ω/km		Max. 93 Ω/km				
Insulation resistance	Min. 10 MΩ/km						
Flexibility	Limited flexibility; valid for ferrite magnet - ferrite magnet (tested 100 cycles with 5x cable diameter, 20 cycles / minute)						
Halogen-free	No						
Flex radius Fixed layout	See figure "Flex radius specification", on page 437 5x cable diameter (plug - ferrite magnet and ferrite magnet - ferrite magnet)						
Weight	Approx. 300 g	Approx. 590 g	Approx. 2100 g	Approx. 3000 g	Approx. 4100 g	Approx. 5100 g	Approx. 6100 g

Table 277: Technical data - SDL cables 5CASDL.0xxx-00

14.2.3 Flex radius specification



Figure 218: Flex radius specification

14.2.4 Dimensions



Figure 219: Dimensions - SDL cable 5CASDL.0xxx-00

14.2.5 Contents of delivery

Amount	Component
1	SDL cable in desired length, plug covers are attached at the cable ends.

Table 278: Contents of delivery - SDL cable 5CASDL.0xxx-00

14.2.6 Cable specifications

The following figure shows the pin assignments for the SDL cable available at B&R. If you want to build a suitable cable yourself, it should be wired according to these specifications.

Warning!

If a self-built cable is used, B&R cannot guarantee that it will function properly. The SDL cables provided by B&R are guaranteed to function properly.



Figure 220: Pin assignments - SDL cable 5CASDL.0xxx-00

14.3 SDL cable with 45° plug 5CASDL.0xxx-01

The SDL cables 5CASDL.0xxx-01 are designed for fixed layout.



Figure 221: SDL cable with 45° plug (similar)

Caution!

The SDI cable can only be plugged in and unplugged when the device is turned off.

14.3.1 Order data

Model number	Description	Note
5CASDL.0018-01	**SDL cable 1.8 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 1.8 m	
5CASDL.0050-01	**SDL cable 5 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 5 m	
5CASDL.0100-01	**SDL cable 10 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 10 m	
5CASDL.0150-01	**SDL cable 15 m 45°** SDL cable for fixed type of layout with one-sided 45° plug; length: 15 m	

Table 279: Order data - SDL cables with 45° plug

14.3.2 Technical data

Features	5CASDL.0018-01	5CASDL.0050-01	5CASDL.0100-01	5CASDL.0150-01
Length Tolerance	1.8 m ±50 mm	5 m ±80 mm	10 m ±100 mm	15 m ±120 mm
Cable diameter Maximum	9 mm		11.5 mm	
Shielding	Individual cable pairs and entire cable			
Connector type Connection cycles	2x DVI-D (24+1), male 100			
Wire cross section	AWG 28		AWG 24	
Line resistance	Max. 237 Ω/km		Max. 93 Ω/km	
Insulation resistance	Min. 10 MΩ/km			
Flexibility	Limited flexibility; valid for ferrite magnet - ferrite magnet (tested 100 cycles with 5x cable diameter, 20 cycles / minute)			
Halogen-free	No			
Flex radius Fixed layout	See figure "Flex radius specification", on page 441 5x cable diameter (plug - ferrite magnet and ferrite magnet - ferrite magnet)			
Weight	Approx. 300 g	Approx. 590 g	Approx. 2100 g	Approx. 3000 g

Table 280: Technical data - SDL cable with 45° plug 5CASDL.0xxx-01

14.3.3 Flex radius specification



Figure 222: Flex radius specification

14.3.4 Dimensions



Figure 223: Dimensions - SDL cable with 45° plug 5CASDL.0xxx-01

14.3.5 Contents of delivery

Amount	Component
1	SDL cable with 45° plug in desired length, plug covers are attached at the cable ends.

Table 281: Contents of delivery - SDL cable with 45° plug 5CASDL.0xxx-01

14.3.6 Cable specifications

The following figure shows the pin assignments for the SDL cable available at B&R. If you want to build a suitable cable yourself, it should be wired according to these specifications.

Warning!

If a self-built cable is used, B&R cannot guarantee that it will function properly. The SDL cables provided by B&R are guaranteed to function properly.



Figure 224: Pin assignments - SDL cable with 45° plug 5CASDL.0xxx-01

14.4 SDL flex cable 5CASDL.0xxx-03

The SDL flex cables 5CASDL.0xxx-03 are designed for both fixed and flexible installations (e.g. in swing arm systems).



Figure 225: SDL cable 5CASDL.0xxx-03 (similar)

Caution!

The SDl cable can only be plugged in and unplugged when the device is turned off.

14.4.1 Order data

Model number	Description	Note
5CASDL.0018-03	**SDL flex cable 1.8 m** SDL cable for fixed and flexible type of layout; length: 1.8 m	
5CASDL.0050-03	**SDL flex cable 5 m** SDL cable for fixed and flexible type of layout; length: 5 m	
5CASDL.0100-03	**SDL flex cable 10 m** SDL cable for fixed and flexible type of layout; length: 10 m	
5CASDL.0150-03	**SDL flex cable 15 m** SDL cable for fixed and flexible type of layout; length: 15 m	
5CASDL.0200-03	**SDL flex cable 20 m** SDL cable for fixed and flexible type of layout; length: 20 m	
5CASDL.0250-03	**SDL flex cable 25 m** SDL cable for fixed and flexible type of layout; length: 25 m	
5CASDL.0300-03	**SDL flex cable 30 m** SDL cable for fixed and flexible type of layout; length: 30 m	

Table 282: Order data - SDL cable 5CASDL.0xxx-03

14.4.2 Technical data

Mechanical characteristics	5CASDL.0018-03	5CASDL.0050-03	5CASDL.0100-03	5CASDL.0150-03	5CASDL.0200-03	5CASDL.0250-03	5CASDL.0300-03
Length Tolerance	1.8 m ±20 mm	5 m ±45 mm	10 m ±90 mm	15 m ±135 mm	20 m ±180 mm	25 m ±225 mm	30 m ±270 mm
Cable diameter Maximum	12 mm						
Shielding	Individual cable pairs and entire cable						
Connector type Connection cycles Contacts Mechanical protection	2x DVI-D (24+1), male Min. 200 Gold plated Metal cover with crimped stress relief						
Max. tension During installation During operation	≤ 400 N ≤ 50 N						
Materials Cable shield Color	RoHS compliant Aluminum foil clad + tinned copper mesh Black (similar to RAL 9005)						
Flexibility	Flexible; valid for ferrite magnet - ferrite magnet (tested 300,000 cycles with 15x cable diameter, 4800 cycles / hour)						
Halogen-free	Yes						
Flex radius Fixed layout flexible installation	See figure "Flex radius specification", on page 446 6x cable diameter (of plug - ferrite magnet) 10x cable diameter (of ferrite magnet - ferrite magnet) 15x cable diameter (of ferrite magnet - ferrite magnet)						
Weight	Approx. 450 g	Approx. 1000 g	Approx. 2000 g	Approx. 3000 g	Approx. 4000 g	Approx. 5000 g	Approx. 6000 g
Electrical properties (at +20°C)							
Wire cross section	24 AWG (control wires) 26 AWG (DVI, USB, data)						
Line resistance 24 AWG 26 AWG	≤ 95 Ω/km ≤ 145 Ω/km						
Insulation resistance	> 200 MΩ/km						
Wave impedance	100 ±10 Ω						
Test voltage Wire / wire Wire / shield	1 kV_{eff} 0.5 kV_{eff}						
Operating voltage	≤ 30 V						
Environmental characteristics							
Temperature resistance Fixed installation Moving Storage	-20 to +80°C -5 to +60°C -20 to +80°C						
Fire resistance	Fire resistant in accordance with UL758 (cable vertical flame test)						

Table 283: Technical data - SDL cable 5CASDL.0xxx-03

Standards and certifications	5CASDL.0018-03	5CASDL.0050-03	5CASDL.0100-03	5CASDL.0150-03	5CASDL.0200-03	5CASDL.0250-03	5CASDL.0300-03
Torsion load	100,000 cycles (tested angle of rotation: ±85° speed: 50 cycles / minute)						
Cable drag chain	300,000 cycles Tested flex radius: 180 mm;15x cable diameter; hub: 460 mm; speed: 4800 cycles / hour						
Approbation	UL AWM 20236 80°C 30 V						
Oil and hydrolysis resistance	According to VDE 0282-10						

Table 283: Technical data - SDL cable 5CASDL.0xxx-03 (Forts.)

14.4.3 Flex radius specification



Figure 226: Flex radius specification

14.4.4 Dimensions



Figure 227: Dimensions - SDL cable 5CASDL.0xxx-03

14.4.5 Contents of delivery

Amount	Component
1	SDL flex cable in desired length, plug covers are attached at the cable ends.

Table 284: Contents of delivery - SDL flex cable 5CASDL.0xxx-03

14.4.6 Construction

Element	Assignment	Cross section	
DVI	TMDS data 0	26 AWG	
	TMDS data 1	26 AWG	
	TMDS data 2	26 AWG	
	TMDS cycle	26 AWG	
USB	XUSB0	26 AWG	
	XUSB1	26 AWG	
Data	SDL	26 AWG	
Control wires	DDC cycle	24 AWG	
	DDC data	24 AWG	
	+ 5 V	24 AWG	
	mass	24 AWG	
	Hot Plug detect	24 AWG	

Schematic display

Table 285: Structure - SDL cable 5CASDL.0xxx-03

14.4.7 Cable specifications

The following figure shows the pin assignments for the SDL cable available at B&R. If you want to build a suitable cable yourself, it should be wired according to these specifications.

Warning!

If a self-built cable is used, B&R cannot guarantee that it will function properly.



Figure 228: Pin assignments - SDL cable 5CASDL.0xxx-03

14.5 SDL flex cable with extender 5CASDL.0x00-13

The SDL flex cables (with extender) 5CASDL.0x00-13 are designed for both fixed and flexible installations (e.g. in swing arm systems).



Figure 229: SDL flex cable with extender - 5CASDL.0x00-13 (similar)

Caution!

SDL cables with extender can only be plugged in and unplugged when the device is turned off. The correct direction of connection (SDL IN, SDL OUT) for the wiring is illustrated on the middle of the extender and between the ferrite magnet and plug (with a sticker).

14.5.1 Order data

Model number	Description	Note
5CASDL.0300-13	**SDL flex cable with extender 30 m** SDL cable with extender for fixed and flexible type of layout; length: 30 m	
5CASDL.0400-13	**SDL flex cable with extender 40 m** SDL cable with extender for fixed and flexible type of layout; length: 40 m	

Table 286: Order data - SDL flex cable with extender

14.5.2 Technical data

Features	5CASDL.0300-13	5CASDL.0400-13
Length Tolerance	30 m ±200 mm	40 m ±200 mm
Dimensions - Extender box	Height 18.5 mm, width 35 mm, length 125 mm	
Cable diameter Maximum	12 mm	
Shielding	Individual cable pairs and entire cable	
Connector type Connection cycles Contacts Mechanical protection	2x DVI-D (24+1), male Min. 200 Gold plated Metal cover with crimped stress relief	
Max. tension During installation During operation	 ≤ 400 N ≤ 50 N	

Table 287: Technical data - SDL flex cable with extender 5CASDL.0x00-13

Features	5CASDL.0300-13	5CASDL.0400-13
Materials Cable shield Color	RoHS compliant Aluminum foil clad + tinned copper mesh Black (similar to RAL 9005)	
Flexibility	Flexible; valid for ferrite magnet - ferrite magnet (tested 300,000 cycles with 15x cable diameter, 4800 cycles / hour)	
Halogen-free	Yes	
Flex radius Fixed layout flexible installation	See figure "Flex radius specification", on page 451 6x cable diameter (of plug - ferrite magnet) 10x cable diameter (of ferrite magnet - extender) 15x cable diameter (of ferrite magnet - ferrite magnet)	
Weight	Approx. 6200 g	Approx. 8000 g
Electrical properties (at +20°C)		
Wire cross section	24 AWG (control wires) 26 AWG (DVI, USB, data)	
Line resistance 24 AWG 26 AWG	 ≤ 95 Ω/km ≤ 145 Ω/km	
Insulation resistance	> 200 MΩ/km	
Wave impedance	100 ±10 Ω	
Test voltage Wire / wire Wire / shield	 1 kV_{eff} 0.5 kV_{eff}	
Operating voltage	≤ 30 V	
Environmental characteristics		
Temperature resistance Fixed installation Moving Storage	 -20 to +60°C -5 to +60°C -20 to +60°C	
Fire resistance	Fire resistant in accordance with UL758 (cable vertical flame test)	
Standards and certifications		
Torsion load	100,000 cycles (tested angle of rotation: ±85° speed: 50 cycles / minute)	
Cable drag chain	300,000 cycles Tested flex radius: 180 mm;15x cable diameter; hub: 460 mm; speed: 4800 cycles / hour	
Approbation	UL AWM 20236 80°C 30 V	
Oil and hydrolysis resistance	According to VDE 0282-10	

Table 287: Technical data - SDL flex cable with extender 5CASDL.0x00-13 (Forts.)

14.5.3 Flex radius specification



Figure 230: Flex radius specification

14.5.4 Dimensions



Figure 231: Dimensions - SDL flex cable with extender 5CASDL.0x00-13

14.5.5 Contents of delivery

Amount	Component
1	SDL flex cable with extender in desired length, plug covers are attached at the cable ends.

Table 288: Contents of delivery - SDL flex cable with extender 5CASDL.0xx0-13

14.5.6 Cable specifications

The following figure shows the pin assignments for the SDL flex cable with extender available at B&R.

Information:

Only B&R SDL flex cables with extender can be used.



Figure 232: Pin assignments - SDL flex cable with extender 5CASDL.0x00-13

14.6 RS232 cable



Figure 233: RS232 extension cable (similar)

14.6.1 Order data

Model number	Description	Note
9A0014.02	**RS232 cable DB9/f:DB9/m 1.8 m** RS232 extension cable for remote operation of a display unit with touch screen, length 1.8 m.	
9A0014.05	**RS232 cable DB9/f:DB9/m 5 m** RS232 extension cable for remote operation of a display unit with touch screen, length 5 m.	
9A0014.10	**RS232 cable DB9/f:DB9/m 10 m** RS232 extension cable for remote operation of a display unit with touch screen, length 10 m.	

Table 289: Order data - RS232 cables

14.6.2 Technical data

Features	9A0014.02	9A0014.05	9A0014.10
Length Tolerance	1.8 m ±50 mm	5 m ±80 mm	10 m ±100 mm
Outer diameter	Max. 5 mm		
Shielding	Entire cable		
Connector type	DSUB (9-pin), male / female		
Wire cross section	AWG 26		
Flexibility	Flexible		
Flex radius	Min. 70 mm		

Table 290: Technical data - RS232 cables

14.6.3 Contents of delivery

Amount	Component
1	RS232 cable in desired length

Table 291: Contents of delivery - RS232 cables 9A0014.xx

14.6.4 Cable specifications

The following figure shows the pin assignments for the RS232 cable available at B&R. If you want to build a suitable cable yourself, it should be wired according to these specifications.

Warning!

If a self-built cable is used, B&R cannot guarantee that it will function properly. The RS232 cables provided by B&R are guaranteed to function properly.



Figure 234: Pin assignments - RS232 cable

14.7 USB cable



Figure 235: USB extension cable (similar)

14.7.1 Order data

Model number	Description	Note
5CAUSB.0018-00	**USB 2.0 cable, A/m:B/m 1.8 m** USB 2.0 connection cable; plug type A - type B; length 1.8 m	
5CAUSB.0050-00	**USB 2.0 cable, A/m:B/m 5 m** USB 2.0 connection cable; plug type A - type B; length 5 m	

Table 292: Order data - USB cables

14.7.2 Technical data

Features	5CAUSB.0018-00	5CAUSB.0050-00
Length Tolerance	1.8 m ±30 mm	5 m ±50 mm
Outer diameter	Max. 5 mm	
Shielding	Entire cable	
Connector type	USB type A male and USB type B male	
Wire cross section	AWG 24, 28	
Flexibility	Flexible	
Flex radius	Min. 100 mm	

Table 293: Technical data - USB cables

14.7.3 Contents of delivery

Amount	Component
1	USB cable in desired length

Table 294: Contents of delivery - USB cable

14.7.4 Cable specifications

The following figure shows the pin assignments for the USB cable available at B&R. If you want to build a suitable cable yourself, it should be wired according to these specifications.

Warning!

If a self-built cable is used, B&R cannot guarantee that it will function properly. The USB cables provided by B&R are guaranteed to function properly.



Figure 236: Pin assignments - USB cable

14.8 APC810 internal supply cable 5CAMSC.0001-00

This supply cable is used internally e.g. to supply special PCI cards. It is connected to the APC810 main board. For requirements and procedures, see "Connection of an external device to the main board", on page 500.

Caution!

Cable can only be plugged in and unplugged when the device is turned off.



Figure 237: APC810 internal supply cable - 5CAMSC.0001-00

14.8.1 Order data

Model number	Description	Note
5CAMSC.0001-00	**APC810 internal supply cable**	

Table 295: Order data - APC810 supply cable

14.8.2 Technical data

Features	5CAMSC.0001-00
Length	100 mm ± 5 mm
Connector type	1x 4-pin male disk drive power plug, 1x 4-pin female plug housing
Wire cross section	AWG 22
Flexibility	Flexible

Table 296: Technical data - APC810 internal supply cable 5CAMSC.0001-00

15. HDD replacement tray 5AC801.FRAM-00

To ensure that a hard disk can be replaced as quickly as possible, we offer the possibility to mount a compartment to the APC810 in which a replacement HDD can be stored. For more information about installing the HDD replacement disk tray, see chapter 7 "Maintenance / Servicing", section 10 "Installing the HDD replacement disk tray", on page 494.



Figure 238: HDD replacement disk tray - 5AC801.FRAM-00

15.1 Order data

Model number	Description	Note
5AC801.FRAM-00	**HDD replacement disk tray** The replacement hard disk is not included in delivery and must be ordered separately. (Order data can be found in Chapter 1 "General information" on page 31.	

Table 297: Order data - HDD replacement disk tray

15.2 Dimensions



Figure 239: Dimensions - HDD replacement disk tray

16. Ready relay 5AC801.RDYR-01

The ready relay 5AC801.RDYR-01 can be connected to the APC810 add-on UPS slot (this slot must be available). For more information about installing the ready relay, see chapter 7 "Maintenance / Servicing", section 11 "Installing the ready relay /2 in the add-on UPS slot", on page 495.

The information sheet included in delivery explains how to attach the label strips to the Automation PC 810.



Figure 240: Ready relay - 5AC801.RDYR-01

16.1 Order data

Model number	Description	Note
5AC801.RDYR-01	**APC810 Ready relay /2** Ready relay for APC810 for installation on an add-on UPS slot	

Table 298: Order data - Ready relay

16.2 Pin assignments

Pin	Assignment	Description	Figure
1	-	Not connected	
2	-	Not connected	
3	NO	Normally open	
4	COM	Change-over contact	
5	NC	Normally closed	
6	-	Not connected	

Table 299: Pin assignments - Ready relay

16.3 Contents of delivery



Figure 241: Contents of delivery - Ready relay

17. HMI Drivers & Utilities DVD 5SWHMI.0000-00

Figure 242: HMI Drivers & Utilities DVD 5SWHMI.0000-00

Model number	Short description	Note
5SWHMI.0000-00	**HMI Drivers & Utilities DVD**	

Table 300: Model number - HMI Drivers & Utilities DVD

This DVD contains drivers, utilities, software upgrades and user's manuals for B&R Panel system products (see B&R homepage **www.br-automation.com** – Industrial PCs, Visualization and Operation).

At the time of its creation, the content on the DVD is identical to the files found in the download area of the B&R homepage (under Service – “Material Related Downloads”).

BIOS upgrades for the products

- Automation PC 620 / Panel PC 700 CPU Board 815E und 855GME BIOS
- Automation PC 620 / Panel PC 700 CPU Board X855GME BIOS
- Automation PC 620 / Panel PC 700 CPU Board 945GME N270 BIOS
- Automation PC 680
- Automation PC 810 / Automation PC 820 / Panel PC 800 B945GME BIOS
- Automation PC 810 / Panel PC 800 945GME N270 CPU Board BIOS
- Automation PC 810 / Panel PC 800 GM45 CPU Board BIOS
- Provit 2000 products - IPC2000/2001/2002
- Provit 5000 products - IPC5000/5600/5000C/5600C

- Power Panel 100 BIOS devices
- Mobile Panel 100 BIOS devices
- Power Panel 100 / Mobile Panel 100 User Boot Logo
- Power Panel 100 / Mobile Panel 100 REMHOST Utility
- Power Panel 300/400 BIOS devices
- Power Panel 300/400 BIOS User Boot Logo
- Panel PC 310

Drivers for the devices

- Automation Device Interface (ADI)
- Audio
- Chipset
- CD-ROM
- LS120
- Graphics
- Network
- PCI / SATA RAID controller
- Touch screen
- Touchpad
- Interfacecard

Firmware Upgrades

- Automation PC 620 / Panel PC 700 (MTCX, SDLR, SDLT)
- Automation PC 810 (MTCX, SDLR, SDLT)
- Automation PC 820 (MTCX, SDLR, SDLT)
- Mobile Panel 100 (SMCX)
- Panel PC 300 (MTCX)
- Power Panel 100 (aPCI)
- Power Panel 300/400 (aPCI)
- Power Panel 300/400 (MTCX)
- Panel PC 800 (MTCX, SDLR, SDLT)
- UPS firmware

Utilities / Tools

- B&R Embedded OS Installer
- Windows CE Tools
- User Boot Logo Conversion Utility
- SATA RAID Installations Utility
- Automation Device Interface (ADI)
- CompactFlash endurance calculator (Silicon Systems)
- Miscellaneous
- MTC Utilities
- Key Editor
- MTC & Mkey Utilities
- Mkey Utilities
- UPS configuration software
- ICU ISA configuration
- Intel PCI NIC Boot ROM
- Diagnostic Utilities

Windows

- Windows CE 6.0
- Windows CE 5.0
- Windows CE 4.2
- Windows CE 4.1
- Windows CE Tools
- Windows Embedded Standard 2009
- Thin Client
- Windows NT Embedded
- Windows XP Embedded
- VNC Viewer

MCAD templates for

- Industrial PCs
- Operator Interface devices
- Legend Strips templates
- Customized designs

ECAD templates for

- Industrial PCs
- Automation PCs
- Automation Panel 900
- Panel (Power Panel)

Documentation for

- Automation PC 620
- Automation PC 680
- Automation PC 810
- Automation PC 820
- Automation Panel 800
- Automation Panel 900
- Panel PC 310
- Panel PC 700
- Panel PC 725
- Panel PC 800
- Power Panel 15/21/35/41
- Power Panel 100/200
- Power Panel 300/400
- Mobile Panel 40/50
- Mobile Panel 100/200
- Mobile Panel connection box
- Provit 2000
- Provit 3030
- Provit 4000
- Provit 5000
- Provit Benchmark
- Provit Mkey
- Windows CE 5.0 help
- Windows CE 6.0 help
- Windows NT Embedded application guide
- Windows XP Embedded application guide
- UPS - uninterruptible power supply

- Implementation instructions
- B&R Hilscher feldbus cards (CANopen, DeviceNet, PROFIBUS, PROFINET)

Service tools

- Acrobat Reader 5.0.5 (freeware in German, English and French)
- Power Archiver 6.0 (freeware in German, English and French)
- Internet Explorer 5.0 (German and English)
- Internet Explorer 6.0 (German and English)

Chapter 7 • Maintenance / Servicing

The following chapter describes service/maintenance work which can be carried out by a trained, qualified user.

1. Changing the battery

Information:

- **The product design allows the battery to be changed with the APC810 switched either on or off. In some countries, safety regulations do not allow batteries to be changed while the module is switched on.**
- **Any BIOS settings that have been made will remain when the battery is changed with the power turned off (stored in non-volatile EEPROM). The date and time must be reset later because this data is lost when the battery is changed.**
- **The battery should only be changed by qualified personnel.**

The following replacement lithium batteries are available: 4A0006.00-000 (1 pc.) and 0AC201.91 (4 pcs.).

1.1 Procedure

- Disconnect the power supply to the Automation PC 810.
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Remove the black plastic cover from the battery compartment and carefully pull out the battery using the removal strips.



Figure 243: Remove battery

- The battery should not be held by its edges. Insulated tweezers may also be used for inserting the battery.



Figure 244: Battery handling

- Insert the new battery with correct polarity.



Figure 245: Battery polarity

- To make the next battery change easier, be sure the removal strip is in place when inserting battery.
- Reconnect power supply to the Automation PC 810 (plug in power cable and press power button).
- Date and time might need to be reset in BIOS.

Warning!

Lithium batteries are considered hazardous waste. Used batteries should be disposed of according to local requirements.

2. Installing / exchanging a slide-in compact drive

Information:

The SATA I interface allows data carriers to be exchanged during operation (hot-plug). To utilize this capability, it must be supported by the operating system.

- Loosen and remove the two ¼ turn screws on the protective cover / slide-in compact drive.



Figure 246: Loosening the ¼ turn screws

- Insert the compact SATA drive and tighten the ¼ turn screws.

Figure 247: Inserting the compact SATA drive

3. Installing / exchanging a slide-in slot drive

Slide-in drives can be installed and exchanged in system units with 2, 3 or 5 card slots.

3.1 Procedure

- Disconnect the power supply to the Automation PC 810.
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Remove the dummy slide-in module or slide-in drive by unscrewing the two ¼ turn screws.



Figure 248: Loosening the ¼ turn screws

- Insert the slide-in drive and tighten with the two ¼ turn screws.



Figure 249: Installing the slide-in drive

4. Installing the slide-in compact adapter

Slide-in compact adapters can be installed and exchanged in system units with 2, 3 or 5 card slots. A slide-in compact drive (e.g. slide-in compact HDD) can be installed in a slide-in slot using the slide-in compact adapter.

4.1 Procedure

- Disconnect the power supply to the Automation PC 810.
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Remove the dummy slide-in module or slide-in drive by unscrewing the two ¼ turn screws.

Figure 250: Loosening the ¼ turn screws

- Insert the slide-in compact adapter and tighten with the two ¼ turn screws.



Figure 251: Installing the slide-in compact adapter

- Once the adapter has been installed, the slide-in compact drive can be inserted.

Figure 252: Inserting the slide-in compact drive

5. Installing / exchanging the fan kit

- Remove side cover (see section "Mounting the side cover", on page 489).
- After the screws have been removed, the fan kit cover can be removed toward the front.



Figure 253: Remove fan kit insert

- Insert the frame - Mount the contact board side to the sliding contacts on the system unit and fasten using the ¼ turn screws.



Figure 254: Inserting and fastening the fan kit

- Place the dust filter in the fan kit cover and secure with the filter clasp.



Figure 255: Securing the dust filter with the filter clasp

- Place the fan kit cover in the housing and fasten using the Torx screws removed earlier.

Information:

Regular control of the dust filter depending on area of use and degree of dirtiness.

Installation is the same as for all APC810 devices.

6. Installing the UPS module

The module is installed using the materials included in the delivery.



Figure 256: Add-on UPS module 5AC600.UPSI-00 - Installation materials

Installation may vary depending the system unit type (1, 2 or 5 card slots) or whether an add-on interface module (IF option) is installed in the APC810.

6.1 Installation without installed add-on interface module

Different parts are used depending on the system unit and whether the add-on interface module is **installed** (description starting on page 483) or **not installed** (description follows).

6.1.1 APC810 1 card slot

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove UPS module cover by removing the 2 marked Torx screws (T10).

Figure 257: Remove UPS module cover

- Screw in spacing bolt and spacing ring on the main board (using M5 hex socket screwdriver).



Figure 258: Screw in spacing bolt and spacing ring

- Install UPS module with 2 Torx screws (T10) on the housing and 1 Torx screw (T10) on the main board (spacing bolt). Use the previously removed Torx screws from the mounting materials.



Figure 259: Install UPS module

- Plug in connection cable (see marked socket).



Figure 260: Plug in connection cable

Information:

When connecting the cable, make sure that the connector locking mechanism is engaged.



Figure 261: Connector locking mechanism

- Attach the side cover.

6.1.2 APC810 2 and 3 card slot

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove UPS module cover by removing the 2 marked Torx screws (T10).



Figure 262: Remove UPS module cover

- Screw in spacing bolt and spacing ring on the main board (using M5 hex socket screwdriver).



Figure 263: Screw in spacing bolt and spacing ring

- Install mounting bracket on UPS module using 2 Torx screws (T10).



Figure 264: Install mounting bracket

- Install UPS module with 2 Torx screws (T10) on the housing and 1 Torx screw (T10) on the main board (spacing bolt). Use the previously removed Torx screws from the mounting materials.



Figure 265: Install UPS module

- Plug in connection cable (see marked socket).



Figure 266: Plug in connection cable

Information:

When connecting the cable, make sure that the connector locking mechanism is engaged.



Figure 267: Connector locking mechanism

- Attach the side cover.

6.1.3 APC810 5 card slot

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove UPS module cover by removing the 2 marked Torx screws (T10).



Figure 268: Remove UPS module cover

- Screw in spacing bolt and spacing ring (using M5 hex socket screwdriver).



Figure 269: Screw in spacing bolt and spacing ring

- Install mounting bracket on UPS module using 2 Torx screws (T10).



Figure 270: Install mounting bracket

- Install UPS module with 2 Torx screws (T10) on the housing and 1 Torx screw (T10) on the main board (spacing bolt). Use the previously removed Torx screws from the mounting materials.



Figure 271: Install UPS module

- Attach connection cable (see marked socket).



Figure 272: Plug in connection cable

Information:

When connecting the cable, make sure that the connector locking mechanism is engaged.



Figure 273: Connector locking mechanism

- Attach the side cover

6.2 Installation with installed add-on interface module

6.2.1 APC810 1 card slot

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove UPS module cover by removing the 2 marked Torx screws (T10).

Figure 274: Remove UPS module cover

- Screw in spacing bolt (using M5 hex socket screwdriver).



Figure 275: Screw in spacing bolt

- Install the UPS module using 3 Torx screws (T10). Use the previously removed Torx screws and one Torx screw from the mounting materials.



Figure 276: Install UPS module

- Plug in connection cable (see marked socket).



Figure 277: Plug in connection cable

Information:

When connecting the cable, make sure that the connector locking mechanism is engaged.



Figure 278: Connector locking mechanism

- Attach cover plate and side cover.

6.2.2 APC810 2 and 3 card slot

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove UPS module cover by removing the 2 marked Torx screws (T10).



Figure 279: Remove UPS module cover

- Screw in spacing bolt (using M5 hex socket screwdriver).







Figure 280: Screw in spacing bolt

- Install mounting bracket on UPS module using 2 Torx screws (T10).

Figure 281: Install mounting bracket

- Install the UPS module using 3 Torx screws (T10). Use the previously removed Torx screws and one Torx screw from the mounting materials.



Figure 282: Install UPS module

- Plug in connection cable (see marked socket).



Figure 283: Plug in connection cable

Information:

When connecting the cable, make sure that the connector locking mechanism is engaged.



Figure 284: Connector locking mechanism

- Attach cover plate and side cover.

6.2.3 APC810 5 card slot

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove UPS module cover by removing the 2 marked Torx screws (T10).



Figure 285: Remove UPS module cover

- Screw in spacing bolt (using M5 hex socket screwdriver).



Figure 286: Screw in spacing bolt

- Install mounting bracket on UPS module using 2 Torx screws (T10).



Figure 287: Install mounting bracket

- Install the UPS module using 3 Torx screws (T10). Use the previously removed Torx screws and one Torx screw from the mounting materials.



Figure 288: Install UPS module

- Plug in connection cable (see marked socket).



Figure 289: Plug in connection cable

Information:

When connecting the cable, make sure that the connector locking mechanism is engaged.



Figure 290: Connector locking mechanism

- Attach cover plate and side cover.

7. Mounting the side cover

The side cover can be easily removed by loosening the Torx (T10) screws. The number of Torx screws can vary depending on the system.

7.1 APC810 with 1 card slot

- Disconnect the power supply to the Automation PC 810.
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Open the orange front cover. Behind the cover there are 4 Kombitorx screws (T10) that must be removed.



Figure 291: Mounting the side cover - APC810 1 card slot

- After the screws have been removed, the side cover can be removed by sliding it toward the front.

7.2 APC810 with 2 and 3 card slot

- Disconnect the power supply to the Automation PC 810.
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Open the orange front cover. Behind the cover there are 4 Kombitorx screws (T10) that must be removed.

Figure 292: Mounting the side cover - APC810 2 card slot

- After the screws have been removed, the side cover can be removed by sliding it toward the front.

7.3 APC810 with 5 card slot

- Disconnect the power supply to the Automation PC 810.
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Open the orange front cover. Behind the cover there are 4 Kombitorx screws (T10) that must be removed.



Figure 293: Mounting the side cover - APC810 5 card slot

- After the screws have been removed, the side cover can be removed by sliding it toward the front.

8. AP Link installation

- Remove side cover (see section "Mounting the side cover", on page 489).
- Remove AP Link module cover by removing the 2 marked Torx screws (T10).



Figure 294: Remove AP Link module cover

- Insert the AP Link card in appropriate slot.

Warning!

When inserting the AP Link card, be sure to push it all the way into the AP Link slot. Do not force the card into the slot.

- Install the AP Link module using 3 Torx screws (T10). Use the previously removed Torx screws and an additional Torx screw from the mounting materials.



Figure 295: Install AP Link module

- Attach cover plate and side cover.

9. Exchanging a PCI SATA RAID hard disk in a RAID 1 system

In the example, the assumption is made that the secondary hard disk (HDD1) is defective in a RAID 1 configuration. In such a case, the defective hard disk can be replaced by the replacement drive SATA hard disk.

Model number - PCI SATA RAID controller	Model number of required replacement SATA HDD	Note
5ACPCI.RAIC-03	5ACPCI.RAIC-04	160 GB hard disk

Table 301: Overview of required replacement SATA HDD for PCI SATA HDD RAID controller

A size 10 Torx screwdriver is needed for exchanging the hard disk.

9.1 Exchange procedure

- Remove the power supply to the device (Automation PC 620 / Panel PC 700 / Automation PC 810).
- Touch the housing or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.
- Remove the side cover.
- Remove the SATA RAID insert.
- Loosen the 4 appropriate mounting screws (M3x5).



Figure 296: Screw layout on the back side of the SATA RAID controller 5ACPCI.RAIC-03

- On the front side, slide the hard disk down and away (image 1).
- Insert the new hard disk carefully into the connector (image 2), being careful to only touch it on the front, and not on the top.



Figure 297: Hard disk exchange

- Re-secure the hard disk using the 4 fastening screws (M3x5) used earlier.
- Reassemble device in the reverse order.
- An error message is output by the RAID BIOS after starting the system "`RAID1 set is in Critical status - press any key to enter Configuration Utility`".
- A rebuild must be executed in the SATA RAID BIOS - for more information on this, see the section "Rebuild mirrored set", on page 237.

10. Installing the HDD replacement disk tray

- Insert the replacement HDD in the replacement disk tray and fasten using the ¼ turn screws.



Figure 298: Installing the replacement hard disk in the replacement disk tray

- Attach the HDD replacement disk tray to the ventilation slots on the APC810 housing using the hooks provided.



Figure 299: Installing the replacement disk tray in the APC810

11. Installing the ready relay /2 in the add-on UPS slot

- Remove side cover (see section 7 "Mounting the side cover", on page 489).
- Remove UPS module cover or mounted UPS by loosening the 2 marked Torx screws (T10).

Figure 300: Remove UPS module cover

- Attach spacing bolt and spacing ring (if not already mounted from the UPS) on the main board (using size 5 hex screwdriver).
  The spacing bolt with a length of 14 mm must be used for APC810 system units 5PC810.SX01-00, 5PC810.SX02-00 and 5PC810.SX03-00. The spacing bolt with a length of 16 must be used for the system unit 5PC810.SX05-00.



Figure 301: Screw in spacing bolt and spacing ring

- Ready relay with 2 Torx screws (T6) and the mounting bracket on the housing and 1 Torx screw (T6) on the main board (spacing bolt).



Figure 302: Installing the ready relay

- Plug in connection cable

Information:

When connecting the internal supply voltage cable, make sure that the connector locking mechanism is engaged.



Figure 303: Plug in connection cable

- Attach the side cover

Appendix A

1. Temperature sensor locations

Sensors indicate temperature values at many different locations in the APC810 (CPU, board I/O, slide-in drive, etc). The temperatures[1)] can be read in BIOS (menu item "advanced" - CPU monitor) or in Microsoft Windows XP/embedded, using B&R Control Center[2)] .



Figure 304: Temperature sensor locations

Position	Measurement point for	Measurement	Max. specified
1	CPU	Processor temperature (sensor integrated on the processor).	100°C
2	Board	CPU board temperature (sensor integrated on the CPU board).	85°C
3	Board I/O	Board I/O area temperature (sensor on the baseboard).	85°C
4	Board ETH2	Baseboard temperature near the ETH2 controller (sensor on the baseboard).	80°C
5	Board power supply	Board power supply temperature (sensor on the baseboard).	80°C
6	ETH2 Controller	Temperature of ETH2 controller (sensor in the ETH2 controller).	125°C
7	Power supply	Power supply temperature (sensor on the power supply).	80°C
8	Slide-in drive 1	Temperature of a slide-in drive 1 (the sensor is integrated on the slide-in drive)	Drive-dependent
8	Slide-in drive 2	Temperature of a slide-in drive 1 (the sensor is integrated on the slide-in drive)	Drive-dependent

Table 302: Temperature sensor locations

1) The measured temperature is a guideline for the immediate ambient temperature, but can be influenced by neighboring components.

2) The B&R Control Center - ADI driver - can be downloaded for free from the download area on the B&R homepage (**www.br-automation.com**).

2. Maintenance Controller Extended (MTCX)

The MTCX controller (FPGA processor) is located on the main board (part of every system unit) of the APC810 device.



Figure 305: MTCX controller location

The MTCX is responsible for the following monitoring and control functions:

- Power on (power OK sequencing) and power fail logic
- Watchdog handling (NMI and reset handling)
- Temperature monitoring (I/O area, power supply, slide-in drive 1/2)
- Fan control
- Key and LED handling/coordination (matrix keyboard on B&R display units)
- Advanced desktop operation (keys, USB forwarding)
- Daisy chain display operation (touch screen, USB forwarding)
- Panel locking mechanism (configurable using B&R Control Center - ADI driver)
- Backlight control for a connected B&R display
- Statistical data recording (power cycles - each power on, power on and fan hours are recorded - every full hour is counted e.g. 50 minutes no increase)
- SDL data transfer (display, matrix keyboard, touch screen, service data, USB)
- Status LEDs (HDD, Panel Lock, Link 1, Link 2)

The functions of the MTCX can be expanded via Firmware upgrade[1)] . The version can be read in BIOS (menu item "advanced" - baseboard/panel features) or in Microsoft Windows XP/embedded, using B&R Control Center.

For more information, see section 2.2 "Firmware upgrade", on page 318.

1) Can be downloaded from the download area on the B&R homepage (www.br-automation.com).

2.1 Temperature monitoring - Fan control

The MTCX constantly monitors the temperature using temperature sensors (see section 1 "Temperature sensor locations", on page 497), which directly determine how the fan is controlled. The RPM depends on the temperature measured. The limit values depend on the MTCX firmware version being used.

Sensor range	Start-up temperature	Max fan speed at:
CPU	+ 65°C	+ 81°C
Board CPU	+ 65°C	+ 81°C
Board I/O	+ 60°C	+ 76°C
Board ETH2	+ 60°C	+ 76°C
Board Power	+ 60°C	+ 76°C
Power supply	+ 60°C	+ 76°C
ETH2 Controller	+ 70°C	+ 86°C
Slide-in 1/2	+ 44°C	+ 60°C

Table 303: Temperature limits of the fan (MTCX PX32 V0.06).

Once the start-up temperature is reached, the device is started at the minimum fan speed. The maximum fan speed is reached at a start-up temperature of 16°C. The fan speed in this area is controlled depending on the temperature.

For example, slide-in 1/2: 44°C + 16°C = 60°C --> maximum fan speed

The fans are first switched off again if the evaluated temperature remains 6°C lower than the start-up temperature for a time span of 4 hours (=lag-time).

3. Connection of an external device to the main board

A plug on the main board enables branching of +5 VDC and +12 VDC for the internal supply of e.g. special PCI cards.

The voltage can be accessed using the "APC810 internal supply cable 5CAMSC.0001-00", on page 457. The plug is located close to the bus unit(s) and can be attached to it with a cable tie (see arrow in image). The APC810 side cover (see 7 "Mounting the side cover", on page 489) and possibly also the slide-in drive and PCI cards must be removed to reach the connector.



Figure 306: Connector location for external devices

Connector for the external devices			
Pin	**Assignment**	**Power**	4-pin connector, male 
1	+12 VDC	Max. 10 watts	
2	GND		
3	GND	Max. 5 watts	
4	+5 VDC		

Table 304: Pin assignments - Connector on main board

Connections are protected with a 1A multi-fuse.

4. B&R Key Editor information

On display units, it is often necessary to adjust the function keys and LEDs for the application software being used. The B&R Key Editor makes it quick and easy to adapt the application to a unique configuration.



Figure 307: B&R Key Editor screenshots Version 3.10 (representation picture)

Features:

- Configuration of normal keys like on a keyboard (A, B, C, etc.)
- Keyboard shortcuts (CTRL+C, SHIFT+DEL, etc.) on one key
- Special key functions (change brightness, etc.)
- Assign functions to LEDs (HDD access, power, etc.)
- 4 assignments per key possible (using layer function)
- Configuration of panel locking time when multiple Automation Panel 900 devices are connected to Automation PCs and Panel PCs devices.

Supports following systems (Version 3.10):

- Automation PC 620
- Automation PC 810
- Automation PC 820
- Automation Panel 800
- Automation Panel 900
- IPC2000, IPC2001, IPC2002
- IPC5000, IPC5600
- IPC5000C, IPC5600C
- Mobile Panel 40/50
- Mobile Panel 100/200
- Panel PC 300
- Panel PC 700
- Panel PC 800
- Power Panel 100/200
- Power Panel 300/400
- Power Panel 500 (the Key Editor device file must be downloaded separately from the B&R homepage)

A detailed guide for configuring keys and LEDs can be found in the B&R Key Editor's online help.

The B&R Key Editor can be downloaded for free from the download area on the B&R homepage (**www.br-automation.com**). Additionally, it can also be found on the B&R HMI Drivers & Utilities DVD (model number 5SWHMI.0000-00).

5. B&R Automation Device Interface (ADI) development kit

This software can be used to activate functions of the B&R Automation Device Interface (ADI) from Windows applications, which, for example, were created using the following development tools:

- Microsoft Visual C++ 6.0
- Microsoft Visual Basic 6.0
- Microsoft eMbedded Visual C++ 4.0
- Microsoft Visual Studio 2005 (or newer)



Figure 308: ADI development kit screenshots (Version 3.10)

Features:

- One Microsoft Visual Basic module with declarations for the ADI functions.
- Header files and import libraries for Microsoft Visual C++.
- Help files for Visual Basic and Visual C++.
- Sample projects for Visual Basic and Visual C++.
- ADI DLL (for testing the applications, if no ADI driver is installed).

Supports following systems (Version 3.10 and higher):

- Automation PC 620
- Automation PC 810
- Automation PC 820
- Mobile Panel 40/50
- Mobile Panel 100/200
- Panel PC 300
- Panel PC 700
- Panel PC 800
- Power Panel 100/200
- Power Panel 300/400
- Power Panel 500

The ADI driver suitable for the device must be installed on the stated product series. The ADI driver is already included in the B&R images of embedded operating systems.

A detailed description of using the ADI functions can be found in the integrated online help.

The B&R Automation Device Interface (ADI) development kit can be downloaded for free from the download area on the B&R homepage (**www.br-automation.com**).

6. B&R Automation Device Interface (ADI) .NET SDK

This software can be used to activate functions of the B&R Automation Device Interface (ADI) from .NET applications, which were created using Microsoft Visual Studio 2005 (or newer).

Supported programming languages:

- Visual Basic
- Visual C++
- Visual C#
- Visual J#

System requirements:

- Developingsystem: PC with Windows XP/7 with
  - Microsoft Visual Studio 2005 or newer
  - Microsoft .NET Framework 2.0 and / or Microsoft .NET Compact Framework 2.0 or newer



Figure 309: ADI .NET SDK Screenshots (Version 1.50)

Features:

- ADI .NET Class Library.
- Help files in HTML Help 1.0 format (.chm file) and MS Help 2.0 format (.HxS file).
- Sample projects and code snippets for Visual Basic, Visual C++, Visual C# and Visual J#.
- ADI DLL (for testing the applications, if no ADI driver is installed).

Supports following systems (Version 1.50 and higher):

- Automation PC 620
- Automation PC 810
- Automation PC 820
- Mobile Panel 40/50
- Mobile Panel 100/200
- Panel PC 300
- Panel PC 700
- Panel PC 800
- Power Panel 100/200
- Power Panel 300/400
- Power Panel 500

The ADI driver suitable for the device must be installed on the stated product series. The ADI driver is already included in the B&R images of embedded operating systems.

A detailed description of using the ADI functions can be found in the integrated online help.

The ADI .NET SDK can be downloaded for free from the download area on the B&R homepage (**www.br-automation.com**).

7. Glossary

A

ACPI

Abbreviation for "**A**dvanced **C**onfiguration and **P**ower **I**nterface". Configuration interface that enables the operating system to control the power supply for each device connected to the PC. With ACPI, the computer's BIOS is only responsible for the details of communication with the hardware.

ADI

Abbreviation for »Automation Device Interface« The ADI interface allows access to specific functions (e.g. brightness control, firmware updates, static value read) of B&R devices. The settings can be read or changed in the Control Panel with the B&R Control Center Applet (already included in the B&R embedded operating system).

APC

An abbreviation for "**A**utomation **PC**".

API

Abbreviation for "**A**pplication **P**rogram **I**nterface" The interface, which allows applications to communicate with other applications or with the operating system.

Automation Runtime

A uniform runtime system for all B&R automation components.

B

Baud rate

Measurement unit for data transfer speed. It indicates the number of states for a transferred signal per second and is measured using the baud unit of measurement. 1 baud = 1 bit/sec or 1 bps.

BIOS

An abbreviation for "**B**asic **I**nput/**O**utput **S**ystem". Core software for computer systems with essential routines for controlling input and output processes on hardware components, for performing tests after system start and for loading the operating system. Although BIOS is used to configure a system's performance, the user does not usually come into contact with it.

Bit

Binary digit > binary position, binary character, smallest discrete unit of information. A bit can have the value 0 or 1.

Bit rate

The number of bits that can be transferred within a specified time unit. 1 bit/sec = 1 baud.

Byte

Data format [1 byte = 8 bits] and a unit for characterizing information amounts and memory capacity. The following units are the commonly used units of progression: KB, MB, GB.

B&R Automation Runtime

Windows-based program for creating installation disks to install B&R Automation Runtime™ on the target system.

C

Cache

Background memory, also known as non-addressable memory or fast buffer memory. It is used to relieve the fast main memory of a computer. For example, data that should be output to slower components by the working memory (e.g. disk storage, printers) is stored temporarily in cache memory and output from there at an appropriate speed for the target devices.

CAN

An abbreviation for "**C**ontroller **A**rea **N**etwork" (serial bus system). Structure according to ISO 11898; Bus medium: twisted pair. Good transfer properties in short distances less than 40 m with a 1 MBit/sec data transfer rate. Maximum number of stations: Theoretically unlimited, but practically limited up to 64. Real-time capable (i.e. defined maximum latency times for messages with high priority). High reliability using error detection, error handling, troubleshooting. Hamming distance.

CD-ROM

Abbreviation for "**C**ompact **D**isc **R**ead-**O**nly **M**emory". A removable data medium with a capacity of ~700 MB. CD-ROMs are optically scanned.

CE mark

A CE mark for a product. It consists of the letters "CE" and indicates conformity to all EU guidelines for the labeled product. It indicates that the individual or corporate body who has performed or attached the label assures that the product conforms to all EU guidelines for complete harmonization. It also indicates that all mandatory conformity evaluation procedures have taken place.

CMOS

"CMOS" is a battery powered memory area where fundamental parameters of an IBM (or compatible) personal computer are stored. Information such as the type of hard drive, size of the working memory and the current date and time are required when booting the computer. As the name suggests, the memory is based on CMOS technology standards.

COM

A device name used to access serial ports in MS-DOS. The first serial port can be accessed under COM1, the second under COM2, etc. A modem, mouse, or serial printer is typically connected to a serial port.

COM1

Device name for the first serial port in a PC system. The input/output area for COM1 is usually found at address 03F8H. Generally, the COM1 port is assigned to IRQ 4. In many systems, an RS232 serial mouse is connected to COM1.

COM2

Device name for the second serial port in a PC system. The input/output area for COM2 is usually found at address 02F8H. Generally, the COM2 port is assigned to IRQ 3. In many systems, a modem is connected to COM2.

COM3

Device name for a serial port in a PC system. The input/output area for COM3 is usually found at address 03E8H. Generally, the COM3 port is assigned to IRQ 4. In many systems, COM3 is used as an alternative for COM1 or COM2 if peripheral devices are already connected to COM1 and COM2.

CompactFlash®

CompactFlash memory cards [CF cards] are exchangeable nonvolatile mass memory systems with very small dimensions [43 x 36 x 3.3 mm, approximately half the size of a credit card]. In addition to the flash memory chips, the controller is also present on the cards. CF cards provide complete PC card / ATA functionality and compatibility. A 50-pin CF card can be simply inserted in a passive 68-pin type II adapter card. It conforms to all electrical and mechanical PC card interface specifications. CF cards were launched by SanDisk back in 1994. Currently, memory capacities reach up to 64 GB per unit. Since 1995, CompactFlash Association [CFA] has been looking after standardization and the worldwide distribution of CF technology

Controller

A device component which allows access to other devices on a computer subsystem. A disk controller, for example, allows access to hard disks and disk drives and is responsible both for physical and logic drive access.

CPU

An abbreviation for "**C**entral **P**rocessing **U**nit". Interprets and executes commands. It is also known as a "microprocessor" or "processor" for short. A processor is able to receive, decode and execute commands, as well as transfer information to and from other resources via the computer bus.

CRT

Abbreviation for Cathode Ray Tube. The main component of a television set or a standard computer screen. A cathode ray tube consists of a vacuum tube that contains one or more electron guns. Each electron gun creates a horizontal electron beam that appears on the front of the tube (the screen). The inner surface of the screen is coated with phosphor, which is lit when hit by the electrons. Each of the electron beams move in a line from top to bottom. In order to prevent flickering, the screen content is updated at least 25 times per second. The sharpness of the picture is determined by the number of pixels on the screen.

CTS

An abbreviation for "**C**lear **T**o **S**end". A signal used when transferring serial data from modem to computer, indicating its readiness to send the data. CTS is a hardware signal which is transferred via line number 5 in compliance with the RS-232-C standard.

D

DCD

An abbreviation for "**D**ata **C**arrier **D**etected". A signal used in serial communication that is sent by the modem to the computer it is connected to, indicating that it is ready for transfer.

Dial-up

Data is transferred over the telephone network using a modem or an ISDN adapter.

DIMM

"Double In-line Memory Module" consisting of one or more RAM chips on a small circuit board that is connected with the motherboard of a computer.

DMA

Direct **M**emory **A**ccess > Accelerated direct access to a computer's RAM by bypassing the CPU.

DRAM

An abbreviation for "**D**ynamic **R**andom **A**ccess **M**emory". Dynamic RAM consists of an integrated semiconductor circuit that stores information based on the capacitor principle. Capacitors lose their charge in a relatively short time. Therefore, dynamic RAM circuit boards must contain a logic that allows continual recharging of RAM chips. Since the processor cannot access dynamic RAM while it is being recharged, one or more waiting states can occur when

reading or writing data. Although it is slower, dynamic RAM is used more often than static RAM since the simple design of the circuits means that it can store four times more data than static RAM.

DSR

An abbreviation for "**D**ata **S**et **R**eady". A signal used in serial data transfer, which is sent by the modem to the computer it is connected to, indicating its readiness for processing. DSR is a hardware signal which is sent via line number 6 in compliance with the RS-232-C standard.

DTR

An abbreviation for "**D**ata **T**erminal **R**eady". A signal used in serial data transfer that is sent by the computer to the modem it is connected to, indicating the computer's readiness to accept incoming signals.

DVD

An abbreviation for "**D**igital **V**ersatile **D**isc". The next generation of optical data carrier technology is able to store a higher volume of data than conventional CDs. Standard DVDs, which have a single layer, can hold 4.7 GB. Dual-layer DVDs can hold 8.5 GB. Double-sided DVDs can therefore hold up to 17 GB. A special drive is needed for DVDs. Conventional CDs can also be played on DVD drives.

DVI

Abbreviation for "**D**igital **V**isual **I**nterface" An interface for the digital transfer of video data.

DVI-A

Analog only

DVI-D

Digital only

DVI-I

Integrated, i.e. analog and digital

E

EDID data

Abbreviation for "**E**xtended **D**isplay **I**dentification **D**ata". EDID data contains the characteristics of monitors / TFT displays transferred as 128 KB data blocks to the graphics card via the Display Data Channel (DDC). This EDID data can be used to set the graphics card to the monitor properties.

EIDE

An abbreviation for "**E**nhanced **I**ntegrated **D**rive **E**lectronics". An expansion of the IDE standard. Enhanced IDE is considered the standard for hardware interfaces. This interface is designed for drives with an integrated drive controller.

EMC

"**E**lectro**m**agnetic **C**ompatibility" The ability of a device or a system to function satisfactorily in its electromagnetic environment without introducing intolerable electromagnetic disturbances to anything in that environment [IEV 161-01-07].

EPROM

Erasable **PROM** > (completely with ultraviolet light).

Ethernet

An IEEE 802.3 standard for networks. Ethernet uses bus or star topology and controls the traffic on communication lines using the access procedure CSMA/CD (Carrier Sense Multiple Access with Collision Detection). Network nodes are connected using coaxial cables, fiber optic cables or twisted pair cabling. Data transfer on an Ethernet network takes place in frames of variable lengths that consist of supply and controller information as well as 1500 bytes of data. The Ethernet standard provides base band transfers at 10 megabit and 100 megabit per second.

Ethernet POWERLINK

An enhancement of standard Ethernet. It enables data exchange under strict real-time conditions with cycle times down to 200 µs and jitter under 1 µs. This makes Ethernet power available on all communication levels of automation technology – from control levels to I/O. Ethernet POWERLINK was initiated by the company B&R Industrie-Elektronik and is now managed by the open end user and vendor association, EPSG - Ethernet POWERLINK Standardization Group (**www.ethernet-powerlink.org**).

ETX

Abbreviation for "**E**mbedded **T**echnology e**X**tended" This established standard offers complete PC functionality on a very compact form factor of just 114 mm x 100 mm (´4.5" x 4"). The flexibility offered by ETX® in the development of system specific main boards allows easy requirement fulfillment in a number of different applications.

F

FDD

Abbreviation for "**F**loppy **D**isk **D**rive". Reading device for removable magnetic memory from the early days of PC technology. Due to their sensitivity and moving components, FDDs have been almost completely replaced by CompactFlash memory in modern automation solutions.

Fiber optics

Fiber optic cable

FIFO

An abbreviation for "**F**irst **I**n **F**irst **O**ut". A queuing organization method whereby elements are removed in the same order as they were inserted. The first element inserted is the first one removed. Such an organization method is typical for a list of documents that are waiting to be printed.

Firmware

Programs stored permanently in read-only memory. Firmware is software used to operate computer-controlled devices that generally stays in the device throughout its lifespan or over a long period of time. Such software includes operating systems for CPUs and application programs for industrial PCs as well as programmable logic controllers (e.g. the software in a washing machine controller). This software is written in read-only memory (ROM, PROM, EPROM) and cannot be easily replaced.

Floppy

Also known as a diskette. A round plastic disk with an iron oxide coating that can store a magnetic field. When the floppy disk is inserted in a disk drive, it rotates so that the different areas (or sectors) of the disk's surface are moved under the read/write head. This allows the magnetic orientation of the particle to be modified and recorded. Orientation in one direction represents binary 1, while the reverse orientation represents binary 0.

FPC

An abbreviation for "**F**lat **P**anel **C**ontroller".

FPD

An abbreviation for "**F**lat **P**anel **D**isplay".

FTP

"**F**ile **T**ransfer **P**rotocol" Rules for transferring data over a network from one computer to another computer. This protocol is based on TCP/IP, which has established itself as the standard for transferring data over Ethernet networks. FTP is one of the most used protocols on the Internet. It is defined in RFC 959 in the official regulations for Internet communication.

G

GB

Gigabyte (1 GB = 230 or 1,073,741,824 Bytes)

H

Handshake

Method of synchronization for data transfer when data is sent at irregular intervals. The sender signals that data can be sent, and the receiver signals when new data can be received.

HDD

An abbreviation for "**H**ard **D**isk **D**rive". Fixed magnetic mass memory with high capacities, e.g. 120 GB.

I

IDE

An abbreviation for "**I**ntegrated **D**rive **E**lectronics". A drive interface where the controller electronics are integrated in the drive.

Interface

From the hardware point of view, an interface is the connection point between two modules/devices/systems. The units on both sides of the interface are connected by the interface lines so that data, addresses, and control signals can be exchanged. The term interface includes all functional, electrical and constructive conditions [encoding, signal level, pin assignments] that characterize the connection point between the modules, devices, or systems. Depending on the type of data transfer, a differentiation is made between parallel [e.g. Centronics, IEEE 488] and serial interfaces [e.g. V.24, TTY, RS232, RS422, RS485], which are set up for different transfer speeds and transfer distances. From the point of view of software, the term "interface" describes the transfer point between program modules using specified rules for transferring the program data.

ISA

An abbreviation for "**I**ndustry **S**tandard **A**rchitecture". A term given for the bus design which allows expansion of the system with plug-in cards that can be inserted in PC expansion slots.

ISO

International Organization for Standardization > Worldwide federation of national standardization institutions from over 130 countries. ISO is not an acronym for the name of the organization; it is derived from the Greek word "isos", meaning "equal" (**www.iso.ch**).

J

Jitter

Jitter is a term that describes time deviations of cyclic events. If, for example, an event should take place every 200ìs and it actually occurs every 198 to 203ìs, then the jitter is 5ìs. Jitter has many causes. It originates in the components and transfer media of networks because of noise, crosstalk, electromagnetic interference and many other random occurrences. In automation technology, jitter is a measure of the quality of synchronization and timing.

Jumper

A small plug or wire link for adapting the hardware configuration used to connect the different points of an electronic circuit.

K

Keypad modules

Keypad modules are divided into two groups: **Standard Keypad Modules** (can be cascaded to a controller) and **Special Keypad Modules** (must be connected by an electrician according to the function e.g. Emergency Stop)

L

LCD

An abbreviation for "**L**iquid **C**rystal **D**isplay". A display type, based on liquid crystals that have a polarized molecular structure and are enclosed between two transparent electrodes as a thin layer. If an electrical field is applied to the electrodes, the molecules align themselves with the field and form crystalline arrangements that polarize the light passing through. A polarization filter, which is arranged using lamellar electrodes, blocks the polarized light. In this way, a cell (pixel) containing liquid crystals can be switched on using electrode gates, thus coloring this pixel black. Some LCD displays have an electroluminescent plate behind the LCD screen for lighting. Other types of LCD displays can use color.

LED

An abbreviation for "**L**ight **E**mitting **D**iode". A semiconductor diode which converts electrical energy into light. LEDs work on the principle of electroluminescence. They are highly efficient because they do not produce much heat in spite of the amount of light they emit. For example, "operational status indicators" on floppy disk drives are LEDs.

LPT

Logical device name for line printers. In MS-DOS, names are reserved for up to three parallel printer ports with the names LPT1, LPT2 and LPT3. The first parallel port (LPT1) is usually identical to the primary parallel output device PRN (in MS-DOS the logical device name for the printer). The abbreviation LPT stands for "Line Printer Terminal".

M

MB

Megabyte (1 MB = 220 or 1,048,576 bytes).

Microprocessor

Highly integrated circuit with the functionality of a CPU, normally housed on a single chip. It comprises a control unit, arithmetic and logic unit, several registers and a link system for connecting memory and peripheral components. The main performance features are the internal and external data bus and address bus widths, the command set and the clock frequency. Additionally, a choice can be made between CISC and RISC processors. The first commercially available worldwide microprocessor was the Intel 4004. It came on the market in 1971.

MIPS

Million instructions per second > Measurement for the computing speed of computers.

Mkey

An abbreviation for "**M**odule **key**block". A common term given to keys found on Provit display units. They can be freely configured with Mkey utilities.

Modem

Modulator/demodulator. > Modulation/demodulation device, add-on card, or external device that allows information to be exchanged between computers over the telephone network using digital/analog or analog/digital signal conversion.

Motherboard

A circuit board that houses the main components of a computer such as the CPU switching circuit, co-processors, RAM, ROM for firmware, interface circuits, and expansion slots for hardware expansions.

MTBF

An abbreviation for "**M**ean **t**ime **b**etween **f**ailure". The average time which passes before a hardware component fails and repair is needed. This time is usually expressed in thousands or ten thousands of hours, sometimes known as power-on hours (POH).

MTCX

An abbreviation for »**M**ain**t**enance **C**ontroller E**X**tended«. The MTCX is an independent processor system that provides additional functions for a B&R industrial PC that are not available with a normal PC. The MTC communicates with the B&R industrial PC via the ISA bus (using a couple register).

Multitasking

Multitasking is an operating mode in an operating system that allows several computer tasks to be executed virtually simultaneously.

N

.NET

DOTNET, Microsoft's new development platform that provides a common runtime library and type system for all programming languages. DOTNET is the umbrella term for the following products, strategies and technologies: .NET Framework, a new software platform, Visual Studio .NET, a new development environment that supports several .NET programming languages (e.g. C# or VB.NET, specially created for .NET), .NET My Services, a group of services taking over functions such as authentication, .NET Enterprise Server, which, apart from its name, is independent of the other technologies and includes the products Exchange Server 2000, Application Center 2000, and SQL Server 2000. .NET devices, supported by a slimmed down version of .NET Framework (.NET Compact Framework).

O

OEM

Abbreviation for "**O**riginal **E**quipment **M**anufacturer"; A company that integrates third-party and in-house manufactured components into their own product range and then distributes these products under its own name.

OPC

OLE for Process Control > A communication standard for components in the area of automation. The goal of OPC development is to provide an open interface that builds on Windows-based technologies such as OLE, COM and DCOM. It allows problem-free standardized data transfer between controllers, operating and monitoring systems, field devices and office applications from different manufacturers. This development is promoted by the OPC Foundation, which is made up of over 200 companies from around the world, including Microsoft and other leading companies. Nowadays, OPC is also interpreted as a synonym for Openness, Productivity and Connectivity, symbolizing the new possibilities that this standard opens up.

OPC server

The missing link between connection modules for the Interbus and the visualization application. It communicates serially with the connection modules via the ISA or PCI bus or Ethernet.

P

Panel

A common term for B&R display units (with or without keys).

Panelware

A generic term given for standard and special keypad modules offered by B&R.

PC Card

Registered trademark of PCMCIA for add-on cards conforming to PCMCIA specifications.

PCI Bus

Abbreviation for "**P**eripheral **C**omponent **I**nterconnect bus". Developed by Intel as an intermediary/local bus for the latest PC generations. It is basically a synchronous bus. The main clock of the CPU is used for synchronization. The PCI bus is microprocessor-independent, 32-bit and 64-bit compatible, and supports both 3.3 V and 5 V cards and devices.

PCMCIA

An abbreviation for "**P**ersonal **C**omputer **M**emory **C**ard **I**nternational **A**ssociation". An association of manufacturers and dealers who are dedicated to the cultivation and further development of common standards for peripheral devices based on PC cards with a slot for such cards. PC cards are mainly used for laptops, palmtops (and other portable computers), and intelligent electronic devices. Version 1 of the PCMCIA standard was introduced in 1990.

PICMG

PCI Industrial Computers Manufacturers Group; Goal; Use of commercial PCI bus for industrial environments, especially CompactPCI bus (**www.picmg.org**).

PLC

Programmable Logic Controller; Computer-based control device that functions using an application program. The application program is relatively easy to create using standardized programming languages [IL, FBD, LAD, AS, ST]. Because of its serial functionality, reaction times are slower compared to connection-oriented control. Today, PLCs are available in device families with matched modular components for all levels of an automation hierarchy.

PnP

An abbreviation for "**P**lug and **P**lay". Specifications developed by Intel. Using Plug and Play allows a PC to automatically configure itself so that it can communicate with peripheral devices (e.g. monitors, modems, and printers). Users can connect a peripheral device (plug) and it immediately runs (play) without having to manually configure the system. A Plug and Play PC requires a BIOS that supports Plug and Play and a respective expansion card.

POH

An abbreviation for "**P**ower **O**n **H**ours". See MTBF.

POST

An abbreviation for "**P**ower-**O**n **S**elf **T**est". A set of routines that are stored in ROM on the computer and that test different system components, e.g. RAM, disk drive and the keyboard in order to determine that the connection is operating correctly and ready for operation. POST routines notify the user of problems that occur. This is done using several signal tones or by displaying a message that frequently accompanies a diagnosis value on the standard output or standard error devices (generally the monitor). If the POST runs successfully, control is transferred over to the system's bootstrap loader.

Power Panel

Power Panel is part of the B&R product family and is a combination of an operator panel and controller in one device. This covers products PP21 and PP41.

Powerlink

See "Ethernet POWERLINK".

PP21

B&R Power Panel type. It is equipped with an RS232 interface, a CAN interface, a PCMCIA slot and integrated digital input/output channels. Additionally, up to six B&R System 2003 screw-in modules can be connected. LCD 4 x 20 characters.

PP41

B&R Power Panel type. It is equipped with an RS232 interface, a CAN interface, a PCMCIA slot and integrated digital input/output channels. Additionally, up to six B&R System 2003 screw-in modules can be connected. 5.7" QVGA b/w LCD.

PROFIBUS-DP

PROFIBUS for "decentralized peripherals". PROFIBUS DB can be used to allow simple digital and analog I/O modules as well as intelligent signal and data processing units to be installed in the machine room, which among other things can significantly reduce cabling costs. Often used for time-critical factory automation applications.

Provit

An abbreviation for "**PRO**cess**VI**sualization**T**erminal" Product family name for B&R industrial PCs.

Provit 2000

Product family name for B&R industrial PCs. It is divided into the following products: IPC2000, IPC2001, Compact IPC (IPC2002) and the display units belonging to them.

Provit 5000

Product family name for B&R industrial PCs. It is divided into the following products: IPC5000, IPC5600, IPC5000C, IPC5600C and the display units belonging to them.

PV

Process variable. Logical storage location for values and states in a program.

Q

QVGA

Abbreviation for "**Q**uarter **V**ideo **G**raphics **A**rray". Usually a screen resolution of 320 × 240 pixels.

QUXGA

Abbreviation for "**Q**uad **U**ltra E**x**tended **G**raphics **A**rray". Generally a screen resolution of 3200 × 2400 pixels (4:3). Quad implies the 4x greater pixel resolution compared to the UXGA.

QWUXGA

Abbreviation for "**Q**uad **WUXGA**"; Generally a screen resolution of 3840 × 2400 pixels (8:5, 16:10).

R

RAM

An abbreviation for "**R**andom **A**ccess **M**emory". Semiconductor memory which can be read or written to by the microprocessor or other hardware components. Memory locations can be accessed in any order. The various ROM memory types do allow random access, but they cannot be written to. The term RAM refers to a more temporary memory that can be written to as well as read.

Real time

A system is operating in real time or has real-time capability if the input sizes (e.g. signals, data) are received and processed in a defined time period, and the results are made available in real time for a partner system or the system environment. See also "real-time demands" and "real-time system".

ROM

An abbreviation for "**R**ead-**O**nly **M**emory". Semiconductor memory where programs or data were permanently stored during the production process.

RS232

Recommended **S**tandard **N**umber **232**. Oldest and most widespread interface standard, also called a V.24 interface. All signals are referenced to ground making this an unbalanced interface. High level: -3 to -30 V, low level: +3 to +30 V; cable lengths up to 15 m, transfer rates up to 20 kbit/s; for point-to-point connections between 2 stations.

RS422

Recommended **S**tandard **N**umber **422**. Interface standard, balanced operation, increased immunity to disturbances. High level: 2 to -6 V, low level: +2 to +6 V; four-line connection [inverted/non-inverted], permissible cable length up to 1200 m, transfer rates up to 10 MBit/s, 1 sender can transfer simplex with up to 10 receivers.

RS485

Recommended **S**tandard **N**umber **485**. Interface standard upgraded from RS422. High level: 1.5 to -6 V, low level: +1.5 to +6 V; two-line connection [half-duplex mode] or four-line connection [full-duplex mode]; permissible cable length up to 1200 m, transfer rates up to 10 MBit/s. Up to 32 stations (sender/receiver) can be connected to an RS485 bus.

RTS

An abbreviation for "**R**equest **T**o **S**end". A signal used in serial data transfer for requesting send permission. For example, it is sent from a computer to the modem connected to it. The RTS signal is assigned to pin 4 according to the hardware specifications of the RS-232-C standard.

RXD

An abbreviation for "Receive (**RX**) **D**ata". A line for transferring serial data received from one device to another, e.g. from a modem to a computer. For connections complying with the RS-232-C standard, the RXD is connected to pin 3 of the plug.

S

SDRAM

An abbreviation for "**S**ynchronous **D**ynamic **R**andom **A**ccess **M**emory". A construction of dynamic semiconductor components (DRAM) that can operate with higher clock rates than conventional DRAM switching circuits. This is made possible using block access. For each access, the DRAM determines the next memory addresses to be accessed.

SFC

Sequential function chart > Graphic input language for PLCs used to represent sequential control.

Special keypad module

The following keypad modules are offered by B&R: Dummy module, emergency stop module, key switch module (made up of 1 key switch and 1 on /off switch) and a start/stop module (made up of 2 buttons and a label field).

Slot PLC

PC insert card that has full PLC functionality. On the PC, it is coupled via a DPR with the process using a fieldbus connection. It is programmed externally or using the host PC.

SoftPLC

Synonym for SoftPLC.

SRAM

An abbreviation for "**S**tatic **R**andom **A**ccess **M**emory". A semiconductor memory (RAM) made up of certain logic circuits (flip-flop) that only keeps stored information while powered. In computers, static RAM is generally only used for cache memory.

Standard keypad module

The following keypad modules are offered by B&R: 16 keys with 16 LEDs, 12+4 keys with 4 LEDs, 8 keys with 4 LEDs and a label field and 4 keys with 4 LEDs and 4 label fields.

SUXGA

Abbreviation for **S**uper **U**ltra **E**xtended **G**raphics **A**rray; Generally a screen resolution of 2048×1536 pixels (4:3). An alternative name is QXGA (**Q**uad **E**xtended **G**raphics **A**rray), which is 4x the pixel resolution of XGA.

SVGA

Abbreviation for "**S**uper **V**ideo **G**raphics **A**rray"; Graphics standard with a resolution of at least 800×600 pixels and at least 256 colors.

Switch

Device, similar to a hub, that takes data packets received in a network and, unlike a hub, does not pass them on to all network nodes, instead only to the respective addressee. Unlike a hub, a switch provides targeted communication within a network that only takes place between sender and receiver. Other network nodes are not involved.

SXGA

Abbreviation for Super Extended Graphics Array. Graphics standard with a screen resolution of 1280 × 1024 pixels (aspect ratio 5:4).

SXGA+

Abbreviation for SXGA Plus; Generally 1400 × 1050 pixels.

System units

Provit system units consist of a mainboard (without processor), slots for RAM modules, VGA controller, serial and parallel interfaces, and connections for the FPD, monitor, PS/2 AT keyboard, PS/2 mouse, USB, Ethernet (for system units with Intel Celeron and Pentium III processors), Panelware keypad modules and external FDD.

T

Task

Program unit that is assigned a specific priority by the real-time operating system. It contains a complete process and can consist of several modules.

TCP/IP

Transmission Control Protocol/Internet Suit of Protocols. Network protocol that has become the generally accepted standard for data exchange in heterogeneous networks. TCP/IP is used both in local networks for communication between various computer and also for LAN to WAN access.

TFT display

LCD (Liquid Crystal Display) technology where the display consists of a large grid of LCD cells. Each pixel is represented by a cell, whereby electrical fields produced in the cells are supported by thin film transistors (TFT) that result in an active matrix. In its simplest form, there is exactly one thin film transistor per cell. Displays with an active matrix are generally used in laptops and notebooks because they are thin, offer high-quality color displays and can be viewed from all angles.

Touch screen

Screen with touch sensors for selecting options in a displayed menu using the tip of the finger.

TXD

An abbreviation for "Transmit (**TX**) **D**ata". A line for the transfer of serial data sent from one device to another, e.g. from a computer to a modem. For connections complying with the RS-232-C standard, the TXD is connected to pin 2 of the plug.

U

UART

An abbreviation for "**U**niversal **A**synchronous **R**eceiver-**T**ransmitter". A module generally consisting of a single integrated circuit that combines the circuits required for asynchronous serial communication for both sending and receiving. UART represents the most common type of circuit in modems for connecting to a personal computer.

UDMA

An abbreviation for "**U**ltra **D**irect **M**emory **A**ccess". A special IDE data transfer mode that allows high data transfer rates for drives. There have been many variations in recent times.
UDMA33 mode transfers 33 megabytes per second.
UDMA66 mode transfers 66 megabytes per second.
UDMA100 mode transfers 100 megabytes per second.
Both the mainboard and the hard drive must support the specification to implement modifications.

UPS

Abbreviation for "**U**ninterruptible **P**ower **S**upply". See "UPS".

Bootstrap loader

A program that automatically runs when the computer is switched on or restarted. After some basic hardware tests have been carried out, the bootstrap loader starts a larger loader and hands over control to it, which in turn boots the operating system. The bootstrap loader is typically found in ROM on the computer.

USB

An abbreviation for "**U**niversal **S**erial **B**us" A serial bus with a bandwidth of up to 12 megabits per second (Mbit/s) for connecting a peripheral device to a microcomputer. Up to 127 devices can be connected to the system using a single multipurpose connection, the USB bus (e.g. external CD drives, printer, modems as well as the mouse and keyboard). This is done by connecting the devices in a row. USB allows devices to be changed when the power supply is switched on (hot plugging) and multi-layered data flow.

UPS

An abbreviation for "**U**ninterruptible **P**ower **S**upply". The UPS supplies power to systems that cannot be connected directly to the power mains for safety reasons because a power failure could lead to loss of data. The UPS allows the PC to be shut down securely without losing data if a power failure occurs.

UXGA

Abbreviation for "**U**ltra **E**xtended **G**raphics **A**rray" Generally a screen resolution of 1600 × 1200 pixels (aspect ratio 4:3, 12:9).

V

VGA

An abbreviation for "**V**ideo **G**raphics **A**dapter". A video adapter which can handle all EGA (Enhanced Graphics Adapter) video modes and adds several new modes.

W

Windows CE

Compact 32-bit operating system with multitasking and multithreading that Microsoft developed especially for the OEM market. It can be ported for various processor types and has a high degree of real-time capability. The development environment uses proven, well-established development tools. It is an open and scalable Windows operating system platform for many different devices. Examples of such devices are handheld PCs, digital wireless receivers, intelligent mobile phones, multimedia consoles, etc. In embedded systems, Windows CE is also an excellent choice for automation technology.

WSXGA

Wide SXGA, generally 1600 × 900 pixels (16:9).

WUXGA

Wide UXGA, generally 1920 × 1200 pixels (16:10).

WXGA

Wide XGA, generally 1280 × 768 pixels.

X

XGA

An abbreviation for "E**X**tended **G**raphics **A**rray". An expanded standard for graphics controllers and monitors that was introduced by IBM in 1990. This standard supports 640x480 resolution with 65,536 colors or 1024x768 resolution with 256 colors. This standard is generally used in workstation systems.

XTX

Abbreviation for "e**X**press **T**echnologoy for ET**X**" A further development consistent with the proven ETX® standard. The newest I/O technology is implemented on a reliable form factor in XTX. The ETX® interface X2 is equipped with new serial buses like PCI Express™ und Serial ATA®, instead of the unpopular ISA bus. All other signals on the X1, X3 and X4 interfaces remain completely compatible with the ETX® Standard (Rev. 2.7). However, if ISA signals are needed, a PCI-ISA can be implemented on the base board. The use of an LPC bus already in XTX™ is considerably cheaper than a bridge solution.

Figure 1: APC810 for central control and visualization ... 40
Figure 2: APC810 as a visualization device ... 41
Figure 3: Configuration - Basic system ... 45
Figure 4: Configuration - Drives, software, accessories ... 46
Figure 5: Interface overview - APC810, 1 card slot variant (top) ... 47
Figure 6: Interface overview - APC810, 1 card slot variant (front) ... 48
Figure 7: Dimensions - APC810 1 card slot variant ... 51
Figure 8: Interface overview - APC810, 2 card slot variant (top) ... 52
Figure 9: Interface overview - APC810, 2 card slot variant (front) ... 53
Figure 10: Dimensions - APC810 2 card slot variant ... 56
Figure 11: Interface overview - APC810, 3 card slot variant (top) ... 57
Figure 12: Interface overview - APC810, 3 card slot variant (front) ... 58
Figure 13: Dimensions - APC810 3 card slot variant ... 61
Figure 14: Interface overview - APC810, 5 card slot variant (top) ... 62
Figure 15: Interface overview - APC810, 5 card slot variant (front) ... 63
Figure 16: Dimensions - APC810 5 card slot variant ... 66
Figure 17: Ambient temperatures without a fan kit with heat sink < Rev. D0 ... 68
Figure 18: Ambient temperatures without a fan kit with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0 ... 69
Figure 19: Ambient temperatures without a fan kit with heat sinks 5AC801.HS00-00 Rev. D0 and 5AC801.HS00-01 Rev. D0 and 5AC801.HS00-02 ... 70
Figure 20: Ambient temperatures with fan kit on CPU boards 5PC800.B945-0x ... 71
Figure 21: Ambient temperatures with fan kit on CPU boards 5PC800.B945-05 and 5PC800.B945-1x ... 72
Figure 22: Supply voltage for system units ... 75
Figure 23: Power calculation with 5PC810.SX01-00 revision >= D0 ... 76
Figure 24: Power calculation with 5PC810.SX01-00 revision < D0 ... 77
Figure 25: Power calculation with 5PC810.SX02-00 revision >= D0 ... 78
Figure 26: Power calculation with 5PC810.SX02-00 revision < D0 ... 79
Figure 27: Power calculation with 5PC810.SX03-00 ... 80
Figure 28: Power calculation with 5PC810.SX05-00 ... 81
Figure 29: Serial number sticker (front) ... 82
Figure 30: Serial number sticker (back) ... 82
Figure 31: Example of serial number search - A3C70168444 ... 83
Figure 32: Block diagram 5PC810.SX01-00 + 5PC810.BX01-00 ... 84
Figure 33: Block diagram 5PC810.SX01-00 + 5PC810.BX01-01 ... 85
Figure 34: Block diagram 5PC810.SX02-00 + 5PC810.BX02-00 ... 86
Figure 35: Block diagram 5PC810.SX02-00 + 5PC810.BX02-01 ... 87
Figure 36: Block diagram 5PC810.SX03-00 + 5PC810.BX03-00 ... 88
Figure 37: Block diagram 5PC810.SX05-00 + 5PC810.BX05-00 ... 89
Figure 38: Block diagram 5PC810.SX05-00 + 5PC810.BX05-01 ... 90
Figure 39: Block diagram 5PC810.SX05-00 + 5PC810.BX05-02 ... 91
Figure 40: Ground connection ... 93
Figure 41: Dimensions - Standard half-size PCI card ... 104
Figure 42: Dimensions - Standard half-size PCIe card ... 104
Figure 43: Front-side status LEDs ... 105
Figure 44: 1 slot bus units ... 117

Figure 45: 2 slot bus units 117
Figure 46: 3 slot bus units 117
Figure 47: 5 slot bus units 118
Figure 48: CPU board..... 119
Figure 49: Heat sink 120
Figure 50: Main memory..... 121
Figure 51: Slide-in compact HDD 40GB EE25 - 5AC801.HDDI-00..... 122
Figure 52: Temperature humidity diagram - 5AC801.HDDI-00 124
Figure 53: Slide-in compact HDD 80GB EE25 - 5AC801.HDDI-01..... 125
Figure 54: Temperature humidity diagram - 5AC801.HDDI-01 127
Figure 55: Slide-in compact HDD 160 GB - 5AC801.HDDI-02..... 128
Figure 56: Temperature humidity diagram - 5AC801.HDDI-02 130
Figure 57: Slide-in compact HDD 250GB - 5AC801.HDDI-03..... 131
Figure 58: Temperature humidity diagram - 5AC801.HDDI-03 133
Figure 59: Slide-in compact SSD 5AC801.SSDI-00..... 134
Figure 60: Temperature humidity diagram - 5AC801.SSDI-00..... 136
Figure 61: ATTO disk benchmark v2.34 - cyclic read..... 137
Figure 62: ATTO disk benchmark v2.34 - cyclic write 137
Figure 63: Hard disk adapter (slide-in compact) 5AC801.ADAS-00..... 138
Figure 64: Slide-in HDD EE25 5AC801.HDDS-00 139
Figure 65: Temperature humidity diagram - 5AC801.HDDS-00..... 141
Figure 66: Slide-in DVD-ROM 5AC801.DVDS-00 142
Figure 67: Temperature humidity diagram - Slide-in DVD-ROM/CD-RW - 5AC801.DVDS-00 144
Figure 68: Slide-in DVD-R/RW - 5AC801.DVRS-00..... 145
Figure 69: Temperature humidity diagram - Slide-in DVD-R/RW, DVD+R/RW - 5AC801.DVRS-00 147
Figure 70: PCI SATA RAID controller - 5ACPCI.RAIC-01..... 148
Figure 71: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-01.. 150
Figure 72: Replacement SATA HDD 60 GB - 5ACPCI.RAIC-02..... 152
Figure 73: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-02.. 154
Figure 74: PCI SATA RAID controller - 5ACPCI.RAIC-03..... 155
Figure 75: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-03.. 157
Figure 76: Replacement SATA HDD 160 GB - 5ACPCI.RAIC-04..... 159
Figure 77: Temperature humidity diagram - SATA RAID hard disk 5ACPCI.RAIC-04.. 161
Figure 78: PCI SATA RAID controller - 5ACPCI.RAIC-05..... 162
Figure 79: Temperature humidity diagram - SATA RAID Hard Disk - 5ACPCI.RAIC-05 164
Figure 80: Replacement SATA HDD 250 GB - 5MMHDD.0250-00..... 166
Figure 81: Temperature humidity diagram - SATA RAID hard disk - 5MMHDD.0250-00 168
Figure 82: Fan kit - 5PC810.FA01-00..... 169
Figure 83: Fan kit - 5PC810.FA02-00 and 5PC810.FA02-01..... 171
Figure 84: Fan kit - 5PC810.FA03-00..... 172
Figure 85: Fan kit - 5PC810.FA05-00..... 173
Figure 86: AP Link SDL transmitter 5AC801.SDL0-00..... 174
Figure 87: Mounting example with the system unit 5PC810.SX02-00 174

Figure 88: Ready relay 5AC801.RDYR-00 177
Figure 89: Mounting example with the system unit 5PC810.SX02-00 177
Figure 90: Add-on interfaces (IF option) 179
Figure 91: Terminating resistor - Add-on CAN interface 5AC600.CANI-00 183
Figure 92: Contents of the delivery / mounting material - 5AC600.CANI-00 183
Figure 93: Add-on RS232/422/485 interface - operated in RS485 mode 186
Figure 94: Contents of the delivery / mounting material - 5AC600.485I-00 188
Figure 95: Mounting plates 189
Figure 96: Standard mounting - vertical 192
Figure 97: Optional mounting - horizontal 192
Figure 98: Standard mounting - Mounting distances 193
Figure 99: Flex radius - Cable connection 194
Figure 100: Grounding concept 195
Figure 101: Configuration - One Automation Panel 900 via DVI (onboard) 197
Figure 102: Configuration - An Automation Panel 900 via SDL (onboard) 200
Figure 103: Configuration - An Automation Panel 800 via SDL (onboard) 203
Figure 104: Configuration - One AP900 and an AP800 via SDL (onboard) 206
Figure 105: Configuration - Four Automation Panel 900 units via SDL (onboard) 208
Figure 106: Configuration - One Automation Panel 900 via SDL (AP Link) 212
Figure 107: Configuration - Four Automation Panel 900 units via SDL (AP Link) 215
Figure 108: Configuration - Two Automation Panel 900 units via SDL (onboard) and SDL (AP Link) 219
Figure 109: Configuration - Eight Automation Panel 900 units via SDL (onboard) and SDL (AP Link) 222
Figure 110: Configuration - Six AP900 and two AP800 devices via SDL (onboard) and SDL (AP Link) 226
Figure 111: Local connection of USB peripheral devices on the APC810 229
Figure 112: Remote connection of USB peripheral devices to the APC900 via DVI 230
Figure 113: Remote connection of USB peripheral devices to the APC800/900 via SDL 231
Figure 114: Open the RAID Configuration Utility 232
Figure 115: RAID Configuration Utility - Menu 232
Figure 116: RAID Configuration Utility - Menu 233
Figure 117: RAID Configuration Utility - Create RAID set - Striped 234
Figure 118: RAID Configuration Utility - Create RAID set - Mirrored 235
Figure 119: RAID Configuration Utility - Delete RAID set 236
Figure 120: RAID Configuration Utility - Rebuild mirrored set 237
Figure 121: RAID Configuration Utility - Resolve conflicts 238
Figure 122: RAID Configuration Utility - Low level format 239
Figure 123: Boot screen 244
Figure 124: 945GME - BIOS Main Menu 246
Figure 125: 945GME - Advanced Menu 247
Figure 126: 945GME - Advanced ACPI configuration 249
Figure 127: 945GME - Advanced PCI Configuration 251
Figure 128: 945GME - Advanced PCI IRQ Resource Exclusion 252
Figure 129: 945GME - Advanced PCI Interrupt Routing 253
Figure 130: 945GME - Advanced PCI Express Configuration 255
Figure 131: 945GME - Advanced Graphics Configuration 257

Figure 132: 945GME - Advanced CPU Configuration 261
Figure 133: 945GME Advanced Chipset Configuration 262
Figure 134: 945GME Advanced I/O Interface Configuration 264
Figure 135: 945GME Advanced Clock Configuration 265
Figure 136: 945GME Advanced IDE Configuration 266
Figure 137: 945GME - Primary IDE Master 268
Figure 138: 945GME - Primary IDE Slave 270
Figure 139: 945GME - Secondary IDE Master 271
Figure 140: 945GME - Secondary IDE Slave 273
Figure 141: 945GME - Advanced USB Configuration 274
Figure 142: 945GME Advanced Keyboard/Mouse Configuration 276
Figure 143: 945GME - Advanced Remote Access Configuration 277
Figure 144: 945GME Advanced CPU board monitor 279
Figure 145: 945GME - Advanced Baseboard/Panel Features 280
Figure 146: 945GME - Panel Control 282
Figure 147: 945GME Baseboard Monitor 283
Figure 148: 945GME - Legacy Devices 284
Figure 149: 945GME - Boot Menu 286
Figure 150: 945GME - Security Menu 288
Figure 151: 945GME Hard disk security user password 289
Figure 152: 945GME Hard Disk Security Master Password 290
Figure 153: 945GME - Power Menu 291
Figure 154: 945GME - Exit Menu 293
Figure 155: CMOS profile hex switch 294
Figure 156: PCI and PCIe routing with activated APIC CPU boards B945GME (COM Express)
for BIOS version ≤ 1.12 311
Figure 157: PCI and PCIe routing with activated APIC CPU boards B945GME (COM Express)
for BIOS version ≥ 1.14 (Bus units 5PC810.BX0x-0x) 312
Figure 158: PCI and PCIe routing with activated APIC CPU boards B945GME (COM Express)
for BIOS version ≥ 1.14 (Bus unit 5PC810.BX05-02) 313
Figure 159: Software version 315
Figure 160: Firmware version of the AP Link SDL transmitter 316
Figure 161: Creating a bootable diskette in Windows XP - step 1 322
Figure 162: Creating a bootable diskette in Windows XP - step 2 322
Figure 163: Creating a bootable diskette in Windows XP - step 3 322
Figure 164: Creating a bootable diskette in Windows XP - step 4 323
Figure 165: Creating a bootable diskette in Windows XP - step 5 323
Figure 166: Creating a USB flash drive for B&R upgrade files 325
Figure 167: Creating a CompactFlash card for B&R upgrade files 327
Figure 168: Automation PC 810 with MS-DOS 328
Figure 169: Windows XP Professional Logo 330
Figure 170: Windows 7 Logo 333
Figure 171: Windows XP Embedded Logo 336
Figure 172: Windows Embedded Standard 2009 Logo 339

Figure 173: Windows Embedded Standard 7 Logo ... 342
Figure 174: ADI Control Center screenshots - Examples (symbol photo) ... 349
Figure 175: ADI Control Center - SDL equalizer settings ... 352
Figure 176: ADI Control Center - UPS settings ... 353
Figure 177: ADI Control Center - UPS monitor ... 355
Figure 178: ADI Control Center - UPS battery settings ... 356
Figure 179: ADI Control Center - UPS settings ... 358
Figure 180: ADI Control Center - Advanced UPS settings ... 360
Figure 181: Replacement fan ... 390
Figure 182: Temperature humidity diagram - CompactFlash cards 5CFCRD.xxxx-04 ... 395
Figure 183: Dimensions - CompactFlash card Type I ... 395
Figure 184: ATTO disk benchmark v2.34 comparison (reading) ... 396
Figure 185: ATTO disk benchmark v2.34 comparison (writing) ... 396
Figure 186: Temperature humidity diagram - CompactFlash cards 5CFCRD.xxxx-03 ... 400
Figure 187: Dimensions - CompactFlash card Type I ... 400
Figure 188: USB Media Drive - 5MD900.USB2-01 ... 401
Figure 189: Dimensions - 5MD900.USB2-01 ... 404
Figure 190: Dimensions - USB Media Drive with front cover ... 405
Figure 191: Installation cutout - USB Media Drive with front cover ... 405
Figure 192: Interfaces - 5MD900.USB2-01 ... 406
Figure 193: Mounting orientation - 5MD900.USB2-01 ... 406
Figure 194: Front cover 5A5003.03 ... 407
Figure 195: Dimensions - 5A5003.03 ... 407
Figure 196: Front cover mounting and installation depth ... 408
Figure 197: Temperature humidity diagram - USB flash drive - 5MMUSB.2048-00 ... 411
Figure 198: Temperature humidity diagram - USB flash drive - 5MMUSB.2048-01 ... 413
Figure 199: UPS principle ... 415
Figure 200: Add-on UPS module 5AC600.UPSI-00 ... 417
Figure 201: Add-on UPS module 5AC600.UPSI-00 - Installation materials ... 418
Figure 202: Battery unit 5AC600.UPSB-00 ... 419
Figure 203: Temperature life span diagram ... 420
Figure 204: Deep discharge cycles ... 420
Figure 205: Dimensions - 5AC600.UPSB-00 ... 421
Figure 206: Drilling template for the battery unit ... 422
Figure 207: UPS connection cable ... 423
Figure 208: B&R power supplies (examples) ... 424
Figure 209: PCI Ethernet card 10/100 - 5ACPCI.ETH1-01 ... 426
Figure 210: Dimensions - 5ACPCI.ETH1-01 ... 428
Figure 211: PCI Ethernet card 10/100 - 5ACPCI.ETH3-01 ... 429
Figure 212: Dimensions - 5ACPCI.ETH3-01 ... 431
Figure 213: DVI extension cable - 5CADVI.0xxx-00 (similar) ... 432
Figure 214: Flex radius specification ... 433
Figure 215: Dimensions - DVI cable 5CADVI.0xxx-00 ... 434
Figure 216: Pin assignments - DVI cable ... 435
Figure 217: SDL extension cable (similar) ... 436
Figure 218: Flex radius specification ... 437
Figure 219: Dimensions - SDL cable 5CASDL.0xxx-00 ... 438

Figure 220: Pin assignments - SDL cable 5CASDL.0xxx-00 ... 439
Figure 221: SDL cable with 45° plug (similar) ... 440
Figure 222: Flex radius specification ... 441
Figure 223: Dimensions - SDL cable with 45° plug 5CASDL.0xxx-01 ... 442
Figure 224: Pin assignments - SDL cable with 45° plug 5CASDL.0xxx-01 ... 443
Figure 225: SDL cable 5CASDL.0xxx-03 (similar) ... 444
Figure 226: Flex radius specification ... 446
Figure 227: Dimensions - SDL cable 5CASDL.0xxx-03 ... 446
Figure 228: Pin assignments - SDL cable 5CASDL.0xxx-03 ... 448
Figure 229: SDL flex cable with extender - 5CASDL.0x00-13 (similar) ... 449
Figure 230: Flex radius specification ... 451
Figure 231: Dimensions - SDL flex cable with extender 5CASDL.0x00-13 ... 451
Figure 232: Pin assignments - SDL flex cable with extender 5CASDL.0x00-13 ... 452
Figure 233: RS232 extension cable (similar) ... 453
Figure 234: Pin assignments - RS232 cable ... 454
Figure 235: USB extension cable (similar) ... 455
Figure 236: Pin assignments - USB cable ... 456
Figure 237: APC810 internal supply cable - 5CAMSC.0001-00 ... 457
Figure 238: HDD replacement disk tray - 5AC801.FRAM-00 ... 458
Figure 239: Dimensions - HDD replacement disk tray ... 459
Figure 240: Ready relay - 5AC801.RDYR-01 ... 460
Figure 241: Contents of delivery - Ready relay ... 461
Figure 242: HMI Drivers & Utilities DVD 5SWHMI.0000-00 ... 462
Figure 243: Remove battery ... 468
Figure 244: Battery handling ... 468
Figure 245: Battery polarity ... 469
Figure 246: Loosening the ¼ turn screws ... 470
Figure 247: Inserting the compact SATA drive ... 470
Figure 248: Loosening the ¼ turn screws ... 471
Figure 249: Installing the slide-in drive ... 471
Figure 250: Loosening the ¼ turn screws ... 472
Figure 251: Installing the slide-in compact adapter ... 473
Figure 252: Inserting the slide-in compact drive ... 473
Figure 253: Remove fan kit insert ... 474
Figure 254: Inserting and fastening the fan kit ... 474
Figure 255: Securing the dust filter with the filter clasp ... 475
Figure 256: Add-on UPS module 5AC600.UPSI-00 - Installation materials ... 476
Figure 257: Remove UPS module cover ... 476
Figure 258: Screw in spacing bolt and spacing ring ... 477
Figure 259: Install UPS module ... 477
Figure 260: Plug in connection cable ... 477
Figure 261: Connector locking mechanism ... 478
Figure 262: Remove UPS module cover ... 478
Figure 263: Screw in spacing bolt and spacing ring ... 479
Figure 264: Install mounting bracket ... 479
Figure 265: Install UPS module ... 479
Figure 266: Plug in connection cable ... 480

Figure 267: Connector locking mechanism 480
Figure 268: Remove UPS module cover 481
Figure 269: Screw in spacing bolt and spacing ring 481
Figure 270: Install mounting bracket 481
Figure 271: Install UPS module 482
Figure 272: Plug in connection cable 482
Figure 273: Connector locking mechanism 482
Figure 274: Remove UPS module cover 483
Figure 275: Screw in spacing bolt 483
Figure 276: Install UPS module 484
Figure 277: Plug in connection cable 484
Figure 278: Connector locking mechanism 484
Figure 279: Remove UPS module cover 485
Figure 280: Screw in spacing bolt 485
Figure 281: Install mounting bracket 485
Figure 282: Install UPS module 486
Figure 283: Plug in connection cable 486
Figure 284: Connector locking mechanism 486
Figure 285: Remove UPS module cover 487
Figure 286: Screw in spacing bolt 487
Figure 287: Install mounting bracket 487
Figure 288: Install UPS module 488
Figure 289: Plug in connection cable 488
Figure 290: Connector locking mechanism 488
Figure 291: Mounting the side cover - APC810 1 card slot 489
Figure 292: Mounting the side cover - APC810 2 card slot 490
Figure 293: Mounting the side cover - APC810 5 card slot 490
Figure 294: Remove AP Link module cover 491
Figure 295: Install AP Link module 491
Figure 296: Screw layout on the back side of the SATA RAID controller 5ACPCI.RAIC-03 .. 492
Figure 297: Hard disk exchange 493
Figure 298: Installing the replacement hard disk in the replacement disk tray 494
Figure 299: Installing the replacement disk tray in the APC810 494
Figure 300: Remove UPS module cover 495
Figure 301: Screw in spacing bolt and spacing ring 495
Figure 302: Installing the ready relay 496
Figure 303: Plug in connection cable 496
Figure 304: Temperature sensor locations 497
Figure 305: MTCX controller location 498
Figure 306: Connector location for external devices 500
Figure 307: B&R Key Editor screenshots Version 3.10 (representation picture) 501
Figure 308: ADI development kit screenshots (Version 3.10) 503
Figure 309: ADI .NET SDK Screenshots (Version 1.50) 505

Table 1: Manual history ... 19
Table 2: Environmentally-friendly separation of materials ... 27
Table 3: Organization of safety notices ... 28
Table 4: Model numbers - System units ... 29
Table 5: Model numbers - Bus units ... 29
Table 6: Model numbers - CPU boards 945GME ... 30
Table 7: Model numbers - Heat sinks ... 30
Table 8: Model numbers - Main memory ... 31
Table 9: Model numbers - Drives ... 31
Table 10: Model numbers - Fan kits ... 32
Table 11: Model numbers - AP Link ... 32
Table 12: Model numbers - Add-on interfaces (IF option) ... 32
Table 13: Model numbers - Uninterruptible power supply ... 32
Table 14: Model numbers - Supply voltage connectors ... 33
Table 15: Model numbers - Batteries ... 33
Table 16: Model numbers - CompactFlash cards ... 33
Table 17: Model numbers - USB flash drives ... 34
Table 18: Model numbers - Cables ... 34
Table 19: Model numbers - PCI cards ... 36
Table 20: Model numbers - Power supplies ... 36
Table 21: Model numbers - Replacement fan filters ... 36
Table 22: Model numbers - Other items ... 37
Table 23: Model numbers - Software ... 37
Table 24: Technical data - APC810, 1 card slot variant ... 49
Table 25: Technical data - APC810, 2 card slot variant ... 54
Table 26: Technical data - APC810, 3 card slot variant ... 59
Table 27: Technical data - APC810, 5 card slot variant ... 64
Table 28: Overview of humidity specifications for individual components ... 74
Table 29: Supply voltage connection + 24VDC ... 92
Table 30: Pin assignments - COM1 ... 94
Table 31: Pin assignments - COM2 ... 95
Table 32: Monitor / Panel connection - RGB, DVI, SDL ... 95
Table 33: Ethernet connection (ETH1) ... 96
Table 34: Ethernet connection (ETH2) ... 98
Table 35: USB1, USB2, USB3, USB4 connection ... 99
Table 36: USB5 connection ... 100
Table 37: MIC, Line IN, Line OUT ... 101
Table 38: Add-on interface slot ... 102
Table 39: Add-on UPS slot (with and without mounted UPS) ... 103
Table 40: Data - status LEDs ... 105
Table 41: CMOS profile switch ... 106
Table 42: Power button ... 107
Table 43: Reset button ... 107
Table 44: Battery ... 108
Table 45: Meaning of battery status ... 108
Table 46: Hardware security key ... 109
Table 47: CompactFlash slot (CF1) ... 110

Table 48: CompactFlash slot (CF2) ... 111
Table 49: Slide-in slot 1 ... 112
Table 50: Slide-in slot 2 ... 113
Table 51: Slide-in compact slot ... 114
Table 52: Technical data - System units ... 115
Table 53: Technical data - Bus units ... 118
Table 54: Technical data - CPU boards ... 119
Table 55: Technical data - Heat sink ... 120
Table 56: Technical data - Main memory ... 121
Table 57: Technical data - Slide-in compact HDD - 5AC801.HDDI-00 ... 122
Table 58: Technical data - Slide-in compact HDD - 5AC801.HDDI-01 ... 125
Table 59: Technical data - Slide-in compact HDD - 5AC801.HDDI-02 ... 128
Table 60: Technical data - Slide-in compact HDD - 5AC801.HDDI-03 ... 131
Table 61: Technical data - Slide-in compact SSD - 5AC801.SSDI-00 ... 135
Table 62: Technical data - Slide-in HDD adapter - 5AC801.ADAS-00 ... 138
Table 63: Technical data - Slide-in HDD EE25 - 5AC801.HDDS-00 ... 139
Table 64: Technical data - Slide-in DVD-ROM - 5AC801.DVDS-00 ... 142
Table 65: Technical data - Slide-in DVD-R/RW, DVD+R/RW - 5AC801.DVRS-00 ... 145
Table 66: Technical data - RAID hard disk - 5ACPCI.RAIC-01 ... 149
Table 67: Technical data - RAID hard disk - 5ACPCI.RAIC-02 ... 152
Table 68: Technical data - RAID hard disk - 5ACPCI.RAIC-03 ... 156
Table 69: Technical data - RAID hard disk - 5ACPCI.RAIC-04 ... 159
Table 70: Technical data - RAID Hard Disk - 5ACPCI.RAIC-05 ... 163
Table 71: Technical data - RAID hard disk - 5MMHDD.0250-00 ... 166
Table 72: Technical data - 5PC810.FA01-00 ... 169
Table 73: Technical data - 5PC810.FA02-00 and 5PC810.FA02-01 ... 171
Table 74: Technical data - 5PC810.FA03-00 ... 172
Table 75: Technical data - 5PC810.FA05-00 ... 173
Table 76: Pin assignment for AP Link connection ... 175
Table 77: Segment lengths, resolutions and SDL cables ... 175
Table 78: Pin assignments - Ready relay 5AC801.RDYR-00 ... 178
Table 79: Add-on CAN interface - 5AC600.CANI-00 ... 180
Table 80: Technical data - Add-on CAN interface - 5AC600.CANI-00 ... 180
Table 81: Pin assignments - CAN ... 181
Table 82: Add-on CAN - I/O Adresse und IRQ ... 181
Table 83: CAN address register ... 181
Table 84: Bus length and transfer rate - CAN ... 182
Table 85: CAN cable requirements ... 182
Table 86: Add-on RS232/422/485 interface - 5AC600.485I-00 ... 184
Table 87: Pin assignments - RS232/RS422 ... 184
Table 88: Add-on RS232/422/485 - I/O address and IRQ ... 185
Table 89: RS232 - Bus length and transfer rate ... 185
Table 90: RS232 - Cable requirements ... 185
Table 91: RS422 - Bus length and transfer rate ... 186
Table 92: RS422 - Cable requirements ... 186
Table 93: RS485 - Bus length and transfer rate ... 187
Table 94: RS485 - Cable requirements ... 187

Table 95: Drilling templates - 1 and 2 card slot system units 190
Table 96: Drilling templates - 3 and 5 card slot system units 191
Table 97: Selecting the display units 196
Table 98: Possible combinations of system unit and CPU board 197
Table 99: Link module for the configuration - One Automation Panel 900 via DVI 198
Table 100: Cables for DVI configurations 198
Table 101: Possible Automation Panel units, resolutions und segment lengths 198
Table 102: Possible combinations of system unit and CPU board 200
Table 103: Link module for the configuration - One Automation Panel 900 via SDL 201
Table 104: Cables for SDL configurations 201
Table 105: Segment lengths, resolutions and SDL cables 202
Table 106: Possible combinations of system unit and CPU board 203
Table 107: Cables for SDL configurations 204
Table 108: Segment lengths, resolutions and SDL cables 204
Table 109: Possible combinations of system unit and CPU board 206
Table 110: Link modules for configuration - One AP900 and one AP800 via SDL (onboard)... 207
Table 111: Possible combinations of system unit and CPU board 208
Table 112: Link modules for the configuration: 4 Automation Panel 900 via SDL on 1 line 209
Table 113: Cables for SDL configurations 209
Table 114: Segment lengths, resolutions and SDL cables 210
Table 115: Possible combinations of system unit and CPU board 212
Table 116: Link modules for the configuration: 4 Automation Panel 900 via SDL on 1 line 213
Table 117: Cables for SDL configurations 213
Table 118: Segment lengths, resolutions and SDL cables 214
Table 119: Possible combinations of system unit and CPU board 215
Table 120: Link modules for configuration - Four Automation Panel 900 units via SDL (AP Link) 216
Table 121: Cables for SDL configurations 216
Table 122: Segment lengths, resolutions and SDL cables 217
Table 123: Possible combinations of system unit and CPU board 219
Table 124: Link modules for configuration - Two Automation Panel 900 units via SDL (onboard) and SDL (AP Link) 220
Table 125: Cables for SDL configurations 220
Table 126: Segment lengths, resolutions and SDL cables 221
Table 127: Possible combinations of system unit and CPU board 223
Table 128: Link modules for configuration: 8 Automation Panel 900 units via SDL and SDL (optional) 223
Table 129: Cables for SDL configurations 223
Table 130: Segment lengths, resolutions and SDL cables 224
Table 131: Possible combinations of system unit and CPU board 227
Table 132: Link modules for configuration: 6 AP900 and 2 AP800 devices via SDL and SDL (optional) 227
Table 133: Segment lengths, resolutions and SDL cables 228
Table 134: BIOS-relevant keys in the RAID Configuration Utility 233
Table 135: 945GME - Bios-relevant keys at POST 244
Table 136: 945GME - Bios-relevant keys in the BIOS menu 245

Table 137: 945GME - Main Menu - Setting options 246
Table 138: 945GME - Advanced Menu - Setting options 247
Table 139: 945GME - Advanced ACPI configuration - Setting options 249
Table 140: 945GME - Advanced PCI configuration - Setting options 251
Table 141: 945GME - Advanced PCI IRQ Resource Exclusion - Setting options 252
Table 142: 945GME - Advanced PCI Interrupt Routing - Setting options 253
Table 143: 945GME - Advanced PCI Express Configuration - Setting options 255
Table 144: 945GME - Advanced Graphics Configuration - Setting options 258
Table 145: 945GME - Advanced CPU Configuration - Setting options 261
Table 146: 945GME Advanced Chipset setting options 263
Table 147: 945GME Advanced I/O Interface Configuration setting options 264
Table 148: 945GME Advanced Clock Configuration setting options 265
Table 149: 945GME Advanced IDE Configuration setting options 266
Table 150: 945GME - Primary IDE Master - Setting options 268
Table 151: 945GME - Primary IDE Slave - Setting options 270
Table 152: 945GME - Secondary IDE Master - Setting options 272
Table 153: 945GME - Secondary IDE Slave - Setting options 273
Table 154: 945GME - Advanced USB Configuration - Setting options 275
Table 155: 945GME Advanced Keyboard/Mouse Configuration setting options 276
Table 156: 945GME - Advanced Remote Access Configuration - Setting options 277
Table 157: 945GME - Advanced Remote Access Configuration - Setting options 279
Table 158: 945GME - Advanced Baseboard/Panel Features - Setting options 281
Table 159: 945GME - Panel Control - Setting options 282
Table 160: 945GME Baseboard Monitor setting options 283
Table 161: 945GME - Legacy Devices - Setting options 284
Table 162: 945GME - Boot Menu - Setting options 286
Table 163: 945GME - Security Menu - Setting options 288
Table 164: 945GME Hard disk security user password 289
Table 165: 945GME Hard Disk Security Master Password 290
Table 166: 945GME - Power Menu - Setting options 291
Table 167: 855GME - (XTX) Exit menu - Setting options 293
Table 168: Profile overview 294
Table 169: 945GME Main profile setting overview 295
Table 170: 945GME Advanced - ACPI configuration profile setting overview 295
Table 171: 945GME Advanced - PCI configuration profile setting overview 296
Table 172: 945GME Advanced - PCI Express configuration profile setting overview 297
Table 173: 945GME Advanced - Graphics configuration profile setting overview 297
Table 174: 945GME Advanced - CPU configuration profile setting overview 298
Table 175: 945GME Advanced - Chipset configuration profile setting overview 298
Table 176: 945GME Advanced - I/O Interface Configuration profile setting overview 298
Table 177: 945GME Advanced - Clock configuration profile setting overview 299
Table 178: 945GME Advanced - IDE configuration profile setting overview 299
Table 179: 945GME Advanced - USB configuration profile setting overview 301
Table 180: 945GME Advanced - Keyboard/Mouse Configuration profile setting overview 301
Table 181: 945GME Advanced - Remote Access Configuration profile setting overview 302
Table 182: 945GME Advanced - CPU board monitor profile setting overview 302
Table 183: 945GME Advanced - Baseboard/Panel Features profile setting overview 302

Table 184: 945GME Boot profile setting overview ... 303
Table 185: 945GME Security profile setting overview ... 304
Table 186: 945GME Power profile setting overview ... 304
Table 187: BIOS post code messages BIOS 945GME ... 306
Table 188: RAM address assignment ... 307
Table 189: I/O address assignment ... 308
Table 190: IRQ interrupt assignments in PCI mode ... 309
Table 191: IRQ interrupt assignments in APIC mode ... 310
Table 192: Order data - MS-DOS ... 328
Table 193: Tested resolutions and color depths for DVI and RGB signals ... 329
Table 194: Oder data - Windows XP Professional ... 330
Table 195: Model numbers - Windows 7 ... 333
Table 196: Oder data - Windows XP Embedded ... 336
Table 197: Device functions in Windows XP Embedded with FP2007 ... 337
Table 198: Order data - Windows Embedded Standard 2009 ... 339
Table 199: Device functions in Windows Embedded Standard 2009 ... 340
Table 200: Model numbers - Windows Embedded Standard 2009 ... 342
Table 201: Device functions in Windows Embedded Standard 7 ... 343
Table 202: Oder data - Windows CE ... 345
Table 203: Windows CE 6.0 features ... 346
Table 204: Overview of standards ... 363
Table 205: Overview of limits and testing guidelines for emissions ... 365
Table 206: Test requirements - Network-related emissions for industrial areas ... 366
Table 207: : Test requirements - Electromagnetic emissions for industrial areas ... 367
Table 208: Overview of limits and testing guidelines for immunity ... 368
Table 209: Test requirements - Electrostatic discharge (ESD) ... 369
Table 210: Test requirements - High-frequency electromagnetic fields (HF field) ... 369
Table 211: Test requirements - High-speed transient electrical disturbances (burst) ... 369
Table 212: Test requirements - Surge voltages ... 370
Table 213: Test requirements - Conducted disturbances ... 370
Table 214: Test requirements - Magnetic fields with electrical frequencies ... 371
Table 215: Test requirements - Voltage dips, fluctuations, and short-term interruptions ... 371
Table 216: Test requirements - Damped vibration ... 371
Table 217: Overview of limits and testing guidelines for vibration ... 372
Table 218: Test requirements - Vibration during operation ... 372
Table 219: Test requirements - Vibration during transport (packaged) ... 373
Table 220: Test requirements - Shock during operation ... 373
Table 221: Test requirements - Shock during transport ... 373
Table 222: Test requirements - Toppling ... 373
Table 223: Test requirements - Free fall ... 374
Table 224: Overview of limits and testing guidelines for temperature and humidity ... 375
Table 225: Test requirements - Worst case during operation ... 375
Table 226: Test requirements - Dry heat ... 375
Table 227: Test requirements - Dry cold ... 375
Table 228: Test requirements - Large temperature fluctuations ... 376
Table 229: Test requirements - Temperature fluctuations during operation ... 376
Table 230: Test requirements - Humid heat, cyclic ... 376

Table 231: Test requirements - Humid heat, constant (storage) ... 376
Table 232: Overview of limits and testing guidelines for safety ... 377
Table 233: Test requirements - Ground resistance ... 377
Table 234: Test requirements - Insulation resistance ... 378
Table 235: Test requirements - High voltage ... 378
Table 236: Test requirements - Residual voltage ... 378
Table 237: Test requirements - Leakage current ... 379
Table 238: Test requirements - Overload ... 379
Table 239: Test requirements - Defective component ... 379
Table 240: Test requirements - Voltage range ... 379
Table 241: Overview of limits and testing guidelines for other tests ... 380
Table 242: Test requirements - Protection ... 380
Table 243: International Certifications ... 381
Table 244: Model numbers - Accessories ... 383
Table 245: Order data - Supply plug ... 387
Table 246: Technical data - TB103 supply plug ... 387
Table 247: Order data Lithium batteries ... 389
Table 248: Technical data - Lithium batteries ... 389
Table 249: Order data - Replacement fan filters ... 390
Table 250: Order data - DVI - CRT adapter ... 391
Table 251: Order data - CompactFlash cards ... 392
Table 252: Technical data - CompactFlash cards 5CFCRD.xxxx-04 ... 393
Table 253: Order data - CompactFlash cards ... 397
Table 254: Technical data - CompactFlash cards 5CFCRD.xxxx-03 ... 398
Table 255: Order data - Uninterruptible power supply ... 401
Table 256: Technical data - USB Media Drive 5MD900.USB2-01 Rev D0 and higher ... 402
Table 257: Contents of delivery - USB Media Drive - 5MD900.USB2-01 ... 406
Table 258: Technical data - 5A5003.03 ... 407
Table 259: Order data - USB flash drives ... 409
Table 260: Technical data - USB flash drive 5MMUSB.2048-00 ... 410
Table 261: Technical data - USB flash drive 5MMUSB.2048-01 ... 412
Table 262: Order data - B&R Automation Runtime Dongle ... 414
Table 263: Order data - Uninterruptible power supply ... 416
Table 264: Technical data - 5AC600.UPSI-00 ... 417
Table 265: Technical data - 5AC600.UPSB-00 ... 419
Table 266: Technical data - UPS connection cable ... 423
Table 267: Single-phase power supplies ... 424
Table 268: Three-phase power supplies ... 425
Table 269: Order data - PCI Ethernet Card 10/100 ... 426
Table 270: Ethernet connection ETH ... 427
Table 271: Order data - PCI Ethernet Card 10/100 ... 429
Table 272: Ethernet connections ETH1, ETH2, ETH3 ... 430
Table 273: Order data - DVI cables ... 432
Table 274: Technical data - DVI cable 5CADVI.0xxx-00 ... 433
Table 275: Contents of delivery - DVI cable 5CADVI.0xxx-00 ... 434
Table 276: Order data - SDL cables ... 436
Table 277: Technical data - SDL cables 5CASDL.0xxx-00 ... 437

Table 278: Contents of delivery - SDL cable 5CASDL.0xxx-00 438
Table 279: Order data - SDL cables with 45° plug 440
Table 280: Technical data - SDL cable with 45° plug 5CASDL.0xxx-01 441
Table 281: Contents of delivery - SDL cable with 45° plug 5CASDL.0xxx-01 442
Table 282: Order data - SDL cable 5CASDL.0xxx-03 444
Table 283: Technical data - SDL cable 5CASDL.0xxx-03 445
Table 284: Contents of delivery - SDL flex cable 5CASDL.0xxx-03 447
Table 285: Structure - SDL cable 5CASDL.0xxx-03 447
Table 286: Order data - SDL flex cable with extender 449
Table 287: Technical data - SDL flex cable with extender 5CASDL.0x00-13 449
Table 288: Contents of delivery - SDL flex cable with extender 5CASDL.0xx0-13 451
Table 289: Order data - RS232 cables 453
Table 290: Technical data - RS232 cables 453
Table 291: Contents of delivery - RS232 cables 9A0014.xx 453
Table 292: Order data - USB cables 455
Table 293: Technical data - USB cables 455
Table 294: Contents of delivery - USB cable 455
Table 295: Order data - APC810 supply cable 457
Table 296: Technical data - APC810 internal supply cable 5CAMSC.0001-00 457
Table 297: Order data - HDD replacement disk tray 458
Table 298: Order data - Ready relay 460
Table 299: Pin assignments - Ready relay 460
Table 300: Model number - HMI Drivers & Utilities DVD 462
Table 301: Overview of required replacement SATA HDD for PCI SATA HDD RAID controller 492
Table 302: Temperature sensor locations 497
Table 303: Temperature limits of the fan (MTCX PX32 V0.06). 499
Table 304: Pin assignments - Connector on main board 500

0

0AC201.91 ..... 33, 108, 383, 389
0PS102.0 ..... 36, 385, 424
0PS104.0 ..... 36, 385, 424
0PS105.1 ..... 36, 385, 424
0PS105.2 ..... 36, 386, 424
0PS110.1 ..... 36, 386, 424
0PS110.2 ..... 36, 386, 424
0PS120.1 ..... 36, 386, 424
0PS305.1 ..... 36, 386, 425
0PS310.1 ..... 36, 386, 425
0PS320.1 ..... 36, 386, 425
0PS340.1 ..... 36, 386, 425
0TB103.9 ..... 33, 383, 387
0TB103.91 ..... 33, 383, 387

1

1A4600.10 ..... 37, 384, 414
1A4600.10-2 ..... 37, 384, 414
1A4600.10-3 ..... 37, 384, 414
1A4600.10-4 ..... 37, 384, 414

4

4A0006.00-000 ..... 33, 108, 383, 389

5

5A5003.03 ..... 34, 384, 407
5AC600.485I-00 ..... 32, 184
5AC600.CANI-00 ..... 32, 180
5AC600.UPSB-00 ..... 32, 384, 416, 419
5AC600.UPSI-00 ..... 32, 384, 416, 417
5AC801.ADAS-0 31
5AC801.ADAS-00 138
5AC801.DVDS-00 ..... 31, 142
5AC801.DVRS-00 ..... 31, 145
5AC801.FA01-00 ..... 36, 386, 390
5AC801.FA02-00 ..... 37, 386, 390
5AC801.FA03-00 ..... 37, 386, 390
5AC801.FA05-00 ..... 37, 386, 390
5AC801.FRAM-00 ..... 37, 386, 458
5AC801.HDDI-00 ..... 31, 122
5AC801.HDDI-01 ..... 31, 125
5AC801.HDDI-02 ..... 31, 128
5AC801.HDDI-03 ..... 31, 131
5AC801.HDDS-00 ..... 31, 139
5AC801.HS00-00 ..... 30, 120
5AC801.HS00-01 ..... 30, 120
5AC801.HS00-02 ..... 30, 120
5AC801.RDYR-00 ..... 32, 103, 177
5AC801.RDYR-01 ..... 37, 386, 460
5AC801.SDL0-00 ..... 32, 103, 174
5AC801.SSDI-00 ..... 31, 134
5AC900.1000-00 ..... 37, 386, 391
5ACPCI.ETH1-01 ..... 36, 385, 426, 429
5ACPCI.ETH3-01 ..... 36, 385, 429
5ACPCI.RAIC-01 ..... 31, 148, 149
5ACPCI.RAIC-02 ..... 31, 152, 153
5ACPCI.RAIC-03 ..... 31, 155, 156, 163
5ACPCI.RAIC-04 ..... 31, 159, 160, 167
5ACPCI.RAIC-05 ..... 31, 162
5CADVI.0018-00 ..... 34, 384, 432
5CADVI.0050-00 ..... 34, 384, 432
5CADVI.0100-00 ..... 34, 384, 432
5CAMSC.0001-00 ..... 35, 385, 457
5CASDL.0018-00 ..... 34, 384, 436
5CASDL.0018-01 ..... 34, 384, 440
5CASDL.0018-03 ..... 34, 384, 444
5CASDL.0050-00 ..... 35, 384, 436
5CASDL.0050-01 ..... 35, 384, 440
5CASDL.0050-03 ..... 35, 384, 444
5CASDL.0100-00 ..... 35, 384, 436
5CASDL.0100-01 ..... 35, 384, 440
5CASDL.0100-03 ..... 35, 385, 444
5CASDL.0150-00 ..... 35, 385, 436
5CASDL.0150-01 ..... 35, 385, 440
5CASDL.0150-03 ..... 35, 385, 444
5CASDL.0200-00 ..... 35, 385, 436
5CASDL.0200-03 ..... 35, 385, 444
5CASDL.0250-00 ..... 35, 385, 436
5CASDL.0250-03 ..... 35, 385, 444
5CASDL.0300-00 ..... 35, 385, 436
5CASDL.0300-03 ..... 35, 385, 444
5CASDL.0300-13 ..... 35, 385, 449
5CASDL.0400-13 ..... 35, 385, 449
5CAUPS.0005-00 ..... 32, 384, 416, 423
5CAUPS.0030-00 ..... 33, 384, 416, 423
5CAUSB.0018-00 ..... 35, 385, 455
5CAUSB.0050-00 ..... 35, 385, 455
5CFCRD.0064-03 ..... 33, 110, 111, 383, 397

5CFCRD.0128-03 ..... 34, 110, 111, 383, 397
5CFCRD.016G-04 .... 33, 110, 111, 383, 392
5CFCRD.0256-03 ..... 34, 110, 111, 383, 397
5CFCRD.0512-03 ..... 34, 110, 111, 383, 397
5CFCRD.0512-04 ..... 33, 110, 111, 383, 392
5CFCRD.1024-03 ..... 34, 110, 111, 383, 397
5CFCRD.1024-04 ..... 33, 110, 111, 383, 392
5CFCRD.2048-03 ..... 34, 110, 111, 383, 397
5CFCRD.2048-04 ..... 33, 110, 111, 383, 392
5CFCRD.4096-03 ..... 34, 110, 111, 383, 397
5CFCRD.4096-04 ..... 33, 110, 111, 383, 392
5CFCRD.8192-03 ..... 34, 110, 111, 384, 397
5CFCRD.8192-04 ..... 33, 110, 111, 383, 392
5MD900.USB2-01 ..... 34, 384, 401
5MMDDR.0512-01 ..... 31, 121
5MMDDR.1024-01 ..... 31, 121
5MMDDR.2048-01 ..... 31, 121
5MMHDD.0250-00 ..... 31, 166
5MMUSB.2048-00 ..... 34, 384, 409
5MMUSB.2048-01 ..... 34, 384, 409
5PC800.B945-00 ..... 30, 119
5PC800.B945-01 ..... 30, 119
5PC800.B945-02 ..... 30, 119
5PC800.B945-03 ..... 30, 119
5PC800.B945-04 ..... 30, 119
5PC800.B945-05 ..... 30, 119
5PC800.B945-10 ..... 30, 119
5PC800.B945-11 ..... 30, 119
5PC800.B945-12 ..... 30, 119
5PC800.B945-13 ..... 30, 119
5PC800.B945-14 ..... 30, 119
5PC810.BX01-00 ..... 29, 118
5PC810.BX01-01 ..... 29, 118
5PC810.BX02-00 ..... 29, 118
5PC810.BX02-01 ..... 29, 118
5PC810.BX03-00 ..... 29, 118
5PC810.BX05-00 ..... 29, 118
5PC810.BX05-01 ..... 29, 118
5PC810.BX05-02 ..... 30, 118
5PC810.FA01-00 ..... 32, 169
5PC810.FA02-00 ..... 32, 171
5PC810.FA02-01 ..... 32, 171
5PC810.FA03-00 ..... 32, 172
5PC810.FA05-00 ..... 32, 173
5PC810.SX01-00 ..... 29, 76, 115
5PC810.SX02-00 29, 78, 103, 115, 174, 177
5PC810.SX03-00 29, 80, 103, 115, 174, 177
5PC810.SX05-00 29, 81, 103, 115, 174, 177
5SWHMI.0000-00 ..... 37, 386, 462
5SWWCE.0826-ENG 39, 345
5SWWI7.0100-ENG 38, 333
5SWWI7.0100-GER 38, 333
5SWWI7.0200-ENG 38, 333
5SWWI7.0200-GER 38, 333
5SWWI7.0300-MUL 38, 333
5SWWI7.0400-MUL 38, 333
5SWWI7.0526-ENG 38, 342
5SWWI7.0626-ENG 38, 342
5SWWI7.0726-MUL 38, 342
5SWWI7.0826-MUL 39, 342
5SWWI7.0900-MUL 39, 342
5SWWI7.1000-MUL 39, 342
5SWWXP.0426-ENG 38, 336
5SWWXP.0500-ENG 38, 330
5SWWXP.0500-GER 38, 330
5SWWXP.0500-MUL 38, 330
5SWWXP.0600-ENG 37, 330
5SWWXP.0600-GER 38, 330
5SWWXP.0600-MUL 38, 330
5SWWXP.0726-ENG 38, 339

9

9A0014.02 ..... 35, 385, 453
9A0014.05 ..... 35, 385, 453
9A0014.10 ..... 35, 385, 453
9S0000.01-010 ..... 37, 328
9S0000.01-020 ..... 37, 328
9S0000.08-010 37
9S0000.08-020 37
9S0000.09-090 37

Symbole

.NET 517

Ziffern

24-hour operation 122, 125, 128, 131
945GME 119

A

AC97 101
AC97 sound 328
ACPI 309, 310, 328, 507
Add-on 73
Add-on CAN interface 180
Add-on RS232/422/485 interface 184
Add-on UPS 103
Add-on UPS module 44, 417
Address register 181
ADI 349, 507
  .NET SDK 505
  Development kit 503
ADI Library 108
Air circulation 193
Ambient temperature 67
  Maximum ambient temperature with a fan kit 71
  Maximum ambient temperature without a fan kit 68
  Minimum ambient temperature 73
AP Link 174
AP Link slot 103
APC 507
APC810 1 card slot 47
  Dimensions 51
  Interfaces 47
  Power calculation 76
  Technical data 49
APC810 2 card slot 52
  Dimensions 56
  Interfaces 52
  Power calculation 78
  Technical data 54
APC810 3 card slot 57
  Dimensions 61
  Interfaces 57
  Power calculation 80
  Technical data 59
APC810 5 card slot 62
  Dimensions 66
  Interfaces 62
  Power calculation 81
  Technical data 64
API 507
ARwin
  Dongle 414
ATX power supply 107
Automation Device Interface 349
Automation Runtime 507

B

B&R Automation Runtime 508
B&R Embedded OS Installer 347
Backup battery 108
Barcodes 82
Basic system 45
Battery status 108
Battery status evaluation 108
Battery temperature measurement 103
Battery unit 419
  Lifespan 419
  Maintenance interval 419
Baud rate 507
Beep codes 306
Beeping code 306
BIOS 507
BIOS 945GME
  ACPI configuration 249
  Advanced 247
  Baseboard monitor 283
  BIOS setup keys 244
  Boot 286
  Chipset configuration 262
  Clock Configuration 265
  CPU board monitor 279
  CPU configuration 261
  Exit 293
  Graphics configuration 257
  Hard disk security master password 290
  Hard disk security user password 289
  I/O interface configuration 264
  IDE Configuration 266

Keyboard/mouse configuration 276
Legacy devices 284
Main 246
Main Board/Panel Features 280
Panel control 282
PCI Configuration 251
PCI express configuration 255
Power 291
Remote access configuration 277
Security 288
USB configuration 274
BIOS default settings 294
BIOS Error signals 306
BIOS upgrade 314
Bit 508
Bit rate 508
Block diagram 84
Block diagram - supply voltage 75
Bootstrap loader 524
Buffer duration 108
Burst 369
Bus length 182
Bus structure 183
Bus unit 117
Byte 508

C

Cable connection 194
Cable connections 194
Cable drag chain 381
Cable type 182, 185, 186, 187
Cables 431
APC810 internal supply cable 457
Cache 508
Cage clamps 92
CAN 44, 179, 508
Bus length 182
Cable type 182
Terminating resistor 183
CAN address register 181
CAN controller 180
Card slot 104
CD-ROM 508
CE mark 508
Certifications 381
Changing the battery 467
Climate conditions 375
CMOS 509
CMOS battery 389
CMOS profile 106
COM 509
COM1 ..... 94, 509
COM2 ..... 95, 509
COM3 509
CompactFlash 509
Dimensions 395, 400
General information 392, 397
Order data 392, 397
Technical data 393, 398
CompactFlash slot 1 110
CompactFlash slot 2 111
Conducted disturbances 370
Configuration 44
Basic system 45
Drives, software, accessories 46
Configure 416
Connection examples 196
Construction 44
Control Center 349, 497
Controller 509
Copper strip 93
Core 2 Duo 44
Core Duo 44
CPU 510
CPU board 119
Creating a CompactFlash card for B&R upgrade files 326
CRT 510
CTS 510

D

Damp heat, constant 376
Damped vibration 371
Data loss 107, 524
Data register 181
DCD 510
Deep discharge cycles 420
Deep discharge protection 416
Deep discharge voltage 419
Defective component 379
Degree of pollution 381
Derating 73

Development kit 503
Device interfaces 92
Dial-up 510
Dimension standards 28
Dimensions
  APC810 1 card slot 51
  APC810 2 card slot 56
  APC810 3 card slot 61
  APC810 5 card slot 66
  Standard half-size PCI card 104
  Standard half-size PCIe card 104
DIMM 510
Disposal 27
Distribution of resources 307
  I/O address assignment 308
  RAM address assignment 307
DMA 510
Dongle 109, 414
Double layer 145
DRAM 510
Drilling template 190
  APC810 1 card slot 190
  APC810 2 card slot 190
  APC810 3 card slot 191
  APC810 5 card slot 191
Dry cold 375
Dry heat 375
DS1425 109
DSR 511
DTR 511
Dual channel memory 44, 121
DVD 511
DVI 95, 511
DVI - CRT adapter 391
DVI cable 432
DVI-A 511
DVI-D 511
DVI-I 511

E

EDID 511
EIDE 512
Electromagnetic emissions 367
Electrostatic discharge 369
Embedded OS Installer 347
EMC 512
Emissions 365, 367
Entire device 47
EPROM 512
Error signals 306
ESD 24, 369
  Electrical components with housing 24
  Electrical components without housing 24
  Individual components 25
  Packaging 24
  Proper handling 24
ETH1 96
ETH2 98
Ethernet 96, 98, 512
ETHERNET Powerlink 512
ETX 512
European directives 363
Extended desktop 219, 222, 226

F

Fan kits 169
  1 card slot 169
  2 card slot 171
  3 card slot 172
  5 card slot 173
FDD 512
Fiber optic cable 105
Fiber optics 516
FIFO 513
Firmware 513
Flex radius 194, 423
Floppy 513
FPC 513
FPD 513
Free fall 374
Front cover 407
FTP 514
Full Speed 99, 100
Functional ground 195
Fuse 92

G

GB 514
Graphics line 174
Ground 93

Ground resistance 377
Grounding concept 195
Grounding point 195
Guidelines 28

H

half-size PCI card 104
half-size PCIe card 104
Handshake 514
Hardware security key 109
HDD 105, 514
HDD replacement disk tray 458
Heat sink 120
HF field 369
Hibernate 105
High speed 99, 100
High voltage 378
High-frequency electromagnetic fields 369
High-speed transient elect. disturbance value 369
Homepage 82
Horizontal 192
Hot Plug 112, 113, 114
Humid heat, cyclic 376

I

IDE 514
IF option 179
Immunity 368
Individual components 115
  AP Link card 174
  AP Link SDL transmitter 174
  Bus unit 117
  CPU board 119
  Drives 122
  Fan kits 169
  Heat sink 120
  Main memory 121
  Ready relay 177
  Slide-in compact HDD ..122, 125, 128, 131
  Slide-in DVD-R/RW 145
  Slide-in DVD-ROM 142
  Slide-in HDD 139
  System unit 115
Installation 189, 193
Installing the UPS service 354
Insulation resistance 378
Interface 514
Interface options 179
ISA 514
ISO 515

J

Jitter 515
Jumper 515

K

Keypad modules 515

L

LCD 515
Leakage current 379
LED 515
Line IN 101
Line OUT 101
Lithium battery 108
Low battery shutdown 362
Low speed 99, 100
LPT 516

M

Magnetic fields with electrical frequencies 371
Main memory 44, 121
Maintenance free rechargeable batteries 416
Maintenance interval 419
Manual history 19
MAXIM 109
MB 516
Mechanical conditions 372
MIC 101
Microprocessor 516
MIPS 516
Mkey 516
Model numbers 29
Modem 516

Monitor / Panel 95
Motherboard 516
Mounting 189
Mounting orientation 192
  Horizontal 192
  Vertical 192
Mounting rail brackets 401
MS-DOS 328
MTBF 516
MTCX 107, 517
Multitasking 517

N

Network-related emissions 366
NMI 180
NTC 103

O

OEM 517
OPC 517
OPC server 518
Overcurrent shutdown 362
Overload 92, 379

P

Panel 518
Panelware 518
Parity error 306
PC Card 518
PCI 104, 518
PCI 2.2 half-size 104
PCI card 104
PCI cards 426
PCI Express 43
PCIe 104
PCIe card 104
PCMCIA 518
PICMG 518
PLC 518
PnP 519
POH 519
POST 519
Post codes 306
Power 50, 55, 60, 65, 75, 105
Power button 107
Power calculation
  5PC810.SX01-00 76
  5PC810.SX02-00 78
  5PC810.SX03-00 80
  5PC810.SX05-00 81
Power management 75
Power Panel 519
Power supplies 424
Power supply 424
Powerlink 519
PP21 519
PP41 519
Procedure following power failure 362
PROFIBUS-DP 519
Programs 27
Protection 380
Provit 520
Provit 2000 520
Provit 5000 520
PV 520

Q

QUXGA 520
QVGA 520
QWUXGA 520
QXGA 522

R

RAID 148, 155, 162
RAID controller 44, 331
RAM 520
Ready relay 177, 460
Real time 520
Real-time clock 44, 108
Relative humidity 74
Relay contacts 177
Replacement PCI SATA RAID HDD ..... 152, 159, ... 166
Requirements for emissions 365
Requirements for immunity to disturbances .. 368
Reset 107

Reset button 107
Residual voltage 378
Reverse polarity protection 92
RGB 329
ROM 521
RS232 ..... 185, 521
  Bus length 185
  Cable type 185
RS232 cable 453
RS232/422/485 179
RS422 ..... 186, 521
  Bus length 186
  Cable type 186
RS485 ..... 186, 521
  Bus length 187
  Cable type 187
RTC 44, 108
RTS 521
RXD 521

S

Safety 377
Safety notices 24
  Dust, humidity, aggressive gases 26
  Environmentally-friendly disposal 27
  Installation 26
  Intended use 24
  Operation 26
  Organization 28
  Policy and procedures 25
  Protection against electrostatic discharges 24
  Transport and storage 25
SATA 44, 112, 113, 114, 148, 155, 162
  RAID controller 148
Screw clamps 92
SDL 95
SDL cable with 45° plug 440
SDL cables 436, 444
SDL equalizer 352
SDL flex cable with extender 449
SDRAM 521
Security Key 109
Self discharging 108
Self-locking nut 93
Sequential Function Chart 521
Serial interface 94, 95
Serial number 82
Serial number sticker 82
SFC 521
Shock during operation 373
Shock during transport 373
Short circuit protection 417
Short-term interruptions 371
Slide-in compact slot 114
Slide-in slot 1 112
Slide-in slot 2 113
Slot PLC 522
Smart Display Link 95
Soft-off 105
SoftPLC 522
Sound 101
Special keypad module 522
SRAM 44, 522
Standard keypad module 522
Standard shutdown 362
Standards 363
  Overview 363
Standards and certifications 363
Starting current 50, 55, 60, 65, 116
Status LED
  HDD 105
  Link 1 105
  Link 2 105
  Power 105
Status LEDs 105
Supply voltage 92
Supply voltage connectors 387
Surge 370
Surge voltages 370
Suspend-to-disk 105
SUXGA 522
SVGA 522
Switch 522
Switching power supply 424
SXGA 522
SXGA+ 522
System unit 115
System units 523

T

Task 523

TCP/IP 523
Technical data
Bus unit 118
CPU board 119
Heat sink 120
Main memory 121
Temperature 497
Temperature fluctuations 376
Operation 376
Temperature monitoring 73
Temperature monitoring - Fan control 499
Temperature sensor 416, 497
Temperature sensor locations 497
Terminating resistor 183
TFT display 523
Toppling 373
Touch screen 523
Transfer rate 96
TXD 523

U

UART 523
UDMA 524
Uninterruptible power supply 415
Upgrade information 314
UPS 105, 415, 524
UPS configuration 353
UPS connection cable 416, 423
USB 524
USB 2.0 99
USB cable 455
USB flash drive 409
General information 409
Order data 409
Technical data 410, 412
USB flash drive for B&R update files 324
USB Media Drive 401
Dimensions 404
Dimensions with front cover 405
Installation 406
Interfaces 406
Mounting orientation 406
Technical data 402
USB peripheral devices 229
USB ports 99
USB1,2,3,4 99
USB5 100
UXGA 524

V

Vertical 192
VGA 524
Vibration during transport 373
Vibration operation 372
Video signals 95
Viruses 27
Voltage dips 371
Voltage fluctuations 371
Voltage range 379

W

WES2009 339
WES7 343
Windows 7 333
Windows CE 345, 525
Embedded OS Installer 347
General information 345
Installation 347
Windows CE 5.0
Features 346
Windows CE 6.0
Features 346
Windows Embedded Standard 2009 339
Windows Embedded Standard 7 342
Touch screen driver 344
Windows XP Embedded 336
Touch screen driver 338, 341
Windows XP Professional 330
Installation 330, 333
Worst case 375
Worst-case 67
WSXGA 525
WUXGA 525
WXGA 525

X

XGA 525
XTX 525